Areas Covered

Before Reading This Manual		
	This section explains the notes for your safety and conventions used in this manual.	
Chapter 1	Overview	
	This chapter explains component names and basic operations of this server, as well as an overview of the software provided with this server. In addition, the workflow, from placing the server to starting the operation, is also described.	
Chapter 2	Checking before OS Installation	
	This chapter explains the preparation on the server and cautions necessary before OS installation. Please read this chapter before starting installation.	
Chapter 3	OS Installation Using ServerStart	
	This chapter explains how to install the OS in the server using ServerStart.	
Chapter 4	Manual OS Installation	
	This chapter explains how to install the OS without using ServerStart.	
Chapter 5	Operations after OS Installation	
	This chapter explains the operations to be performed after OS installation. Be sure to perform those operations before operating the server.	
Chapter 6	High Reliability Tools	
	For stable PRIMERGY server operations, we recommend that high reliability tools be installed. This chapter explains the installation and necessary settings of high reliability tools.	
Chapter 7	Installing Hardware Options	
	This chapter explains how to install internal options.	
Chapter 8	Configuring Hardware and Utilities	
	This chapter explains how to make the environment settings necessary to operate the server and how to use each utility.	
Chapter 9	Operation and Maintenance	
	This chapter explains the operations that become necessary after starting to use this server as well as daily care and maintenance.	
Appendix		
	This appendix explains the specifications for the server and for its internal options.	

Before Reading This Manual

For Your Safety...

This manual contains important information, required to operate the server safely.

Thoroughly review the information in this manual before using the server. Especially note the points under "Safety Precautions", and only operate the server with a complete understanding of the material provided.

This manual and "Safety Precautions" should be kept in an easy-to-access location for quick reference when using this server.

Data Backup

To protect data stored in this device (including basic software and application software), perform backup and other necessary operations. Note that data protection is not guaranteed when repairs are performed. It is the customer's responsibility to maintain backup copies in advance.

In case of data loss, Fujitsu assumes no liability for data maintenance or restoration and damages that occur as a result of the data loss for any reason, except for items covered under warranty.

High Safety

The Products are designed, developed and manufactured as contemplated or general use, including without limitation, general office use, personal use, household use, and ordinary industrial use, but are not designed, developed and manufactured as contemplated for use accompanying fatal risks or dangers that, unless extremely high safety is secured, could lead directly to death, personal injury, severe physical damage, or other loss (hereinafter "High Safety Required Use"), including without limitation, nuclear reaction control in nuclear facility, aircraft flight control, air traffic control, mass transport control, medical life support system, missile launch control in weapon system. You shall not use this Product without securing the sufficient safety required for the High Safety Required Use. If you wish to use this Product for High Safety Required Use, please consult with our sales representatives in charge before such use.

Problems may occur with this device in the event of an instantaneous voltage drop of the power supply due to lightning, etc. To prevent an instantaneous voltage drop of the power supply, we recommend that you use an uninterruptible power supply system.

Trademarks

Microsoft, Windows, and Windows Server are trademarks or registered trademarks of Microsoft Corporation in the USA and other countries.

Intel, Celeron, Pentium, and Xeon are registered trademarks or trademarks of Intel Corporation or its subsidiaries in the USA and other countries.

Linux is a trademark or registered trademark of Linus Torvalds in the USA and other countries.

Red Hat and all Red Hat-based trademarks and logos are trademarks or registered trademarks of Red Hat, Inc. in the USA and other countries.

Other product names used are trademarks or registered trademarks of their respective manufacturers.

Other products are copyrights of their respective manufacturers.

All Rights Reserved, Copyright© FUJITSU LIMITED 2006

Screen shot(s) reprinted with permission from Microsoft Corporation.

Remarks

Warning Descriptions

Various symbols are used throughout this manual. These are used to emphasize important points for your safety and that of others. The following are the symbols and their meanings. Fully understand these symbols when reading this manual.

WARNING	Ignoring this symbol could be potentially lethal.
	Ignoring this symbol may lead to physical injury and/or damage the server or internal options.

The following symbols are used to indicate the type of warning or caution being described.

\triangle	A triangle mark emphasizes the urgency of the WARNING and CAUTION. Details are described next to the triangle.
\oslash	A barred circle (\bigotimes) warns against certain actions (Do Not). Details are described next to the circle.
0	A black circle indicates actions that must be taken. Details are described next to the black circle.

Symbols

Symbols used in this manual have the following meanings.

MPORTANT	These sections explain prohibited actions and points to note when using this device. Make sure to read these sections.
POINT	These sections explain information needed to operate the hardware and software properly. Make sure to read these sections.
\rightarrow	This mark indicates reference pages or manuals.

Key Descriptions / Operations

Keys are represented throughout this manual in the following manner.

E.g.: [Ctrl] key, [Enter] key, $[\rightarrow]$ key, etc.

The following indicate pressing several keys at once:

E.g.: [Ctrl] + [F3] key, $[Shift] + [\uparrow]$ key, etc.

CD-ROM Drive and DVD-RAM Drive Descriptions

In this manual, both CD-ROM and DVD-RAM drives are described as CD-ROM drives. Unless otherwise noted, a CD-ROM drive can also mean a DVD-RAM drive.

Entering Commands (Keys)

Command entries are displayed in the following way.

diskcopy a: a: ↑ ↑

- At each blank in a command line (as pointed out above), press the [Space] key once.
- When using Windows or DOS OS, commands are not case sensitive.
- CD-ROM drive names are shown as [CD-ROM drive]. Enter your drive name according to your environment.

[CD-ROM drive]:\setup.exe

Screen Shots and Figures

Screen shots and figures are used as visual aids throughout this manual. Windows, screens, and file names may vary depending on the OS, software, or configuration of the server used. Figures in this manual may not show cables that are actually connected for convenience of explanation.

Consecutive Operations

Consecutive operations are described by connecting them with arrows (\rightarrow) .

Example: Procedure of clicking the [Start] button, pointing to [Programs], and clicking [Accessories] ↓

Click [Start] \rightarrow [Programs] \rightarrow [Accessories].

Server Types

Server types are described as follows.

table: Server Types

Туре	Expressions and abbreviations
Servers without an internal hard disk	Diskless type
Stationary servers	Tower type
Rack mount servers using a Rack Conversion kit	Rack mount type

Abbreviations

The following expressions and abbreviations are used throughout this manual.

table: Abbreviations of Product Names			
Product name	Expressions and abbreviations		3
PRIMERGY TX150 S5	This server or the server		
Microsoft [®] Windows [®] Small Business Server 2003	SBS 2003 *1		Windows
Microsoft [®] Windows [®] Small Business Server 2003 R2	SBS 2003 R2		
Microsoft [®] Windows Server [®] 2003 R2, Standard Edition	Windows Server 2003 R2	Windows Server 2003	
Microsoft [®] Windows Server [®] 2003, Standard Edition	Windows Server 2003, Standard Edition		
Microsoft [®] Windows Server [®] 2003, Standard x64 Edition	Windows Server 2003 x64 *1		
Microsoft [®] Windows Server [®] 2003 R2, Standard x64 Edition	Windows Server 2003 R2 x64		
Microsoft [®] Windows [®] 2000 Server	Windows 2000 Server		
Microsoft [®] Windows [®] Preinstallation Environment	Windows PE		
Microsoft [®] Windows [®] XP Professional	Windows XP Professional		
Microsoft [®] Windows [®] 2000 Professional	Windows 2000 Professional		1
Microsoft [®] Windows Server [®] 2003 Service Pack	Service Pack		•

*1: Unless otherwise noted, Windows Server 2003 can also mean SBS 2003 and Windows 2003 x64.

Linux

Reference Information

Microsoft[®] Windows[®] 2000 Service Pack Red Hat Enterprise Linux ES (v.4 for x86)

Red Hat Enterprise Linux ES (v.4 for EM64T)

Software Manuals

Software Manual contains other reference information and cautions for ServerStart not described in this manual. Please read it before using ServerStart.

Software Manual is contained as a "README.TXT" file in the root directory on the ServerStart CD-ROM. Use a text editor to read it.

Latest Information about Software Provided with This Server

For the latest information regarding ServerStart and other software provided with this server, refer to the Fujitsu PRIMERGY website (http://primergy.fujitsu.com).

Warning and Caution Labels

Warning and caution labels are found on the server. Do not remove or stain these labels.

Contents

Chapter 1 Overview

1.1 TX150 S5 14
1.2 Supplied Software 16
1.2.1 Setup Support Tool - ServerStart16
1.2.2 High Reliability Tools
1.2.3 Installing High Reliability Tools
1.3 Component Names and Functions
1.3.1 Server (Front View)
1.3.2 Server (Rear View)
1.3.3 Server (Internal)
1.3.4 Baseboard
1.4 Standard Operations 30
1.4.1 Sliding the Drive Cover
1.4.2 Opening the Rack Door
1.4.3 Turning On the Server
1.4.4 Turning Off the Server
1.4.5 Inserting and Ejecting a Floppy Disk
1.4.6 Inserting and Ejecting a CD-ROM (DVD-RAM)
1.5 Workflow

Chapter 2 Checking before OS Installation

2.1 Preparation on the Server	42
2.1.1 Installing Internal Options	42
2.1.2 Hardware Settings	43
2.2 Selecting the Installation Method	45
2.3 Precautions on Installation	47
2.3.1 Installation Partition Size	47
2.3.2 Notes on Configuring RAID	47
2.3.3 Notes on a Multiple LAN Adapter Configuration	49
2.3.4 Cautions for Using ServerStart	49
2.3.5 Expansion Cards Supported by ServerStart	50
2.3.6 Cautions for Manual Installation	50
2.4 Preparation for Using ServerStart on a Client Computer	52
2.4.1 Installing ServerStart	52
2.4.2 Uninstalling ServerStart	54
2.4.3 Creating the ServerStart Floppy Disk	55

Chapter 3 OS Installation Using ServerStart

3.1 Guided Mode	58
-----------------	----

	3.1.1 Starting Up the Guided Mode	58
	3.1.2 Opening/Creating a Configuration File	62
	3.1.3 RAID and Disk Wizard	63
	3.1.4 OS Installation Wizard	66
	3.1.5 Application Wizard	71
	3.1.6 Closing/Saving the Configuration File	72
	3.1.7 Starting OS Installation	72
	3.2 Preparation Mode	75
	3.2.1 Starting Up the Preparation Mode	75
	3.2.2 Configuring Settings in Wizards	77
	3.2.3 Closing/Saving the Configuration File	77
	3.2.4 Starting OS Installation	
	3.3 Expert Mode	81
	3.3.1 Starting Up the Expert Mode	
	3.3.2 Disk Manager	
	3.3.3 OS Installation Wizard	
	3.3.4 Application Wizard	
	3.3.5 Starting OS Installation	
	3.4 Remote Installation	
	3.4.1 Overview of Remote Installation	88
	3.4.2 System Requirements for Remote Resource/PXE Servers	
	3.4.3 Preparation of the PXE Server (When the PXE Server is Used)	
	3.4.4 Preparation of Remote Resources	
	3.4.5 Starting Remote Installation Using a PXE Server	
	3.4.6 Starting Remote Installation Using a Remote Resource Server	
	3.5 Installation on Multiple (the Second and Subsequent) Serv	
	3.5.1 Preparation for Installation	
	3.5.2 Installation in Guided Mode	
	3.5.3 Installation in Preparation Mode	
л	Manual OS Installation	

Chapter 4 Manual OS Installation

4.1 Creating Driver Disks	112
4.1.1 Required Driver Disks	112
4.1.2 How to Create Driver Disks [FloppyBuilder function]	114
4.2 Starting Manual Installation	117
4.2.1 Installing Windows Server 2003 x64	117
4.2.2 Installing Windows Server 2003 / SBS 2003	120
4.2.3 Installing Windows 2000 Server	123
4.2.4 Installing Linux	127
4.3 Installing the LAN Driver	128
4.3.1 Installing the LAN Driver (Windows Server 2003 x64)	129
4.3.2 Installing the LAN Driver (Windows Server 2003 / SBS 2003) .	131
4.3.3 Installing the LAN Driver (Windows 2000 Server)	132

	4.3.4 Latest Drivers	133
Chapter 5	Operations after OS Installation	
	5.1 Memory Dump/Paging File Setting	. 136
	5.1.1 How to Obtain Memory Dump for Windows Server 2003 and Windo	ws
	Server 2003 x64	136
	5.1.2 How to Obtain Memory Dump for Windows 2000 Server	141
	5.2 Creating a Disk for System Recovery	. 146
	5.2.1 Creating the Automated System Recovery (ASR) Set for Windows S	Server
	2003 and Windows Server 2003 x64	146
	5.2.2 Creating a System Recovery Disk for Windows 2000 Server	147
	5.3 Storing the System Configuration Information	. 148
	5.3.1 Storing the BIOS Information and the Remote Management Controll	er
	Information	149
	5.3.2 Recovering the BIOS Information	150
	5.3.3 Recovering the Remote Management Controller Information	
	5.4 Creating Maintenance Tools	. 152
	5.4.1 Creating a Hardware Configuration Tool	152
	5.4.2 Creating a DOS Diskette	156
	5.5 Notes before Operating the Server	. 157
	5.5.1 Applying the Hotfix	157
	5.5.2 Auto-run Function from CD-ROM Drives	158
	5.5.3 Drive Letter Assignment in Expert Mode	158
	5.5.4 Notes on Advanced Uninterruptible Power Supply (UPS)	159
	5.5.5 Turning the Power On via a LAN	159
	5.5.6 Other Notes on Operation	160
	5.6 LAN Driver Advanced Setup [BACS]	. 161
	5.6.1 BACS Installation	161
	5.6.2 VLAN Setup Procedure	163
	5.6.3 Cautions for Onboard LAN Driver Ver9.25.0.0	165
	5.7 LAN Driver Advanced Setup [Intel® PROSet]	. 166
	5.7.1 Intel® PROSet Installation	166
	5.7.2 Cautions for PG-185x/186x/188x/189x/286x LAN Driver V10.3	167
	5.7.3 Teaming Function	167
	5.7.4 VLAN	169
•••••		

Chapter 6 High Reliability Tools

6.1 RAID Management Tool	172
6.1.1 Installing RAID Management Tool	
6.2 Server Monitoring Tool [ServerView]	173
6.2.1 Installing ServerView	
6.2.2 Setting Required after Installation	
6.3 Solving Problems Early [DSNAP]	175

	6.3.1 Installing DSNAP
Chapter 7	Installing Hardware Options
	7.1 Before Installing Hardware Options
	7.2 Removing and Attaching Covers
	7.2.1 Removing Covers
	7.2.2 Removing the Top Cover of the Rackmount Type
	7.3 Installing Memory Modules 185
	7.3.1 Where to Install the Memory Module
	7.3.2 Installable Memory Modules and Notes
	7.3.3 How to Install Memory Module
	7.3.4 Defective Memory Disconnection Function
	7.4 Installing Expansion Cards 189
	7.4.1 Where to Install an Expansion Card
	7.4.2 Installable Expansion Cards and Notes
	7.4.3 How to Install Expansion Cards
	7.5 Installing Internal Hard Disk Units
	7.5.1 Where to Install Internal Hard Disk Units
	7.5.2 Installable Internal Hard Disk Units and Notes
	7.5.3 How to Install the Internal Hard Disk Unit
	7.5.4 How to Remove the Internal Hard Disk Unit
	7.5.5 Replacing the Failed Internal Hard Disk Unit (in the array configuration only
	7.6 Installing 5-inch Internal Options
	7.6.1 Where to Install 5-inch Internal Devices
	7.6.2 Installable 5-inch Internal Devices and Notes
	7.6.3 How to Install the 5-inch Internal Device
	7.6.4 How to Install a DVD-RAM Unit
	7.7 Installing a Parallel Port Option
	7.7.1 How to Install a Parallel Port
	7.8 Installing a Serial Port
	7.8.1 Where to Install a Serial Port
	7.8.2 How to Install a Serial Port
	7.9 Connecting External SCSI Devices
Chapter 8	Configuring Hardware and Utilities

212
213

8.2.4 Boot Options Submenu	.218
8.2.5 Advanced Menu	.219
8.2.6 Peripheral Configuration Submenu	.220
8.2.7 PCI Configuration Submenu	.222
8.2.8 Advanced System Configuration Submenu	.223
8.2.9 Power On/Off Submenu	.224
8.2.10 IPMI Submenu	.225
8.2.11 Security Menu	.227
8.2.12 Server Menu	.229
8.2.13 Exit Menu	.232

Chapter 9 Operation and Maintenance

9.1 Daily Maintenance	234
9.1.1 Checking the Server Condition	
9.1.2 Cleaning	
9.2 Troubleshooting	237
9.2.1 Hardware Troubleshooting	
9.2.2 Error Messages	
9.2.3 Software Troubleshooting	
9.3 System Event Log	252
9.3.1 How to Use Server Management Tools	
9.3.2 Saving/Deleting the System Event Log	
9.4 Security	
9.4.1 Hardware Security	
9.4.2 Security against Unauthorized Use	
9.4.3 Security When Disposing of the Server	
9.5 Backup	
9.5.1 Importance of Backups	
9.5.2 Backup Devices, Software and Their Operations	
9.6 Restoring the System	
9.6.1 For Windows Server 2003	
9.6.2 For a Windows 2000 Server	
9.7 Reinstalling the OS	
9.7.1 Checking before OS Reinstallation	
9.7.2 Reinstallation Using ServerStart	
9.8 Maintenance Service	
9.8.1 Contacting Maintenance Support	

Appendix

	ifications	
A.1 Diskless	Туре	268
B Specificatio	ns for Internal Options	269
B.1 Memory		269

B.2 Internal Hard Disk Units
B.3 Parallel Port Option
B.4 Serial Port
B.5 Power Cord Selection
C Remote Control Function 273
C.1 Preparation for Using Remote Control Function
C.2 Remote Power Supply Control
D Remote Management Controller 278
D.1 Overview of the Remote Management Controller
D.2 Preparation for Using Remote Management Controller
D.3 Window of the Remote Management Controller
D.4 Remote Management Controller Upgrade (PG-RMCU1)
E Recycling

Chapter 1

Overview

This chapter explains component names and basic operations of this server, as well as an overview of the software provided with this server. In addition, the workflow, from placing the server to starting the operation, is also described.

1.1	TX150 S5	14
1.2	Supplied Software	16
1.3	Component Names and Functions	22
1.4	Standard Operations	30
1.5	Workflow	40

1.1 TX150 S5

This server is entry server with high-speed processing and cost-effectiveness. This server has the following features.

High Reliability

Memory Modules Enabling High-Speed Processing

For the memory, the system is equipped with DDR II 533 Unbuffered Lowprofile DIMM enabling highspeed processing.

Disk Array Configuration

The array system can be configured using an onboard SAS array controller. In the case of the onboard SAS array controller, the array system (RAID1) can be configured with two hard disk drives. Also, a SAS array controller card is supported. In the case of the SAS array controller card, the array system (RAID 0/1/5/0+1) can be configured.

MPORTANT

When configuring the array system using onboard SAS controller

Up to two hard disk units can be installed.

Redundant Function

For the disk array configuration (except for RAID 0), a failed hard disk unit in a storage system can be replaced or repaired without turning off the server and peripheral devices (a hot-plug is supported).

Hardware and Software Designed for Data Security

Locks on the drive covers and the password setting in the BIOS Setup Utility protect hardware and data assets in the server against theft, ensuring data security.

Proactive Fan Function

When a fan fails or the ambient temperature rises, the system fan speed is increased automatically to avoid increase in temperature in the server, ensuring stable server operation.

High Reliability Tools

High reliability tools, such as ServerView which is the tool for monitoring the server status, offer stable system operation. For information about high reliability tools, refer to "1.2.2 High Reliability Tools" (\rightarrow pg.20).

High-speed Processing

Intel[®] Processor

The server has an $Intel^{\mathbb{R}}$ processor.

When Intel[®] Pentium[®] D Processor or Intel[®] Xeon[®] Processor is installed, it is a dual core processor, which physically functions as two CPUs.

Excellent Scalability

• Maximum Memory Size of 8 GB

In addition to the preinstalled 512MB memory, the memory is expandable to 8GB.

• Maximum Hard Disk Size of 587.2 GB

Up to four internal hard disk units can be installed in the 3.5-inch storage bays. The hard disk size can be increased up to 587.2 GB.

MPORTANT.

When configuring the array system using onboard SAS controller

• Up to two internal hard disk units can be installed. More than two hard disk units cannot be added. Also, when RAID 1 is configured, capacity for one hard disk is available.

Five PCI Slots

The server has five PCI slots. Functions can be added by using expansion cards.

• 5-inch Internal Option Bay

The server has three 5-inch storage bays. One of them has an internal CD-ROM drive by default. The 5-inch internal options such as backup unit can be installed to accommodate for an increasing amount of data.

Rack Mount Type

With the Rack Conversion kit, the server can be installed on a rack.

1.2 Supplied Software

ServerStart for supporting setup and high reliability tools for avoiding problems during server operation are supplied with this server.

1.2.1 Setup Support Tool - ServerStart

ServerStart is a setup support tool that helps to install PRIMERGY. It offers easy server installation and proper installation of recommended drivers.

■ Installing the OS using ServerStart

The following benefits are provided by using ServerStart to install the OS.

Not using ServerStart

- Complex hardware settings (e.g. RAID setting)
- User definition, access privileges, network settings
- It is necessary to input successively for installation, resulting in more mistakes and longer time

Example:

Operations such as setting IP address, creating users, and registering computer name are required



Using ServerStart RAID can be configured automatically Auto installation of recommended drivers (SCSI, LAN, etc.) enables high reliable installation High reliability tools can be installed automatically *2 Example: Operations during OS installation is automated *1

- *1 Some input (License window, etc.) and media repositioning are excluded
- *2 High reliability tools are software with comprehensive strength for stable system operation of the server management

Supported OSs

The following OSs can be installed using ServerStart V6.609.

- Microsoft[®] Windows Server[®] 2003, Standard Edition
- Microsoft[®] Windows Server[®] 2003, Enterprise Edition
- Microsoft[®] Windows Server[®] 2003, Standard x64 Edition
- Microsoft[®] Windows Server[®] 2003, Enterprise x64 Edition
- Microsoft[®] Windows Server[®] 2003 R2, Standard Edition
- Microsoft[®] Windows Server[®] 2003 R2, Enterprise Edition
- Microsoft[®] Windows Server[®] 2003 R2, Standard x64 Edition
- Microsoft[®] Windows Server[®] 2003 R2, Enterprise x64 Edition
- Microsoft[®] Windows[®] 2000 Server
- Microsoft[®] Windows[®] 2000 Advanced Server

POINT

- ServerStart does not support to install SBS 2003 / Linux.
- The OS which the server does not support cannot be installed.

Configuration File (SerStartBatch.ini)

A configuration file stores the server setup information configured in ServerStart. To create a configuration file, use the ServerStart floppy disk supplied with this server. Store only one file on each floppy disk. Do not set the ServerStart floppy disk to the write-protected state.

You can use any name for the configuration file. However, the file must be installed in the server as "SerStartBatch.ini". When installing the configuration file, make sure to save it as "SerStartBatch.ini" on the ServerStart floppy disk.

Start up ServerStart, insert the ServerStart floppy disk containing "SerStartBatch.ini", and click [Start] to install the server.




The intuitive user interface allows you to easily set the necessary information.

Main Window

When ServerStart is started, the following window appears. The window and tool bar differ depending on the mode.

Serve	erStart		_ 8 ×
8	<u> </u>		FUĴÎTSU
	Welco	ome to ServerStart	<u>A</u>
	٢	Click here to prepare and/or initiate an operating system installation	
		Information	
	1	FlappyBuilder	
		End-User License Agreement for ServerStart's Operating System	
Done		V5.405.03 CAPS NUM 10.14 AM	2/24/2005

Tool Bar



MPORTANT

While the wizard is running, do not click the ◀ ▲ ▷ icon to move to the previous or next window or to upper tree level. To move to a different window, click the [Previous], [Up], or [Next] button at the bottom of the wizard window.

Wizard Window

Clicking a wizard displays a wizard window.

Set items in the wizard window. To move to a step in the next wizard window, click the operation button at the bottom of the window. Clicking [help] displays a tip for setting the item.

rverStart		_ 6
	Application Wizard	
Installable applications:	Selected applications:	
MS Windows Server 2003 Service Pack 1	DSNAP	
User specific software	Broadcom Advanced Control Suite	
1	RAID Management Tool	
	Fujitsu ServerView	
I		
Install selected application from Local CD		
Install selected application from Remote Server		
Remote Source Path:		
(e.g. Wnyserver\share)		
Remote Username:		
Remote Password:		
Userspecific Command:		
Available, but not installable:	Prerequisite(s):	
(Select an item and see «Prerequisite(s)»)	(of the item currently selected)	
MS Windows 2000 ServicePack 4	For MS Windows Server 2003 only !	
	-	
< previous next >	leave wizard	help
N previous	leave wizaid	neip
	V5 603 03	CARS NUM 4:36 PM 4/25/20

Network Configuration

ServerStart can configure a network at server installation. For details on available network patterns, refer to "Using ServerStart to Configure the Network".

Automatic Driver Installation

Recommended drivers for automatically recognized expansion cards are installed with the server. This prevents possible mistakes in driver installation, such as installation of an older version or drivers which were not supplied with this server.

Automatic RAID Configuration

When an array controller card is used, specify the RAID type and the number of hard disk units before starting installation. A storage system can be configured without starting the RAID utility.

Remote Installation

Using ServerStart, you can store resources necessary for installation, such as the OS and ServicePack, in another server on the network, and install the OS via the network. This method is convenient when the server does not have a CD-ROM or floppy disk drive.

SystemcastWizard Professional (optional) is a useful tool for extracting a lot of files in a short time.

1.2.2 High Reliability Tools

High reliability tools are a comprehensively useful set of software for stable system operations of the server. The following tools have respective roles to manage normal operations or recovery from errors:

- Server monitoring tools
- · System diagnosis support tools
- · LAN driver detailed setting tools

Server Monitoring Tools

The server monitoring tools monitor the hardware status on behalf of the administrator and notify him/ her in the event of an error.

Early Detection of a Server Failure [ServerView]

ServerView is software that monitors whether the server hardware is in a normal state to protect important server resources. When using ServerView, the server hardware is monitored all the time. If an error that could cause trouble is detected, the administrator is notified in real-time. This allows the server administrator to remove a system error early and avoid trouble.

Early Detection of a Disk Problem [RAID Management Tool]

RAID Management Tool is software that performs array configurations, disk initialization and storage system monitoring. When an event occurs, it leaves an event log in the event viewer's application logs. At the same time, a pop-up window indicates a hard disk failure, rebuild status, etc.

System Diagnosis Support Tools

The system diagnosis support tools are for supporting system diagnosis during normal operation or in the event of trouble.

Early Solution to Problems [DSNAP]

DSNAP is a command line utility for collectively acquiring failure investigation information. Command line operation makes easy to set the configuration information of the system file and major registries, and collect the event log.

When a problem occurs in your Windows Server 2003 / Windows 2000 Server system, DSNAP is used for a support engineer to understand your system software configuration and settings correctly and to promote research smoothly. Provide this with memory dump to your support engineer.

LAN Driver Advanced Setup Tools

These tools set details on the LAN, including the use of the Teaming (load balance) function and VLAN configuration.

Broadcom Advanced Control Suite (BACS)

BACS is a tool for setting details on the onboard LAN when it is used to configure a VLAN.

Intel[®] PROSet

Intel[®] PROSet is a tool for setting details on the LAN card when it is used for using the Teaming function or when it is used for configuring a VLAN.

1.2.3 Installing High Reliability Tools

You can install all high reliability tools provided with PRIMERGY by specifying them in "Application Wizard" when the OS is installed is initiated with ServerStart. The following high reliability tools are installed.

High reliability tool	ServerStart installation		
	Guided mode	Expert mode	
RAID Management Tool / ServerView (for apache)	S	N	
RAID Management Tool / ServerView (for IIS)	Ν	N	
DSNAP	S	S	
Broadcom Advanced Control Suite (BACS)	A	N	
Intel [®] PROSet	Α	А	

A: Installed in any case

N: Installed if selected (Not selected by default)

S: Installed if selected (Selected by default)

MPORTANT

- SBS 2003 and Linux do not support batch installation with ServerStart.
- ServerView must be configured after installation even when the high reliability tools have been installed at once with ServerStart. Refer to "Chapter 6 High Reliability Tools" (→pg.171).

POINT

- When using ServerStart to install the OS, RAID Management Tool and ServerView are installed at a time. These cannot be selected individually.
- To use all functions of ServerView, "Java2 Runtime Environment Standard Edition" and "Web server" are required. When using ServerStart to install the OS, "Java2 Runtime Environment Standard Edition" is installed automatically. For Web server, you can use either of the followings by selecting a menu.
 - ServerView (for apache) Install ServerView Web-Server (Web server for ServerView, Apache for Win32 base) and install ServerView configuring to use this Web server.
 - ServerView (for IIS)
 Install Microsoft Internet Information Server (IIS) supplied with Windows separately. ServerView is
 installed with the setting to operate using IIS installed on the system.


When IIS is not found in the system, ServerView Web-Server is installed even if "ServerView (for IIS)" is selected. ServerView (for apache) is selected by default for guided mode. To install ServerView (for IIS), select "RAID Management Tool / ServerView (for IIS)". If "RAID Management Tool / ServerView (for IIS)" is selected, ServerView (for apache) is not installed.

- Intel[®] PROSet will be installed only when an optional LAN card is installed properly and the driver is applied correctly.
- If the OS is installed on other than drive C using ServerStart, Intel[®] PROSet will not be installed. In this case, install Intel[®] PROSet manually. For details, refer to "5.7.1 Intel[®] PROSet Installation" (→pg.166).

1.3 Component Names and Functions

This section explains the component names and functions of the server and baseboard.

1.3.1 Server (Front View)



a Drive cover key

We recommend you lock it to prevent unauthorized access to the inside of the server.

b System identification LED

This LED is used for maintenance. When pressing the system identification LED button, the front and rear LEDs are lit blue so that the locations of devices being maintained can be determined.

Also, the [System Identification LED Display] button of ServerView can be used to light them.

c System identification LED button

When pressing system identification LED button, the front and rear system identification LEDs are lit blue so that the locations of devices being maintained can be determined.

d Reset switch

Pressing this switch resets and restarts the system.

MPORTANT

 Do not restart the system when the hard disk access LED is blinking. Data in the hard disk may be damaged.

e Maintenance switch

This switch is used only by maintenance personnel. Do not touch this.

f System status LED (

This LED lights or blinks in amber when an error is detected in the server components. If this LED lights or blinks, contact an office listed in the "Contact Information" of "Start Guide".

g Hard disk access LED (

This LED blinks when data is being written to or read from the hard disk.

h Power LED (())

This LED is lit green when the server is turned on.

POINT

Power LED is lit when the server is in standby mode (when the AC power is on and the DC power is off), but this does not indicate an error.

Power switch

Press this switch to turn the server on.

MPORTANT

 Do not turn the server off when the hard disk access LED is blinking. Data in the hard disk may be damaged.

5-inch storage bay

Contains a 5-inch internal device.

Unlike external devices, an internal option does not need to be connected to the outlet because its power is supplied from the server. It also saves space.

k CD-ROM drive

Reads data or programs from a CD-ROM.

CD-ROM eject button

Press this button to eject a CD-ROM.

Do not press this when the CD-ROM access LED is on.

m CD-ROM access LED

This LED blinks when data is being read from a CD-ROM.

n Drive cover

This slides up and down.

Floppy disk eject button

Press this button to eject a floppy disk.

Do not press this when the floppy disk access LED is on.

P Floppy disk access LED

This LED blinks when data is being written to or read from a floppy disk.


q Floppy disk drive

Writes/reads data to/from a floppy disk.

r USB connector (↔)

Connects peripheral equipment conforming to the USB standard (2.0 or 1.1).

■ Inside the Hard Disk Cover



a 3.5-inch storage bay

Contains an internal hard disk.

b Hard disk access display LED (\odot)

This LED is lit green when data is being written to or read from the hard disk.

table: Meaning of the Hard Disk Access Display LED

LED status	Hard disk access status	
Off	Hard disk is not accessed	
Lights in green	Hard disk is accessed	


c Hard disk failure LED (\otimes)

It is lit or blinks depending on the hard disk status as follows.

table: Meaning of the Hard Disk Failure LED

LED status	Hard disk status	
Off	In normal mode or hot spare mode	
Lights in amber	Error detected in the hard disk (in an array configuration)	
Blinks in amber	Rebuilding	

1.3.2 Server (Rear View)



a Inlet

Connects power cables.

b Mouse connector (\dashv)

A mouse is plugged in.

c System status LED

This LED lights or blinks in amber when an error is detected in the server components. If this LED lights or blinks, contact an office listed in the "Contact Information" of "Start Guide".

POINT

 System status LED is lit when the server is in standby mode (when the AC power is on and the DC power is off), but this does not indicate an error.

d System identification LED

This LED is used for maintenance. When pressing the system identification LED button, the front and rear LEDs are lit blue so that the locations of devices being maintained can be determined.

Also, the [System Identification LED Display] button of ServerView can be used to light them.

A keyboard is plugged in.

f Serial port connector ([OIO])

Cables of peripheral equipment conforming to the RS-232C standard such as modems are plugged in.

g Display connector (

A display cable is plugged in.

h Parallel port (option)

A printer cable is plugged in.

I USB connector (∞)

Connects peripheral equipment conforming to the USB standard (2.0 or 1.1).

j Remote Management Controller port

This is a port for the Remote Management Controller. The Remote Management function can be used from Web interface by connecting a LAN cable. For information on how to use the Remote Management Controller, refer to "D Remote Management Controller" (→pg.278).

An Unshielded Twisted Pair (UTP) cable is plugged in.

For 1000Mbps connection, a category 5 enhanced or a category 6 cable is required.

For 10Mbps/100Mbps connection, a category 5 or higher cable is required.




The meaning of the LED is shown in the table below.

LED location	LED status	Connection status
Upper LED	Lights in green	Link is being established
	Blinks in green	Data is being transferred
	Off	Link is not established
Lower LED	Lights in amber	Connection established at 1000 Mbps
	Lights in green	Connection established at 100 Mbps
	Off	Connection established at 10 Mbps

table: Meaning of the LAN Port LED

1.3.3 Server (Internal)



a Power supply unit

b Memory slot

Contains memory.

c 5-inch storage bay

Contains a 5-inch internal optional device.

Unlike external devices, an internal option does not need to be connected to the outlet because its power is supplied from the server. It also saves space.

d 3.5-inch storage bay

Contains a 3.5-inch internal optional device.


e Expansion Card Slot

Contains extension cards that enhance the server functions.

PCI cards with the PCI bus interface can be installed in the Expansion Card slots.

f CPU

1.3.4 Baseboard



a Parallel port connector

A parallel port cable is plugged in when using a parallel port option.

b CPU socket

Installs the CPU.

c Memory slot

Contains memory. If more memory is added, the amount of the data that can be read at a time increases and the processing performance of the server improves.

d Front Panel connector

A front panel cable is plugged in.

e Floppy connector

A floppy disk drive cable is plugged in.

f Power connector

g IDE connector

An IDE cable for the internal CD-ROM drive unit or the internal DVD-RAM drive unit is plugged in.

- h USB connector
- ATX 12V Power connector
- **j** SATA connector

This is not used for this server.

k SAS connector

A SAS cable for the internal hard disk is plugged in. Although there are two SAS connectors, use upper connector only.

Internal battery

Settings for the clock function of this server and for BIOS are saved.

m PCI Slots

Contains an expansion card. PCI slots (1 to 5) are numbered from bottom to top in the above figure.

n Jumper

For details about jumper settings, refer to "8.1 Jumper Settings" (→pg.212).

• Serial connector


A serial port cable is plugged in when installing a serial port.

1.4 Standard Operations

This section explains such standard operations as turning the server on/off and inserting/ejecting CD-ROMs.


1.4.1 Sliding the Drive Cover

1 Turn the drive cover key counterclockwise to unlock the cover.



2 Slide the drive cover.

Slide the drive cover down to use the floppy disk drive, CD-ROM drive, or a 5-inch internal option device.



POINT


- The driver cover key is unique to each device. Do not lose the key.
- If the key is lost, the lock must be broken and replaced on a paid basis. Manage the drive cover key very carefully.
- Contact an office listed in the "Contact Information" of "Start Guide" if you lose it.

1.4.2 Opening the Rack Door


This section explains how to open the front and rear doors of the 40U standard rack. Refer to the manual included with the rack for procedures on opening other rack doors.

Opening the Front Door

1 Turn the rack key and pull the rack handle up.




2 Turn the handle in the direction of the arrow and pull it forward.




Opening the Rear Door

1 Turn the rack key and pull the rack handle up.



2 Turn the handle in the direction of the arrow and pull it forward.



POINT

- Unless you are inserting/removing media or turning the power on/off, keep the door closed. Keeping the door closed blocks electric waves from cell phones, etc.
- Do not lose the keys. Contact an office listed in the "Contact Information" of "Start Guide" if you do lose them.

1.4.3 Turning On the Server



• Do not move, strike, or shake the server when it is turned on. This can damage the hard disk in the server and cause data loss.



 Turn the server on when the temperature is in its operating environment range (10-35°C). For details about the operating environment, refer to "Start Guide" and "Safety Precautions".

When operating the device outside of this operating environment, the server may operate improperly, damage data etc.

Furthermore, Fujitsu cannot be held responsible for any related damage, malfunction, or loss of data, etc.



• The fans rotate at high speed immediately after the server is turned on, but this is not defective. When the temperature is in the server's operating environment range (10-35°C), they start to rotate at normal speed later.



 Be sure to wait for 10 seconds or more after shutdown before turning the server on. **1** Slide the drive cover.


→"1.4.1 Sliding the Drive Cover" (pg.30)

- 2 Make sure that the floppy disk drive and CD-ROM drives are empty.
- **3** Turn on the display and peripheral devices.

4 Press the power switch on the front of the server.

The server's power LED is lit green.

When the power is turned on, the server performs Power On Self Tests (POST). If any abnormalities are detected by POST, error messages are displayed ("9.2.2 Error Messages" $(\rightarrow pg.239)$).



POINT

- The time to turn the server off can be set with the ASR setting (on the [Power On/Off] tab) using ServerView. For details, refer to "3.4 Serious Error Handling (ASR)" in "ServerView User's Guide."
- If you press the [F12] key right after the POST memory amount check, the Boot Menu is displayed, where you can change the boot disk ("■ How to Start the BIOS Setup Utility" (→pg.213)).

1.4.4 Turning Off the Server



• In the event of smoke or sparks, immediately unplug the electric cord. Failure to do so could lead to a fire or electrocution.



 Follow the procedures below to turn off the server. Data can be lost if these procedures are not followed correctly.

1 Slide the drive cover.

→"1.4.1 Sliding the Drive Cover" (pg.30)

2 Make sure that the floppy disk drive and CD-ROM drives are empty.

3 Shut down the OS.


In the following cases, the server is turned off after the OS is shut down (Step 4 is not necessary).

- Windows OS
- · ServerView is installed

In other cases, make sure that the access LEDs of floppy disk and hard disk are off when the OS is shut down.

4 Press the power switch on the front of the server.

The server's power LED is lit amber.



5 Turn off the display and peripheral devices.



Be sure to wait for 10 seconds or more after shutdown before turning the server on.

POINT

The time to turn the server off can be set with the ASR setting (on the [Power On/Off] tab) using ServerView. For details, refer to "3.4 Serious Error Handling (ASR)" in "ServerView User's Guide."

Cautions when Turning the Power Off (When the OS is Windows Server 2003 or Windows 2000 Server)

• For Windows Server 2003

"Do Nothing", "Prompt Input", "Standby", "Hibernation", or "Shutdown" can be specified as the operating mode of the power switch in the OS settings (normally, "Shutdown" is specified).

For Windows 2000 Server
 "Standby", "Hibernation", or "Power Off" can be specified as the operating mode of the power switch
 in the OS settings (normally, "Power Off" is specified).

On this server, functions corresponding to "Standby" and "Hibernation" are supported as BIOS and hardware functions. However, some drivers and software installed in the server do not support these functions. For this reason, functions corresponding to "Standby status" and "Hibernation status" are unavailable on this server.

When the operating mode is set to "Standby" or "Hibernation", the system may operate improperly or hard disk data may be corrupted. For details about operating mode settings, refer to the OS manual.

1.4.5 Inserting and Ejecting a Floppy Disk

Cautions

When using floppy disks, note the following points to avoid failures:


- Do not expose the disk to any fluids.
- Do not open the shutter of the floppy disk and touch the disk surface.
- Do not bend the floppy disk or place heavy objects on it.
- Do not expose the floppy disk to strong magnetic fields.
- Do not drop the floppy disk on hard surfaces.
- Do not store the disk in extremely hot or cold conditions.
- Do not store the disk in humid or dusty conditions.
- Do not put layers of labels on the floppy disk. Doing so may cause the drive to be clogged with the disk.
- · Keep the disk away from condensation or water droplets.

Inserting the Floppy Disk

POINT


- Use a floppy disk formatted in DOS/Windows. Operations are not guaranteed when you use other floppy disks.
 - Insert the floppy facing the label up into the floppy disk drive at the side with a shutter.

It makes a clicking sound and the floppy disk eject button pops out.



Ejecting the Floppy Disk


1 Make sure that the floppy disk access LED is off.



MPORTANT

- Do not eject the floppy disk while the floppy disk access LED is on. Doing so may damage data.
- **2** Press the floppy disk eject button.

The floppy disk comes out.



1.4.6 Inserting and Ejecting a CD-ROM (DVD-RAM)

This section explains how to insert and eject a CD-ROM and DVD-RAM. Unless otherwise noted, CD-ROM includes DVD-RAM.

When using CD-ROMs, note the following points to avoid failures.

Cautions for Handling CD-ROMs

- Do not put labels, or apply ink or pencil, to both sides of the CD-ROM.
- Do not touch or scratch the data side of the CD-ROM.
- Do not bend the CD-ROM or place heavy objects on it.
- When cleaning the CD-ROM, use a slightly wet cloth to wipe it from the center to the edge, and then wipe it with a dry cloth.
- Do not expose the disk to any fluids.
- Do not store the disk in extremely hot or cold conditions.
- Do not store the disk in humid or dusty conditions.

Cautions for Handling Drives


- Do not use CD-ROMs that do not follow the notes described in "■ Cautions for Handling CD-ROMs" (→pg.38), or distorted, broken, or cracked CD-ROMs. Doing so may cause failures. If these CD-ROMs are used and the drive fails, the warranty will be invalidated.
- This server supports only circular CD-ROMs. Do not use noncircular CD-ROMs. Doing so may cause failures. If noncircular CD-ROMs are used and the drive fails, the warranty will be invalidated.
- If commercially available CD-ROM cleaning disks are used, dust may get on the lens. Do not use CD-ROM cleaning disks.
- Some copy control music CDs cannot be used.
- This server supports CD-ROMs with the following logo. Do not use CD-ROMs without the logo. Doing so may cause failures.




For information about DVD-RAM drive, refer to the manual which comes with the internal DVD-RAM unit.

■ Inserting the CD-ROM

1 Make sure the server is turned on and press the CD-ROM eject button. The CD-ROM tray comes out a little.



2 Place the CD-ROM (label side up) onto the tray.



3 Press the CD-ROM eject button.

The tray is inserted into the server and CD-ROM is set.

POINT

When CD-ROM is set, the CD-ROM access LED is lit. To do next operation, confirm that the LED is off.


Ejecting the CD-ROM

To eject the CD-ROM, confirm that the CD-ROM access LED is off and then press the CD-ROM eject button.

1

1.5 Workflow

To start the server operation, perform the following procedures.



Chapter 2

Checking before OS Installation

This chapter explains the preparation on the server and cautions necessary before OS installation. Please read this chapter before starting installation.

2.1	Preparation on the Server	42
2.2	Selecting the Installation Method	45
2.3	Precautions on Installation	47
2.4	Preparation for Using ServerStart on a Client Computer	52

2.1 Preparation on the Server

Before starting installation, install internal options to the server and perform necessary hardware settings.

2.1.1 Installing Internal Options

Internal options are classified into those that must be installed before the OS installation and those that must be installed after the OS installation.

For installation procedures, refer to "Chapter 7 Installing Hardware Options" (→pg.177).

Options That Must be Installed before the OS Installation

- · Memory modules
- · Expansion cards

Options That Must be Installed after the OS Installation

- Optional SCSI devices
- · Internal hard disk units where the OS is not installed

MPORTANT

If an internal option device that must be installed after the OS installation has been already installed, remove the device, install the OS, and then reinstall the device.

Installing Optional External Devices

When installing external hard disk drives and/or USB devices, turn off their power or unplug their connection cables from the server during the OS installation. Connect them after the OS installation.

Cautions for Installing an Expansion Card

When using an expansion card, read the notes on the expansion card.

Cautions for Installing a Memory Module

This server supports up to 8GB of memory. However, the maximum installable size varies depending on the OS. Furthermore, since the server uses part of the memory as PCI resources, the maximum available size is limited.

The following shows the maximum installable size and the maximum available size.

OS	Installed memory size	Available memory size
Windows 2000 Server	3.5GB or smaller	Same as the installed memory size
Windows Server 2003 / R2 SBS 2003	4.0GB or larger	Installed memory size - $(0.5GB)^{*1}$
Windows Server 2003 x64 / R2 x64	Installed memory size	Same as the installed memory size

table: Maximum Installable Size and Maximum Availal	ole Size
---	----------

*1:0.5GB is used as PCI resources.

For Windows Server 2003, Standard Edition, available memory size can be same as the installed memory if Service Pack 1 is applied to and the following setting is configured using the BIOS Setup Utility.

- 1. Start the BIOS Setup Utility.
- 2. Select the [Advanced System Configuration] submenu from the [Advanced] menu.

3. Set [NX Memory Protection] to [Enabled].

LAN Cable

Be sure to connect the LAN cable when the server is not connected to the Internet.

MPORTANT

Connecting to the Internet during setup can cause security problems. Do not connect to the Internet until the setup completes.

If the OS is installed or applications are automatically installed without connecting the LAN cable to the LAN card, an error may be recorded in the event viewer after setup completes.

2.1.2 Hardware Settings

Before starting installation, set necessary hardware, such as the BIOS Setup Utility.

BIOS Setup Utility

The BIOS Setup Utility must be set in the following cases. For details on how to set the BIOS Setup Utility, refer to "8.2 BIOS Setup Utility" (\rightarrow pg.213).

Changing the Boot Drive

To change the boot drive, start up the BIOS Setup Utility, select [Boot Option], and set the boot drive. \rightarrow "8.2.4 Boot Options Submenu" (pg.218)

• Performing Remote Installation

Before performing remote installation of ServerStart, use the following procedures to enable network startup (PXE). In addition, check the MAC address.

- Take the following steps in the BIOS Setup Utility.
 - 1. Start the BIOS Setup Utility.
 - →"8.2.1 Starting and Exiting the BIOS Setup Utility" (pg.213)
 - 2. Select the [Peripheral Configuration] submenu from the [Advanced] menu and press the [Enter] key.
 - 3. Set [LAN Remote Boot] to [PXE].
 - 4. Select [Save Changes & Exit] from the [Exit] menu and exit BIOS Setup Utility.
 - 5. Start the BIOS Setup Utility again.
 - 6. Select the [Boot Option] submenu from the [Main] menu and press the [Enter] key. The Boot Option submenu window appears.
 - 7. Change the [Boot Sequence] settings as shown below.

```
1 BootManage PXE, Slot 0A00
2 CD-ROM
3 Diskette
4 Hard Drive
```

8. Exit the BIOS Setup Utility and turn off the server.

2 Check the MAC address.

Start up the server from the network.

The MAC address is displayed as shown below.

CLIENT MAC ADDR: XX XX XX XX XX XX

The MAC address is required for remote installation. Write it down.

POINT

You can turn the power on from a client (via a LAN) by utilizing the Wakeup On LAN (WOL) function. Refer to "5.5.5 Turning the Power On via a LAN" (→pg.159).

MPORTANT


Be sure to install ServerView to control the power supply via a LAN.
 Unless ServerView is installed, the server is not turned off automatically after shutting down the OS.

2.2 Selecting the Installation Method

When installing the OS for the first time, there are multiple installation methods. Refer to the following to decide on the method.

POINT

To set up multiple servers with the same model and configuration, refer to "3.5 Installation on Multiple (the Second and Subsequent) Servers" (→pg.107).



Installation Using ServerStart

When an OS is installed using ServerStart, the driver for the expansion card that is automatically recognized will be installed automatically. In addition, high reliability tools and array controller administrative tools are installed automatically. Installation using ServerStart is recommended because it helps install the OS without mistakes.

For features of ServerStart, refer to "1.2.1 Setup Support Tool - ServerStart" (→pg.16).

Installation While Maintaining the Established RAID Environment

In guided mode or preparation mode, select [Logical Drive View] at [Raid and Disk Configuration Wizard] (in the [Configuration for Disks and RAID Controllers] window) and install the OS.

Installation Using ServerStart While Maintaining the Existing Partitions

In expert mode of ServerStart, start up Disk Manager, format the installation partition, and install the OS.

■ To Configure the RAID 0+1 and Install the OS

The RAID 0+1 cannot be configured using ServerStart [RAID and Disk Wizard]. To configure the RAID 0+1 and install the OS, configure the RAID manually in advance and select [Logical Drive View] in guided mode or preparation mode.

2.3 Precautions on Installation

Read the following notes before starting OS installation.

2.3.1 Installation Partition Size

For installation using ServerStart, the installation partition size can be set as follows, depending on the OS to be installed and format.

Available size	Windows Server 2003 Windows Server 2003 x64	Windows 2000 Server
Minimum	2200MB	2048MB
Maximum	2TB	2TB

table: Installation Partition Size

Notes

• When you want to set the OS and BOOT partitions in different partitions, specify the partition size directly.

(The BOOT partition is the partition for startup. Minimum information required for startup, such as "ntldr", is stored.

The OS partition is the partition for installing the OS.)

- In either of the following cases, specify a partition size less than 2TB.
 - When the same partition is specified as the OS and BOOT partitions
 - · When different partitions are specified as the OS and BOOT partitions
- The OS cannot be installed in a partition larger than 2TB.
- For SBS 2003, ServerStart cannot be used to install the OS.

2.3.2 Notes on Configuring RAID

RAID can be configured with hard disk units connected to the SAS controller on the baseboard. Available RAID levels are different between the array configuration with the onboard array controller and the array configuration with the SAS array controller card. Check the following notes before configuring the RAID.

Array Configuration with the Onboard Array Controller

Hardware Configuration

- Only internal hard disk units can be used. Although four internal hard disk units can be installed on this server, up to two hard disk units can be used when configuring RAID with the onboard array controller.
- · Be sure to use hard disk units of the same model and with the same capacity.

Array Configuration

Only RAID 1 level can be configured. The array is configured for two internal hard disks on the server. For details, refer to "Integrated Mirroring SAS User's Guide" in the Array Controller Document & Tool CD.

Array Configuration with the SAS Array Controller Card

Hardware Configuration

- Be sure to install the SAS array controller card (PG-140F).
- Only internal hard disk units can be used. Up to four internal hard disk units can be installed on this server.
- Be sure to use hard disk units of the same model and with the same capacity.
- The hot spare (standby disk) can be configured. For details and notes on the hot spare disk, refer to "MegaRAID SAS User's Guide" in the Array Controller Document & Tool CD.

Array Configuration

The following RAID levels can be configured. The number of units that can be set varies according to the RAID level. For details, refer to the manual in the Document & Tool CD supplied with the SAS array controller card.

Notes

· When a RAID-configured disk is used

Hard disk units that have been used before may have unwanted partition information or array configuration information, which may cause unexpected problems. If you connect any hard disk units with usage history to this server, format them at low level on another system before connecting them to the server. For information on how to format the hard disk units, refer to the manual supplied with the system to be used.

• Number of disk units

If the number of actually installed units is smaller than the setting for the number of units (+1 when a hot spare is specified), installation using ServerStart is aborted because of an error.

When the number of installed disk units is greater than the setting, the disk units are set up according to the setting. Extra units will be configured as standby disk units.

2.3.3 Notes on a Multiple LAN Adapter Configuration

Using the OS installation wizard of ServerStart, you can configure multiple LAN adapters (network adapters) on the system. However, there are the following limitations.

Adapter Numbers

To configure multiple LAN cards, select the adapter numbers in order of Adapter 1 and Adapter 2, and enter settings for each adapter. Note that the order of adapter numbers is not necessarily the same as the order of slots for the installed LAN adapters. This means that the setting for Adapter 1 is not always applied to the onboard LAN. After installing the OS, check the LAN adapters to make sure that they are configured as intended.

2.3.4 Cautions for Using ServerStart

Operating ServerStart

Most ServerStart operations are performed with the mouse. Items may not be moved with the [Tab] key or cursor keys. Be sure to use the mouse when operating ServerStart.

Ejecting the CD-ROM

Do not eject the ServerStart CD-ROM while ServerStart is running. If the ServerStart CD-ROM is ejected and inserted again, ServerStart starts up in multiple windows, and settings you have made can be lost.

ServerStart CD-ROM

ServerStart supplied with this server contains Disc 1 and Disc 2. Disc 1 creates a configuration file and installs the OS. When required, insert Disc 2 during the installation.

Switching the Mode

When opening the configuration file and inputting information in the installation fields in the wizard, do not switch any other mode by manipulating the tree or by any other means (e.g. do not start up the Windows 2000 Server guided mode during Windows Server 2003 guided mode operation). Before switching the mode while inputting information, you must save the configuration file. If you do not save the configuration file, clicking [Cancel] will delete any changes that have been made.

Installing Windows 2000 Server

To install Windows 2000 Server, you have to use Service Pack 4 integrated OS media or select "Windows 2000 Server Service Pack 4" at the "Application Wizard" menu.

Exiting ServerStart

After operation in guided or expert mode, exiting ServerStart restarts the system. Remove disks from the floppy disk and CD-ROM drives and click [OK]. When the display on the screen disappears, turn off the system.

License for Use of System for ServerStart

"License for Use of System for ServerStart" linked from the ServerStart startup window is a license for use of Windows PE contained in the ServerStart CD-ROM. Windows PE for starting up ServerStart can be only used for installing Windows Server 2003 or Windows 2000 Server provided under a separate legal license.

Setting Up the Printer

ServerStart does not support setup of printers. Perform installation after setup is completed.

2.3.5 Expansion Cards Supported by ServerStart

ServerStart supports automatic driver installation for the following expansion cards.

Name	Model	Bus
Onboard FDD/IDE	-	-
Onboard LAN	-	PCI-E
Onboard VGA	-	PCI
SAS array controller card	PG-140F	PCI
LAN Card	PG-1892	PCI
	PG-2861	PCI-E
SCSI card	PG-1281	PCI

table: Automatic Expansion Card Driver Installation

2.3.6 Cautions for Manual Installation

Notes on Using an Array Controller Card

Before the OS is installed, the array controller card must be configured and the system drive under the array controller card must be initialized. To check the array controller card settings, start up WebBIOS. For more details, refer to the manual which comes with the array controller card.

Installing Windows 2000 Server

To install Windows 2000 Server directly, you have to use Service pack 4 integrated OS media or install Service Pack 4 or newer Service Pack.

And please install hotfix module named KB904374 after OS installation.

Please find out hotfix module of your language version from the following folder on ServerStart CD. [CD-ROM drive]: \HOTFIX\W2K\

Free Space Required for Installation

The partition where the OS is installed must have enough free space for obtaining memory dump. For more details, refer to"5.1 Memory Dump/Paging File Setting" (→pg.136).

Cautions on Restarting

In the course of installation, a message appears to indicate that the setup program restarts. Wait until it restarts automatically.

2.4 Preparation for Using ServerStart on a Client Computer

When using the preparation mode for setting installation information in advance or when creating a driver disk using the FloppyBuilder function, install ServerStart on the client computer.

• System Requirements for Client Computers

Client computers must satisfy the following requirements.

Hardware	Personal computers operated with Windows XP Professional, or Windows 2000 Professional (A CD-ROM drive and 10MB or more of free space are required.)
Software	Microsoft® Internet Explorer 5.5 or later

POINT

Using ServerStart on the server

➤ ServerStart can be installed to the server where Windows 2000 Server or Windows Server 2003 is installed. Perform the procedure in "2.4.1 Installing ServerStart" (→pg.52) to install ServerStart. Note that ServerStart cannot be installed to the server where Windows Server 2003 x64 is installed.

2.4.1 Installing ServerStart

MPORTANT

If a different version of ServerStart has been installed, uninstall it. The FloppyBuilder function or installation wizard may not operate properly on a different version. For details on how to uninstall ServerStart, refer to "2.4.2 Uninstalling ServerStart" (→pg.54). **1** Insert the ServerStart CD-ROM Disc 1 into the client computer.

The [ServerStart Launcher] window appears. When the [ServerStart Launcher] window does not appear, execute "SeStSetup.exe" in the CD-ROM.

🤗 Fujitsu Sie	emens ServerS	tart Setup	×
We make sure		Fujitsu Siemens ServerStart	
		ServerStart Functions Classic + Remote Installation Classic + Remote Installation (incl. Win x64) PXE Server ServerStart add-on Data packages for Remote Installation Data packages for Remote Installation (incl. Win x64) State Waiting for start Information Dk Cancel	

- **2** Check an only [Classic] and click [OK]. The Setup window appears.
- 3 Click [Next].

The [License Agreement] window appears.

- **4** Select [I accept the license agreement] and click [Next]. The [User Information] window appears.
- **5** Enter the user information of the software and click [Next]. The [Destination Folder] window appears.

📴 Fujitsu Siemens ServerStart Setup	×
Destination Folder Select a folder where the application will be installed.	
The Wise Installation Wizard will install the files for Fujitsu Siemens Serve following folder.	erstart in the
To install into a different folder, click the Browse button, and select anot You can choose not to install Fujitsu Siemens Serverstart by clicking Car Wise Installation Wizard.	
C:\Program Files\Fujitsu Siemens\ServerStart\	Browse
Wise Installation Wizard®	
< Back Next >	Cancel

6 Specify the installation folder and click [Next]. To change the installation folder, click [Browse] and select the folder.

The [Ready to Install the Application] window appears.

7 Click [Next].

Installation is executed.

POINT

If a message prompts you to restart the system before or after installation, eject the CD-ROM and restart the system according to the message. When the system restarts, insert the Server-Start CD-ROM and start installation again.
If the "This program does not respond " message appears during restart operation, click [Exit]

If the "This program does not respond." message appears during restart operation, click [Exit] to continue the restart operation.

When the installation is completed, the completion window appears.

8 Click [Exit].

ServerStart has been installed to the client computer.

2.4.2 Uninstalling ServerStart

Perform the following procedure to uninstall ServerStart from the client computer.

 Click [Start] → [Programs] → [Fujitsu Siemens ServerStart] → [Uninstall ServerStart].

2 Click [OK].

When the uninstallation is executed successfully, Fujitsu ServerStart is deleted.

2.4.3 Creating the ServerStart Floppy Disk

When using a floppy disk (new disk) other than the ServerStart floppy disk in guided mode, create the ServerStart floppy disk in advance. If you use the floppy disk supplied with ServerStart, creating the ServerStart floppy disk is not required since the disk is already ServerStart floppy disk.

1 Start up ServerStart.

If ServerStart has already been started, it is not necessary to start it up again. If it has not, start it up according to the following procedures:

Click [Start] → [Programs] → [Fujitsu Siemens ServerStart] → [ServerStart(Start from CD)].

ServerStart starts up and the [Welcome to ServerStart] window appears.

ServerStart	
🙆 🔟 <	
	V5.411.07
Welc	ome to ServerStart Click here to prepare an operating system installation for a PRIMERGY Server
	Information
1	FloppyBuilder

2 Click [FloppyBuilder].

The [ServerStart FloppyBuilder] window appears.

🖗 Serv	erStart	
8		
	_	
	Serv	verStart FloppyBuilder
		A click on 🧝 at the right side shows additional information about the corresponding menu item.
		18a -
	.	ServerStart Status Diskette
		Selverstall Status Diskelle
		DOS Diskette (Please refer to the "FreeDOS" folder of ServerStart CD-ROM for the license.)
	-	(Please feler to the Preedos Tolder of Serverstant Co-Rominon the license.)
		Drivers Diskettes (for Windows Server 2003 / Windows 2000 Server)
	*	Deiner Distantes Kerkters Course 2002 (CA)
		Drivers Diskettes (for Windows Server 2003 x64)
	1	Hardware Configuration Tools

3 Click [ServerStart Status Diskette].

A message prompts you to insert the floppy disk.

4 Insert the floppy disk and click [OK].

POINT

• Set the floppy disk in the write-enabled state.

Creation of a ServerStart floppy disk starts. When the creation is completed, the message "Floppy disk has been created." appears.

5 Click [OK].

Chapter 3

OS Installation Using ServerStart

This chapter explains how to install the OS in the server using ServerStart.

3.1	Guided Mode	58
3.2	Preparation Mode	75
3.3	Expert Mode	81
3.4	Remote Installation	88
3.5	Installation on Multiple (the Second and Subsequent) Server	s
		107


3.1 Guided Mode

In guided mode, follow the wizard to specify hardware configuration and the OS to be installed, save the information necessary for installation in a configuration file, and install the OS.

3.1.1 Starting Up the Guided Mode

Start up the guided mode.

1 Turn on the server and insert the ServerStart Disc 1 CD-ROM immediately. ServerStart starts up and a message prompts you to insert the ServerStart floppy disk.



2 Insert the ServerStart floppy disk supplied with the server. Make sure that "Removable media" and "A:" are selected and click [Create].

POINT

Set the ServerStart floppy disk in the write-enabled state.

Language settings		
Select language:	English	🔿 German
Select keyboard layout:	US-Internationa	
 Obtain IP address from O Use the following IP address 		ess to network drives)—
C Obtain IP address from		ess to network drives)
 Obtain IP address from O Use the following IP address 		ess to network drives)

The network setting window for remote installation appears.

3 Click [OK].

The [Initialization of ServerStart core running] window appears and the ServerStart initialization process starts. Depending on the hardware configuration, this process may take a few minutes.

ServerStart Unattended Mo	de	×
Initialization of ServerS	lart core running	
		z
ServerStart is copying file: ServerStart state:		
Jorrenstan sidit.	SeSt Registering core components	Wed May 25 19:04:42 2005



When the process is completed, the [Create a ServerStart Floppy Disk] window appears.

4 Click [Build a ServerStart Floppy Disk].


Creation of a ServerStart floppy disk starts. When the creation is completed, the "Floppy disk has been created" message appears.

5 Click [OK].

"Please Select your keyboard" Window appears.

6 Select your keyboard language from the drop-down list and click [OK].

The subsequent start procedure may take several minutes. The [Welcome to ServerStart] window appears.



7 Click [Click here to prepare and/or initiate an operating system installation]. The [Select the operating system to be installed] window appears. Click [Special Hints on Operating System Installation] and read the contents. Important information such as limitations on disk configuration is described.

Click [MS Windows Operating Systems].
 The [Microsoft Windows Operating System Installation] window appears.


9 Click the OS to install.

10 Click [Prepare & initiate an unattended installation of (OS)]. The guided mode for the selected OS starts up.

ServerStart	_ # ×
	<u>×</u>
Installation of MS Windows Server 2003 (pudded mode) A click on [®] at the right side shows additional information about the corresponding menu item. 	
Start here to create a complete configuration file	
RAID and Disk Wizard: RAID configuration and hard disk partitioning / formatting	8
Operating System Wizard: Specify operating system parameters	
🎓 Application Wizard: Select additional software components	
Close and save Configuration File	
Click here, to start the Installation of MS Windows Server 2003 Rola: Depending on the hardware detected in your PRIMERGY system ServerStart might install drivers that are not yet certified by t	Microsoft!
Done	V5.405.03 CAPS NUM 10.41 AM 2/24/2005

Start up the wizards to set items in the following procedures.

Exiting the wizard returns the display to the guided mode window.



MPORTANT

• Make sure to open the menu of each wizard and confirm the settings.

3

3.1.2 Opening/Creating a Configuration File

Open a configuration file. Or create a new one.

1 Click [Start here to create a complete configuration file]. The [Open ServerStart Configuration File] window appears.

Open Fer	verStart Configuration File	
per se	The settings for an unattended configuration and ins stored in a ServerStart configuration file.	tallation process are
	Please create a new one or open an existing one.	
a:	_	
€ A:\		
File name	x SerStartBatch.ini	Create
Files of ty	pe: (A:\SerStartBatch.ini)	
		<u>C</u> ancel
		Import

MPORTANT

- Once a configuration file is opened, another file cannot be opened until you click [Close and save Configuration File].
- **2** Select the configuration file and click [Create].

The [RAID and Disk Wizard] starts up automatically (→"3.1.3 RAID and Disk Wizard" (pg.63)).

3.1.3 RAID and Disk Wizard

Configure RAID, and create and format hard disk partitions.

 Click [RAID and Disk Wizard: RAID configuration and hard disk partitioning / formatting].

The [Configuration for Disks and RAID Controllers] window appears.

ServerStart		_ 8 ;
8 🖬 \land 🔺 🖾 🖬 🖬		
Raid and Disk Configuration Wizard		
Configuration for Disks and RAID Controllers		
C Logical Drive View (The system will be used as it is, with the current RAID configuration)		
C Mass Storage Controller View (The RAID configuration can be specified)		
A serverStart will delete all existing partitions on all disks where new partitions are defined. Note:		
Select «Logical Drive View» in case of install to Onboard SAS HDD.		
Please set up as following, in case of configure RAID with PO-142E3. (You don't have to configure the RAID if you are going to use current configuration.)		
Ouided mode : select 'MegaRAD SAS PCI Express(TM) ROME' of 'RAID controller'. Preparation mode : enter '1' to Controller Number.		
 Preparation model, enser i to consider rounder. 		
Logical Drive 1 LSI MegaRAID SAS RMB1.02 Add Partition		
< previous next > leave wizard		help
	V5.603.03	CAPS NUM 6:25 PM 6/13/2006

Only array controllers already installed are displayed.

2 Select the method of RAID configuration.

To install the OS while maintaining the established RAID environment

Select [Logical Drive View], and add partitions as necessary. For more details, refer to " \blacksquare Installation While Maintaining the Established RAID Environment" (\rightarrow pg.64).

To configure RAID

Select [Mass Storage Controller View], and add controllers as necessary. For more details, refer

to " \blacksquare Configuring RAID" (\rightarrow pg.65).

MPORTANT

The RAID 0+1 cannot be configured using ServerStart. To configure the RAID 0+1, configure the RAID manually in advance and select [Logical Drive View] on the [Configuration for Disks and RAID Controllers] window.

3 Set items and click [leave wizard].

The RAID and Disk wizard closes.

■ Installation While Maintaining the Established RAID Environment

 Select [Logical Drive View] on the [Configuration for Disks and RAID Controllers] window.

Add a partition

- 1. Click [Add Partition].
 - A partition is added.
 - Add required partitions.
- 2. Click [Details] and modify the settings as necessary.

The partition configuration is displayed. As the default values are configured, confirm the settings and modify them as necessary.

	Raid an	d Disk Configuration Wizard		
	Configuration for I	Disks and RAID Cont	rollers	
	(The system will be used as it is, with the current RAID conf roller View (The RAID configuration can be specified)	iguration)		
ServerStart will der Hote: Select «Logical Drive Vier	e all existing partitions on all disks where new partitions are in case of install to Onboard SAS HDD.	defined.		
(You don't have to config - Guided mode : select	In case of configure RAD with P0-142E3, re the RAD if you are going to use current configuration.) degaRAD SAS PCI Express(TM) ROME' of RAD controller', ar '1' to Controller Number.			
, in the second s	1 LSI MegaRAID SAS RMB1.02	Add Partition		
	Label system Filesystem NTFS 💌			
	Partition Size C Automatic C Size in MB 15 Quick Format C Yes C No	000		
	Partition Usage 🗹 Boot 🔽 OS 🗖 Data	oply Reset		

MPORTANT

- Partition size of the FAT file system When "FAT" is selected in [File system] and a value equal to or more than 4090MB or "Automatic setting" is specified in [Partition size], the size of created partitions will be 4090MB.
- The following limits apply to the volume label length. A volume label longer than the limit may be used. However, it can cause installation failure. Enter a volume label within the limit.
 FAT: Up to 11 characters

•NTFS: Up to 32 characters

Configuring RAID

 Select [Mass Storage Controller View] on the [Configuration for Disks and RAID Controllers] window.

Add partitions as necessary.

erverStart	
Reid and Disk Configuration Wizard	
Configuration for Disks and RAID Contro	ollers
Logical Drive View (The system will be used as it is, with the current RAID configuration) Mass Storage Controller View (The RAID configuration can be specified)	
A ServerStart will delete all existing partitions on all disks where new partitions are defined.	
Select Logical Drive Yews in case of instal to Choosed SAS HOC. Peace set up as following, in case of conjinger RAD with Pc1423. (You don't have to configure the RAD if you are grapping to use current configuration.) - Outside mole: sete: MegRACD SAS PCI Express (M) ROME of RAD controller. - Preparation mode: cetter "1' to Controller Number.	
Controller: RAD ISUMylex Raid Controller Details << Configure RAD © Automatically or C Manually	
Delete Existing RAID Array	
Controller Vendor: LSI/Mylex Raid Controller	
Controller Number:	
RAID Level: RAID 1	
Number of Disks:	
Hotspare: C Yes C No	
Apply Reset	
Disk 1 Faid disk. Add Partition	
< previous next > leave wizard	help
	V5.603.03 CAPS NUM 6:26 PM 6/13/20

POINT

- One hot spare (standby disk) can be configured. When the hot spare disk is set to "Yes", set the number of disk units to the number of installed disk units minus 1.
 - E.g.: When four hard disk units are installed, set the [RAID Level] to "RAID 5", and when the [Hotspare] is set to "Yes", set the [Number of Disks] to "3".
- Set the [Number of Disks] to "0" when configuring the RAID with all installed hard disk units.

Add a partition

1. Click [Add Partition].

A partition is added.

Add required partitions.

3

2. Click [Details] and modify the settings as necessary.

The partition configuration is displayed. As the default values are configured, confirm the settings and modify them as necessary.

N ServerStart	_ 8 ×
Reid and Disk Configuration Wizard	
Configuration for Disks and RAID Controllers	
C Logical Drive View (The system will be used as it is, with the current RAID configuration)	
Mass Storage Controller View (The RAID configuration can be specified) ServerStart will delete all existing partitions on all disks where new partitions are defined.	
Control and the device and an advanced prelimiter of the data while the hyperbolic data devices Holder: Seeter (adjoind Criter Views) in case of instals to Christoward SAS 1400 Press and tay as to Kontrol, in case of contrager PAQ with PFS 14/425 Press and tay as to Kontrol, in case of contrager PAQ with PFS 14/425 Advanced address and the MayerMAD SAS PD Enversar(10) ROLEF of the Controller: - Preparation onds - rise* 11% Control for RAD controller:	
Controller : RAID Y LS/Mylex Raid Controller Details >> Disk 1 raid disk Add Partition	
#1 - boot os - 15000 - NTFS - system Delatis <	
Label system	
Filesystem NTFS - Partition Size C Automatic C Size in MB 15000	
Quick Format C Yes @ No	
Partition Usage 🖉 Boot 🖉 OS 🗆 Data	
Apply Reset	
< previous next > leave wizard	help
	UM 6:26 PM 6/13/2006

3.1.4 OS Installation Wizard

Set computer information, user information, and the network protocol.

ServerStart can configure multiple network patterns. When configuring a domain controller, refer to "Using ServerStart to Configure the Network".

POINT

The setup window differs depending on the OS to be installed. The following describes operations on Windows Server 2003 R2.

To install another OS, interpret Windows Server 2003 R2 as your OS.

 Click [Operating System Wizard: Operating system parameters]. The [Windows Installation] window appears.

ServerStart		
🔕 🖸 \land 🔺 🖻		
	Windows Serv	er 2003 Setup Configuration Wizard
Windows Installation		
vvindows installation		
Regional settings (with keyboard layout):	C Use the default regional settings	s for the Windows-Version you are installing
(C Select here:	English United States
	C Select here:	English_onited_states
Password for Administrator account:		
Please repeat Password		

2 Enter the password in [Password for Administrator account] and [Please repeat Password] and click [Next].

POINT

• If the password differs between [Password for Administrator account] and [Please repeat Password], an error dialog window appears. Enter the password correctly.

The [Computer Identification] window appears.

ServerStart				_ 8 ×
🔇 🖸 \land 🔺 🕨 🖾 🔛				
	Windows Serv	er 2003 Setup Configuration Wizard		
Computer Identification				
Operating System Type:	Windows Server 2003 R2,	Standard Edition 💌		
License Mode:	C PerSeat € perServer U	ser permitted: 5		
will participate in:	⊙ a workgroup C a domain			
Workgroup or Domain Name:	MYUSERGROUP			
Operating system source media is available in Operating system source media is available or Remote Source Partie (e.g. Mnyserverbahre) Remote Userverbahre) Remote Dessword:		En Install Windows Server 2003 R2 C R2 Components source media is Rende Source Public Rende Source Public Rende Source Public Rende Username: Rende Username: Rende Password	available in local CD-ROM drive]
< previous next >	leave wizard			help
			V5.603.03	CAPS NUM 4:37 PM 4/25/2006

3 Set items and click [Next].

POINT

When using the CD-ROM applied Service Pack 1 on Windows Server 2003, select the [(OS) including SP1] menu from the [Operating System Type] list.

The [Installation Directory and Time Zone] window appears.

ServerStart		
	Ø 🖬 F	
		Windows Server 2003 Setup Configuration Wizard
Installation Directory	and Time Zone	
-		
Time Zone:	(GMT+01:00) Amst	erdam, Berlin, Bern, Rome, Stockholm, Vienna 💌
Installation Drive:	C Use Default	
	C Drive Letter:	C: SYSTEM
Installation Directory:	O Use default	
	C Prompt User	
	C Specify now:	

3

4 Set items and click [Next].

The [User Name] window appears.

ServerStart	
🕺 🗖 \land 📐 🖻	
	Windows Server 2003 Setup Configuration Wizard
User Name	
User Name:	
Organization:	
Computer Name:	
Product-ID (optional):	
If you use an OEM operating system CD y	u don't need to enter a Product-ID.

5 Set items and click [Next].

The [Display Settings] window appears.

📽 ServerStart						
🔕 🔟	\triangleleft	Δ	\triangleright	φ	F	
						Windows Server 2003 Setup Configuration Wizard
Display	Setti	ngs				
	_					
Resolution:	80	0 * 600) 🔻			
VRefresh:	70	-				
BitsPerPel:	16	•				

6 Set items and click [Next].

The [Network Protocol] window appears.

ServerStart				
😆 🖸 🔍 🛆 🕨	ō I I			
	Windows Serve	r 2003 Setup Configuration	Wizard	
Network Protocol				
Install Unattended				
C Install Unattended				
C Install Manually				
Available Protocols:	TCPIP 🔺 Se	ected Protocols:	TCPIP	
	NWIPX			
	AppleTalk -	Add ->		Remove
Adapter Name:	(1,1,0) 1 - Intel(R) PRO/1000 CT N	etwork Connection	-	
Connection Name:		-	_	
	1			
Use DHCP	IP-Address:			More IP
	Subnet Mask:			Addresses, Gateways
				DNS/WINS
	Default Gateway:			Configuration
	Netbios Option: Use NetBIOS set	ting from the DHCP Se	nver 🔻	
		-	_	

7 Set items and click [Next].

The [Software Components] window appears.

ServerStart					
Windows Server 2003 Setup Configuration Wizard					
Software Components					
Sonware components					
Install default Components					
C Install customized Components					
R2					
R2 Components Properties					
Accessories and Utilities Accessories					
Cipboard viewer					
M Desktop Wallpaper					
₩ Document Templates					
M Paint					
M All available mousepointers					
₩ Wordpad					
M Calculator					
🔽 Character Map					
Communications					
HyperTerminal					
Application Server					
ASP.NET web development platform					
Application Server console					
Internet Information Services (IIS)					
FTP Services Properties					
NNTP Service					
M NNTP Service					
SMTP Service					
I SMTP Service World Wide Web Server					
wund wue web Server					
Internet Information Services web DAV publishing					
World Wide Web (VWWV) Service Properties					
Internet Information Services internet data connector					
☐ Internet Information Services web user interface					
Management Console-based administration tools for IIS					
M Internet Information Services					
network COM+ access					
T DTC network access					
☑ Indexing Service Files					
Terminal Services Properties					
Terminal Services licensing					
Remote Installation Services Certificate Services					
Certificate Services					
Web client components of the Certificate Services					
POP3 root component					
F POP3 main service					
POP3 web user interface					
< previous next > leave wizard					

MPORTANT

If Windows Server 2003 R2 is selected at the Computer Identification, R2 components are always copied to the hard disk. To install the components, click [Properties] and check the components to be installed.

8 Set items and click [Next].

The [Services] window appears.

ServerStart	
😣 🗖 \land 📐 🖻 🗉	
	Windows Server 2003 Setup Configuration Wizard
Services	
Other Network File and Print Services	
Services for Macintosh (SFM)	
Print Services for Macintosh	
Print Services for Unix	
Networking Services	
WINS Server	
Internet Authentication Services (IAS)	
MS DNS Server	Setup Domain Controller
Simple TCP/IP Services	
MS DHCP Server	
Management and Monitoring Tools	
Network Monitor Tools	
SNMP Service	Properties

POINT

SNMP Service is always installed. Click [Properties] to change the settings, if needed.

9 Set items and click [leave wizard].

The OS installation wizard closes.

3.1.5 Application Wizard

Specify installation of supplied applications such as high reliability tools.

1 Click [Application Wizard: Select additional software components]. The application wizard appears.

	Application Wizard	
Installable applications:	Selected applications:	
MS Windows Server 2003 Service Pack 1	DSNAP	
User specific software	Broadcom Advanced Control Suite RAID Management Tool	
	Fujitsu ServerView	
Install selected application from Local CD Install selected application from Remote Server		
Remote Source Path:		
(e.g. \\myserver\share) Remote Username;		
Remote Password:		
Kemote Password: Userspecific Command:		
Available, but not installable: (Select an item and see «Prerequisite(s)»)	Prerequisite(s): (of the item currently selected)	
MS Windows 2000 ServicePack 4	For MS Windows Server 2003 only !	
	v.	
7		
< previous next >	leave wizard	h

2 From the [Installable applications] list, select applications to be installed and click [>>].

Set all applications to be installed on the [Selected applications] list.

POINT

- The following applications are always installed in guided mode. In expert mode, the selection can be released.
 - •Broadcom Advanced Control Suite
 - •RAID Management Tool
 - •Fujitsu ServerView (for apache)
 - •Fujitsu ServerView (for IIS)

3 Click [leave wizard].

The application wizard closes.

3

3.1.6 Closing/Saving the Configuration File

When settings in all wizards are completed, save the configuration file.

1 Click [Close and save Configuration File].

The [Save ServerStart Configuration File] window appears.

2 Click [Save As].

The configuration file is saved.

MPORTANT

You can specify any name for the configuration file. However, OS installation is possible only when it is saved as "SerStartBatch.ini". When installing the OS, make sure to save it as "Ser-StartBatch.ini" on the ServerStart floppy disk.

3.1.7 Starting OS Installation

Install the OS to the server.

During installation, do not use the mouse or keyboard unless it is necessary for installation operations. Otherwise, installation may fail.

1 Click [Click here, to Start the Installation of (OS)].

The [ServerStart Unattended Mode] window appears.

ServerStart Unattended Moo	le			×
Unattended Installation Press "Stop" button in	will be started in 7 seconds. order to start ServerStart Wizard	Start now	Stop	
				1
ServerStart is copying file: ServerStart state:			Tue Mar 08	× 11:49:29 2005

2 Click [Start now].

POINT

Clicking [Start now] deletes all disk contents and starts installation. Click [Stop] when you do
not perform installation.

After 10 seconds, installation starts automatically.

- 1. When RAID has been configured, the system restarts.
- 2. If a message prompts you to insert the Array Controller Document & Tool CD, insert the CD-ROM and click [OK].
- 3. If a message prompts you to insert the ServerView CD-ROM, insert the PRIMERGY Document & Tool CD and click [OK].
- 4. If a message prompts you to insert the Service Pack CD-ROM, insert the CD-ROM and click [OK].
- 5. For Windows Server 2003 x64, a message prompts you to insert the ServerStart Disc 2 and restart the system. Insert the ServerStart Disc 2 and restart the system.
- **3** When a message prompts you to insert the OS CD-ROM, insert the CD-ROM and click [OK].

For Windows 2000 / Windows Server 2003 / Windows Server 2003 x64

- 1. Insert the OS CD-ROM (Installation CD-ROM). The License Agreement window appears.
- 2. Click [I agree].

After files are copied, a message prompts you to eject the CD-ROM and floppy disk.

For Windows Server 2003 R2 / Windows Server 2003 R2 x64

- Insert the OS CD-ROM (Installation CD-ROM) Disc 1. The License Agreement window appears.
- Click [l agree].
 Files are copied.
- 3. If a message prompts you to insert the Disc 2, eject the Disc 1 and insert the OS CD-ROM (Installation CD-ROM) Disc 2.

After files are copied, a message prompts you to eject the CD-ROM and floppy disk.

4 Eject the CD-ROM and floppy disk and click [OK].

Then the system is restarted.

The system continues the installation operation after restart.

OS GUI setup, LAN utility installation, Service Pack installation, and Active Directory installation are performed automatically.

5 When a confirmation message to restart appears, click [Restart].

The system restarts and installs high reliability tools.

6 When a message on installation completion appears, press any key.

7 Restart the system.

Click [Start] \rightarrow [Shutdown]. Select [Restart] and click [OK]. The system restarts.



8 When the system restarts, log on to the server using the Administrator account for the local computer.

The server setup and OS installation have been completed.

Refer to "Chapter 5 Operations after OS Installation" (→pg.135) and perform necessary procedures before starting server operations.

3.2 Preparation Mode

In preparation mode, set and save the information necessary for installation in a configuration file on a client computer (with a CD-ROM drive and 10MB or more of free space). Set the saved configuration file on the server for installation.

POINT

- If ServerStart is not installed in the client computer where the preparation mode is executed, refer to "2.4 Preparation for Using ServerStart on a Client Computer" (→pg.52) to install ServerStart. If a different version of ServerStart has been installed, uninstall it and install the proper version. For details on how to uninstall ServerStart, refer to "2.4.2 Uninstalling ServerStart" (→pg.54).
- Prepare the ServerStart floppy disk. When using a formatted new disk, create the ServerStart floppy disk in advance, referring to "2.4.3 Creating the ServerStart Floppy Disk" (→pg.55).

3.2.1 Starting Up the Preparation Mode

Start up the preparation mode.

1 Start up ServerStart.

If ServerStart has already been started, it is not necessary to start it up again. If it has not, start it up according to the following procedures:

Click [Start] → [Programs] → [Fujitsu Siemens ServerStart] → [ServerStart(Start from CD)].

ServerStart starts up and the [Welcome to ServerStart] window appears.



2 Click [Click here to prepare an operating system installation for a PRIMERGY Server].

The [Prepare the installation of an operating system for PRIMERGY Server] window appears.

MPORTANT

4

- Click [Special on Hints on Operating System Installation] and read this section carefully before starting the installation. This section describes the important information such as restrictions of the disk configurations.
- 3 Click [Creation of ServerStart Configuration file for the installation of an Microsoft Windows Operating System].

The [Microsoft Windows Operating System Installation] window appears.

📽 ServerStart	
😢 🗖 🔺 📐 🕨 🔳 📰	
Microsoft Windows Operating	System Installation
• A click on 度 at the right side shows additional info	rmation about the corresponding menu item.
Create a configuration file for the installat	ion of MS Windows 2000
Create a configuration file for the installat	ion of MS Windows Server 2003
Create a configuration file for the installat	ion of MS Windows Server 2003 x64

Select [Create a configuration file for the installation of (OS)]. The [Preparing the Installation of MS Windows Server 2003] window appears.



3.2.2 Configuring Settings in Wizards

Click the wizards to set items in the following procedures. For setting procedures, refer to description on guided mode wizards ("3.1.2 Opening/Creating a Configuration File" (\rightarrow pg.62) to "3.1.5 Application Wizard" (\rightarrow pg.71)).

Open/create configuration file

RAID and Disk wizard

RAID and Disk wizard

OS installation wizard

Application wizard

Close/save configuration file

Activate ServerStart in the server

Starting OS installation

Exiting a wizard returns the display to the preparation mode window.

MPORTANT

• Make sure to open the menu of each wizard and confirm the settings.

3.2.3 Closing/Saving the Configuration File

When settings in all wizards are completed, save the configuration file.

Click [Close and save Configuration File].
 The [Save ServerStart Configuration File] window appears.

2 Click [Save As].

The [ServerStart Session IP Settings] window appears.



3 Set items when performing remote installation.

4 Click [Set].

The configuration file is saved.

MPORTANT

You can specify any name for the configuration file. However, OS installation is possible only when it is saved as "SerStartBatch.ini". When installing the OS, make sure to save it as "SerStartBatch.ini" on the ServerStart floppy disk.

3.2.4 Starting OS Installation

Install the OS to the server using the created configuration file.

During installation, do not use the mouse or keyboard unless it is necessary for installation operations. Otherwise, installation may fail.

- 1 Turn on the server and insert the ServerStart Disc 1 CD-ROM immediately. A message prompts you to insert the ServerStart floppy disk.
- 2 Insert the ServerStart floppy disk containing the created configuration file and click [OK].

MPORTANT

 Set the ServerStart floppy disk in the write-enabled state. If it is write protected, installation will fail.

The [Initializing ServerStart] window appears and the ServerStart initialization process starts. Depending on the hardware configuration, this process may take a few minutes. When initialization is completed, the [ServerStart Unattended Mode] window appears.

ServerStart Unattended Mode				×
Unattended configuration fil important data may get lost Unattended Installation. Pres start ServerStart Wizard.	if you start Unattended Itton in order to start	Start	Stop	
				5
				V
ServerStart is copying file:				
ServerStart state:	eSt: Writing system data to Se	rverStart floppy disk	Wed	1ay 25 20:09:59 2005

3 Click [Start].

A message appears.

4 Click [OK].

Installation starts.

- 1. When RAID has been configured, the system restarts.
- 2. If a message prompts you to insert the Array Controller Document & Tool CD, insert the CD-ROM and click [OK].

3

- 3. If a message prompts you to insert the ServerView CD-ROM, insert the PRIMERGY Document & Tool CD and click [OK]. This message does not appear when the PRIMERGY Document & Tool CD has been inserted already.
- 4. If a message prompts you to insert the Service Pack CD-ROM, insert the CD-ROM and click [OK].

This message does not appear when Service Pack is not selected.

- 5. If a message prompts you to insert the ServerStart CD-ROM, insert the ServerStart Disc 1 CD-ROM and click [OK].
- **5** When a message prompts you to insert the OS CD-ROM, insert the CD-ROM and click [OK].

For Windows 2000 / Windows Server 2003 / Windows Server 2003 x64

- 1. Insert the OS CD-ROM (Installation CD-ROM). The License Agreement window appears.
- 2. Click [I agree]. After files are copied, a message prompts you to eject the CD-ROM and floppy disk.

For Windows Server 2003 R2 / Windows Server 2003 R2 x64

- 1. Insert the OS CD-ROM (Installation CD-ROM) Disc 1. The License Agreement window appears.
- 2. Click [I agree]. Files are copied.
- 3. If a message prompts you to insert the Disc 2, eject the Disc 1 and insert the OS CD-ROM (Installation CD-ROM) Disc 2.

After files are copied, a message prompts you to eject the CD-ROM and floppy disk.

6 Eject the CD-ROM and floppy disk and click [OK]. The system restarts. The system continues the installation operation after restart. OS GUI setup, LAN utility installation, Service Pack installation, and Active Directory installation are performed automatically.

7 When a confirmation message appears on restart, click [Restart]. The system restarts and installs high reliability tools.

8 When a message on installation completion appears, press any key.

9 Restart the system.

Click [Start] \rightarrow [Shutdown]. Select [Restart] and click [OK]. The system restarts.



10 When the system restarts, log on to the server using the Administrator account for the local computer.

The server setup and OS installation have been completed.

Refer to "Chapter 5 Operations after OS Installation" (→pg.135) and perform necessary procedures before starting server operations.

3.3 Expert Mode

In expert mode, start up Disk Manager, format the installation partition, and install the OS.

Use the expert mode only when you want to perform installation while maintaining the existing partitions. Use the guided mode for normal installation.

3.3.1 Starting Up the Expert Mode

Start up the expert mode.

- **1** Turn on the server and insert the ServerStart Disc 1 CD-ROM immediately. ServerStart starts up and a message prompts you to insert the ServerStart floppy disk.
- 2 Insert the ServerStart floppy disk supplied with the server. Make sure that "Removable media" and "A:" are selected and click [Create]. The network setting window for remote installation appears.

POINT

Set the ServerStart floppy disk in the write-enabled state.

3 Click [OK].

The [Initialization of ServerStart core running] window appears and the ServerStart initialization process starts. Depending on the hardware configuration, this process may take a few minutes. When the process is completed, the [Create a ServerStart Floppy Disk] window appears.

4 Click [Build a ServerStart Floppy Disk].

Creation of a ServerStart floppy disk starts. When the creation is completed, the "Floppy disk has been created." message appears.

5 Click [OK].

"Please Select your keyboard" window appears.

6 Select your keyboard language from the drop-down list and click [OK].


The subsequent start procedure may take several minutes. The [Welcome to ServerStart] window appears.

7 Click [Click here to prepare and/or initiate an operating system installation]. The [Select the operating system to be installed] window appears. Click [Special Hints on Operating System Installation] and read the contents. Important

B Click [MS Windows Operating Systems].

The [Microsoft Windows Operating System Installation] window appears.

9 Select the OS to install.





Start up the configuration tools to set items in the following procedures. Exiting a tool returns to the display to the expert mode window.



MPORTANT

• Make sure to open the menu of each wizard and confirm the settings.

3.3.2 Disk Manager

Start up Disk Manager and format the installation partition.

 Click [Use Disk Manager to partition and format your disk drives]. Disk Manager starts up.

뤔Die	sk Man	ager									×
File	Disk	Partit	ion	View	Help						
	<u>)</u> Ri	oot									
	:		:0	:0	1020304	FUJITSU	MAP	3367NC			
				PART	ITION_IFS		0:\	NTFS	14998	MB	SYSTEM
				PART	ITION_IFS		D:\	NTFS	19854	MB	DATA

2 Format the OS installation partition. Select the OS installation partition and click the [Partition] menu \rightarrow [Format].

The [Format Partition] window appears.

🖶 Format Partition			×
<u>D</u> rive Letter	DV	Quick Format 🔽	
File System <u>T</u> ype	NTFS	Active Partition ₩	
Volume <u>L</u> abel			
	Format	Cancel	

MPORTANT

- Be sure to specify the active partition on drive C.
- Partitions equal to or larger than 4096MB cannot be FAT formatted.
- **3** Set items and click [Format].

The partition is formatted.

4 When the formatting is completed, click the [File] menu \rightarrow [Exit]. Disk Manager closes and the display returns to the expert mode window. 3

OS Installation Using ServerStart

3.3.3 OS Installation Wizard

Set computer information, user information, and the network protocol.

ServerStart can configure multiple network patterns. When configuring a domain controller, refer to "Using ServerStart to Configure the Network".

POINT

> The setting window differs depending on the OS to be installed. The following describes operations on Windows Server 2003 R2.

To install another OS, interpret Windows Server 2003 R2 as your OS.

1 Click [Installation Wizard for MS Windows Server 2003].

A message prompts you to specify the configuration file.

ServerSta	t 🛛 🕅
?	Do you want to specify an existing configuration file to preset the parameters for the Operating System Wizard and the Application Wizard ?
	Yes No

2 Click [No].

The [Windows Server 2003 Installation] window appears.

3 Enter the password in [Password for Administrator account] and [Please repeat Password] and click [Next].

POINT

If the password differs between [Password for Administrator account] and [Please repeat • Password], an error dialog window appears. Enter the password correctly.

The [Computer Identification] window appears.

4 Set items and click [Next].

The [Installation Directory and Time Zone] window appears.

POINT

- Þ When using the CD-ROM applied Service Pack 1 on Windows Server 2003, select the [(OS) including SP1] menu from the [Operating System Type] list.
- 5
 - Set items and click [Next].

The [User Name] window appears.

6 Set items and click [Next]. The [Display Settings] window appears.

7 Set items and click [Next].

The [Network Protocol] window appears.

8 Set items and click [Next].

The [Software Components] window appears.

MPORTANT

If Windows Server 2003 R2 is selected at the Computer Identification, R2 components are always copied to the hard disk. To install the components, click [Properties] and check the components to be installed.

Set items and click [Next].

The [Services] window appears.

POINT

 Simple Network Management Protocol is always installed. Click [Properties] to change the settings.

10 Set items and click [leave wizard].

The display returns to the expert mode window.

3.3.4 Application Wizard

Specify installation of supplied applications such as high reliability tools. For details on the application wizard, refer to "3.1.5 Application Wizard" (\rightarrow pg.71).

3.3.5 Starting OS Installation

Install the OS to the server.

MPORTANT

Notes on the Installation

- When the installation partition is not empty, a confirmation message appears. If it does not matter, click [OK] to continue the installation procedure.
- If an incorrect setting (such as the CD key) is found during installation, an error window will appear. Enter the correct value in the window to continue the installation procedure. However, corrections made here are not reflected to the configuration file.
- **1** Click [Click here, to Start the Installation of (OS)].

A confirmation window asking whether you want to save the current settings appears.

2 Click [Yes].

The following window appears.

Back un	Conv of	the ServerStart Configuration Fi	le	
	You ca	n create a back up copy of the current ie used as an input file for future sessio	interna	al configuration file.
C:\ C:\ Ap Ru Se	SYSTEM plicationT inOnce rverStartT imens	emp		
File nam Files of t				<u>S</u> ave As
- riies of (урс.	Configuration files *.ini	Ĩ	<u>C</u> ancel Export

3 Enter the file name and click [Save As].

Installation starts automatically.

ServerStart Unattended Mode	×
Unattended Installation running	
Start of Unattended Installation: Installation of operating system WinNet, configuration file: V/\sestcfg\config1.txt Contents V5.411.07	X
ServerStart is copying file: Z:\DEM\\FSC.gif ServerStart state: SeSt: Searching for OEM controllers	▼ 100 %

- 1. If a message prompts you to insert the Array Controller Document & Tool CD, insert the CD-ROM and click [OK].
- 2. If a message prompts you to insert the ServerView CD-ROM, insert the PRIMERGY Document & Tool CD and click [OK].
- 3. If a message prompts you to insert the Service Pack CD-ROM, insert the CD-ROM and click [OK].
- 4. For Windows Server 2003 x64, a message prompts you to insert the ServerStart Disc 2 and restart the system. Insert the ServerStart Disc 2 and restart the system.

4 When a message prompts you to insert the OS CD-ROM, insert the CD-ROM and click [OK].

For Windows 2000 / Windows Server 2003 / Windows Server 2003 x64

- 1. Insert the OS CD-ROM (Installation CD-ROM).
 - The License Agreement window appears.
- 2. Click [I agree].

After files are copied, a message prompts you to eject the CD-ROM and floppy disk.

For Windows Server 2003 R2 / Windows Server 2003 R2 x64

- Insert the OS CD-ROM (Installation CD-ROM) Disc 1. The License Agreement window appears.
- 2. Click [l agree]. Files are copied.
- 3. If a message prompts you to insert the Disc 2, eject the Disc 1 and insert the OS CD-ROM (Installation CD-ROM) Disc 2.

After files are copied, a message prompts you to eject the CD-ROM and floppy disk.

5 Eject the CD-ROM and floppy disk and click [OK].

Then the system is restarted.

The system continues the installation operation after restart.

OS GUI setup, LAN utility installation, Service Pack installation, and Active Directory installation are performed automatically.

- **6** When a confirmation message to restart appears, click [Restart]. The system restarts and installs high reliability tools.
- 7 When a message on installation completion appears, press any key.
- 8 Restart the system.

Click [Start] \rightarrow [Shutdown]. Select [Restart] and click [OK]. The system restarts.

9 When the system restarts, log on to the server using the Administrator account for the local computer.

The server setup and OS installation have been completed.

Refer to "Chapter 5 Operations after OS Installation" (\rightarrow pg.135) and perform necessary procedures before starting server operations.

3.4 Remote Installation

ServerStart supports remote installation.

MPORTANT

 Before performing remote installation, be sure to read "Cautions for Remote Installation" in the online help.

3.4.1 Overview of Remote Installation

Remote installation is a method to save resources necessary for installation, such as the OS and Service Pack, in a different server on the network and install them via the network.

If a remote resource server is configured, you can install the same resources to multiple servers. This method is useful in configuring multiple servers.

• Target Server and Remote Resource Server/PXE Server


A server to which resources are installed is called a "target server". A server that stores resources necessary for remote installation is called a "remote resource server". A server that can start up a target server through network startup (PXE) is called a "PXE server".

Installation Method

Remote installation uses a PXE or a remote resource server.

Remote Installation Using a PXE Server


In remote installation using a PXE server, the network startup (PXE) function of the PXE server starts up the target server and performs installation in preparation mode. This method is used when the target server does not have a CD-ROM or floppy disk drive.



In addition to the PXE server, a "remote resource server" that stores remote resources and a "DHCP server" that performs the DHCP service are required for remote installation using a PXE server. When you have only one server, store remote resources on the PXE server to install the DHCP service. When you have multiple servers, select one for performing the DHCP service and another for storing remote resources.

• Remote Installation Using a Remote Resource Server

In remote installation using a remote resource server, ServerStart starts up on the target server. Procedures for starting installation are the same as those in normal installation (preparation, guided, and expert modes). Once installation started, resources necessary for installation are provided from the remote resource server. Thus, procedures such as inserting a CR-ROM are not necessary.



3.4.2 System Requirements for Remote Resource/PXE Servers

Because remote installation is performed via a network, the environment must have at least one Windows server and a local area network.

In addition, the following environment is required.

Remote Resource/PXE Server Requirements

	PXE server	Remote resource server			
OS	Windows 2000 Server SP2 to 4 Windows Server 2003	Windows Server 2003 Windows 2000 Server			
Memory	256MB or more	256MB or more			
Operating environment	DHCP server function (required on the same network)File sharing function (required)	• File sharing function (required)			

table: System Requirements for Remote Resource/PXE Servers

MPORTANT

Notes on the PXE server

- Check that no other PXE server exists on the same LAN.
- Servers installed with software with the PXE function such as SystemcastWizard/SystemcastWizard Professional, Quick Recovery Manager, or the Microsoft RIS function cannot be used as a PXE server.

Checking Server Free Space

Decide a server to use as a remote resource server / PXE server and check it for enough free space for storing resources.

• Checking the Number of Servers

- When you have only one server, use it as the remote resource server, PXE server, and DHCP service server. Check it for the required amount of free space.
- · When you have multiple servers
 - Check if a server performing the DHCP service exists. If not, decide a server for the DHCP service.
 - When there are multiple resources, they can be divided and stored in multiple remote resource servers.

Checking Server Free Space

The following table shows the amount of free space required for each installation resource.

Resource	Required free space
ServerStart Disc 1	approx. 650MB
ServerStart Disc 2	approx. 450MB
Windows Server 2003	644MB
Windows 2000 Server	472MB
Windows Server 2003 Service Pack 1	389MB
Windows 2000 Service Pack 4	433MB
Windows Server 2003 R2, Standard Edition Disc 1	609MB
Windows Server 2003 R2, Standard Edition Disc 2	125MB
Windows Server 2003 R2, Enterprise Edition Disc 1	610MB
Windows Server 2003 R2, Enterprise Edition Disc 2	125MB
Windows Server 2003 R2, Standard x64 Edition Disc 1	629MB
Windows Server 2003 R2, Standard x64 Edition Disc 2	172MB
Windows Server 2003 R2, Enterprise x64 Edition Disc 1	631MB
Windows Server 2003 R2, Enterprise x64 Edition Disc 2	172MB


table: Free Space Required for Resources

Calculate the total resource size. Check that the remote resource server / PXE server has enough free space (free space greater than the space required for the resources). When the amount of free space is insufficient, you must use more remote resource servers.

3.4.3 Preparation of the PXE Server (When the PXE Server is Used)

When performing remote installation using a PXE server, preparatory procedures, such as installing ServerStart, are required.

Perform the following procedures to prepare the PXE server.



Starting the DHCP Service

Check that the DHCP service is running on the same network. If the DHCP service function is not installed, perform the following procedures to install the DHCP service. The following procedures are examples for Windows Server 2003.

- **1** Click [Start] \rightarrow [Control Panel] \rightarrow [Add or Remove Applications].
- 2 Click [Add or Remove Windows Components]. Click the [Dynamic Host Configuration Protocol (DHCP)] service from [Network Services]. The DHCP service is installed.
- **3** Create and configure a DHCP scope so that the IP address can be distributed.

Installing ServerStart

1 Insert the ServerStart Disc 1 CD-ROM into the PXE server.

The [Fujitsu Siemens ServerStart Setup] window appears.

When the [Fujitsu Siemens ServerStart Setup] window does not appear, execute "SeStSetup.exe" in the CD-ROM.

🔮 Fujitsu Sie	emens ServerSt	art Setup	X
We make sure		Fujitsu Siemens ServerStart	
		ServerStart Functions Classic Classic + Remote Installation Classic + Remote Installation (incl. Win x64) PXE Server ServerStart add-on Ø Data packages for Remote Installation Data packages for Remote Installation (incl. Win x64) State Waiting for start Information Øk	

2 Check [Classic+Remote Installation (OS)], [PXE Server] and [Data packages for Remote Installation (OS)], and click [OK].

For [Classic + Remote Installation (OS)] and [Data packages for Remote Installation (OS)], check the items of the corresponding OS. The setup window appears.

3 Click [Next].

The [Destination Folder] window appears.



4 Select the installation folder and click [Next].

To change the installation folder, click [Browse] and select the folder. The [Selection of LAN card] window appears.

🙀 Fujitsu Siemens ServerStart PXE Server - InstallShield Wizard	<u>×</u>
Selection of LAN card	FUJITSU COMPUTERS
Please select LAN card that PXE Service uses.	
 [1] "Local Area Connection" - 192.168.0.18 [2] "Local Area Connection 2" - "Media disconnected" [3] <nothing></nothing> [4] <nothing></nothing> [5] <nothing></nothing> [7] <nothing></nothing> [8] <nothing></nothing> 	
InstaliShield	Cancel

5 Select the LAN controller to use and click [Next]. The [proxy DHCP Configuration] window appears.

6 Select [Yes] to run the DHCP service on the PXE server or select [No] to run the DHCP service on the other server on the network, and click [OK]. The [Ready to Install the Application] window appears.

7 Click [Install].

Installation starts. When the installation is completed, the [InstallShield Wizard Completed] window appears.

8 Click [finish].

The setup window appears.

9 Click [Next].

The [License Agreement] window appears.

- **10** Select [I accept the license agreement] and click [Next]. The [User Information] window appears.
- **11** Enter the user information of the software and click [Next]. The [Destination Folder] window appears.

🙀 Fujitsu Siemens Serverstart Data packages V6.606 Setup	
Destination Folder Select a folder where the application will be installed.	
The Wise Installation Wizard will install the files for Fujitsu Siemens Serverstart D packages V6.606 in the following folder.	lata
To install into a different folder, click the Browse button, and select another fold You can choose not to install Fujitsu Siemens Serverstart Data packages V6.60 clicking Cancel to exit the Wise Installation Wizard.	
Destination Folder	
C:\Program Files\Fujitsu Siemens\	se
network share for the ServerStart Data packages	
SeSt_ISO_V6.606.02	
Wise Installation Wizard (R)	
< <u>B</u> ack <u>Next></u>	Cancel

12 Select the installation folder, configure ServerStart image that is required for network booting (PXE), and click [Next].

To change the installation folder, click [Browse] and select the folder. The [Select Features] window appears.

🙀 Fujitsu Siemens Serverstart Data packages ¥6.605 Setup				
Select Features Please select which features you would like to install.				
ServerStart Content 32Bit	Feature Description:			
important hint ! The Features were preselected by SeStSetup.exe !!	This feature will be installed on the local hard drive.			
	This feature requires 12KB on your hard drive. It has 0 of 1 subfeatures selected. The subfeatures require 0KB on your			
Wise Installation Wizard (R)				
<u>D</u> isk Cost <u>R</u> eset < <u>B</u> ack	< <u>N</u> ext > Cancel			

Clicking [Disk Cost] displays the following window where you can check the amount of free space.

1	Fujitsu Siemens Serve	rstart Data packages ¥6.605 Setup	×				
	The current selections require the following amount of disk space on the different volumes. The highlighted volumes do not have enough disk space available for the currently selected features.						
	Volume	Disk Avail Requi Differ					
	⊂C:	278GB 276GB 2680KB 276GB					
		ОК					

13 Click [Next].

The [Useraccount for access to the ServerStart Data packages] window appears.

🚏 Fujitsu Siemens Serverstart Data packages V6.605 Setup	_ 🗆 🗡				
Useraccount for access to the ServerStart Data packages please enter username and password for the account which is necessary for access to the ServerStart Data packages during remote installation	UJITSU COMPUTERS				
Use the Browse button to choose users from your network. For domains, us must be in the format of DOMAIN/UserName.	er names				
User Name:	Browse				
Password:					
Create New User					
~ hint					
During the configuration of the remote installation for a client you have to specify a user account for the access to the ServerStart Data packages. The ServerStart Data packages are shared automatically by the installer.					
Wise Installation Wizard (R) <a>K Next >	Cancel				

Clicking [Create New User] displays the [Create New User] window. Configure each item to create a new user.

🙀 Create New User	
	at defines the new user you are creating. r creation permissions on the domain or
Domain/Server:	
User Name:	
Password:	
Confirm Password:	
Group:	
	OK Cancel

14 Enter a user name and a password, and click [Next].

The [Ready to Install the Application] window appears.

15 Click [Install].

Installation starts. When the installation is completed, the [InstallShield Wizard Completed] window appears.

16 Click [finish].

The setup window appears.

17 Click [Next].


The [License Agreement] window appears.

18 Select [I accept the license agreement] and click [Next].

The [User Information] window appears.

19 Enter the user information of the software and click [Next].

The [Destination Folder] window appears.



20 Specify the installation folder and click [Next]. To change the installation folder, click [Browse] and select the folder.

The [Select Features] window appears. Clicking [Disk Cost] displays the following window where you can check the amount of free space.

21 Click [Next].

The [Ready to Install the Application] window appears.

22 Click [Next].

Installation is executed.

POINT

If a message prompting you to restart the system appears before or after installation, eject the CD-ROM and restart the system according to the message. When the system restarts, insert the ServerStart CD-ROM and start installation again.

If the "This program does not respond." message appears during restart operation, click [Exit] to continue the restart operation.

When the installation is completed, the completion window appears.

23 Click [Exit].

In case of Windows Server 2003 x64 installation, the [Browse for Folder] window appears. Insert the ServerStart Disc 2 CD-ROM and continue installation. ServerStart has been installed to the client computer.



24 Click [Start] \rightarrow [Shutdown]. Select [Restart] and click [OK].

The system restarts.

Checking Services

• Checking [PXE Services] and [TFTP Service]

1 Right-click the [My Computer] icon and click [Manage].

2 Select [Services] from [Services and Applications].

On the Services list, check that PXE Services and TFTP Service have been installed and started.

Action Yiew 🛛 🗢 🔿 🗈 🔃	🖻 🗗 🗟 😫 🛛 🕨	■ ■>			
Tree	Name 🔺	Description	Status	Startup Type	Log (
Computer Management (Local)	With NT LM Security Sup	Provides s		Manual Manual	Loca Loca
🖹 🌇 System Tools	Performance Logs a	Configures			
🕀 🔝 Event Viewer	Plug and Play	Manages d	Started	Automatic	Loca
🕀 😼 System Information	Print Spooler	Loads files	Started	Automatic	Loca
Performance Logs and Alerts	Protoctod Storago	Providos pr		Automatic	Loca
E Shared Folders	PXE Services	Fujitsu Sie	Started	Automatic	Loca
Device Manager	QOS RSVP	Provides n		Manuai	LOCA
🗄 🔣 Local Users and Groups	Remote Access Aut	Creates a		Manual	Loca
🗄 🊈 Storage	Remote Access Con	Creates a	Started	Manual	Loca
Disk Management	Remote Procedure	Provides th	Started	Automatic	Loca
	Remote Procedure	Manages t		Manual	Loca
- Dogical Drives	Remote Registry Se	Allows rem	Started	Automatic	Loca
🗈 😭 Removable Storage	Removable Storage	Manages r	Started	Automatic	Loca
Services and Applications House H	Routing and Remot	Offers rout		Disabled	Loca
😟 🖶 DHCP	RunAs Service	Enables st	Started	Automatic	Loca
WMI Control	Security Accounts	Stores sec	Started	Automatic	Loca
Services	Server .	Provides R	Started	Automatic	Loca
	SeStManager	FSC Server	Started	Automatic	Loca
	Smart Card	Manages a		Manual	Loca
	Smart Card Helper	Provides s		Manual	Loca
	I I				D

• Checking the DHCP Service

Perform the following check only when the PXE server performs the DHCP service.

- 1 On the PXE server, click [Start] \rightarrow [Programs] \rightarrow [Administrative Tools] \rightarrow [DHCP] to start up the DHCP administrative tool.
- **2** Click [Server Options] and check that the "060 ClassID" server option is added.

Action View 🖉 🗢 🗈 📧 😰 🚱 😰 🧬					
Tree	Server Options				
Ф ОНСР	Option Name	Vendor	Value	Class	
DHCP DHCP	😡 060 ClassID	Standard	PXEClient	None	
Int Scope [192.168.16.0] int					
Server Options					
	4			F	
	<u>, , , , , , , , , , , , , , , , , , , </u>				

Setting TFTP

TFTP is an FTP service function that requires no authentication. In remote installation, the TFTP service is used to distribute the boot image required for startup. For the TFTP path, set the appropriate access rights for the Guest account to obtain the image via network startup (PXE).

- 1 Click [Start] → [Programs] → [Accessories] → [Windows Explorer] and move to the TFTP path (the default is C:\Program Files\Fujitsu Siemens\DeploymentService\tftp).
- **2** Right-click the TFTP folder and click [Properties].
- **3** Click the [Security] tab, add the Guest account, and set the "Read and execute", "List Folder Contents", and "Read" access permissions.

tftp Properties		? ×
General Sharing Security		
Name		Add
Administrators (PXESERVER\Administrators) GREATOR OWNER	ato	<u>R</u> emove
Guest (PXESERVER\Guest)		
Power Users (PXESERVER\Power Use SYSTEM	ers 🗸	
A SYSTEM		
Permissions:	Allow	Deny
Full Control		
Modify		
Read & Execute	. ⊡)	
List Folder Contents		
Read		님
Write		
Ad <u>v</u> anced		
Allow inheritable permissions from parent object	to propag	jate to this
OK Ca	ancel	Apply

The preparation of the PXE server has been completed.

Then, perform "3.4.4 Preparation of Remote Resources" (\rightarrow pg.99).

3.4.4 Preparation of Remote Resources

Store resources to be installed on the remote resource server (PXE server) before starting installation.

MPORTANT

- For sharing resources, log on to the remote resource/PXE server with the Administrator account.
- **1** Prepare resources required for installation.
 - CD-ROM for the OS to be installed
 - Service Pack CD-ROM for the OS to be installed
 - · ServerStart floppy disk
 - PRIMERGY Document & Tool CD (for installing ServerView)
 - Array Controller Document & Tool CD (for RAID configuration)
 - Others


2 Create a shared folder for storing resources.

Create a shared folder for each CD prepared in Step 1. E.g.:E:\W2K3Sv for Windows Server 2003

3 Extract the resources.

Using Windows Explorer, copy the CD-ROM for the resource to the shared folder.

3.4.5 Starting Remote Installation Using a PXE Server



Perform remote installation using a PXE server in the following procedures.

■ Checking the Network Startup (PXE) Setting

Remote installation using a PXE server is performed via the onboard LAN. Enable the network startup (PXE) of the target server.

For more details on network startup, refer to "2.1.2 Hardware Settings" (→pg.43).

Checking the MAC Address of the Onboard LAN

In remote installation, target servers are identified according to the MAC address. MAC addresses are unique information to LAN cards. Check the MAC address on each target server. Write down the MAC address of the onboard LAN. For details on how to check the MAC address of an onboard LAN, refer to "2.1.2 Hardware Settings" (\rightarrow pg.43).

Creating a Configuration File

You can create a configuration file on a client computer before starting installation. For the procedure, refer to "3.2.1 Starting Up the Preparation Mode" (\rightarrow pg.75) and "3.2.2 Configuring Settings in Wizards" (\rightarrow pg.77).

When creating a configuration file on the PXE server, start installation.

POINT

• Specify the shared name prepared instead of the local CD-ROM as installation information.

Starting Installation

1 On the PXE server, start up ServerStart.

If ServerStart has already been started, you do not have to restart it. If it is not started, click $[Start] \rightarrow [Programs] \rightarrow [Fujitsu Siemens ServerStart] \rightarrow [ServerStart(start from HD)].$ The [Welcome to ServerStart] window appears.

2 Click [Click here to prepare an operating system installation for a PRIMERGY Server].


The [Select an Operating System] window appears.

3 Click [Microsoft Windows Server Operating System -Preparing and/or initiating a Remote Installation].

The [Microsoft Windows Operating System Installation] window appears.

4 Click the OS to install.

The [Preparing the Installation] window appears. If a configuration file has already been created, go to Step 6.



5 Set items in wizards to create a configuration file.
 Refer to "3.2.2 Configuring Settings in Wizards" (→pg.77). Set items in wizards and save the configuration file.
 Exiting a wizard returns to the preparation mode window.

6 Click [Click here to initiate the Remote Installation Process]. The [Remote Installation Target Server] window appears. **7** Configure remote installation.

emote Installation Target System	n te installation process ServerStart needs some data:
- Target system	
MAC address of target system:	11-11-11-11-11
(The MAC address can be optained via the target system with PXE option s	a FSC ServerView, or by reading the console output during the boot process of
PRIMERGY model type:	PRIMERGY TX200 S2
	<u>R</u> emote Control
Configuration File:	c:\serstartbatch.ini Browse
Access to ServerStart data:	
ServerStart contents tree (UNC):	\\PXESERVER\SeSt_ISO\iso
User name for remote access:	pxeserver\Administrator
Password:	×
-Remote Installation Linux	
Boot image directory	
Bootstrap Loader	Browse
Remote installation incl. SCU settin	gs and/or RAID configuration
	Start Installation Cancel
	<u></u>

- 1. Enter the "MAC address of target system".
- 2. Select the "PRIMERGY model type".
- 3. Specify the "Configuration File" containing the installation settings.

8 Click [Start Installation].

Installation starts. All disk contents on the target server are deleted.

The [ServerStart Boot Manager] window appears.

Check that the status is "Waiting for client".

ServerStart Boot Manager			_ 🗆 🗙
Boot Images: <all images=""></all>	Active clients:	Terminated clients:	Overview
Status of client 11-11-11-11-11-11:			System data
State: BootManager: Waiting	g for client		Repeat
Error message:		×	
Progress of installation:			- Show
<none></none>		<u> </u>	Progress
			C Logfile
			C System date

9 Turn on the target server.

It is started up via the network (PXE) and installation starts. When the resources have been copied, the "Preparation for automatic OS installation has

completed." message appears.

Subsequent installation is performed automatically.

When the installation is completed, an installation completion message appears on the target server.

For the RAID configuration, the system is restarted. When the message "Rebooting the System" appears and the system is restarted, set the Boot priority to give the highest priority to onboard LAN. For details about how to change the Boot priority, refer to "8.2.4 Boot Options Submenu" (→pg.218).

10 Press any key on the target server.

11 Restart the system on the target server.

The server setup and OS installation have been completed.

Refer to "Chapter 5 Operations after OS Installation" (→pg.135) and perform necessary procedures before starting server operations.

3.4.6 Starting Remote Installation Using a Remote **Resource Server**

In remote installation using a remote resource server, installation is performed using shared resources on the remote resource server.

Perform "3.4.4 Preparation of Remote Resources" (→pg.99) before starting installation.

Configuring a Remote Floppy

A remote floppy is a shared folder for storing and using a configuration file on the network, instead of loading it from the ServerStart floppy disk. When the server does not have a floppy disk drive and installation is performed in guided mode/expert mode, use a remote floppy.

15 IMPORTANT

- A remote floppy cannot be used when installing Windows Server 2003 x64.
- **1** Create a new folder in the shared folder on the remote resource server. E.g.: C:\export\ServerStart\Floppy
- 2 Create a "ServerStart Floppy Disk" tag file for the ServerStart floppy disk. Start up Command Prompt and enter the following command. C:\>copy nul C:\export\ServerStart\Floppy\"ServerStart Floppy Disk"

Checking Remote Resources

Check that the remote resource server is shared properly.

- Start up "Command Prompt" on the remote resource server. Enter the following and press the [Enter] key.
 - prompt:>net share Check that the created shared folder is displayed properly. For the net command, refer to Windows Help.

Starting Installation

Start installation from the target server.

In Guided Mode/Expert Mode

1 Turn on the server and insert the ServerStart Disc 1 CD-ROM immediately. ServerStart starts up and a message prompts you to insert the ServerStart floppy disk.

2 Create a ServerStart floppy disk.

When the ServerStart floppy disk supplied with the server is used

- Insert the ServerStart floppy disk supplied with the server. Make sure that "Removable media" and "A:" are selected and click [Create]. The network startup setting window for remote installation appears.
- 2. Click [OK].

The [Initialization of ServerStart core running] window appears and the ServerStart initialization process starts. Depending on the hardware configuration, this process may take a few minutes. When the process is completed, the [Create a ServerStart Floppy Disk] window appears.

3. Click [Build a ServerStart Floppy Disk].

Creation of a ServerStart floppy disk starts. When the creation is completed, the "Floppy disk has been created." message appears.

When the remote floppy is used

1. Select "Remote (media)" and click [OK].

The [Network Startup Setting] window for remote installation appears.

POINT

- If the SCSI option device is installed and a message prompts you to insert the ServerStart floppy disk, "Removable media" is selected. Be sure to select "Remote (media)".
- 2. Click [OK].

The [Specify Drive] window appears.

3. Enter [Remote path], [User name], and [Password] and click [OK]. The [Initialization of ServerStart core running] window appears and the ServerStart initialization process starts. Depending on the hardware configuration, this process may take a few minutes. When the process is completed, the [Welcome to ServerStart] window appears.

3 Click [Click here to prepare and/or initiate an operating system installation]. The [Select the operating system to be installed] window appears.

Click [Special Hints on Operating System Installation] and read the contents. Important information such as limitations on disk configuration is described.

4 Click [MS Windows Operating Systems]. The [Install Microsoft Windows Operating System Installation] window appears.

5 Select the OS to install and the mode.

6 Set items in wizards and save the configuration file.

For settings in wizards, refer to "3.1 Guided Mode" (\rightarrow pg.58) or "3.3 Expert Mode" (\rightarrow pg.81). Set items in wizards and save the configuration file. When using the remote floppy, specify the path to the shared folder for the remote floppy as the configuration file saving location.

POINT

 Specify the shared name of the prepared shared folder instead of the local CD-ROM as installation source information.

7 Click [Click here, to Start the Installation of (OS)].

Installation starts. At steps where the CD-ROM for resources such as the OS to be installed is necessary, the resource is automatically acquired from the resource server via the network.

8 Eject the CD-ROM and floppy disk and click [OK].

The system restarts. When the installation is completed, an installation completion message appears on the target server.


9 Press any key on the target server.

10 Restart the system on the target server.

The server setup and OS installation have been completed.

Refer to "Chapter 5 Operations after OS Installation" (\rightarrow pg.135) and perform necessary procedures before starting server operations.

• In Preparation Mode



For the creation procedure, refer to "3.2 Preparation Mode" (→pg.75).

POINT

 Specify the shared name of the prepared shared folder instead of the local CD-ROM as installation source information.

2 Turn on the server and insert the ServerStart Disc 1 CD-ROM immediately. ServerStart starts up and a message prompts you to insert the ServerStart floppy disk.

3 Set the created configuration file and click [OK].

The [Initialization of ServerStart core running] window appears and the ServerStart initialization process starts. Depending on the hardware configuration, this process may take a few minutes. When the process is completed, the [ServerStart Unattended Mode] window appears.

4 Click [Start].

Installation starts. At steps where the CD-ROM for resources such as the OS to be installed is necessary, the resource is automatically acquired from the resource server via the network.

5 Eject the CD-ROM and floppy disk and click [OK].

The system restarts. When the installation is completed, an installation completion message appears on the target server.

- 6 Press any key on the target server.
- **7** Restart the system on the target server.

The server setup and OS installation have been completed.

Refer to "Chapter 5 Operations after OS Installation" (\rightarrow pg.135) and perform necessary procedures before starting server operations.

3.5 Installation on Multiple (the Second and Subsequent) Servers

This chapter explains how to perform installation on multiple servers using ServerStart.

By editing the configuration file created for installation on the first server, you can use it for installation on other servers of the same model and configuration. This reduces the setup time. However, installation on the first server must be performed using ServerStart in guided or preparation mode.

MPORTANT

Check that ServerStart supplied with the first server is of the same version as that supplied with the other servers. If the version is different, this installation method will not work.

3.5.1 Preparation for Installation

Required Software

The following software is required for installation on the second and subsequent servers. Be sure to have these items close at hand.

- CD-ROM for the OS to be installed
- ServerStart CD-ROM
- · ServerStart floppy disk

A: ServerStart floppy disk containing the configuration file used for installation on the first server B: ServerStart floppy disks supplied with the ServerStart CD-ROMs for the second and subsequent servers

If ServerStart floppy disks are not supplied, prepare as many floppy disks as there are servers.

- PRIMERGY Document & Tool CD (for installing ServerView)
- Array Controller Document & Tool CD (for RAID configuration)
- Service Pack CD-ROM for the installed OS

Preparatory Procedure

Perform the following procedure before installation.

Using Explorer or Command Prompt, copy the ServerStart floppy disk (A) to the ServerStart floppy disk (B).

3.5.2 Installation in Guided Mode

Edit the configuration file and perform installation in guided mode.

1 Turn on the server and insert the ServerStart Disc 1 CD-ROM immediately after that.

ServerStart starts up and a message prompts you to insert the ServerStart floppy disk.

2 Insert the ServerStart floppy disk copied in the preparatory procedure into the floppy disk drive and click [Create].

The network setting window for remote installation appears.

3 Click [OK].

The [Initialization of ServerStart core running] window appears and the ServerStart initialization process starts. Depending on the hardware configuration, this process may take a few minutes. When the process is completed, the [Create a ServerStart Floppy Disk] window appears.

4 Click [or insert a Server Start Floppy Disk to Start Server Start]. The [Welcome to ServerStart] window appears.

- 5 Click [Click here to prepare and/or initiate an operation system installation]. The [Select the operating system to be installed] window appears.
- 6 Click [MS Windows Operating Systems]. The [Microsoft Windows Operating System Installation] window appears.
- 7 Click the OS to install.
- 8 Click [Prepare & initiate an unattended installation of (OS)]. The guided mode starts.
- **9** Click [Start here to create a complete configuration file]. The [Open ServerStart Configuration File] window appears.

Specify "SerStartBatch.ini" on drive A and click [Create].
 The display returns to the guided mode window.
 For procedures from setting wizards to completion of installation, refer to "3.1 Guided Mode" (→pg.58).
 When performing remote installation, refer to "3.4 Remote Installation" (→pg.88).

MPORTANT

Settings values in wizards

Setting items in wizards are set to the values set on the first server. For installation on subsequent servers, you must change the following items in the "OS installation wizard". For other items, change the settings as necessary. You do not need to start up wizards where no settings will be changed.

table: Settings to be Changed for Installation on Subsequent Servers
--

Window name	Setting item name	Remarks
User Information	Computer name	The setting must be changed when the second and subsequent servers are on the same network as the first server.
	Product ID/CD key	The setting must be changed.
Network Protocol	IP address	The setting must be changed when the second and subsequent servers are on the same network as the first server.

If the settings for the first server are not reflected to wizards, perform the procedure over again from copying the floppy disk.

3.5.3 Installation in Preparation Mode

Edit the configuration file and perform installation in preparation mode.

If ServerStart is not installed in the client computer where the preparation mode is executed, refer to "2.4 Preparation for Using ServerStart on a Client Computer" (\rightarrow pg.52) to install ServerStart. If a different version of ServerStart has been installed, uninstall it and install the proper version. For details on how to uninstall ServerStart, refer to "2.4.2 Uninstalling ServerStart" (\rightarrow pg.54).

MPORTANT

ServerStart starts up when it is installed. However, be sure to follow these installation procedures. Performing the procedure in "3.2.1 Starting Up the Preparation Mode" (→pg.75) deletes the contents of the ServerStart floppy disk, making the disk unavailable for installation on multiple servers.

1 Start up ServerStart.

If ServerStart has already been started, you do not have to restart it. If it is not started, perform the following startup procedures.

- 1. Insert the ServerStart Disc 1 CD-ROM into the client computer.
- Click [Start] → [Programs] → [Fujitsu Siemens ServerStart] → [ServerStart(Start from CD)].

ServerStart starts up and the [Welcome to ServerStart] window appears.

2 Select the OS to be installed.

The preparation mode starts up.

3 Insert the ServerStart floppy disk copied in the preparatory procedure into the floppy disk drive and click [Start here to configuration file].

The [Open ServerStart Configuration File] window appears.

4 Specify "SerStartBatch.ini" on drive A and click [Create].

The display returns to the preparation mode window.

For procedures from setting wizards to completion of installation, refer to "3.2 Preparation Mode" (\rightarrow pg.75).

When performing remote installation, refer to "3.4 Remote Installation" (→pg.88).

MPORTANT

Settings values in wizards

Setting items in wizards are set to the values set on the first server. For installation on subsequent servers, you must change the following items in the "OS installation wizard". For other items, change the settings as necessary. You do not need to start up wizards where no settings will be changed.

table. Cettings to be changed for installation on Cabbequent Cervers			
Window name	Setting item name	Remarks	
User Information	Computer name	The setting must be changed when the second and subsequent servers are on the same	
		network as the first server.	
	Product ID/CD key	The setting must be changed.	
Network Protocol	IP address	The setting must be changed when the second and subsequent servers are on the same network as the first server.	

table: Settings to be Changed for Installation on Subsequent Servers

If the settings for the first server are not reflected to wizards, perform the procedures from copying the floppy disk over again.

Chapter 4

Manual OS Installation

This chapter explains how to install the OS without using ServerStart.

4.1	Creating Driver Disks	112
4.2	Starting Manual Installation	117
4.3	Installing the LAN Driver	128

4.1 Creating Driver Disks

When installing the OS manually, it is necessary to create driver installation disks beforehand. Also, driver disks must be created when you add an expansion card during server operation.

4.1.1 Required Driver Disks

Prepare for the floppy disks in advance to create the driver disks. A floppy disk is necessary for each driver.

The driver disks to be created differ depending on the OS to be installed.

POINT

- Standard driver provided with the OS is installed automatically at the OS installation.
- You need a Server Start Disc 1 CD-ROM to install the driver provided with the Server Start CD-ROM. Prepare for it in advance.

■ For Windows Server 2003 x64

Expansion card / onboard controller	Driver
Chipset	Driver provided with the Server Start CD-ROM
Graphic controller	Driver provided with the Server Start CD-ROM
Onboard SAS controller	Integrated Mirroring SAS Driver Windows 2003 for x64 Edition Drivers Disk V1.21.13L10 ^{*1}
SAS array controller card (PG-140F)	MegaRAID SAS Driver Windows 2003 for x64 Edition Drivers Disk V1.18L10 ^{*1}
Onboard LAN	TX150 S5 Onboard LAN Driver Windows 2003 x64 Drivers Disk Ver9.25.0.0 *1
LAN card (PG-1892)	PG-185x/186x/188x/189x LAN Driver Windows 2003 for x64 Edition Drivers Disk Ver10.3 ^{*1}
LAN card (PG-2861)	PG-286x LAN Driver Windows 2003 for x64 Edition Drivers Disk Ver10.3 *1
SCSI card (PG-1281)	Standard driver provided with the OS
Other expansion cards	Driver supplied with the expansion card

table: Drivers Required for Installing Windows Server 2003 x64

*1: Created by the ServerStart FloppyBuilder function

■ For Windows Server 2003 / SBS 2003

Expansion card / onboard controller	Driver
Chipset	Driver provided with the Server Start CD-ROM
Graphic controller	Standard driver provided with the OS
Onboard SAS controller	Integrated Mirroring SAS Driver Windows 2000/2003 Drivers Disk V1.21.13L10 ^{*1}
SAS array controller card (PG-140F)	MegaRAID SAS Driver Windows 2000/2003 Drivers Disk V1.20L10 ^{*1}
Onboard LAN	TX150 S5 Onboard LAN Driver Windows 2003 Drivers Disk Ver9.25.0.0 *1
LAN card (PG-1892)	PG-185x/186x/188x/189x LAN Driver Windows 2000/2003 Drivers Disk Ver10.3 *1
LAN card (PG-2861)	PG-286x LAN Driver Windows 2000/2003 Drivers Disk Ver10.3 ^{*1}
SCSI card (PG-1281)	Standard driver provided with the OS
Other expansion cards	Driver supplied with the expansion card

table: Drivers Required for Installing Windows Server 2003 / SBS 2003

*1: Created by the ServerStart FloppyBuilder function

■ For Windows 2000 Server

table: Drivers Required for Installing Windows 2000 Server

Expansion card / onboard controller	Driver
Chipset	Driver provided with the Server Start CD-ROM
Graphic controller	Driver provided with the Server Start CD-ROM
Onboard SAS controller	Integrated Mirroring SAS Driver Windows 2000/2003 Drivers Disk V1.21.13L10 ^{*1}
SAS array controller (PG-140F)	MegaRAID SAS Driver Windows 2000/2003 Drivers Disk V1.20L10 *1
Onboard LAN	TX150 S5 Onboard LAN Driver Windows 200 Drivers Disk Ver9.25.0.0 *1
LAN card (PG-1892)	PG-185x/186x/188x/189x LAN Driver Windows 2000/2003 Drivers Disk Ver10.3 *1
LAN card (PG-2861)	PG-286x LAN Driver Windows 2000/2003 Drivers Disk Ver10.3 ^{*1}
SCSI card (PG-1281)	Standard driver provided with the OS
Other expansion cards	Driver supplied with the expansion card

*1: Created by the ServerStart FloppyBuilder function

4.1.2 How to Create Driver Disks [FloppyBuilder function]

Driver disks are created from the ServerStart CD-ROM using the ServerStart FloppyBuilder function. The FloppyBuilder function is available in the following environments.

- Starting up the ServerStart system on a client computer (Recommended)
- Starting up the system from the ServerStart CD-ROM on the server

POINT

When creating driver disks on a client computer, it is necessary to install ServerStart on the client computer beforehand. Install it according to "2.4 Preparation for Using ServerStart on a Client Computer" (→pg.52).

If a different version of ServerStart has been installed, uninstall it and install the proper version. For details on how to uninstall ServerStart, refer to "2.4.2 Uninstalling ServerStart" (\rightarrow pg.54).

Starting ServerStart

If ServerStart has already been started, you do not have to restart it. If it is not started, perform the following startup procedures.

• For Creation on a Client Computer

- Insert the ServerStart Disc 1 CD-ROM into the client computer.
- 2 Click [Start] → [Programs] → [Fujitsu Siemens ServerStart] → [ServerStart(start from CD)].

ServerStart starts up and the [Welcome to ServerStart] window appears.



For Creation on the Server


- **1** Turn on the server and insert the ServerStart Disc 1 CD-ROM immediately. ServerStart starts up and a message prompts you to insert the ServerStart floppy disk.
- 2 Insert the attached [ServerStart floppy disk] into the server's floppy disk drive. Then make sure "Removable media" and "A:" are selected and click [Create]. A network setup window for remote installation appears.

 If a configuration file already exists in the ServerStart floppy disk and [OK] is clicked without clicking [Create], the [ServerStart Unattended Mode] window appears. Make sure to click [Exit]. The [Welcome to ServerStart] window appears.

If [Start] is clicked in the [ServerStart Unattended Mode] window, the installation of the server will start and all disk contents will be deleted.

3 Click [OK].

The [Initializing ServerStart] window appears and the ServerStart initialization process starts. Depending on the hardware configuration, this process may take a few minutes. When the process is completed, the [Create a ServerStart Floppy Disk] window appears.



4 Click [or Insert a ServerStart Floppy Disk to Start ServerStart]. The [Welcome to ServerStart] window appears.




5 Eject the ServerStart floppy disk.

Creating Driver Disks

Start up ServerStart and confirm that the [Welcome to ServerStart] window is displayed.

1 Click [FloppyBuilder].

The [ServerStart FloppyBuilder] window appears.



2 Select the Drivers Diskettes for Windows Server 2003 / Windows 2000 Server or Windows Server 2003 x64.

The [FloppyBuilder Driver Disk] window appears.

- **3** Click the type of the driver you want to create.
- **4** Click the driver disk you want to create. Follow the message and insert a floppy disk.
- 5 Perform the procedures following the messages on the window.The floppy disk will be formatted automatically and file copying will start.The driver disk is automatically created. When a message appears indicating that creating the disk is completed, click [OK] and eject the floppy disk.

4.2 Starting Manual Installation

This section explains the procedures for installing the OS manually.

POINT

 The Microsoft package products shipped after July 2003 and the volume-licensed Windows 2000 Server CD-ROM are already applied to Service Pack 4. However, the volume license also provides Windows 2000 Server CD-ROM not applied to Service Pack 4.
 You can confirm whether Service Pack 4 or later is applied by checking the label of your Windows 2000 Server CD-ROM.

4.2.1 Installing Windows Server 2003 x64

POINT

 For details on the OS settings, refer to the following URL. http://www.microsoft.com/technet/prodtechnol/exchange/2003/Library/default.mspx

1 Create driver disks.

Prepare necessary drivers before installing Windows Server 2003 x64. Some drivers are created from the ServerStart CD-ROM. For how to create driver disks, refer to "4.1 Creating Driver Disks" (→pg.112).

2 Turned on the server and configure RAID. If RAID is not required to be configured, proceed to step 3.

Turn off the server after configuring the array system.

To configure the array system with onboard SAS array controller

Turn on the server to display the following message and press the [Ctrl] + [C] key to start up the BIOS Utility.

Press Ctrl C to start LSI Logic Configuration Utility

Configure the array system using the BIOS Utility. For more details, refer to "Integrated Mirroring SAS User's Guide" in the Array Controller Document & Tool CD.

To configure the array system with the array controller card (PG-140F)

Turn on the server to display the following message and press the [Ctrl] + [H] key to start up the WebBIOS.

Press <Ctrl><H> for WebBIOS

Configure the array system using WebBIOS. For more details, refer to "MegaRAID SAS User's Guide" in the Array Controller Document & Tool CD.

3 Prepare the Windows Server 2003 x64 CD-ROM.

Turn on the server and insert the Windows Server 2003 x64 CD-ROM immediately into the CD-ROM drive. Confirm that the floppy drive is empty. When the active area is specified on the hard disk, the following message appears.

Press any key to boot from CD....

Pressing any key while this message is displayed boots the system from the CD-ROM.

4 The [Windows Server 2003 x64 Setup] window appears. Immediately, the following message appears at the bottom of the window. Press the [F6] key.

Press F6 if you need to install a third party SCSI or RAID

MPORTANT

driver ...

This message will be displayed for a short time after the setup window (blue screen) appears. Þ Press the [F6] key immediately after the window turns blue.



- Install the Drivers for the array controller manually.
 - 1. When the following message appears, press the [S] key.

```
To specify additional SCSI adapters, CD-ROM drives, or
special disk controllers for use with Windows, including
those for which you have a devicesupport disk from a mass
storage device manufacturer, press S.
```

2. When the "Please insert the disk labeled Manufacturer-supplied hardware support disk into Drive A:" message appears, insert the driver disk created from the driver's CD and press the [Enter] key.

The following message appears.

```
You have chosen to configure a SCSI Adapter for use with
Windows, using a device support disk provided by an
adapter manufacturer.
Select the SCSI Adapter you want from the following list,
or press ESC to return to the
previous screen.
```

3. Select either of the followings according to your controller and press the [Enter] key.

· For onboard SAS array controller

LSI Logic Fusion-MPT SAS Driver (Server 2003 x64)

For SAS array controller card (PG-140F)

```
LSI Logic MegaRAID SAS RAID Controller Driver (Server
2003 for x64)
```

4. When the following message appears, press the [S] key.

```
The driver you provided seems to be newer than the Windows default driver. Windows already has a driver that you can use for "MEGARAID SCSI 320-0X RAID Controller Driver" Unless the device on the floppy disk, you should use the driver in Windows.
```

5. Follow the instructions in the window to perform installation The message which prompts you to set the floppy disk appears during the installation, set the driver disk and push the [Enter] key.

6 Follow the instructions from the setup program to continue the installation procedure.

If a message indicating that the driver has not passed Windows Logo testing to verify its compatibility with Windows appears, select [Yes] to continue the installation procedure.

7 Install the LAN driver.

Install the LAN driver using the driver disk created from the ServerStart CD-ROM. For more details, refer to "4.3 Installing the LAN Driver" (→pg.128).

8 Install the ChipSet driver.

- 1. Insert the ServerStart Disc 1 CD-ROM into the drive of the server. When the ServerStart window appears, exit ServerStart.
- Execute the following command on the CD-ROM. [CD-ROM drive] :\DRIVERS\ChipSet\Intel\Intel3000\infinst_autol.exe The installation wizard starts up.
- 3. Click [Next]. Follow the instructions in the window to perform installation.
- When the "InstallShieled(R) wizard has completed" message appears, eject the ServerStart CD-ROM from the CD-ROM drive and click [Finish] to restart the system.

9 Install the Display driver.

- 1. Insert the ServerStart Disc 1 CD-ROM into the drive of the server. When the ServerStart window appears, exit ServerStart.
- Execute the following command on the CD-ROM. [CD-ROM drive] :\DRIVERS\VIDEO\MATROX\w2k3x64\setup.bat The installation wizard starts up.
- 3. Click [Next]. Follow the instructions in the window to perform installation.
- 4. When the installation is completed, eject the ServerStart CD-ROM from the CD-ROM drive and click [Finish] to restart the system.

10 Installing high reliability tools.

To ensure stable server operation, refer to "Chapter 6 High Reliability Tools" (\rightarrow pg.171) and install high reliability tools. Please install the RAID Management Tool when you configure RAID.

The installation of Windows Server 2003 x64 has completed.

Before Starting Operation

After OS installation, refer to "Chapter 5 Operations after OS Installation" (→pg.135) and perform the necessary procedures.

4.2.2 Installing Windows Server 2003 / SBS 2003

POINT

 For details on the OS settings, refer to the following URL. http://www.microsoft.com/technet/prodtechnol/exchange/2003/Library/default.mspx

MPORTANT

To install SBS 2003

In the installation of SBS 2003, install the operating system and the server tools / the application in this order. It is necessary to connect the local network adaptor of the server that SBS 2003 is installed with hub. Confirm it before the installation begins.

1 Create driver disks.

Prepare necessary drivers before installing Windows Server 2003. Some drivers are created from the ServerStart CD-ROM. For how to create driver disks, refer to "4.1 Creating Driver Disks" (→pg.112).

2 Turned on the server and configure RAID. If RAID is not required to be configured, proceed to step 3.

Turn off the server after configuring the array system.

To configure the array system with onboard SAS array controller

Turn on the server to display the following message and press the [Ctrl] + [C] key to start up the BIOS Utility.

Press Ctrl C to start LSI Logic Configuration Utility

Configure the array system using the BIOS Utility. For more details, refer to "Integrated Mirroring SAS User's Guide" in the Array Controller Document & Tool CD.

To configure the array system with the array controller card (PG-140F)

Turn on the server to display the following message and press the [Ctrl] + [H] key to start up the WebBIOS.

Press <Ctrl><H> for WebBIOS

Configure the array system using WebBIOS. For more details, refer to "MegaRAID SAS User's Guide" in the Array Controller Document & Tool CD.

3 Prepare the Windows Server 2003 CD-ROM.

Turn on the server and insert the Windows Server 2003 CD-ROM or CD-ROM Disk1 for SBS 2003 immediately into the CD-ROM drive. Confirm that the floppy drive is empty. When the active area is specified on the hard disk, the following message appears.

```
Press any key to boot from CD....
```

Pressing any key while this message is displayed boots the system from the CD-ROM.

4 The Windows Server 2003 setup window appears.

Immediately, the following message appears at the bottom of the window. Press the [F6] key.

```
Press F6 if you need to install a third party SCSI or RAID driver ...
```

MPORTANT.

- This message will be displayed for a short time after the setup window (blue screen) appears. Press the [F6] key immediately after the window turns blue.
- 5 Install the Drivers for the array controller manually.
 - 1. When the following message appears, press the [S] key.

```
To specify additional SCSI adapters, CD-ROM drives, or
special disk controllers for use with Windows, including
those for which you have a devicesupport disk from a mass
storage device manufacturer, press S.
```

 When the "Please insert the disk labeled Manufacturer-supplied hardware support disk into Drive A:" message appears, insert the driver disk created and press the [Enter] key.

The following message appears.

```
You have chosen to configure a SCSI Adapter for use with
Windows, using a device support disk provided by an
adapter manufacturer.
Select the SCSI Adapter you want from the following list,
or press ESC to return to the
previous screen.
```

- Select either of the followings according to your controller and press the [Enter] key.
 - · For onboard SAS array controller

LSI Logic Fusion-MPT SAS Driver (Server 2003 32-bit)

• For SAS array controller card (PG-140F)

```
LSI Logic MegaRAID SAS RAID Controller Driver (Server 2003 32-bit)
```

4. When the following message appears, press the [S] key.

```
The driver you provided seems to be newer than the Windows default driver. Windows already has a driver that you can use for "LSI MEGARAID Products for Windows 2003(x86)"(or "LSI Logic PCI SCSI/FC MPI Miniport Driver(Server 2003 32bit)) Unless the device on the floppy disk, you should use the driver in Windows.
```

5. Follow the instructions in the window to perform installation

The message which prompts you to set the floppy disk appears during the installation, set the driver disk and push the [Enter] key.

6 Follow the instructions from the setup program to continue the installation procedure.

If a message indicating that the driver has not passed Windows Logo testing to verify its compatibility with Windows appears, select [Yes] to continue the installation procedure. For SBS 2003

The server is restarted after installing the operating system.

 After restarting the server, log on to the server with the Administrator account. The installation of server tools and the application is started, and the following window appears.



2. Click [Cancel] to cancel the installation.

7 Install the LAN driver.

Install the LAN driver using the driver disk created from the ServerStart CD-ROM. For more details, refer to "4.3 Installing the LAN Driver" (→pg.128).

- 8 Install the ChipSet driver.
 - Insert the ServerStart Disc 1 CD-ROM into the drive of the server. When the ServerStart window appears, exit ServerStart.
 - Execute the following command on the CD-ROM. [CD-ROM drive] :\DRIVERS\ChipSet\Intel\Intel3000\infinst_autol.exe The installation wizard starts up.

- 3. Click [Next]. Follow the instructions in the window to perform installation.
- When the "InstallShieled(R) wizard has completed" message appears, eject the ServerStart CD-ROM from the CD-ROM drive and click [Finish] to restart the system.
- **9** Install the Display driver.
 - 1. Insert the ServerStart Disc 1 CD-ROM into the drive of the server. When the ServerStart window appears, exit ServerStart.
 - Execute the following command on the CD-ROM. [CD-ROM drive] :\DRIVERS\VIDEO\MATROX\w2k_w2k3\setup.bat The installation wizard starts up.
 - 3. Click [Next]. Follow the instructions in the window to perform installation.
 - 4. When the installation is completed, eject the ServerStart CD-ROM from the CD-ROM drive and click [Finish] to restart the system.
- **10** For SBS 2003, double-click the [Continue Setup] icon on the desktop.

When the "Microsoft Windows Small Business Server Setup" window appears, click [Next] and follow the instructions in the window to perform installation.

MPORTANT

 "Component Message" appears when there are errors or messages that relate to the installed component. Perform installation again after check and solve problems.

11 Apply Windows Server 2003 Service Pack.

For details, refer to the description in the window.

12 Installing high reliability tools.

To ensure stable server operation, refer to "Chapter 6 High Reliability Tools" (\rightarrow pg.171) and install high reliability tools. Please install the RAID Management Tool when you configure RAID.

Before Starting Operation

After OS installation, refer to "Chapter 5 Operations after OS Installation" (\rightarrow pg.135) and perform the necessary procedures.

4.2.3 Installing Windows 2000 Server

1 Create driver disks.

Prepare necessary drivers before installing Windows 2000 Server. Some drivers used with Windows 2000 Server are created from the ServerStart CD-ROM. For how to create driver disks, refer to "4.1 Creating Driver Disks" (→pg.112).

2 Turned on the server and configure RAID. If RAID is not required to be configured, proceed to step 3.

Turn off the server after configuring the array system.

4

To configure the array system with onboard SAS array controller

Turn on the server to display the following message and press the [Ctrl] + [C] key to start up the BIOS Utility.

Press Ctrl C to start LSI Logic Configuration Utility

Configure the array system using the BIOS Utility. For more details, refer to "Integrated Mirroring SAS User's Guide" in the Array Controller Document & Tool CD.

To configure the array system with the array controller card (PG-140F)

Turn on the server to display the following message and press the [Ctrl] + [H] key to start up the WebBIOS.

```
Press <Ctrl><H> for WebBIOS
```

Configure the array system using WebBIOS. For more details, refer to "MegaRAID SAS User's Guide" in the Array Controller Document & Tool CD.

3 Prepare the Windows 2000 Server CD-ROM.

Turn on the server and insert the Windows 2000 Server CD-ROM immediately into the CD-ROM drive. Check there are no floppy disks in the floppy disk drive. When the active area is specified on the hard disk, the following message appears.

Press any key to boot from CD....

Pressing any key while this message is displayed boots the system from the CD-ROM.

4 The [Windows 2000 Server Setup] window appears.

Immediately, the following message appears at the bottom of the window. Press the [F6] key.

```
Press F6 if you need to install a third party SCSI or RAID
driver ...
```

MEDIMPORTANT

This message will be displayed for a short time after the setup window (blue screen) appears. Press the [F6] key immediately after the window turns blue.

5 Install the Drivers for the array controller manually.

1. When the following message appears, press the [S] key.

```
To specify additional SCSI adapters, CD-ROM drives, or
special disk controllers for use with Windows 2000,
including those for which you have a device support disk
from a mass storage device manufacturer, press S.
```

 When the "Please insert the disk labeled Manufacturer-supplied hardware support disk into Drive A:" message appears, insert the driver disk created and press the [Enter] key.

The following message appears.

```
You have chosen to configure a SCSI Adapter for use with
Windows 2000, using a device support disk provided by an
adapter manufacturer.
Select the SCSI Adapter you want from the following list,
or press ESC to return to the
previous screen.
```

- Select either of the followings according to your controller and press the [Enter] key.
 - · For onboard SAS array controller

LSI Logic Fusion-MPT Driver for SAS1068 (Windows 2000)

• For SAS array controller card (PG-140F)

```
LSI Logic MegaRAID SAS RAID Controller Driver (Windows 2000)
```

4. When the following message appears, press the [S] key.

```
The driver you provided seems to be newer than the Windows default driver. Windows already has a driver that you can use for "LSI MEGARAID Products for Windows 2000" (or "LSI Logic PCI SCSI/FC MPI Miniport Driver) Unless the device on the floppy disk, you should use the driver in Windows.
```

- 5. Follow the instructions in the window to perform installation The message which prompts you to set the floppy disk appears during the installation, set the driver disk and push the [Enter] key.
- 6 Follow the instructions from the setup program to continue the installation procedures.

19 IMPORTANT

Cautions on Restarting

In the course of installation, a message appears to indicate that the setup program restarts. Wait until it restarts automatically.

7 Install the LAN driver.

Install the LAN driver using the driver disk created from the ServerStart CD-ROM. For more details, refer to "4.3 Installing the LAN Driver" (\rightarrow pg.128).

- 8 Install the ChipSet driver.
 - 1. Insert the ServerStart Disc 1 CD-ROM into the drive of the server. When the ServerStart window appears, exit ServerStart.
 - Execute the following command on the CD-ROM. [CD-ROM drive] :\DRIVERS\ChipSet\Intel\Intel3000\infinst_autol.exe The installation wizard starts up.

Manual OS Installation

- 3. Click [Next]. Follow the instructions in the window to perform installation.
- When the "InstallShieled(R) wizard has completed" message appears, eject the ServerStart CD-ROM from the CD-ROM drive and click [Finish] to restart the system.
- **9** Install the Display driver.
 - 1. Insert the ServerStart Disc 1 CD-ROM into the drive of the server. When the ServerStart window appears, exit ServerStart.
 - Execute the following command on the CD-ROM. [CD-ROM drive] :\DRIVERS\VIDEO\MATROX\w2k_w2k3\setup.bat The installation wizard starts up.
 - 3. Click [Next]. Follow the instructions in the window to perform installation.
 - 4. When the installation is completed, eject the ServerStart CD-ROM from the CD-ROM drive and click [Finish] to restart the system.
- **10** Install the USB 2.0 driver.
 - 1. Insert the ServerStart Disc 1 CD-ROM into the drive of the server. When the ServerStart window appears, exit ServerStart.
 - 2. Right-click the [My Computer] icon on the desktop and click [Manage] from the displayed menu.
 - 3. Click [Device Manager] from the displayed list.
 - Double-click [USB 2.0 Root Hub] under [Universal Serial Bus (USB) controller]. The properties window appears.
 - 5. Click the [Driver] tab and click [Update Driver]. The "Device Driver Upgrade Wizard" window appears.
 - 6. Click [Next].
 - 7. Select [Find an optimum driver (Recommended)] and click [Next].
 - 8. Select only [CD-ROM drive] in [Search location options] and click [Next].
 - 9. Select [Install another driver] and click [Next].
 - Select [USB 2.0 Root Hub] and click [Next]. Installation starts. When it is completed, a completion message appears.
 - 11. Click [Finish].
 - 12. Click [Close] to close the properties window.

11 Installing high reliability tools.

To ensure stable server operation, refer to "Chapter 6 High Reliability Tools" (\rightarrow pg.171) and install high reliability tools. Please install the RAID Management Tool when you configure RAID.

The installation of Windows 2000 Server has completed.

Before Starting Operation

After OS installation, refer to "Chapter 5 Operations after OS Installation" (→pg.135) and perform the necessary procedures.

4.2.4 Installing Linux

For the use of Linux, refer to the Fujitsu PRIMERGY website (http://primergy.fujitsu.com).

4.3 Installing the LAN Driver

This section explains the procedure for installing the driver. In addition to the case where the OS is installed manually, the driver must be installed when a LAN card is added.


Checking the LAN device after OS installation

For Windows Server 2003 x64, Windows Server 2003, and SBS 2003, the LAN driver installation procedure differs depending on whether the network adapter was recognized during the OS installation. Check whether or not a recognized network adapter is present by the following procedures in advance.

1 Click [Start] \rightarrow [Administrative Tools] \rightarrow [Computer Management].

2 Click [Device Manager].

On the Device Manager list, check if a recognized network adapter is present. (Window example)



When a recognized network adapter is present, [Network adapters] appears.

When a recognized network adapter is present


Perform "■ Updating LAN Drivers" (→pg.131) on the LAN device name under [Network adapters], then "■ Installing the LAN Driver" (→pg.131) on [Ethernet controller] under [Other devices].

When a recognized network adapter is not present

Perform "■ Installing the LAN Driver" (→pg.131) on [Ethernet controller] under [Other devices].

When the LAN driver is installed to [Other devices] before updating the driver for the network adapter recognized immediately after the OS installation

• When driver installation starts, the following window appears.



Clicking [Finish] displays the [Help and Support Center] window. Click [X] to close the window. After installation, the "!" mark is displayed at the LAN device name in Device Manager. Device names are displayed properly when all LAN drivers are installed and the system is restarted.

4.3.1 Installing the LAN Driver (Windows Server 2003 x64)

LAN cards except PG-2861 are recognized as the network adapters when the OS is installed. Perform "■ Updating the LAN Cards" (→pg.129) on all LAN device names under [Network adapters], and then perform "■ Installing the LAN Driver" (→pg.130) on the Ethernet controllers under [Other devices].

POINT

- For the following LAN cards, the network adapters are recognized when the cards are mounted during OS installation.
 - PG-1892

Updating the LAN Cards

Perform the following procedures on all LAN device names under [Network adapters] in [Device Manager].

- **1** Click [Start] \rightarrow [Administrative Tools] \rightarrow [Computer Manager].
- 2 Click [Device Manager].
- 3 Double-click a LAN device name under [Network adapters].

Names of the LAN devices are displayed as follows.


table: LAN device name

LAN cards	LAN device name
Onboard LAN (1000BASE-T)	Broadcom NetXtreme Gigabit Ethernet
PG-1892	Intel(R) PRO/1000 MT Server Adapter

4 Insert the driver disk created from the ServerStart CD-ROM into the server.

5 Click [Update Driver] in the [Driver] tab window.The "Welcome to the Hardware Update Wizard" window appears.

- 6 Check [No, not this time] and click [Next].
- 7 Select [Install the software automatically (Recommended)] and click [Next]. The driver will be installed.
- 8 Click [Finish].
- 9 Click [Close] to close the properties window.



Perform the following procedures on each [Ethernet controller] under [Other devices] in [Device Manager].

- **1** Insert the driver disk created from the ServerStart CD-ROM into the server.
- 2 Double-click [Ethernet controller] under [Other devices]. The properties window for the Ethernet controller appears.
- Click [Reinstall Driver] in the [General] tab window.The [Welcome to the Hardware Update Wizard] window appears.
- **4** Check [No, not this time] and click [Next].
- **5** Select [Install the software automatically (Recommended)] and click [Next]. The driver will be installed.
- 6 Click [Finish].
- 7 Click [Close] to close the properties window.
- 8 Remove the driver disk and restart the system.

• After LAN driver installation, names of the LAN devices are displayed as follows.

table: LAN device name		
LAN cards	LAN device name	
Onboard LAN (1000BASE-T)	Broadcom NetXtreme Gigabit Ethernet	
PG-1892	Intel(R) PRO/1000 MT Server Adapter	
PG-2861	Intel(R) PRO1000 PT Dual Port Server Adapter	

4.3.2 Installing the LAN Driver (Windows Server 2003 / SBS 2003)

The LAN driver installation procedure differs depending on whether the network adapter was recognized during the OS installation.

Updating LAN Drivers

Perform the following procedures on all LAN device names under [Network adapters] in [Device Manager].


- 1 Double-click a LAN device name under [Network adapters].
- **2** Insert the driver disk created from the ServerStart CD-ROM into the server.
- **3** Click [Update Driver] in the [Driver] tab window. The "Welcome to the Hardware Update Wizard" window appears.
- **4** Select [Install the software automatically (Recommended)] and click [Next]. The driver will be installed.
- 5 Click [Finish].
- 6 Click [Close].

Installing the LAN Driver

Perform the following procedures on each [Ethernet controller] under [Other devices] in [Device Manager].

- Insert the driver disk created from the ServerStart CD-ROM into the server.
 For the onboard LAN, insert the ServerStart CD-ROM.
- **2** Double-click [Ethernet controller] under [Other devices]. The properties window for the Ethernet controller appears.

3 Click [Reinstall Driver] in the [General] tab window. The [Welcome to the Hardware Update Wizard] window appears.



- 5 Click [Finish].
- 6 Click [Close] to close the properties window.
- 7 Remove the driver disk and restart the system.

POINT

• After LAN driver installation, names of the LAN devices are displayed as follows.

table: LAN device name		
LAN cards	LAN device name	
Onboard LAN (1000BASE-T)	Broadcom NetXtreme Gigabit Ethernet	
PG-1892	Intel(R) PRO/1000 MT Server Adapter	
PG-2861	Intel(R) PRO1000 PT Dual Port Server Adapter	

4.3.3 Installing the LAN Driver (Windows 2000 Server)

- **1** Insert the driver disk created from the ServerStart CD-ROM into the server.
- **2** Right-click the [My Computer] icon on the desktop and select [Manage] from the displayed menu.
- Glick [Device Manager]. As many [Ethernet controller] items as the installed LAN ports are displayed under [Other devices]. Double-click each [Ethernet controller] item and perform the following Steps 4 to 11 on all LAN ports.
 Double-click [Ethernet controller] under [Other devices]. The properties window for the Ethernet controller appears.
 Click [Reinstall Driver] in the [General] tab window. The [Device Driver Upgrade Wizard] window appears.
 Click [Next].
 - 7 Select [Search for a suitable driver for my device (Recommended)] and click [Next].

The [Identify Driver File] window appears.

8 Select [Floppy disk drive] in [Search location options] and click [Next]. Detected drivers are displayed.

9 Click [Next].

Driver installation starts. When it is completed, a completion window appears.

- **10** Click [Finish].
- **11** Click [Close] to close the properties window.

POINT

- When [Ethernet controller] items are displayed under [Other devices], perform the above Steps 4 to 11 on all [Ethernet controller] items.
- 12 Remove the driver disk and restart the system.

MPORTANT.

- When a LAN card is added, the following window may appear at system startup after addition of a LAN card. Perform the appropriate procedure according to the displayed window.
 - •When the "New Hardware Detection Wizard" window appears Insert the driver disk created from the ServerStart CD-ROM and perform Step 6 and subsequent steps in "Updating LAN Drivers"
 - •When the [Insert Disk] window prompts you to insert the "Intel PRO Adapter CD-ROM or floppy disk" or "Intel[®] PRO/1000 Disk Driver"
 - Insert the driver disk created from the ServerStart CD-ROM and install the driver.

POINT

After LAN driver installation, names of the LAN devices are displayed as follows.

table: LAN device name		
LAN cards	LAN device name	
Onboard LAN (1000BASE-T)	Broadcom NetXtreme Gigabit Ethernet	
PG-1892	Intel(R) PRO/1000 MT Server Adapter	
PG-2861	Intel(R) PRO1000 PT Dual Port Server Adapter	

4.3.4 Latest Drivers

For the latest drivers, refer to the Fujitsu PRIMERGY website (http://primergy.fujitsu.com).

Chapter 4 Manual OS Installation

Chapter 5

Operations after OS Installation

This chapter explains the operations to be performed after OS installation. Be sure to perform these operations before operating the server.

5.1	Memory Dump/Paging File Setting	136
5.2	Creating a Disk for System Recovery	146
5.3	Storing the System Configuration Information	148
5.4	Creating Maintenance Tools	152
5.5	Notes before Operating the Server	157
5.6	LAN Driver Advanced Setup [BACS]	161
5.7	LAN Driver Advanced Setup [Intel® PROSet]	166

5.1 Memory Dump/Paging File Setting

Before starting operating this server, configure the setting for obtaining memory dump.

Memory Dump

If memory dump is set, debugging information will be automatically saved when a STOP error (fatal system error) occurs in the system. Using the saved memory dump, error cause can be analyzed. If the amount of installed memory is large, pay special attention when setting the memory dump file. The settings for obtaining memory dump should be configured after installing the files to be used for operations (OS, applications, etc.).

5.1.1 How to Obtain Memory Dump for Windows Server 2003 and Windows Server 2003 x64

Check the following settings before starting configuration to obtain memory dump.

Checking Hard Disk Free Space

To obtain memory dump, sufficient hard disk capacity is required for creating paging files and memory dump files.

The obtainable dump types and required hard disk capacity are as follows:

• Complete Memory (Full) Dump (recommended)

When the system unexpectedly stops, contents of the whole system memory are recorded. The file is stored in the directory displayed in the [Dump file] box.

- Paging file: Installed physical memory + 11MB (Recommended: Installed physical memory x 1.5)
- · Memory dump file: Same amount as installed physical memory

MPORTANT

 Complete memory dump cannot be used on the computer in which the 2GB or more memory is installed.

• Kernel Memory Dump

Information of only kernel memory space is recorded. The file is stored in the directory displayed in the [Dump file] box. Capacity required for kernel memory dump is as follows:

- Paging file: Depending on installed physical memory amount For memory of 256 to 1,373MB - Installed physical memory x 1.5 For memory of 1,374MB or more - 32-bit system: 2GB + 16MB, 64-bit system: Installed physical memory + 128MB
- · Memory dump file: Depending on the used amount of kernel-mode address space during STOP

Small Memory Dump

Minimum amount of useful information for problem identification is recorded. If this option is specified, a new file is created each time the system unexpectedly stops.

History of such files is stored in the directory displayed in [Small dump directory].

- Paging file: 2MB or more
- Memory dump file: 64KB or 128KB

Memory Dump File Setting

Set up the memory dump file according to the following procedures:

- **1** Log on to the server with administrator privileges.
- Check free space of the drive where the memory dump file is to be stored.
 Check the required amount of free space according to "■ Checking Hard Disk Free Space" (→pg.136).

If the drive has no free space, refer to "■ Cannot Collect the Memory Dump" (→pg.248).

Click [Start] → [Control Panel] → [System].
 The [System Properties] window appears.

4 Click the [Advanced] tab and click [Settings] in [Startup and Recovery]. The [Startup and Recovery] window appears.

Startup and Recovery
System startup
Default operating system:
"Windows Server 2003, Standard" /fastdetect
Time to display list of operating systems: 30 😴 seconds
Time to display recovery options when needed: 30 🚊 seconds
To edit the startup options file manually, click Edit.
System failure
✓ Write an event to the system log
Send an administrative alert
✓ Automatically restart
Write debugging information
Complete memory dump
Dump file:
%SystemRoot%\MEMORY.DMP
☑ Overwrite any existing file
OK Cancel

5 Set as follows:

- 1. In the [Write debugging information] section, select the memory dump file type.
 - Complete memory dump (Recommended) The whole system memory information is recorded to the memory dump file.
 - Kernel memory dump Only kernel memory is recorded to the memory dump file.
 - Small memory dump (64KB) Minimum information is recorded to the memory dump file.
 Each time a fatal error occurs, a new file is created in the directory specified in [Small dump directory].
- In [Dump file] or [Small dump directory], specify the directory to save the memory dump file, with its full path.

In case of kernel memory dump or complete memory dump, if [Overwrite any existing file] is checked, debugging information is overwritten to the specified file every time.

- **6** Click [OK] to close the [Startup and Recovery] window.
- **7** Click [OK] to close the [System Properties] window.
- 8 Restart the system.

The setting is enabled after the system is restarted.



Set up the paging file according to the following procedures:

- **1** Log on to the server with administrator privileges.
- 2 Check free space of the drive where the system is installed.

Check the required amount of free space according to "■ Checking Hard Disk Free Space" (→pg.136).

If the drive has no free space, refer to "■ Cannot Collect the Memory Dump" (→pg.248).

- Click [Start] → [Control Panel] → [System].
 The [System Properties] window appears.
- 4 Click the [Advanced] tab and click [Settings] in [Performance]. The [Performance Options] window appears.
- **5** Click the [Advanced] tab.

Performance Op	tions			? ×
Visual Effects	Advanced			
Processor sch	neduling			
Choose how	to allocate pr	ocessor r	esources.	
Adjust for be	st performan	ce of:		
C Programs	. (Backg	round <u>s</u> ervices	3
r Memory usag				
	c to allocate sy	stem mer	nory.	
Adjust for be	st performan	ce of:		
C Programs	. (System cache 		
└── Virtual memor	v			
	is an area on	the hard	disk that Wind	lows uses as
Total paging	file size for all	l drives:	384 MB	
				⊆hange
	0	К	Cancel	Apply



6 Click [Change] in the [Virtual memory] section. The [Virtual Memory] window appears.

Virtual Memory		? ×
Drive [Volume Label]	Paging File Size (MB)	
G	384 - 768	
E: F:		
· ·		
Paging file size for sel	ected drive	
Drive:	C:	
Space available:	2724 MB	
Output of the state of the s		
Initial size (MB):	384	
Ma <u>x</u> imum size (MB):	768	
C System managed	size	
C No paging file	<u>S</u> et	
Total paging file size f	or all drives	
Minimum allowed:	2 MB	
Recommended:	381 MB	
Currently allocated:	384 MB	
	OK Car	ncel

7 Specify the drive where the paging file is to be created.

In [Drive], select the drive where the system is installed. The selected drive is displayed in [Drive] in [Paging file size for selected drive].

8 Select [Custom size] and enter a value in [Initial size].

The value depends on the type of the set dump file.

Specify a value larger than the value shown in [Recommended] in [Total paging file size for all drives].

MPORTANT

When a smaller value is specified for the paging file size, performance may be affected. For maximum system efficiency, be sure to set [Initial size] with a value larger than the [Recommended] size described in [Total paging file size for all drives]. The recommended size is total memory installed in the system x 1.5. However, if a program consuming a large amount of memory is regularly used, set a larger size as required.

9 Enter a value in [Maximum size].

Specify a value larger than the [Initial size].

10 Save the settings.

Click [Set] in the [Paging file size for selected drive] section. The settings are saved, and the value specified is displayed in [Paging File Size] of [Drive].

- **11** Click [OK] to close the [Virtual Memory] window.
- **12** Click [OK] to close the [Performance Options] window.
- **13** Click [OK] to close the [System Properties] window.

14 Restart the system.

The setting is enabled after the system is restarted.

5.1.2 How to Obtain Memory Dump for Windows 2000 Server

Check the following settings before starting configuration to obtain memory dump.

■ Checking Hard Disk Free Space

Once memory dump is obtained, a file containing contents of the whole physical memory installed in the system is created. Before storing the dump file, confirm that there is sufficient free space in the hard disk.

The obtainable dump types and required hard disk capacity are as follows:

• Complete Memory (Full) Dump (recommended)

When the system unexpectedly stops, contents of the whole system memory are recorded. If this option is selected, space to retain the paging file as large as the whole physical memory $\times 1.3$ is required in the boot volume.

- Included information Common header, all virtual address pages that are not paged out during STOP
- Required size Installed physical memory × 1.3

MPORTANT

Complete memory dump cannot be used on the computer in which the 2GB or more RAM is installed.

Kernel Memory Dump

Information of only kernel memory space is recorded. When the system unexpectedly stops, the process that records information to the log file is speeded up. According to the amount of memory installed in the server, available area of 50 to 800MB is required for the paging file in the boot volume.

- Included information
 Common header, summary dump header (complete memory dump) (user process space page) (cache region page) (unused pool region page)
- · Required size

Depending on the used amount of kernel-mode address space during STOP

Small Memory Dump

Minimum amount of useful information for problem identification is recorded. In this option, a paging file of at least 2MB is required in the boot volume. Also, a new file is created each time the system unexpectedly stops.

History of such files is stored in the directory displayed in [Small dump directory] (usually, C:\winnt\minidump).

- · Included information Common header, minidump header, kernel module, memory information, processor information, process information, threads information, stuck page, unloaded module information
- Required size 2MB or more

Memory Dump File Setting

Set up the memory dump file according to the following procedures:

- Log on to the server with administrator privileges. 1

- **2** Check free space of the drive where the memory dump file is to be stored. Check the required amount of free space according to "■ Checking Hard Disk Free Space" (→pg.141).

If the drive has no free space, refer to " \blacksquare Cannot Collect the Memory Dump" (\rightarrow pg.248).

- **3** Click [Start] \rightarrow [Settings] \rightarrow [Control Panel].
- **4** Double-click the [System] icon.

The [System Properties] window appears.

5 Click the [Advanced] tab and click [Startup and Recovery]. The [Startup and Recovery] window appears.

Startup and Recovery	? ×
- System startup	
Default operating system:	
"Microsoft Windows 2000 Server" /fastdetect	•
$\overrightarrow{\mathbf{P}}$ Display list of operating systems for $\boxed{30}$ $\frac{30}{2}$ seconds.	
System Failure	
☑ Write an event to the system log	
Send an administrative alert	
Automatically reboot	
Write Debugging Information	
Complete Memory Dump	
Dump File:	
%SystemRoot%\MEMORY.DMP	
Qverwrite any existing file	
OK Car	ncel

- 6 Set as follows:
 - 1. In the [Write debugging information] section, select the memory dump file type.
 - Complete memory dump (Recommended) The whole system memory information is recorded to the memory dump file.
 - Kernel memory dump Only kernel memory is recorded to the memory dump file.
 - Small memory dump (2MB or more) Minimum information is recorded to the memory dump file.
 Each time a fatal error occurs, a new file is created in the directory specified in [Small dump directory].
 - 2. In [Dump File] or [Small dump directory], specify the directory to save the memory dump file, with its full path.

In case of kernel memory dump or complete memory dump, if [Overwrite any existing file] is checked, debugging information is overwritten to the specified file every time.

- 7 Click [OK] to close the [Startup and Recovery] window.
- 8 Click [OK] to close the [System Properties] window.
- **9** Restart the system.

The setting is enabled after the system is restarted.



Paging File Setting

Set up the paging file according to the following procedures:

- 1 Log on to the server with administrator privileges.
- **2** Check free space of the drive where the system is installed.

Check the required amount of free space according to " \blacksquare Checking Hard Disk Free Space" (\rightarrow pg.141). If the drive has no free space, refer to " \blacksquare Cannot Collect the Memory Dump" (\rightarrow pg.248).

- **3** Click [Start] \rightarrow [Settings] \rightarrow [Control Panel].
- **4** Double-click the [System] icon.

The [System Properties] window appears.

5 Click the [Advanced] tab and click [Performance Options]. The [Performance Options] window appears.

Performance Options
Application response Optimize performance for:
C Applications C Background services
Virtual memory Total paging file size for all drives: 384 MB
OK Cancel

6 Click [Change] in the [Virtual memory] section. The [Virtual Memory] window appears.

'irtual Memory					<u>?</u> ×
Drive [Volume Label]	Pa	aging File Si:	ze (MB)		
C:		384 - 7	68		
E:					
Paging file size for sel	ected drive				
Drive: Space available:	C: 3330 MB				
Initial size (MB):	384				
Ma <u>x</u> imum size (MB):	768			5	jet
Total paging file size f	or all drives	;			
	2 MB				
	381 MB				
Currently allocated:	384 MB				
Registry size					
Current registry size:		9 MB			
Maximum registry size	(MB):	68			
			ОК		Cancel

7 Specify the drive where the paging file is to be created.

In [Drive], select the drive where the system is installed. The selected drive is displayed in [Drive] in [Paging file size for selected drive].

8 Specify the [Initial size].

The value depends on the type of the set dump file. Specify a value larger than the value shown in [Recommended] in [Total paging file size for all drives].

MPORTANT

When a smaller value is specified for the paging file size, performance may be affected. We recommend to specify the paging file size larger than the recommended value.

9 Specify the [Maximum size].

Specify a value larger than the [Initial size].

10 Save the settings.

Click [Set] in the [Paging file size for selected drive] section. The settings are saved, and the value specified is displayed in [Paging File Size] of [Drive].

- 11 Click [OK] to close the [Virtual Memory] window.
- **12** Click [OK] to close the [Performance Options] window.
- **13** Click [OK] to close the [System Properties] window.

14 Restart the system.

The setting is enabled after the system is restarted.

5.2 Creating a Disk for System Recovery

If the installation of the OS was performed manually, create a system recovery disk.

POINT

- If the system file, system configuration or environment setting change at startup, etc., is damaged, such data can be reconstructed using the recovery information stored in the created system recovery disk.
- > To create a recovery disk, you need an unused formatted floppy disk. Prepare it in advance.

5.2.1 Creating the Automated System Recovery (ASR) Set for Windows Server 2003 and Windows Server 2003 x64

After setting up Windows Server 2003, create a system recovery set. To do this, you need an unused formatted floppy disk and a medium to store back up files.



Click [Start] \rightarrow [All Programs] \rightarrow [Accessories] \rightarrow [System Tool] \rightarrow [Backup]. The [Backup or Recovery Wizard] window appears.

2 Click [Next].

The [Backup or Recovery] window appears.

3 Select [Create a backup of files and settings], and then click [Next]. The [Items to Create Backups] window appears

4 Select [All the information in this computer], and then click [Next]. The [Backup Type, Destination and Name of the Backup File] window appears.

5 Specify name and destination of the backup file, and then click [Next]. The [Backup or Recovery Wizard Complete] window appears.

- 6 Click [Finish]. Backup process starts.
- 7 If a message prompts you to insert a floppy disk, insert the floppy disk and click [OK].

Automated system recovery disk is created.

- 8 When the process is completed, a message appears. Eject the floppy disk according to the message and put a label on it. Label Example: "Windows Automated System Recovery Disk: Backup.bkf, Created at 12:00 04/01/2003"
- **9** Click [OK] to exit [Backup Utility].
- Click [Close] to close the [Backup Progress] window.An automated system recovery set has been created.Store the automated system recovery set just created in a secure location.

5.2.2 Creating a System Recovery Disk for Windows 2000 Server

After setting up Windows 2000 Server, create a system recovery disk. To do this, you need an unused formatted floppy disk.

- **1** Put a label showing "Windows 2000 system recovery disk" onto a floppy disk and insert it into the floppy disk drive.
- 2 Click [Start] → [Programs] → [Accessories] → [System Tools] → [Backup]. The backup window appears.
- **3** Click the [Wizard] tab and click [System Recovery Disk]. Create a system recovery disk by following the window instructions.

5.3 Storing the System Configuration Information

Before starting operations and when changing the system configuration information, store the configuration information. By storing this information, the system can be recovered with the stored information in case of a system failure (such as when the baseboard fails). Use Server Management Tools for storing and recovering the system configuration information.

MPORTANT

- Since the system configuration information is significant in maintaining the server, be sure to store the configuration information after the following operations:
 - · When the information is changed with the BIOS Setup Utility
 - When the hardware configuration of this server is changed (e.g. CPU, memory, baseboard or expansion card is added/removed or changed)
 - When the Remote Management Controller information is changed
- > As the stored system configuration information will be used for maintenance operation.

Cautions

- "Server Management Tools" disk is exclusively for this server. Do not use it on other systems. Otherwise, the systems may be damaged.
- Only the information that is configured with the BIOS Setup Utility and the configuration information of the Remote Management Controller can be stored/recovered. However, a user account for the Remote Management Controller and the license information of the Remote Management Controller Upgrade Kit cannot be stored.
- Make sure to perform this operation only when the server is started with the "Server Management Tools" disk. Do not run Server Management Tools on the server started from the hard disk or by the other floppy disk. Otherwise, the system may be damaged.
- Do not eject a floppy disk while the floppy disk access LED is on. Such an action may lead not only to corruption of the floppy disk data but also an unstable state of the system.
- If an error message appears while running Server Management Tools, respond to the message according to "■ Server Management Tools Error Messages" (→pg.244).

5.3.1 Storing the BIOS Information and the Remote Management Controller Information

Store the BIOS information and the Remote Management Controller information according to the following procedures.

MPORTANT

 Before starting the operation, if the "OS Boot Monitoring" function of ServerView is enabled, disable it (it is disabled by default).

If you start up the system while the "OS Boot Monitoring" function remains effective, the operation of the server may become unpredictable at such times as an abrupt power interruption or restart. If it is necessary to operate the server with the "OS Boot Monitoring" function enabled, enable the function after storing the BIOS/Remote Management Controller information. For details of ServerView, refer to "ServerView User's Guide".

1 Turn on the server and insert the "Server Management Tools" disk into the floppy disk drive.

The window for selecting a keyboard appears.

```
Please select:
   1 = JP Keyboard
   2 = US Keyboard
Your selection
```

2 Select a keyboard.

Select [1] for Japanese keyboard or select [2] for English keyboard. Japanese keyboard is selected by default.

3 When the DOS prompt window appears, enter the following command and press the [Enter] key.

A:\ SMT\>biossave.bat

4 If the BIOS information or the Remote Management Controller information is stored correctly, the following message appears.

NORMAL END

5 Confirm that the stored information files are created.

Enter the following command to display the stored information files which are created. A:\SMT>dir

The BIOS information has been stored. The server can now be turned off safely.

5.3.2 Recovering the BIOS Information

If the information configured with the BIOS Setup Utility was deleted due to a drain of the built-in server battery, etc., restore the BIOS information according to the following procedures.

MPORTANT

- Do not turn off the server while a program is running.
- Before starting up the system, check that the "OS Boot Monitoring" function of ServerView is disabled (it is disabled by default).

If you start up the system while the "OS Boot Monitoring" function remains effective, the operation of the server may become unpredictable at such times as an abrupt power interruption or restart. If the server is operated with the "OS Boot Monitoring" function enabled, enable the function again before resuming operation. For details of ServerView, refer to "ServerView User's Guide".

1 Turn on the server and insert the "Server Management Tools" disk into the floppy disk drive.

The window for selecting a keyboard appears.

```
Please select:
   1 = JP Keyboard
   2 = US Keyboard
Your selection
```

2 Select a keyboard.

Select [1] for Japanese keyboard or select [2] for English keyboard. Japanese keyboard is selected by default.

3 When the DOS prompt window appears, confirm that the BIOS stored information files are in the floppy disk.

Enter the following command to confirm that the stored information files are in the floppy disk. A:\SMT>dir

- 4 Enter the following command and press the [Enter] key A:\SMT>biosrest.bat
- **5** If the BIOS information is restored correctly, the following message appears.

NORMAL	EBD			

6 The BIOS information will be enabled after the next system restart. Restart the server.

Perform Step 1 to display the DOS prompt window.

The restoration procedure has been completed. The server can now be turned off safely.

5.3.3 Recovering the Remote Management Controller Information

If the Remote Management Controller information is changed to the default setting due to a baseboard failure, etc., restore the information according to the following procedures.

MPORTANT

- Do not turn off the server while a program is running.
- Before starting up the system, check that the "OS Boot Monitoring" function of ServerView is disabled (it is disabled by default).

If you start up the system while the "OS Boot Monitoring" function remains effective, the operation of the server may become unpredictable at such times as an abrupt power interruption or restart. If the server is operated with the "OS Boot Monitoring" function enabled, enable the function again before resuming operation. For details of ServerView, refer to "ServerView User's Guide".

1 Turn on the server and insert the "Server Management Tools" disk into the floppy disk drive.

The window for selecting a keyboard appears.

```
Please select:
  1 = JP Keyboard
  2 = US Keyboard
Your selection
```

2 Select a keyboard.

Select [1] for Japanese keyboard or select [2] for English keyboard. Japanese keyboard is selected by default.

- When the DOS prompt window appears, confirm that the Remote Management Controller stored information files are in the floppy disk.
 Enter the following command to confirm that the files are created.
 A:\SMT>dir
- 4 Enter the following command and press the [Enter] key A:\SMT>irmcrest.bat
- **5** If the Remote Management Controller information is restored correctly, the following message appears.

NORMAL EBD

6 Turn off the server, unplug the power cable, reconnect it after 10 seconds or more, and then turn on the server for restored Remote Management Controller information to be enabled.

5.4 Creating Maintenance Tools

This section explains how to create tools for maintaining the server. Maintenance tools are created with the FloppyBuilder function of ServerStart.

With the FloppyBuilder function of ServerStart, you can create the following tool:

- Hardware Configuration Tool
- DOS Diskette

The FloppyBuilder can be used under environments such as:

- the ServerStart system started on a client computer (recommended)
- · the system started on the server using the ServerStart CD-ROM

POINT

When creating the tools on a client computer, it is necessary to install ServerStart on the client computer beforehand. Install it according to "2.4 Preparation for Using ServerStart on a Client Computer" (→pg.52).

If ServerStart of a different version is installed in the computer, make sure to uninstall the ServerStart. Then perform installation again. For details on how to uninstall ServerStart, refer to "2.4.2 Uninstalling ServerStart" (\rightarrow pg.54).


5.4.1 Creating a Hardware Configuration Tool

This section explains how to create a Hardware Configuration Tool from the ServerStart CD-ROM. Prepare floppy disks as many as the tools you want to create beforehand. Types of a Hardware Configuration Tool vary by model.

Starting ServerStart

• For Creation on a Client Computer

- Insert the ServerStart Disc 1 CD-ROM into the client computer's CD-ROM drive.
- **2** Click [Start] \rightarrow [Programs] \rightarrow [Fujitsu ServerStart] \rightarrow [ServerStart]. ServerStart starts up and the [Welcome to ServerStart] window appears.



• For Creation on the Server

1 Turn on the server and insert the ServerStart Disc 1 CD-ROM immediately after that.

ServerStart starts up and a message prompts you to insert the ServerStart floppy disk.

2 Insert the attached "ServerStart floppy disk" into the server's floppy disk drive. Then make sure "Removable media" and "A:" are selected and click [Create]. A network setup window for remote installation appears.

POINT

If a configuration file already exists in the ServerStart floppy disk and [OK] is clicked without clicking [Create], the [ServerStart Unattended Mode] window appears. Make sure to click [Exit]. The [Welcome to ServerStart] window appears.

If [Start] is clicked in the [ServerStart Unattended Mode] window, the installation of the server will start and all disk contents will be deleted.

Operations after OS Installation

3 Click [OK].

The [Initializing ServerStart] window appears and the ServerStart initialization process starts. Depending on the hardware configuration, this process may take a few minutes. When the process is completed, the [Create a ServerStart Floppy Disk] window appears.



4 Click [or Insert a ServerStart Floppy Disk to Start ServerStart]. The [Welcome to ServerStart] window appears.

😨 ServerSt	tart	
😣 🖸		$\Delta \triangleright$ 6 F
	Welco	ome to ServerStart
	()	Click here to prepare and/or initiate an operating system installation
		Information
	1	FloppyBuilder
		End-User License Agreement for ServerStart's Operating System


5 Eject the ServerStart floppy disk.

■ Creating a Hardware Configuration Tool

Start up ServerStart and confirm that the [Welcome to ServerStart] window is displayed.

1 Start up ServerStart and click [FloppyBuilder].

The [ServerStart FloppyBuilder] window appears.



- **2** Click [Hardware Configuration Tools].
- Click the tool you want to create.Insert the prepared floppy disk by following the message.
- 4 Perform the subsequent operations according to the messages on the window. The floppy disk will be formatted automatically and file copying will start. The respective tools will be created automatically. When a message appears indicating that the disk is created, click [OK] and eject the disk.



5.4.2 Creating a DOS Diskette

For DOS data stored into the floppy disk, refer to the file in the following folder of the ServerStart Disc 1 CD-ROM.


[CD-ROM drive] :\FreeDOS

To create a DOS diskette, you need an unused floppy disk. Prepare it in advance.



Start up ServerStart and Click [FloppyBuilder].

For details on procedures for starting up ServerStart, refer to "■ Starting ServerStart" (→pg.153).



Insert the prepared floppy disk by following the message.

3 Perform the subsequent operations according to the messages on the window. The floppy disk will be formatted automatically and file copying will start. The DOS diskette will be created automatically.

When a message appears indicating that the disk is created, click [OK] and eject the disk.

5.5 Notes before Operating the Server

This section explains the settings required before starting to operate the server. For details on the settings, refer to the following URL. http://www.microsoft.com/technet/prodtechnol/exchange/2003/Library/default.mspx

- If a LAN card was added, install a driver according to "4.3 Installing the LAN Driver" (→pg.128).
- When connecting a SCSI optional device (such as a DAT), connect it according to "Chapter 7 Installing Hardware Options" (→pg.177).
- For the settings for the installed applications supplied with the product, refer to the manuals of each application.

5.5.1 Applying the Hotfix

A hotfix needs to be applied in order to operate the server. For the hotfix, use the "ServerStart Disc 1 CD-ROM" supplied with the server.

Installing Windows 2000 Server

To install Windows 2000 Server directly, you have to use Service pack 4 integrated OS media or install Service Pack 4 or newer Service Pack.

And please install hotfix module named KB904374 after OS installation.

Please find out hotfix module of your language version from the following folder on ServerStart CD. [CD-ROM drive]: \HOTFIX\W2K\

5.5.2 Auto-run Function from CD-ROM Drives

Perform the following procedures to change the settings of the auto-run function from the CD-ROM drives after server installation:

1 Make the registry editable, and change the value of AutoRun of the following registry key:

HKEY_LOCAL_MACHINE\System\CurrentControlSet\Services\CDRom Set the value of Autorun to "1" to enable auto-run, and set the value to "0" to disable auto-run.

2 Restart the system.

The setting is enabled after the system is restarted.

5.5.3 Drive Letter Assignment in Expert Mode

In expert mode, you cannot specify a drive letter to a particular partition arbitrarily. Drive letters specified with Disk Manager in expert mode will be sequentially assigned from the first partition with "C, D, E..." when installation is completed, and an unused drive letter will be assigned to the CD-ROM drive.

To change the drive letter, perform the following procedures after installation.

MPORTANT

• You cannot change the drive letters for the system and boot drive.

For Windows Server 2003

- **1** Click [Start] \rightarrow [Administrative Tools] \rightarrow [Computer Management].
- **2** Click [Disk Management].
- **3** Right-click the partition to change the letter and click [Change Drive Letter and Path].

The [Change Drive Letter and Path] window appears.

- **4** Click [Edit]. The [Change Drive Letter or Path] window appears.
- **5** Change the drive letter.

■ For Windows 2000 Server

- 1 Right-click [My Computer] icon on the desktop and select [Manage].
- **2** Click [Disk Management].

3 Right-click the partition to change the letter and select [Change Drive Letter and Path].

The [Change Drive Letter and Path] window appears.

4 Click [Edit].

The [Change Drive Letter or Path] window appears.

5 Change the drive letter.

5.5.4 Notes on Advanced Uninterruptible Power Supply (UPS)

Note the following points when using an advanced uninterruptible power supply (referred to as UPS afterward).

UPS Shutdown Time Setting

Specify enough time for the UPS power-off time (time from the shutdown direction to the actual poweroff). If this time is set insufficiently, the power will be cut off before system shutdown, which may result in destruction of data. For more details, refer to the manuals for UPS and UPS management software.

Power Supply Control by UPS

Change the BIOS Settings to turn on the server automatically at power recovery or during scheduled operation using the UPS management software (PowerChute Network Shutdown, PowerChute Business Edition).

1 Start the BIOS Setup Utility.

→"8.2.1 Starting and Exiting the BIOS Setup Utility" (pg.213)

2 Select the [Power On/Off] submenu from the [Advanced] menu, and press the [Enter] key.
The [Power On/Off] submenu window encours

The [Power On/Off] submenu window appears.

- **3** Set [Power Failure Recovery] to [Always On].
- 4 Save changes and exit the BIOS Setup Utility.

5.5.5 Turning the Power On via a LAN

You can turn the power on the server from a client (via a LAN) by utilizing the Wakeup on LAN (WOL) function.

MPORTANT

• Be sure to install ServerView to control the power supply via a LAN.



- When the power cable is disconnected from the server or the server is powered off due to power interruption, restart the server. Unless the server is restarted, the WOL function will be disabled.
- Only the onboard LAN supports the WOL function on this server. To control power supply via a LAN, make sure you connect the onboard LAN and set the onboard LAN adapter bind to "1".

BIOS Setup Utility Setting

When power management is performed via a LAN, configure the settings as follows using the BIOS Setup Utility. This is set to "Enabled" by default.

Start the BIOS Setup Utility.

→"8.2.1 Starting and Exiting the BIOS Setup Utility" (pg.213)

2 Select the [Power On/Off] submenu from the [Advanced] menu, and press the [Enter] key.

The [Power On/Off] submenu window appears.

- **3** Set [Power On Source:LAN] to [Enabled].
- **4** Save changes and exit the BIOS Setup Utility.

POINT

To start up the server via a LAN, refer to "● Performing Remote Installation" (→pg.43).

5.5.6 Other Notes on Operation

Unnecessary Files

After OS installation is completed, folders named Runonce and Runonce 2 may be left in the drive where the OS is installed. Delete these folders since you do not need them for the system operation.

Notes on 24-hour Operation

Automated System Operation

To provide an extra margin of safety against unintentional damage, introduce disaster-prevention measures in the office and keep disaster prevention personnel (such as a security guard or janitor) in the building.

Unintentional Power-off Prevention

We recommend the installation of a special power supply device (such as a distribution board) to prevent unplanned power shut-offs.

5.6 LAN Driver Advanced Setup [BACS]

BACS is an integrated GUI application consisting of programs such as BASP (Broadcom Advanced Server Program) that provides the load balancing feature, etc., by teaming up multiple adapters. BACS is used in the following situations:

- · Setup a VLAN using the onboard LAN
- · Perform the other advanced setups of the onboard LAN

POINT

Use of Intel® PROSet

- Use Intel[®] PROSet (→pg.166) to perform the following advanced setups of a LAN card:
 - · Use the Teaming function between LAN cards or between a LAN card and the onboard LAN
 - Setup a VLAN using a LAN card
 - · Perform the other advanced setups of a LAN card

5.6.1 BACS Installation

If [Broadcom Control Suite 2] is not displayed in the [Control Panel], install BACS according to the following installation procedures:


■ For Windows Server 2003 x64

Execute the following file contained in the ServerStart Disc 1 CD-ROM. [CD-ROM drive]: \PROGRAMS\GENERAL\Broadcom\MgmtApps_x64\setup.exe The installer starts up.



2 Click [Next].

License agreement window appears.



3 Click [I accept the terms in the license agreement] and click [Next]. Custom Set up window appears.

🛃 Broadcom Management Programs - InstallShield V	Wizard X
Custom Setup Select the program features you want installed.	
Click on an icon in the list below to change how a feature is in	
BASP	This feature vill install the Broadcom Advanced Control Suite graphical user interface . This application contains a set of utilities supporting diagnostics, monitoring, and configuration for Broadcom network adapters. This feature requires 2408KB on your hard drive.
InstallShield	
Help < <u>B</u> ack	<u>N</u> ext > Cancel



Click [Next].

Proceed the installation by following the window instruction.

■ For Windows Server 2003, Windows 2000 Server

POINT

- If the OS is installed using ServerStart, "BACS" is already installed with the driver. If the OS is installed manually, BACS will not be installed.
- Execute the following file contained in the ServerStart Disc 1 CD-ROM. [CD-ROM drive]: \PROGRAMS\GENERAL\Broadcom\MgmtApps\setup.exe The installer starts up.
- **2** Proceed the installation by following the window instructions.

When the window below appears during the installation procedure, check [BASP] and click [Next].

Broadcom Management Prog Select Features Choose the features 3		×
Select the features : want to install.	vou want to install, and clear the features you do not Description This component will install the Broadcom Advanced Server Program	
Space Required C: Space Available C: InstallShield	12370 K 7233649 K <u>< B</u> ack <u>N</u> ext > Cancel	

5.6.2 VLAN Setup Procedure

- 1 Start up BACS. The procedure differs depending on the OS being used. For Windows Server 2003 / Windows Server 2003 x64
 - 1. Click [Start] \rightarrow [Control Panel] \rightarrow [Broadcom Control Suite 2].


For Windows 2000 Server

- 1. Click [Start] \rightarrow [Settings] \rightarrow [Control Panel].
 - The [Control Panel] window appears.
- 2. Start up "Broadcom Control Suite 2".
- 2 Right-click a LAN adapter or the Team name of a teamed up adapter and click [Create a VLAN] or [Add VLAN] from the displayed menu.

POINT

- ▶ A LAN adapter is displayed with a 📲 mark.
- The Team name of a Teamed Up adapter is displayed with a mark.

3 Click [Expert Mode] on the [Broadcom Teaming Wizard].



4 Specify [Team Name], [VLAN ID], and [VLAN Name] in the [Create New VLAN] window.

The [Team Name] is not displayed when the [Add VLAN] window appears.

The [VLAN ID] should be identical with the switch setting.

The [VLAN Name] does not need to be identical with the switch setting.

Create New VLAN	×
Team Name: TX150S5	
VLAN ID Enter the VLAN ID that will identify a VLAN in your network. (Range :0 - 4094)	
Untagged VLAN	
VLAN Name Enter a name you will use to identify this VLAN	
VLAN1	
Cancel	

POINT

- You cannot use a "VLAN ID" or "VLAN Name" that has already been used. Enter another set value.
- **5** When the setting for the team is completed, click [OK].

6 Click [Apply] to apply the settings.

After the network is temporarily disconnected, a window is displayed. Click [Yes (Y)].

5.6.3 Cautions for Onboard LAN Driver Ver9.25.0.0

Event Log

Once a Team and VLAN are setup, multiple logs that start with the following log may be stored in the system log file of the event viewer at system start-up.

Source	Blfm
ID	8
Туре	Error
Description	Could not bind to adapter \DEVICE\{(adapter name)}. * (adapter name) varies depending on the OS or hardware configuration.

Since such event logs will be stored even if the Teaming function and VLAN function are operated normally, ignore them.

5.7 LAN Driver Advanced Setup [Intel[®] PROSet]

"Intel[®] PROSet" is a tool for configuring details on the LAN driver. This is used in the following cases.

- Use the Teaming function between LAN cards or between a LAN card and the onboard LAN
- · Setup a VLAN using a LAN card
- · Perform the other advanced setups of a LAN card



Use of BACS

- ▶ Use BACS (→pg.161) to perform the following advanced setups of the onboard LAN:
 - Setup a VLAN using the onboard LAN
 - Perform the other advanced setups of the onboard LAN

5.7.1 Intel[®] PROSet Installation

If the tabs such as [Link], [Teaming] and [VLANs] are not displayed in the property of LAN adapters which can be selected from the [Device Manager], install Intel[®] PROSet according to the following installation procedures:

Execute the following file contained in the ServerStart Disc 1 CD-ROM. For Windows Server 2003 x64 [CD-ROM drive]:\Tools\GENERAL\Intel\ProSet\Ws03_32e\InstPROSet.EXE For Windows Server 2003 / Windows 2000 Server

- [CD-ROM drive]:\Tools\GENERAL\Intel\ProSet\Ws03xp2k\InstPROSet.EXE
- 2 Click [Next].
- 3 Click [Accept].
- 4 Select [complete] for [Setup type] and click [Next].
- 5 Click [Install].
- 6 Click [Finish].

5.7.2 Cautions for PG-185x/186x/188x/189x/286x LAN Driver V10.3

Event Log

Once a Team is setup, multiple identical logs from the same source that starts with the following log may be stored in the system log file of the event viewer at system start-up.

Source	iANSMiniport
ID	11
Туре	Warning
Description	The following adapter link is not connected: (adapter name) * (adapter name) varies depending on the OS or hardware configuration.

Since such event logs will be stored even if the Teaming function is operated normally, ignore them.

5.7.3 Teaming Function

Notes

When using the Teaming function, note the following points.

- You require Service Pack 2 or later for Windows 2000 Server.
- For AFT/ALB/Static link type, you can incorporate up to four LAN ports into one team and two ports for a SFT type team.
- Once a Team is created, virtual adapters (Team:(Team Name)) will be created in the [Device Manager] and/or [Network and Dial-up Connections] of the system. Do not disable or delete this virtual adapter from the [Device Manager] or [Network and Dial-up Connections]. When deleting a virtual adapter, make sure to use "Intel[®] PROSet".
- When the Teaming function is being used, you can only use the following protocols:
 - For AFT/SFT/Static link type: IP, NetBEUI, IPX (NCP), IPX (NetBIOS)
 - For ALB type: IP, IPX (NCP)
- When the Teaming function is being used, you cannot use the hardware assist function of IPSEC. Do not use this function even if the function is installed in all cards in the team.
- When the Teaming function is being used, you cannot use Windows Load Balancing Service (WLBS) and Network Load Balancing (NLB).
- If Static link type is selected, you can only use the switch for link aggregation.
- When adding/deleting a Static link type member, perform such operation under a linked down state.
- If the onboard LAN is set to RemoteControlService and Team is configured on the onboard LAN, remote control function with RemoteControlService does not work properly.

- The team with the Intel[®] PROSet Broadcom onboard LAN and the Intel LAN card can be configured, but note the following points.
 - The team cannot be configured with only Broadcom onboard LANs. It is necessary to incorporate in Intel LAN card more than one port.
 - Make sure to set any port of the Intel LAN card as [Set Primary]. To configure it, click the [Settings] tab and [Modify Team...], select the LAN card, and click [Set Primary].

MPORTANT

Only a link down error between a LAN card (onboard LAN) and the switch it connects with, and the equivalent errors lead to switching of the route. Therefore, if only the switch or LAN card (onboard LAN) is partially damaged and the route being used is sound at the link level, the route will not be switched in the team, but the communication with the Team may become an error.

Teaming Configuration Procedure

Start up Intel[®] PROSet. The procedure differs depending on the OS being used.

For Windows Server 2003

```
Click [Start] \rightarrow [Administrative Tools] \rightarrow [Computer Management].
```

For Windows 2000 Server

Click [Start] \rightarrow [Programs] \rightarrow [Administrative Tools] \rightarrow [Computer Management].

- 2 Click [Device Manager] and double-click a LAN adapter to incorporate in a Team.
- **3** Click the [Teaming] tab, select [Team with other adapters] and click [New Team].
- 4 Enter a team name and click [Next].
- 5 Check the LAN adapter to incorporate in the Team and click [Next].

MPORTANT

Do not check an onboard LAN (do not incorporate it in a Team) if the onboard LAN is controlled remotely by RemoteControlService.

6 Select a Teaming type with which you want to create a Team.

Select the following depending on the Teaming type selected accordingly:

- AFT type: "Adapter fault tolerance"
- ALB type: "Adaptive load balancing"
- SFT type: "Switch fault tolerance"
- Static link type: "Static link aggregation"
- 7 Click [Finish].
- 8 Click [OK] to close the property window for created Teaming adapter.

9 Click [OK] to close the property window for the LAN adapter.

When the Teaming setting is completed, the following virtual adapter will be created.

• "Team:(Team Name)"

Upper protocols will be bound with the main virtual adapter.

You cannot bind them with the LAN card consisting of a Team.

The IP address can be set in the main virtual adapter.

5.7.4 VLAN

Notes

When using a VLAN, note the following points.

- You can only have "NetBIOS over TCP/IP" enabled for up to four VLANs in the whole system.
- On a VLAN, do not use protocols other than TCP/IP.
- You can only set ten or less VLANs to a LAN port.
- When adding or deleting a VLAN, always use "Intel(R) PROSet". Do not disable or delete a VLAN from the [Device Manager] or [Network and Dial-up Connections].

VLAN Configuration Procedure

1 Start up Intel[®] PROSet. The procedure differs depending on the OS being used.

For Windows Server 2003

Click [Start] \rightarrow [Administrative Tools] \rightarrow [Computer Management].

For Windows 2000 Server

Click [Start] \rightarrow [Programs] \rightarrow [Administrative Tools] \rightarrow [Computer Management].

- 2 Click [Device Manager] and double-click a LAN card to setup a VLAN.
- 3 Double-click the [VLANs] tab, and click [New...].
- 4 Specify [VLAN ID] and [VLAN Name]. Then click [OK].

The [VLAN ID] should be identical with the switch setting. 1 to 4094 can be specified. Any name can be specified as the [VLAN Name].

5 Click [OK] to close the property window for the LAN adapter.

When setup of the VLAN is completed, the following virtual adapter will be created.

"(LAN Adapter Name)-VLAN:(VLAN Name)"
 Upper protocols will be bound with the main virtual adapter. You cannot bind them with the LAN card consisting a VLAN. The IP address should be specified in the main virtual adapter.

Chapter 5 Operations after OS Installation

Chapter 6

High Reliability Tools

For stable PRIMERGY server operations, we recommend that high reliability tools be installed. This chapter explains the installation and necessary settings of high reliability tools.

6.1	RAID Management Tool	172
6.2	Server Monitoring Tool [ServerView]	173
6.3	Solving Problems Early [DSNAP]	175

6.1 RAID Management Tool

RAID Management Tool is software that performs array configuration, disk initialization and disk array monitoring. For more details, refer to the manual in Array Controller Document & Tool CD.

POINT

OS installation using ServerStart

If the OS is installed using ServerStart, RAID Management Tool is installed with the OS and other high reliability tools.

6.1.1 Installing RAID Management Tool

To install RAID Management Tool individually using the standard installer, follow the procedures below.

MPORTANT

- Before installing RAID Management Tool, check that TCP/IP is installed and works properly.
 - 1 Log on to the server with administrator privileges.

MPORTANT

- Exit all programs before starting installation.
 Installation will fail if "Event Viewer" or "Computer Management" is run.
- 2 Insert the Array Controller Document & Tool CD. Click [Start] \rightarrow [Run...].
- 3 Enter a name in the [Open:] field as follows and click [OK]. [CD-ROM drive]:\RAIDTOOL\SVRAID\Windows\install.bat Installation starts and the wizard window appears. For subsequent procedures, refer to Array Controller Document & Tool CD.

6.2 Server Monitoring Tool [ServerView]

ServerView constantly monitors the status of the servers' hardware in the network and provides a console with which the administrator can check the status of all the servers at a glance. When using ServerView, the server hardware is monitored all the time. If an error that could cause trouble is detected, the administrator is notified in real-time. This allows the server administrator to remove a system error early and avoid trouble.

Importance of Monitoring the Server with ServerView

For safe operation of PRIMERGY, always monitor the server using ServerView. Even if the server is operated in the redundancy configuration, overlooking or neglecting errors could result in a system stop or data loss. As soon as one constituent part of the redundancy configuration fails, the corresponding countermeasures must be taken. For that reason, monitoring the server with ServerView is necessary. If ServerView is not applied, the following very serious problems may occur.

RAID Error Monitoring

ServerView notifies of the RAID errors. In an environment where ServerView is not applied, the administrator is not notified of the RAID errors. Leaving the RAID error unattended may lead to a system stop with multiple dead drives.

Memory Monitoring

ServerView monitors the memory. In an environment where ServerView is not applied, a memory single-bit error cannot be detected during operation. In order to detect the error, the server must reboot to run the BIOS Setup Utility or the Server Management Tools. Leaving this error unattended may lead to multiple-bit errors and a system stop.

Fan Monitoring

ServerView monitors the fan. In an environment where ServerView is not applied, fan irregularities (failure/stop) cannot be detected during operation. In order to detect the problem, the server must reboot to run the BIOS Setup Utility or the Server Management Tools. Leaving the fan problem unattended may lead to overheating inside the server and a system stop.

• Temperature Monitoring

ServerView monitors the temperature. In an environment where ServerView is not applied, the increased temperature inside the server, due to the fan problem described above, cannot be detected and the system stop cannot be prevented. In order to detect the problem, the server must reboot to run the BIOS Setup Utility or the Server Management Tools.

Voltage Monitoring

ServerView monitors the voltage. In an environment where ServerView is not applied, voltage irregularities cannot be detected during operation. In order to detect the problem, the server must reboot to run the BIOS Setup Utility or the Server Management Tools. As leaving the voltage surges, the server may malfunction or data loss may occur.

6

Power Supply Monitoring

ServerView monitors the power supply. In an environment where ServerView is not applied, power supply irregularities cannot be detected during operation. In order to detect the problem, the server must reboot to run the BIOS Setup Utility or the Server Management Tools. System stops due to power supply failures cannot be prevented.

6.2.1 Installing ServerView

When Installed Using ServerStart

If the OS is installed using ServerStart, ServerView will be installed at once with the OS and other high reliability tools.

When Installed Manually (SBS 2003 / Linux)

ServerView cannot be installed using ServerStart. To install ServerView manually into a Linux system, refer to "Installing" in "ServerView User's Guide".

MPORTANT

Be sure to install SNMP service before installing ServerView.

When an error screen appears after ServerView installation (Windows Server 2003 only)

If Windows Server 2003 Service Pack 1 is applied, the following message may appear on restarting after installing/uninstalling ServerView.

```
In order to protect the computer, this program is terminated by
Windows.
Name: SNMP Service
```

There is no problem with operations. Click [Close Message] to close the message.

6.2.2 Setting Required after Installation

Perform necessary operations after ServerView installation referring to "2.4 Checking after Installation" in "ServerView User's Guide".



Boot Monitoring Setting

We recommend enabling the "Boot Monitoring" function after ServerView is installed. For setting procedures and explanation on the function, refer to "[Restart Settings] Tab" of "3.4 Serious Error Handling (ASR)" in "ServerView User's Guide".

6.3 Solving Problems Early [DSNAP]

DSNAP is a tool for collectively acquiring failure investigation information such as server environment information.

POINT

OS installation using ServerStart

• If the OS is installed using ServerStart, DSNAP is installed with the OS and other high reliability tools.

6.3.1 Installing DSNAP

• For Windows Server 2003 x64

Copy the following file stored in the ServerStart Disc 1 CD-ROM into the server's hard disk. [CD-ROM drive]: \PROGRAMS\Japanese\DSNAPx64\DSNAPx64.EXE

• For Windows Server 2003, SBS 2003, Windows 2000 Server

When installing DSNAP separately, copy the following file stored in the ServerStart Disc 1 CD-ROM into the server's hard disk. [CD-ROM drive]: \PROGRAMS\Japanese\DSNAP\DSNAP.EXE

6.3.2 How to Use

• For Windows Server 2003 x64

Refer to the following file stored in the ServerStart Disc 1 CD-ROM. Use a text editor to open it. [CD-ROM drive]: \PROGRAMS\Japanese\DSNAPx64\README.TXT

• For Windows Server 2003, SBS 2003, Windows 2000 Server

Refer to the following file stored in the ServerStart Disc 1 CD-ROM. Use a text editor to open it. [CD-ROM drive]: \PROGRAMS\Japanese\DSNAP\README.TXT Chapter 6 High Reliability Tools

Chapter 7


Installing Hardware Options

This chapter explains how to install and remove the various hardware options.

7.1	Before Installing Hardware Options	178
7.2	Removing and Attaching Covers	180
7.3	Installing Memory Modules	185
7.4	Installing Expansion Cards	189
7.5	Installing Internal Hard Disk Units	192
7.6	Installing 5-inch Internal Options	198
7.7	Installing a Parallel Port Option	204
7.8	Installing a Serial Port	208
7.9	Connecting External SCSI Devices	210

7.1 Before Installing Hardware Options

The following types of hardware options can be installed in this server.



POINT

- If the optional devices listed below are purchased, refer to the following to check the packaged items before installing.
 - Memory→"B.1 Memory" (pg.269)
 - Internal Hard Disk Units →"B.2 Internal Hard Disk Units" (pg.270)
 - Parallel port option →"B.3 Parallel Port Option" (pg.270)
 - Serial port → "B.4 Serial Port" (pg.271)
- When installing and removing options, make sure to use the removed screws on the same devices that were last installed or removed. Failure to do so can damage the device.
- The types of optional devices listed in this manual are liable to be updated without any notice. Please be forewarned.
- When installing optional products (such as internal/external options and USB equipments), be sure to use the products in a system configuration diagram for stable PRIMERGY server operations. Fujitsu does not warrant that the server related products will operate properly if you use the unauthorized third party options.

Installing hardware options

179



Before installing/removing internal options to/from the server, turn off the server, all peripheral devices, and any other connected devices. Also unplug all power cables from the outlet. Failure to do so can cause electric shock ("1.4.4 Turning Off the Server" (\rightarrow pg.34)).

• Do not disassemble the PSU. Doing so can cause electric shock.



electricity.

- Use our genuine internal options only. Failure to do so may cause a device failure, fire, or electric shock.
- Do not damage or modify internal cables or devices. Doing so may cause a device failure, fire, or electric shock.



- Devices inside the server remain hot after shutdown. Wait for approximately 10 minutes after shutdown before installing or removing internal options.
- The circuit boards and soldered parts of internal options are exposed. They
 can be damaged by static electricity.
 Before handling them, first touch a metal part of the server to discharge static
- Do not touch the circuitry on boards and soldered parts. Hold the metallic areas or the edge of the circuit boards.
- When installing a 5-inch internal device, make sure to avoid pinching cables.
- If devices are installed or disassembled by other methods than those outlined in this chapter, the warranty will be invalidated.

7.2 Removing and Attaching Covers


Remove covers to install peripheral devices. Perform the following procedures to remove covers.




Electric Shock • Before removing or attaching covers, turn off the server, all peripheral devices, and any other connected devices. Also unplug all power cables from the outlet. Failure to do so can cause electric shock ("1.4.4 Turning Off the Server" $(\rightarrow pg.34)$).

7.2.1 Removing Covers


- **1** Turn off the server and connected devices, and unplug all power cables from the outlet.
- 2 Remove the hard disk cover. Tilt the hard disk cover toward you and pull it up to remove.



- **3** Remove the side cover.
 - 1. Remove the screws on the rear side. Do not lose the screws.




2. Slowly slide the side cover to the rear side, and then tilt it toward you to remove it from the server.



4 Remove the front cover.

The front cover is fastened with five tabs. Pull the left tabs first, and then remove the front cover while pressing the right tabs.




POINT

Remove the front cover as necessary, e.g., when you install a 5-inch internal device.

MPORTANT

When removing the front cover, if the latches on the back of the front cover are hard to release from the frame, insert a long stick-shaped object inside the server, press the latch on the back of the front cover in the direction of the arrow (1), and release it (2), as shown in the figure below. The latch of the front cover may break if you try to release it by force.



Installing Covers

To attach covers, simply reverse the removal procedures.



• Before turning on the server, make sure that all covers are in place.



• Check to make sure no tools or unnecessary components are left inside the server before attaching the side cover back into place.


7.2.2 Removing the Top Cover of the Rackmount Type

When the Rackmount Conversion kit (optional) is used, remove the top cover. The top cover of the rackmount type corresponds to the side cover of the tower type.

1 Open the rack door.


→"1.4.2 Opening the Rack Door" (pg.31)

- **2** Remove all cables connected to the server.
- **3** Remove the retaining screws used to fasten the server to the rack.



4 Slide the server.

Hold the handles from inside and pull the server out toward you until it clicks, so that it locks in place on the rails on both sides.



5 Remove the top cover.

The procedures for removing the top cover is the same as that for removing the side cover. Remove the screws on the rear side. Slowly slide the top cover to the rear side, and then remove it from the server.

Attaching the Top Cover

To attach the top cover, simply reverse the removal procedures.




· Before turning on the server, make sure that all covers are in place.




• Check to make sure no tools or unnecessary components are left inside the server before attaching the side cover back into place.

7.3 Installing Memory Modules


Additional memory will help increase the amount of data that can be read at a time and improve the server processing capability.



- Do not insert and remove memory modules repeatedly. This could damage the server.
- Hold the edges of the memory module, as shown in the figure below. Do not touch the gold contacts and memory chip.



7.3.1 Where to Install the Memory Module



Install memory modules to the memory slots in the server.

- DIMM1A: For basic RAM modules or memory modules that can be installed with the basic RAM module conversion kit.
- DIMM2A, DIMM1B, DIMM2B: For add-on RAM modules.

7.3.2 Installable Memory Modules and Notes

	Instal	lable	Memory	/ Modules
--	--------	-------	--------	-----------

The following memory module types can be used in this server.

table: List of Installable Memory Modules


Model	Remarks
Memory Module-512MB (PG-RM51BE)	512MB (512MB-DIMM x 1)
Memory Module-1GB (PG-RM1BE)	1GB (1GB-DIMM x 1)
Memory Module-2GB (PG-RM2BE)	2GB (2GB-DIMM x 1)

Order of Memory module Installation

Install memory modules in the order of DIMM1A, DIMM1B, DIMM2A and DIMM2B.

7.3.3 How to Install Memory Module

- **1** Turn off the server and connected devices, and unplug all power cables from the outlet.
- 2 Remove the side cover.
 - \rightarrow "7.2 Removing and Attaching Covers" (pg.180)
- **3** Touch a metal part of the server to discharge static electricity.
- **4** To replace the memory module, open outward the retention clips on both sides of the slot.






- Make sure not to open the clips outward too quickly because the memory module may pop up, which could cause damage.
- **5** Open the retention clips on both sides of the slot and insert the memory module.

Align a notch of the memory module to correspond with the memory slot and insert the module perpendicularly to the slot.

When the module is correctly inserted, the retention clips on both sides will close. Then, check that they secure the memory module.

If the retention clips are not securely closed, push them with your fingers to close.





- An improperly engaged memory module could cause a fire. Do not insert the memory module on the wrong side.
- 6 Attach the side cover.

7.3.4 Defective Memory Disconnection Function

This server is equipped with the defective memory disconnection function. This function disconnects the memory judged to be defective (abnormal) during Power On Self Test (POST) to start the server. If the memory capacity is discovered to be smaller than the capacity of the memory installed during POST, there is a possibility of memory defect. You can check the slot whose memory is defective from the system event log. Replace the defective memory, if discovered, and then restart the server.

Replacing the Defective Memory

- Check the slot whose memory is defective from the system event log.
 →"9.3 System Event Log" (pg.252)
- 2 Replace the defective memory with a new one according to "7.3.3 How to Install Memory Module" (→pg.187).

Start the BIOS Setup Utility.
 →"8.2.1 Starting and Exiting the BIOS Setup Utility" (pg.213)

4 Select the [Memory Status] submenu from the [Server] menu and check that replaced memory module is set to [Enabled].

If the item is set to [Failed], change the setting to [Enabled].


"■ Memory Status Submenu" (→pg.230)

POINT

If it is not set to [Enabled], the server will start with the memory module recognized as being defective and constantly disconnected. To use a new memory module, set the item to [Enabled] for releasing the failed memory status at the next startup.


7.4 Installing Expansion Cards

This section explains the types of expansion card, notes and installation procedures.



7.4.1 Where to Install an Expansion Card

The server has five PCI slots to accommodate up to five expansion cards. The specification is different according to the PCI slot number.



7.4.2 Installable Expansion Cards and Notes

Installable Expansion Cards

table: List of Installable Expansion Cards

Installable card (Model name)	Number of cards	Remarks
SAS array controller card (PG-140F)	1	For an array card type, this is installed by default.
SCSI card (PG-1281)	2	For external/internal options (Ultra 160 SCSI)
LAN card (PG-2861)	1	PCI-Express 1000BASE-T
LAN card (PG-1892)	3	1000BASE-T

Order of Expansion Card Installation

Install expansion cards into the slots in accordance with the priority indicated in the following table.

Installable expansion card (Model name)		PCI slot				Installation	
		2	3	6	7	order	
SAS array controller card (PG-140F)	-	1	-	-	-	1	
SCSI card (PG-1281)	1	-	2	-	-	2	
LAN card (PG-2861)	-	-	-	1	-	3	
LAN card (PG-1892)	3	2	1	-	-	4	

table: Expansion Card Installation Order and Slots

MPORTANT

Follow the "Installation order" shown in the table when installing the cards and drivers. If you turn on the power after installing multiple expansion cards simultaneously or in a wrong order, they will not function properly.

Notes on Installing Expansion Cards

- Install installable expansion cards only.
- Before installing an expansion card, refer to the manual supplied with the options.

7.4.3 How to Install Expansion Cards

- **1** Turn off the server and connected devices, and unplug all power cables from the outlet.
- **2** Remove the side cover.


→"7.2 Removing and Attaching Covers" (pg.180)

3 Touch a metal part of the server to discharge static electricity.


- 4 Remove the screw that fixes the slot cover (1), and remove the slot cover (2).

POINT

- Be sure to keep the removed slot cover for later use. If operating the server with no expansion card, attach the slot cover to keep dust away.
- **5** Firmly press the expansion card into the connector of the PCI slot.



6 Fix the expansion card with the screw.



7 Attach the side cover.

Removing the Expansion Card

To remove the expansion card, simply reverse the installation procedures.

7.5 Installing Internal Hard Disk Units

This section explains how to install internal hard disk units.

Electric Shock • When installing or removing internal hard disk units, turn off the server, all peripheral devices, and any other connected devices. Also unplug all power cables from the outlet. However, when the array system is configured (except for RAID 0), the defect hard disk unit can be replacing without turning off the server.

• Install our genuine internal hard disk units only. Failure to do so may cause a device failure, fire, or electric shock.



/!\WARNING

 When installing or removing hardware options, make sure to remove the screws on the specified points only.
 There is a chance of injury if screws other than those on the specified points



Touch only the specified part of the printed circuit board. Failure to do so could cause injury and also damage the server.


are removed. This could also damage the server.

POINT

Before adding an internal hard disk unit, install the OS and turn off the server.

7.5.1 Where to Install Internal Hard Disk Units

Install internal hard disk units in 3.5-inch storage bay.



7.5.2 Installable Internal Hard Disk Units and Notes

Before installing an internal hard disk unit, check the following points.

Installable Internal Hard Disk Units

The following types of SAS hard disks can be installed in this server.

Product name	Model number	Overview			
Internal hard disk unit -73 GB	PG-HDB75A	73.4 GB, 15,000 rpm, SAS 3.5 inch, hot-pluggable			
Internal hard disk unit -147 GB	PG-HDB45A	146.8 GB, 15,000 rpm, SAS 3.5 inch, hot-pluggable			

table: Installable Internal Hard Disk Units

Notes

Note the following points to avoid failures:

- Inside the hard disk unit, the disk for storing data is rotating at high speed to read and write data. Because this server is very delicate, do not move, strike, or shake it when it is turned on.
- Do not use or store the device in a location affected by extreme temperature changes.
- Keep the device away from direct sunlight and from radiators or other heat source.
- Use or store the device on a shock-and-vibration free surface.
- Do not use or store the device in a humid or dusty place.
- Do not use or store the device near magnets or devices that generate magnetic fields.
- Do not disassemble or take the device apart.
- Keep the disk away from condensation or water droplets.

MPORTANT

Mishandling could result in destruction of the data stored in the disk. Make sure to keep a backup of important data.

Even if the hard disk is of the same type, there could be a slight difference in storage capacity. We recommend backing up data on the basis of files or sectors rather than hard disks.

Array Configuration and Maximum Number of Installable Hard Disk Units

• When Not Configuring the Array System

Up to four internal hard disk units can be installed. Install them in the order of Bay 1, Bay 2, Bay 3 and Bay 4.

• When Configuring the Array System with an Onboard SAS Array Controller

Up to two internal hard disk units can be installed. Install hard disk units of the same model in Bay 1 and Bay 2.

When Configuring the Array System with a SAS Array Controller Card

Up to four internal hard disk units can be installed. Install them in the order of Bay 1, Bay 2, Bay 3 and Bay 4. The SAS array controller card (PG-140F) needs to be installed in PCI slot 2.

Slot Number

The slot numbers which are displayed on the software such as RAID Management tool correspond to the hard disk bay numbers as follows.

Bay Number	1	2	3	4
Slot Number	0	1	2	3

Replacing the Failed Internal Hard Disk Unit

When the hard disk is failed, it can be replaced and repaired without turning off the server and peripheral devices (hot-swappable/hot-pluggable).


For details about the array system and replacing the failed hard disk unit, refer to "MegaRAID SAS User's Guide" or "Integrated Mirroring SAS User's Guide" in the Array Controller Document & Tool CD.

7.5.3 How to Install the Internal Hard Disk Unit

- **1** Turn off the server and connected devices, and unplug all power cables from the outlet.
- 2 Remove the hard disk cover.
 → "7.2 Removing and Attaching Covers" (pg.180)
- **3** Touch a metal part of the server to discharge static electricity.


4 Remove the dummy unit from the bay to accommodate an internal hard disk unit.

Pull the dummy unit out towards you with its tabs being pressed inward. Be sure to keep the removed dummy units for later use.



5 Install the internal hard disk unit into the server unit.

Push the unit into the bay with the handle up and pull down the handle to secure.




6 Attach the hard disk cover.

7.5.4 How to Remove the Internal Hard Disk Unit

- **1** Turn off the server and connected devices, and unplug all power cables from the outlet.
- **2** Remove the hard disk cover.
 - →"7.2 Removing and Attaching Covers" (pg.180)
- **3** Touch a metal part of the server to discharge static electricity.

4 Remove the internal hard disk unit.

With pressing the front tab of the internal hard disk unit to remove, turn the handle upward and pull the hard disk unit towards you. To remove the internal hard disk unit, use both hands to pull it out.



- **5** Install a dummy unit or a new hard disk unit.
- 6 Attach the hard disk cover.

7.5.5 Replacing the Failed Internal Hard Disk Unit (in the array configuration only)

When an array system (except for RAID 0) is configured with this server, a failed hard disk unit can be replaced and repaired without turning off the server and peripheral devices (hot-swappable/hot-pluggable).

For replacing procedures, refer to the manual in the Array Controller Document & Tool CD. Follow the procedure below to insert and remove the hard disk unit.

- **1** Open the hard disk cover.
- 2 Touch a metal part of the server to discharge static electricity.
- **3** Pull the handle while pressing the tab on the front of the failed hard disk unit, pull out the unit by only 1 to 3 cm, and disconnect it from the SAS connector.

POINT

- Do not pull out the hard disk unit fully from the server.
- **4** Wait more than one minute (until the hard disk stops rotating) and pull out the failed hard disk unit.
- **5** Remove faulty hard disk.
- 6 Insert a new hard disk unit.

Insert it to the bay with the handle of the hard disk unit raised, and then bring down the handle to fix it.

7 Confirm the status by using the RAID Management tool.

For details, refer to the manual in the Array Controller Document & Tool CD. For an onboard array controller, execute Rebuild using the RAID Management tool.

8 Attach the hard disk cover.

7.6 Installing 5-inch Internal Options

This section explains how to install a 5-inch internal device. Unlike external devices, internal device does not need to be connected to the outlet because its power is supplied from the server. In addition, it offers the advantage of space saving.



Electric Shock • When installing or removing internal devices, turn off the server, all peripheral devices, and any other connected devices. Also unplug all power cables from the outlet.

Failure to do so can cause electric shock.

• Install our genuine internal devices only. Failure to do so may cause a device failure, fire, or electric shock.



 When installing or removing hardware options, make sure to remove the screws on the specified points only.
 There is a chance of injury if screws other than those on the specified points are removed. This could also damage the server.



Touch only the specified part of the printed circuit board. Failure to do so could cause injury and also damage the server.

POINT

• Before adding a 5-inch internal device, install the OS and turn off the server once.

7.6.1 Where to Install 5-inch Internal Devices

5 inch storage bay 3 5 inch storage bay 2 5 inch storage bay 1 (Preinstalled CD-ROM drive)

Install 5-inch internal devices in 5-inch storage bays.

7.6.2 Installable 5-inch Internal Devices and Notes

This section explains installable 5-inch internal devices, SCSI-IDs, and connections. Check this section before installing.

■ Installable 5-inch Internal Devices and SCSI-IDs

The following types of 5-inch internal devices can be installed in this server. For the combination of additional internal 5-inch options and their SCSI IDs, refer to the following table:

Product name	Model	number of installed devices	maximum	Available bay	SCSI ID
Internal DVD-RAM drive unit	PG-DVA102D	1	1	Bay 1	-
Internal DAT72 unit	PG-DT5041	1	2	Bay 2	-
Internal VXA2 unit	PG-VX201	1		or Bay 3	Bay 2=ID5
Internal LTO2 unit	PG-LT201	1			Bay 3=ID6

table: Installable 5-inch Internal Devices

MPORTANT

 Install the SCSI card (PG-1281) in advance when installing an internal VXA2 unit or an internal LTO2 unit.

7.6.3 How to Install the 5-inch Internal Device

POINT

To install DVD-RAM unit

▶ Before installing a DVD-RAM unit, remove the preinstalled CD-ROM drive unit. For details on how to install a DVD-RAM unit, refer to "7.6.4 How to Install a DVD-RAM Unit" (→pg.202)

Perform the following procedures to install a 5-inch internal device.

- Turn off the server and connected devices, and unplug all power cables from the outlet.
- **2** Remove the side and front covers.


→"7.2 Removing and Attaching Covers" (pg.180)

3 Install the SCSI card (PG-1281) for an internal VXA2 unit or an internal LTO2 unit.

→"7.4.3 How to Install Expansion Cards" (pg.190)

4 Remove the dummy unit.

Pull the dummy unit out slowly towards you, keeping the tabs on the 5-inch storage bay rails (on both sides) pressed inward.




POINT

Be sure to keep the removed dummy units for later use.



Detach the 5-inch storage bay rails from the removed dummy unit.

Remove eight screws that fix the 5-inch storage bay rails to detach.






6 Attach the removed 5-inch storage bay rails to the internal device to be added.

Use the supplied screws if the screws are supplied with the internal option.

If these are not supplied, use four screws which were removed when the 5-inch storage bay rails were detached.



7 Install the internal device to the 5-inch storage bay.




8 Connect a USB cable or a SCSI cable to the internal devices.

The cables differ according to the internal options.


For internal DAT72 unit

Connect a USB cable that is in the server. Remove the cap before connecting the cable.



For internal VXA2 unit or internal LTO2 unit

Connect a SCSI cable to the internal options. Use port A for one internal option. To connect two internal options, use port A for the internal option installed in the bay 3 and use port B for the internal option installed in the Bay 2.



9 Connect the power cable to the 5-inch internal devices.

When the option is installed in the Bay 2, connect the power cable P3. When the option is installed in the Bay 3, connect the power cable P2.

10 Attach the front and side covers.

11 Setup SCSI-ID.

Use the utility supplied with the SCSI card.

For details on how to use the utility, refer to the manual of SCSI card.

For SCSI-ID of each option, refer to "■ Installable 5-inch Internal Devices and SCSI-IDs" (→pg.199)


7.6.4 How to Install a DVD-RAM Unit

Before installing a DVD-RAM unit, remove the preinstalled CD-ROM drive unit. Perform the following procedures to install a DVD-RAM unit.

- **1** Turn off the server and connected devices, and unplug all power cables from the outlet.
- 2 Remove the side and front covers. →"7.2 Removing and Attaching Covers" (pg.180)
- **3** Remove the IDE cable and power cable from the CD-ROM drive unit.

4 Remove the CD-ROM drive unit.

Pull the CD-ROM drive unit out slowly towards you, keeping the tabs on the 5-inch storage bay rails (on both sides) pressed inward.




5 Detach the 5-inch storage bay rails from the removed CD-ROM drive unit. Remove four screws that fix the 5-inch storage bay rails to detach.




6 Attach the removed 5-inch storage bay rails to the DVD-RAM drive unit.



7 Install the DVD-RAM drive unit.



8 Connect the IDE cable and power cable to the DVD-RAM drive unit. Connect the power cable to the conversion cable that is supplied with the DVD-RAM drive unit,



9 Attach the front and side covers.

203

7.7 Installing a Parallel Port Option

When a parallel port is necessary, install a parallel port option.

POINT

► For the parallel port location, refer to "1.3.2 Server (Rear View)" (→pg.25).



Electric Shock
 When installing or removing a parallel port, turn off the server, all peripheral devices, and any other connected devices. Also unplug all power cables from the outlet.
 Failure to do so can cause electric shock.




Touch only the specified part of the printed circuit board.
Failure to do so could cause injury and also damage the server.
Be careful not to be injured when handling the parallel port connector panel that is removed from the rear of the server.

7.7.1 How to Install a Parallel Port

- **1** Turn off the server and connected devices, and unplug all power cables from the outlet.
- 2 Remove the side cover.→"7.2 Removing and Attaching Covers" (pg.180)
- **3** Touch a metal part of the server to discharge static electricity.


4 Remove the system fan.

Remove the system fan cable and lift the system fan to remove it.




5 Remove the parallel port connector panel from the rear side.


Insert a flat blade screwdriver into the hole at the center of the panel. Move the screwdriver to the right and left and pull the panel off.



6 Connect a parallel cable to the onboard parallel connector and attach the connector of the cable to the rear panel.




7 Secure the connector using screws from the rear side.



8 Attach the system fan.

Connect a system fan cable to the system fan connector to attach the system fan.



9 Attach the side cover.



7.8 Installing a Serial Port

When a serial port is necessary, install an optional serial port.




Electric Shock • When installing or removing a serial port, turn off the server, all peripheral devices, and any other connected devices. Also unplug all power cables from the outlet. Failure to do so can cause electric shock.



• Touch only the specified part of the printed circuit board. Failure to do so could cause injury and also damage the server.

7.8.1 Where to Install a Serial Port

Install a serial port in the PCI slot 5 and connect a serial cable to the serial cable connector.




7.8.2 How to Install a Serial Port

- **1** Turn off the server and connected devices, and unplug all power cables from the outlet.
- **2** Remove the side cover.

→"7.2 Removing and Attaching Covers" (pg.180)

3 Touch a metal part of the server to discharge static electricity.

4 Remove the screw that fixes the slot cover (1), and remove the slot cover (2).



POINT

- Be sure to keep the removed slot cover for later use. When a serial port is removed, attach the slot cover to keep dust away.
- **5** Install a serial port, and connect a serial cable to the serial cable connector.
- **6** Fix the serial port with the screw.
- **7** Attach the side cover.

7.9 Connecting External SCSI Devices

This section explains connection of external SCSI devices.

■ Connectable External SCSI Devices

The following external SCSI devices can be connected to this server.

table: Connectable External SCSI Devices

Product name	Model		
PRIMERGY SX10	PG-R1BC4		

Connecting Backup Cabinet

To connect backup cabinet, install SCSI card (PG-1281) to this server.

Notes on Connecting External SCSI Devices

Settings for SCSI-ID

Be sure to set up each device with no overlaps.

• Daisy Chain Connection

Daisy chain connection is not available for PRIMERGY SX10.

Chapter 8

Configuring Hardware and Utilities

This chapter explains how to make the environment settings necessary to operate the server and how to use each utility.

8.1	Jumper Settings	212
8.2	BIOS Setup Utility	213

8.1 Jumper Settings

The BIOS password setting can be deleted through the jumper settings.


MPORTANT

• Do not change the jumper settings except when deleting the BIOS password.

8.1.1 Jumper Location and Settings

Jumper Location


The jumper of the server is located on the baseboard as shown below.



Jumper

Jumper Settings

To delete password setting, set the jumper as follows:



8.2 BIOS Setup Utility

This section explains settings for the BIOS Setup Utility and items regarding each setting.

8.2.1 Starting and Exiting the BIOS Setup Utility

The following explains how to start and exit the BIOS Setup Utility.

■ How to Start the BIOS Setup Utility

- 1 Turn the server on.
- 2 During POST, press the [F2] key while the message "<F2>BIOS Setup / <F12> BOOT Menu" is displayed on the screen.

The [Main menu] window appears when the POST completes.

	PhoenixBIC	S Setup Utility	
Main Advanced	Security	Server Exit	
System Time: System Date: Diskette A: Standard IDE:	[HH:MM:SS] [MM:DD:YYYY] [1.4M] [******]	I	Item Specific Help
 Boot Options Base Memory: Extended Memory: 	640KB ****M		
F1 Help ↑↓ Select Esc Exit ←→ Select		Change Values Select ► Sub-Menu	F9 Setup Defaults F10 Save and Exit

POINT

When the [Main menu] window does not appear

When the [Main menu] window does not appear because the [F2] is pressed at wrong timing, press the [Ctrl] + [Alt] + [Delete] keys at the same time to restart the system, then start the BIOS Setup Utility.

8

POINT

While the message "<F2> BIOS Setup / <F12> BOOT Menu" is displayed, pressing the [F12] key causes the Boot Menu screen to appear when POST completes.

Boot Menu
 CD-ROM Drive +Diskette +Hard Drive Legacy LAN Card
< ↑ ↓ > Select <enter> Confirm</enter>

• Key Operations in the BIOS Setup Utility

The roles of the keys used for setting the BIOS Setup Utility are as follows:

Key	Description
[F1]	Displays the system information. Press the [Esc] key to close it.
[Esc]	Ends a submenu and returns to the previous menu. Or displays the Exit menu.
[↑][↓]	Scrolls through the menu option list.
[←][→]	Switches between menus.
[-][+]	Changes the value of an item.
[Enter]	Selects an item. In items in which ► is displayed the sub menu appears.
[F9]	Sets each item to its initial (default) value.
[F10]	Saves the value of each item and exits the BIOS Setup Utility.

How to Exit the BIOS Setup Utility

1 Use the $[\leftarrow] [\rightarrow]$ keys to display the [Exit] menu.

PhoenixBIOS Setup Utility									
	Main	Adv	anced	Secur	ity	Server	Exit		
	Save Chai Discard Cl Get Defau Load Prev	nanges It Value	& Exit s					Item	Specific Help
F1 Es	Help c Exit	↑↓ ←→	Select Ite Select M		-/+ Enter	Change Execute	Values Command	F9 F10	Setup Defaults Save and Exit

2 Use the $[\uparrow]$ [\downarrow] keys to select the exit mode.

To save configuration changes before exiting:

Move the cursor to [Save Changes & Exit] and press the [Enter] key.

The message "Save configuration changes and exit now?" is displayed.

To exit without saving configuration changes:

Move the cursor to [Discard Changes & Exit] and press the [Enter] key. When the settings are changed, the "Configuration has not been saved Save before exiting?" message is displayed.

3 Use the [←] [→] keys to move the cursor to [Yes] or [No], and press the [Enter] key.

If you selected [Save Changes & Exit] from the [Exit] menu:

- Select [Yes] to exit. After saving changes to settings, the BIOS Setup Utility closes and the server restarts.
- Select [No] not to exit. The display returns to the BIOS Setup Utility window.

If you selected [Discard Changes & Exit] from the [Exit] menu:

- Select [Yes] to save changes before exit. The BIOS Setup Utility closes and the server restarts.
- Select [No] when not saving the settings.

The BIOS Setup Utility closes and the OS starts.

8.2.2 Main Menu

-							
PhoenixBIOS Setup Utility							
Main Advance	ed Security	Server	Exit				
System Time: System Date: Diskette A: Standard IDE: Boot Options	[HH:MM:SS] [MM:DD:YY [1.4M] [******]			ltem	Specific Help		
Base Memory: Extended Memory:	640KB ***M						
· · · · · ·	ect Item -/+ lect Menu En	0	Values ▶ Sub-Menu		Setup Defaults Save and Exit		

The [Main] menu is initially displayed when you start the BIOS Setup Utility. Settings for time and date and for the drives are configured on the [Main] menu.

table: Items on the Main Menu

Item	Setting	Description			
System Time	Present time	The system time is set in "hours:minutes:seconds" format. The hours should be based on a 24-hour clock. For example, 6:30:00 P.M. is set as "18", "30", "00". If a highly precise system time is necessary, install a network synchronized time system (NTP, etc.).			
System Date Present date		The system date is set in "month:day:year" format. For example, September 20, 2005 is set as "09", "20" "2005".			
Diskette A	1.4M (Unchangeable)	Sets the type of Floppy Disk Drive A (recording density and drive size).			
Standard IDE	· · · · ·	the type and operating mode for connected IDE devices. the [Enter] key to display the "8.2.3 Standard IDE Submenu" (→pg.217) w			
Boot Options	Sets system startup options. Press the [Enter] key to display the "8.2.4 Boot Options Submenu" (→pg.218) window.				
Base Memory	A usable base memory size	of less than 1MB appears.			
Extended Memory	A memory size of more than 1MB appears.				

8.2.3 Standard IDE Submenu

Use this submenu to set the type and operating mode for connected IDE devices. When the drives are installed to Standard IDE Master or Standard IDE Slave, each menu is displayed. Displayed items differ from drive to drive.

			Phoer	nixBIO	S Setup I	Jtility		
Main	Adv	anced	Securi	ty :	Server	Exit		
	Standa	rd IDE:	[*****]				Item	Specific Help
PIO Mode DMA Moo Firmware	le:		PIO 4 UDMA 2 ****					
F1 Help Esc Exit		Select It Select N		-/+ Enter	•	Values Sub-Menu		

table: Items on the Standard IDE Submenu

Item	Setting	Description	
PIO Mode	PIO 4	Displays the current PIO (Programmed I/O) transfer mode. The fastest PIO transfer mode among connected IDE devices is automatically set.	
DMA Mode	UDMA 2	Displays the current DMA (Direct Memory Access) data transfer mode. The fastest DMA transfer mode among connected IDE devices is automatically set.	
Firmware	Displays the version of the firmware.		

8.2.4 Boot Options Submenu

		PhoenixE	BIOS Setup	Utility		
Main	Advanced	Security	Server	Exit		
	I	Boot Options			Item	Specific Help
POST Erro Keyboard SM Error I Fast Boot: Quiet Boo Boot Menu NumLock: MultiBoot	Check: Halt: t: J: for HDs:	[Halt On All [Enabled] [Disabled] [Disabled] [Enabled] [Auto] [Enabled]	Errors]			
F1 Help Esc Exit	↑↓ Select ←→ Select		•	e Values ▶ Sub-Menu	F9 F10	Setup Defaults Save and Exit

Use this submenu to set system startup options.

table: Items on the Boot Options Submenu

Item	Setting	Description
POST Errors	Halt On All Errors (Unchangeable)	Sets whether or not to stop the boot process and shut down the system, in case a POST (Power On Self Test) error is detected.
Keyboard Check	DisabledEnabled (Initial value)	Sets whether or not to check keyboard connection during POST.
SM Error Halt	DisabledEnabled (Initial value)	Sets the procedure in case an error occurs regarding the fan or temperature sensor.
Fast Boot	Disabled (Unchangeable)	Sets whether or not to reduce the scope of POST and thereby speed up system startup.
Quiet Boot	Disabled (Unchangeable)	Sets whether or not to display the logo screen instead of POST information.
Boot Menu	Enabled (Unchangeable)	Sets whether or not to display the boot drive selection window after POST. By selecting the boot drive from the [Boot Menu] window, startup can be done from the selected boot drive regardless of the [Boot Sequence] setting.
NumLock	Auto (Unchangeable)	The state of the NumLock during activation.
MultiBoot for HDs	Enabled (Unchangeable)	Sets whether or not it is possible to specify the order of hard disks to boot the operating system (OS) when multiple hard disk units are installed. To perform a PXE boot, set to [Enabled].

Item	Setting	Description
Boot Sequence	 CD-ROM Drive Diskette Hard Drive Legacy LAN Card Boot Manage PXE, Slot 0A00 (displayed when LAN Remote Boot is set to PXE) 	The order of reading the OS is set by pressing [Enter]. Use the [+] [-] keys to change the order of priority for the selected device. Booting from a selected device can be disabled with the [Space] key. (The mark "!" is displayed by the name of the disabled device.) If a non-existing device is displayed, delete it from the list by pressing the [*] key.

table: Items on the Boot Options Submenu

8.2.5 Advanced Menu

The [Advanced] menu sets the peripheral device and PCI device options.

	PhoenixBIOS Setup Utility					
Main	Advanced	Security	Server	Exit		
Setup Warning Item Specific Help Setting items on this menu to incorrect values may cause your system to malfunction. Item Specific Help						
 PCI Configu Advanced S 	 Peripheral Configuration PCI Configuration Advanced System Configuration Power On/Off IPMI 					
Reset configuration Data: [No]						
F1 Help Esc Exit	↑↓ Select li ←→ Select M		•	Values ▶ Sub-Menu	F9 F10	

table: Items on the Advanced Menu

Item	Setting Description				
Peripheral Configuration	Configures the serial port, parallel port, etc. Press the [Enter] key to display the "8.2.6 Peripheral Configuration Submenu" (→pg.220) window.				
PCI Configuration	Configures the PCI device. Press the [Enter] key to display the "8.2.7 PCI Configuration Submenu" (→pg.222) window.				
Advanced System Configuration	Configures additional settings. Press the [Enter] key to display the "8.2.8 Advanced System Configuration Submenu" (→pg.223) window.				
Power On/Off	Configures power On/Off settings. Press the [Enter] key to display the "8.2.9 Power On/Off Submenu" (→pg.224) window.				
IPMI	Configures server management settings. Press the [Enter] key to display the "8.2.10 IPMI Submenu" (→pg.225) window.				
Reset Configuration Data	Yes Sets whether or not to initialize the Extended System Configuration Data (ESCD) where the system resour are recorded.				

8.2.6 Peripheral Configuration Submenu

Use this submenu to set the serial port, parallel port, etc.

The items not listed in the figure below can be displayed using the scroll bar.

Pho	PhoenixBIOS Setup Utility					
Main Advanced Secu	rity Server Exit					
Peripheral Con	Peripheral Configuration Item Specific Help					
Serial 1: Serial Multplexer: Serial 2: Parallel: Parallel Mode: USB Enable Ports: USB 2.0 Host Controller: USB BIOS Supported Devices: USB Boot Delay: ► ATA Controller Config	[Auto] [System] [Auto] [Auto] [Bidirection] [All] [Enabled] [Auto] [0 s]					
Diskette Controller: Mouse Controller:	[Enabled] [Auto Detect]					
F1 Help ↑↓ Select Item Esc Exit ←→ Select Menu	-/+ Change Values Enter Select ► Sub-Menu	F9 Setup Defaults F10 Save and Exit				

table: Items on the Peripheral Configuration Submenu

Item	Setting	Description
Serial 1	 Disabled Enabled Auto (Initial value) OS Controlled 	 Sets whether to enable or disable the serial port. Set this to "Disabled" when used as a server management port. Note: When [Serial Multiplexer] is changed to "iRMC", set this item to "Disabled".
Serial 1 Address	3F8h (Unchangeable)	Appears when "Enabled" is selected for [Serial 1].
Serial Multiplexer	 System (Initial value) iRMC 	 Switches the function of serial port 1. System Uses this port as a serial port. (Setting at the time of UPS connection) iRMC Uses this port as a server management port. In this case, set [Serial 1] to "Disabled".
Serial 2	 Disabled Enabled Auto (Initial value) OS Controlled 	Sets whether to enable or to disable the serial port.
Serial 2 Address	2F8h, IRQ 3 (Unchangeable)	Appears when "Enabled" is selected for [Serial 2].
Parallel	Auto (Unchangeable)	Sets whether to enable or to disable the parallel port.
Parallel Mode	Bidirection (Unchangeable)	Sets the data transfer mode of the parallel port.
USB Enable Ports	All (Unchangeable)	Sets whether or not to use the USB port.
USB 2.0 Host Controller	Enabled (Unchangeable)	Sets whether or not to enable the USB controller (2.0 standard).

Item	Setting	Description
USB BIOS Supported Devices	Auto (Unchangeable)	Sets whether the USB device can be used on the OS that does not support USB.
USB Boot Delay	Os (Unchangeable)	Sets the delay time by the second for initializing USB mass storage device during the POST.
ATA Controller Config	Press the [Enter] key to displa cannot be changed.	y the [ATA Controller Config] submenu. These items
S-ATA Mode	Native (Unchangeable)	Sets the serial ATA operation mode.
P-ATA Maps To	Secondary (Unchangeable)	Sets the parallel ATA mapping. This item is displayed when "S-ATA" is set to "Compatible".
Primary IDE Channel	Enabled (Unchangeable)	Sets whether or not to enable primary IDE channel.
Tertiary IDE Channel	Enabled (Unchangeable)	Sets whether or not to enable IDE channel.
Quaternary IDE Channel	Enabled (Unchangeable)	Sets whether or not to enable IDE channel.
Diskette Controller	Enabled (Unchangeable)	Configures the floppy disk controller.
Mouse Controller	Auto Detect (Initial value)	Sets whether or not to use the mouse connected to the mouse port.
LAN Controller	Enabled (Unchangeable)	Sets whether to enable or disable the onboard LAN controller.
LAN Remote Boot	 Disabled (Initial value) Enabled 	Sets whether or not to perform a network boot. This function allows booting the server via the network. It is used for remote installation of the OS, etc. You can set this item only when [LAN Controller] is set to [Enabled].
Management LAN	Enabled (Unchangeable)	Sets whether to enable or disable the port for the Remote Management Controller.
SAS Controller	Enabled (Unchangeable)	Sets whether to enable or disable the onboard SAS controller.
SAS Option ROM Scan	Enabled (Unchangeable)	Sets whether or not to initialize the extended ROM.

table: Items on the Peripheral Configuration Submenu

8.2.7 PCI Configuration Submenu

Use this submenu to set the PCI device.

	PhoenixBIOS Setup Utility					
Main	Advanced	Security	Server Exit			
	PCI	Configuration		Item	Specific Help	
	S Configuration: Configuration:					
F1 Help Esc Exit	↑↓ Select If ←→ Select N		0		Setup Defaults Save and Exit	

table: Items on the PCI Configuration Submenu

Item	Setting	Description
PCI SLOTS Configuration	Configures the PCI slots. Pr Configuration] submenu wit	ess the [Enter] key to display the [PCI SLOTS ndow.
PCI Slot 1 Configuration Option ROM SCAN	EnabledDisabled (Initial value)	Sets whether or not to initialize the extended ROM in each PCI slot.
PCI Slot 2 Configuration Option ROM SCAN	Enabled (Initial value)Disabled	
PCI Slot 3 Configuration Option ROM SCAN	EnabledDisabled (Initial value)	
PCI-E Slot 6 Configuration Option ROM SCAN	EnabledDisabled (Initial value)	
PCI-E Slot 7 Configuration Option ROM SCAN	EnabledDisabled (Initial value)	
PCI IRQ Configuration Sets PCI IRQs for the PCI st Configuration] submenu win		lots. Press the [Enter] key to display the [PCI IRQ ndow.
PCI IRQ Line 1–8	Auto (Unchangeable)	Sets the PCI IRQ.

8.2.8 Advanced System Configuration Submenu

Pr	noenixBIOS Setup Utility	
Main Advanced Sec	curity Server Exit	
Advanced System	n Configuration	Item Specific Help
ECC Memory Checking: PCI Bus Parity Checking: BIOS Work Space Location: CPU Frequency(GHz): Limit CPUID Functions: CPU Mismatch Detection CPU Thermal Management: CPU Halt Mode: NX Memory Protection: Virtualization Technology: Hardware Prefetch: Adjacent Sector Prefetch CPU Timeout Counter	[Enabled] [Enabled] [Expansion ROM Area] [Automatic] [Disabled] [Enabled] [Enhanced] [Disabled] [Enabled] [Enabled] [Enabled] [Enabled] [Disabled]	
F1 Help ↑↓ Select Item Esc Exit ←→ Select Menu	-	F9 Setup Defaults F10 Save and Exit

Use this menu to configure the settings which are related to CPU, memory and USB.

table: Items on the Advanced System Configuration Submenu

Item	Setting	Description
ECC Memory Checking	Enabled (Unchangeable)	Sets whether to enable or disable to check ECC error of memory.
PCI Bus Parity Checking	Enabled (Unchangeable)	Sets whether to enable or disable the PCI bus parity checking.
BIOS Work Space Location	Expansion ROM Area (Unchangeable)	Sets the location on the memory to assign the data area that BIOS uses.
Limit CPUID functions	Disabled (Unchangeable)	Sets whether or not to limit CPUID expanded function. If the OS does not support expanded function, the system may not start.
CPU Mismatch Detection	Enabled (Unchangeable)	Sets whether to enable or disable checking the CPU type and frequency.
CPU Thermal Management	Enhanced (Unchangeable)	Configures the CPU internal setting.
CPU Halt Mode	Enhanced (Unchangeable)	
NX Memory Protection	Disabled (Initial value)Enabled	Sets whether to enable or disable "execute disable bit function" of processor.
Virtualization Technology	Disabled (Initial value)Enabled	Sets whether to enable or disable Virtualization Technology.
Hardware Prefetch	Enabled (Unchangeable)	Configures the CPU internal setting.
Adjacent Sector Prefetch	Enabled (Unchangeable)	
CPU Timeout Counter	Disabled (Unchangeable)	
Enhanced SpeedStep	Disabled (Initial value)Enabled	Sets whether to enable or disable the power saving function.
CPU MC Status Clear	Next Boot (Unchangeable)	Configures the CPU internal setting.

8

Item	Setting	Description
Discard Timer Mode	1024 clocks (Unchangeable)	Configures the delayed transfer of PCI bus burst transfer.
SMART Device Monitoring	Enabled (Unchangeable)	Sets whether or not to monitor SMART device.
High Precision Event Timer	Disabled (Unchangeable)	Sets whether or not to use the high precision timer of the chipset.

table: Items on the Advanced System Configuration Submenu

8.2.9 Power On/Off Submenu

Use this submenu to configure power On/Off settings.

F	PhoenixBIOS Setup Utility	
Main Advanced Se	ecurity Server Exit	
Power	On/Off	Item Specific Help
Power-on Source Remote: LAN: Wake up Timer: Wake up Time: Wake up Mode:	[Bios Controlled] [Disabled] [Enabled] [Disabled] [00:00:00] [Dally]	
Power-Off Source Software: Power Button: Power Failure Recovery:	[Enabled] [Enabled] [Previous State]	
F1 Help ↑↓ Select Item Esc Exit ←→ Select Menu	° °	

table: Items on the Power On/Off Submenu

Item	Setting	Description
Power On Source	BIOS Controlled (Unchangeable)	Configures the power-on setting.
Remote	Disabled (Initial value)Enabled	Sets whether or not the power is turned on when the modem (connected to the serial port) receives a ring signal.
LAN	DisabledEnabled (Initial value)	Sets whether or not to enable the power to be turned on via LAN.
Wake Up Timer	Disabled (Unchangeable)	Sets whether or not the power is turned on at a certain time or after a certain time has passed. A separate program is necessary for setting startup time. Sets the following items if [Wake Up Timer] is set to [Enabled].
Wake Up Time	Sets the startup time when using [Wake Up Timer].	
Wake Up Mode	Daily (Unchangeable)	Sets the startup mode when using [Wake Up Timer].

	Item	Setting	Description
Po	wer Off Source		
	Software	Enabled (Unchangeable)	Sets whether or not to enable the power to be turned off using a program or the operating system.
	Power Button	Enabled (Unchangeable)	Sets whether or not to allow the use of the power switch for turning the power off, when the ACPI function is disabled.
Power Failure Recovery		 Always On Always Off Previous State (Initial value) 	 Sets whether to turn the power on or off after a temporary main power outage due to power interruption, etc. Note: For UPS scheduled operation, set to [Always On]. Otherwise, the power may not be turned on at the specified time.

table: Items on the Power On/Off Submenu

8.2.10 IPMI Submenu

Use this submenu to configure server management settings.

PhoenixBIOS Setup Utility		
Main Advanced	Security Server	Exit
	IPMI	Item Specific Help
SEL Load Clear System Event Log Event Log Full Mode iRMC Time Sync System Event Log SDRR Browser LAN Setting	xx% [Disabled] [Overwrite] [Enabled]	
F1 Help ↑↓ Select Iter Esc Exit ←→ Select Me	•	ValuesF9Setup DefaultsSub-MenuF10Save and Exit

table: Items on the IPMI Submenu

Item	Setting	Description
SEL Load	Displays the usage of even	t log space as a percentage.
Clear System Event Log	Disabled (Unchangeable)	Sets whether or not to clear the event log.
Event Log Full Mode	Overwrite (Unchangeable)	Sets whether or not to overwrite the event log when space available for it becomes full.
		 Note: Changing this setting deletes the existing event log. Before making changes, refer to "9.3.1 How to Use Server Management Tools" (→pg.252) for saving the event log.

8

225

Item	Setting	Description
iRMC Time Sync	Enabled (Unchangeable)	Synchronizes the internal clock of the Baseboard Management Controller (BMC) with the system time.
System Event Log	Displays the system event logs. Press the [Enter] key to display the system event log window. Display previous and subsequent entries using [+] [-] keys.	
SDRR Browser	Displays sensor information. The SDRR Browser is displayed by pressing [Enter].	
LAN Setting	Configures the LAN settings of the Remote Management Controller port. This setting is required when performing the remote operation using RemoteControlService. Press the [Enter] key to display the "■ LAN Settings Submenu" (→pg.226) window.	
Reset Configuration DATE	YesNo (Initial value)	Sets whether or not to reset plug and play information which is saved in ESCD (Extended System Configuration Data) at the booting.

table: Items on the IPMI Submenu

■ LAN Settings Submenu

Use this submenu to configure LAN settings when performing the remote operation using RemoteControlService.

table: Items on the LAN Settings Submenu

Item	Setting	Description
DHCP	Disabled (Initial value)Enabled	Sets whether or not to obtain LAN IP address of the Remote Management Controller port from the DHCP server.
Local IP address	 Enter an IP address for the Remote Management Controller port. Note: Set an IP address different from that in OS settings. 	
Subnet mask	Sets the subnet mask of the Remote Management Controller port that is specified for "Local IP address".	
Gateway address	Sets the gateway address of the Remote Management Controller port that is specified for "Local IP address".	

8.2.11 Security Menu

	PhoenixBIOS Setup	Utility
Main Advanced	Security Server	Exit
Setup Password: System Password:	Not installed Not installed	Item Specific Help
Set Setup Password: Setup Password Lock: Set System Password: System Password Mode: System Password Lock:	[Press Enter] [Standard] [Press Enter] [System] [WOL Skip]	
System Load: Setup Prompt: Virus Warning:	[Standard] [Enabled] [Disabled]	
Diskette Write: Flash Write:	[Enabled] [Enabled]	
F1 Help ↑↓ Select I Esc Exit ←→ Select M	•	Values F9 Setup Defaults ▶ Sub-Menu F10 Save and Exit

table: Items on the Security Menu

Item	Setting	Description				
Setup Password	Displays the setting of a password (setup password) that is used for security of BIOS setup.Not Installed: A password has not been set.Installed: A password has been set.					
System Password	Displays the setting of a password (system password) that is used for security of system start-up.Not Installed: A password has not been set.Installed: A password has been set.					
Set Setup Password	Sets a setup password. Setting a setup password makes it necessary to enter the password in order to start the BIOS Setup Utility. Press the [Enter] key to display the password entry screen. Enter the setup password. For more details, refer to "9.4.2 Security against Unauthorized Use" $(\rightarrow pg.256)$.					
Setup Password Lock	 Standard (Initial value) Extended Keyboard can be locked while initializing expansion card. When the expansion card that ca execute the setup during system start-up is installe the setting of the expansion card can be protected by locking the keyboard. You can set this item only when [Setup Password is specified. 					
Set System Password	Sets a system password. Setting a system password makes it necessary to enter the password in order to access this server. [Setup Password] must be specified. Press the [Enter] key to display the password input window. Enter the setup password. For more details, refer to "9.4.2 Security against Unauthorized Use" (→pg.256).					

Item	Setting	Description
System Password Mode	 System (Initial value) Keyboard 	 Sets the password entering for system start-up. You can set this item only when [System Password] is specified. System System The password entry screen is displayed when the system is started. You can unlock the system with the password. Keyboard A password is not required. Keyboard and mouse are locked to prevent the operation. You can unlock the system by entering the password on the keyboard and pressing the [Enter] key.
System Password Lock	StandardWOL Skip (Initial value)	Sets whether or not to skip entering the password when the system is started with Wakeup on LAN. You can set this item only when [System Password Mode] is set to [System].
System Load	Standard (Initial value)Diskette/CDROM Lock	Sets whether to enable or disable system startup from a floppy disk or CD-ROM.
Setup Prompt	DisabledEnabled (Initial value)	Sets whether or not to display a setup message " <f2>BIOS Setup/<f12>BOOT Menu" on the [POST] window during system startup.</f12></f2>
Virus Warning	Disabled (Unchangeable)	Sets whether or not to check the boot sector of the hard disk drive after the previous system startup. If the boot sector is changed without a clear reason, it is necessary to scan the system for computer viruses with a virus detection program.
Diskette Write	DisabledEnabled (Initial value)	Sets whether or not to allow writing on a floppy disk.
Flash Write	DisabledEnabled (Initial value)	Sets whether or not to allow writing on the BIOS Flash ROM.

table: Items on the Security Menu

8.2.12 Server Menu

Diagnostic System:

CPU Status
Memory Status
Console Redirection

Help

Esc Exit

F1

Temperature Monitoring:

↑↓

←→

ſ			PhoenixBl	OS Setup	Utility	
	Main	Advanced	Security	Server	Exit	
	[
	O/S Boot 1	Time out	[Dischlad]			Item Specific Help
1		nmeout:	[Disabled]			
1	Action:		[Reset]			
1	Timeout	Value:	[0]			
	ASR&R B	oot Delay:	[2]			
	Power Cyc	cle Delay:	[7]			
	Boot Retry	Counter:	[3]			
- 1		- ·				

[Disabled]

[Disabled]

-/+

Enter

Select Item

Select Menu

The [Server] menu sets the server options.

table: Items on the Server Menu

Setup Defaults

Save and Exit

F9

F10

Change Values

Select ► Sub-Menu

Item	Setting	Description
O/S Boot Time out	 Disabled (Initial value) Enabled 	Sets whether to enable or disable the OS Boot Monitoring function, when ServerView is installed to the OS. When this function is enabled, if for some reason booting the operating system is interrupted, the system will automatically restart. The OS Boot Monitoring function can also be enabled or disabled from ServerView.
		 Note: If ServerView is not installed to the OS, be sure to set to [Disabled]. If the setting is enabled, the server may automatically turn off or restart improperly. Even when ServerView is installed to the OS, if starting the system while the ServerStart CD-ROM or DOS diskette is inside, be sure to disable the OS Boot Monitoring function. If the system is started with this function enabled, the server may automatically turn off or restart improperly. When setting this function, refer to "ServerView User's Guide" to fully learn about its specifications, in order to use it properly with the correct settings.
Action	ContinueReset (Initial value)Power Cycle	Sets the operation when the OS did not boot successfully within the time set with the [Timeout Value] setting.
Timeout Value	0 (Initial value)1–100	Sets the timeout period in minutes.

8

Item	Setting	Description			
ASR&R Boot Delay	 2 (Initial value) 1–30	Sets the standby time for startup after shutdown due to trouble (such as overheating) in minutes. The system restarts after the set standby time.			
Power Cycle Delay	 7 (Initial value) 0-15	Sets the time until the server is turned on after it is turned off.			
Boot Retry Counter	 3 (Initial value) 0–7	Sets the maximum number of retries to boot the operating system within the range of 0 to 7.			
Diagnostic System	Disabled (Unchangeable)	Sets whether or not to diagnose the BootDevice when restarting with ASR&R.			
Next Boot uses	Boot option (Unchangeable) Sets the boot device for restarting.				
Device Instance	1 (Unchangeable) Sets the device ID of LAN Boot Device diagnosis				
Temperature Monitoring	 Disabled (Unchangeable) Enabled Sets whether or not the server can be turned on whether the temperature is not in its operating environment range (10-35 °C). 				
CPU Status	Press the [Enter] key to display the "■ CPU Status Submenu" (→pg.230) window.				
Memory Status	Press the [Enter] key to display the "■ Memory Status Submenu" (→pg.230) window.				
Console Redirection	Press the [Enter] key to display the "■ Console Redirection Submenu" (→pg.231) window.				

table: Items on the Server Menu

■ CPU Status Submenu

This submenu sets whether or not to allow the use of the installed CPU.

table: Items on the CPU Status Menu

Item	Setting	Description
CPU 0 Status	Enabled (Unchangeable)	Sets whether or not to allow the use of CPUs installed in CPU Socket 0.

Memory Status Submenu

This submenu sets whether or not to allow the use of the installed memory.

table: Items on the Memory Status Menu

Item	Setting	Description
DIMM-1A	Enabled (Unchangeable)	Sets whether or not to allow the use of memory in
DIMM-2A		Memory Slots 1A to 2B.
DIMM-1B		
DIMM-2B		

■ Console Redirection Submenu

This submenu configures detailed settings for console redirection.

Item	Setting	Description
Console Redirection	Disabled (Initial value)Enabled	Sets whether to enable or disable console redirection. When set to [Enabled] the following parameters appear. Set each of them. If set to [Disabled], the items are not displayed.
Port	Serial1 (Initial value)Serial2	Sets the serial port to be used for console redirection.
Baud Rate	 1200 2400 4800 9600 (Initial value) 19.2K 38.4K 57.6K 115.2K 	Sets the speed of the console redirection connection (in bps).
Protocol	 VT100 VT100,8bit PC-ANSI,7bit PC-ANSI VT100+ (Initial value) 	Sets the console type for console redirection.
Flow Control	NoneXON/XOFFCTS/RTS (Initial value)	Sets flow control for console redirection.
Mode	StandardEnhanced (Initial value)	Sets the range of use for console redirection.

table: Items on the Console Redirection Menu

8

8.2.13 Exit Menu

This menu exits the BIOS Setup Utility.

\bigcap				Phoe	nixBIO	S Setup U	tility		
	Main	Adv	anced	Secur	ity	Server	Exit		
	Discard Get Dei	hanges & Changes ault Value evious Va	s & Exit es					Item	I Specific Help
F	1 Help sc Exit	1 T	Select It Select N		-/+ Enter	Change \ Execute (F9 d F10	Setup Defaults Save and Exit

Select the option for handling BIOS settings when exiting the utility.

table: Items on the Exit Menu

Item	Description
Save Changes & Exit	Save the current settings and exit the BIOS Setup Utility. After it exits the server reboots.
Discard Changes & Exit	Exits the BIOS Setup Utility without saving current settings. Previously saved settings remain valid.
Get Default Values	Returns to the server's default values for all items.
Load Previous Values	Sets all items to the values before the last changes by reading from CMOS. Current setting values are discarded.

Chapter 9

Operation and Maintenance

This chapter explains the operations that become necessary after starting to use this server as well as daily care and maintenance.

Daily Maintenance	234
Troubleshooting	237
System Event Log	252
Security	255
Backup	259
Restoring the System	262
Reinstalling the OS	264
Maintenance Service	265
	Troubleshooting

9.1 Daily Maintenance

This section explains how to check the status of the operating server, as well as how to perform daily maintenance.

Information for PRIMERGY

For the latest information on PRIMERGY, update modules, drivers and the software, refer to the Fujitsu PRIMERGY website. http://primergy.fujitsu.com

9.1.1 Checking the Server Condition

Checking Each LED

This server is equipped with LEDs that display various hardware conditions. Check the server status via each LED after starting the server. For positions and functions of each status LED, refer to "1.3 Component Names and Functions" (\rightarrow Pg.22).

Server Monitoring Tool (ServerView)

ServerView is software that monitors whether the server hardware is in a normal state in order to protect important server resources. When using ServerView, the server hardware is monitored all the time. If an error that could cause trouble is detected, the administrator is notified in real-time which enables early detection. This allows the server administrator to remove a system error early and avoid trouble. For an overview and installation of ServerView and other high reliability tools, refer to "1.2.2 High Reliability Tools" (\rightarrow Pg.20) and "Chapter 6 High Reliability Tools" (\rightarrow Pg.171).

9.1.2 Cleaning

Clean the server regularly.



Electric Shock • Before cleaning, turn off the server and unplug the power cables from the outlets. Also power off peripherals and disconnect them from the server. Failure to do so may cause electric shock (\rightarrow "1.4.4 Turning Off the Server" (Pg.34)).

Cleaning the Server

Wipe with a soft, dry cloth. For stains that do not come off with a dry cloth, wipe with a cloth lightly dampened with a mild detergent. Once the stain has been removed, wipe off any remaining detergent with a cloth dampened with water. When wiping the server, be sure that no moisture enters the server machine.

Do not use solvents. Use a mild detergent only. Otherwise, the server may be damaged. Use a vacuum cleaner periodically to prevent dust buildup in ventilation holes.

POINT

In dusty environments, dust piles up on the front and rear panels of the server over short periods. Install the server in a different location to avoid failures.

■ Cleaning the Server Interior

In dusty environments, dust deposits in the server. Dust deposits may cause a server failure, fire, or electric shock. To keep the PRIMERGY server in good condition, use a vacuum cleaner periodically to remove dust deposits.

POINT

Cleaning components

- CPU: Dust deposits must be removed because it will impair the cooling performance.
- Fan: Remove dust from and around the fan.
- Memory / Expansion cards: Remove dust between memory modules and between expansion cards. Remove dust from the connector before adding a memory module or an expansion card.
- Internal hard disk units / 5-inch internal devices: Remove dust deposits from units and devices. Tape devices are particularly susceptible to dust and may cause failures. Install them in a clean environment.



Electric Shock • Do not disassemble the PSU when cleaning the server interior. Doing so can cause failures or electric shock.

MPORTANT.

- Be careful when removing components such as CPU, memory modules, or hard disk units. Be sure to install parts and cables in the original position.
- Leaving dust on the server can cause failure. Be sure to remove any dust from the server.

Cleaning the Keyboard

Wipe with a soft, dry cloth.

Cleaning the Mouse

Wipe the surface with a soft, dry cloth. If the tracking ball does not spin or roll smoothly, remove the ball and clean it.

Cleaning Method

1 Remove the cover from the base of the mouse.

Remove the cover by rotating it in the direction of the arrow.




2 Remove the ball and rinse it with water.

Flip the mouse over to remove the ball. Afterwards, wash it with water.



3 Clean the inside of the mouse.

Wipe the inside of the mouse, the roller, and the bottom cover with a damp cloth.



4

Insert the ball and apply the cover.

After the ball and inside of the mouse are dry, insert the ball and apply the cover.

Cleaning the Floppy Disk Drive

Prolonged use of the floppy disk drive accumulates dust on the device head (the part which reads/writes data). A dirty head can impair the ability to read/write data to/from a floppy disk correctly. Clean the head once every three months.

Cleaning Method

- **1** Insert the cleaning disk into the floppy disk drive.
- **2** Access the floppy disk drive from the OS.
 - For Windows, access it via Explorer.
 - For Linux, execute the "mount" or "dd" commands of the floppy disk drive.

The process is completed when an error message such as indicating that the disk cannot be read is displayed.

3 Remove the cleaning disk from the floppy disk drive.

Optional Devices

For details about cleaning optional devices, refer to "PRIMERGY ServerBooks" supplied with the server, and "Supplement" supplied with options.

9.2 **Troubleshooting**

This section explains the resolutions when the server is not running properly or when error messages are displayed.

For each situation, refer to the following.

- Hardware problems: "9.2.1 Hardware Troubleshooting"
- Error messages: "9.2.2 Error Messages" (→Pg.239)
- Software problems: "9.2.3 Software Troubleshooting"

If the problem is not resolved after performing these troubleshooting, contact an office listed in the "Contact Information" of "Start Guide".

When contacting your maintenance engineer, refer to "9.8.1 Contacting Maintenance Support" $(\rightarrow Pg.265)$ and collect the required information.

Information for PRIMERGY

For the latest information on PRIMERGY, update modules, drivers and the software, refer to the Fujitsu PRIMERGY website. http://primergy.fujitsu.com

9.2.1 Hardware Troubleshooting

This section explains hardware related troubleshooting. If it does not operate properly or if a failure is suspected, check the following.

For optional devices, refer to "PRIMERGY ServerBooks" supplied with the server, and "Supplement" supplied with options.

Server

• The server does not power on, or the power LED on the front of the server does not light up.

Check to see whether the power cable is properly connected to the outlet. For instructions on connecting the power cable, refer to "Start Guide".

• The access LED does not light up.

The server may be damaged. Contact an office listed in the "Contact Information" of "Start Guide". When contacting your maintenance engineer, refer to "9.8.1 Contacting Maintenance Support" $(\rightarrow Pg.265)$ and collect the required information.

• An error message is displayed.

Adopt suitable measures, referring to "9.2.2 Error Messages" (→Pg.239).

Display

The display does not power on.

Check to see whether the power cable of the display is properly connected to the outlet. For details, refer to "Start Guide" and the manual of the display.

The screen is distorted when Linux shuts down.

Although the screen display may be distorted when shutting down the system in the Linux environment, the system is shut down normally. This has no harmful effect on the system.

Nothing is displayed on the screen.

- Check to see whether the display cable is connected properly. If it is not connected, turn the server off and then connect the cable. For the connection location, refer to "Start Guide".
- Check that the brightness volume and contrast volume of the display are adjusted correctly. If they
 need to be adjusted, perform the necessary adjustments.
 For details, refer to the manual of the display.
- There may be an error in the system area of the memory. Contact an office listed in the "Contact Information" of "Start Guide".

Typing the keyboard does not display any characters, or the mouse cursor does not move.

Check to see whether the keyboard and mouse are connected properly. If they are not connected, turn the server off and then connect the cables to the server. For the connection location, refer to "Start Guide".

• The screen shakes.

If a device that produces a strong magnetic field such as a television or speaker is near the display, place them further away from the display.

The display may also shake if a nearby cell-phone receives a call. Do not use a cell-phone near the display.

Floppy Disk Drive

• Cannot read or write to the floppy disk.

The head may be dirty. Clean the drive using a cleaning disk. For cleaning methods, refer to "9.1.2 Cleaning" (\rightarrow Pg.234).

Cannot write to the floppy disk.

The write protection of the floppy disk may be applied. Flip the switch on the disk to allow writing.

SCSI Device (Internal / External)

• The unit does not operate properly.

- Check to see whether the internal cable is connected properly. If it is not connected, correctly connect the internal cable. For the connection location, refer to "7.6.2 Installable 5-inch Internal Devices and Notes" (→Pg.199).
- For SCSI devices, check to see whether the SCSI ID and terminator are set correctly. If they are not set, correctly set the SCSI ID and terminator.

CD-ROM Drive Unit / DVD-RAM Drive Unit

Cannot read data.

- Check to see whether the CD-ROM is inserted properly. If it is not inserted, correctly insert the CD-ROM so that the label is facing up.
- The CD-ROM may be dirty. If it is dirty, wipe it with a soft, dry cloth.
- The CD-ROM may be scratched or bent. If scratched or damaged, replace the CD-ROM.

• The unit does not operate properly.

Check to see whether the internal cable is connected properly. If it is not connected, correctly connect the internal cable.

9.2.2 Error Messages

POST Error Messages

This section explains error messages of Power On Self Test: a device check performed during the server startup (POST).

If an error occurs during POST, the following messages are displayed.

POINT

- When checking/changing the settings of the BIOS Setup Utility, refer to "8.2 BIOS Setup Utility" (→Pg.213).
- ► For instructions on checking peripheral connections, refer to "Start Guide".
- ► For details on installing internal options, refer to "Chapter 7 Installing Hardware Options" (→Pg.177).

Message	Description
Failure Fixed Disk	IDE device error. Confirm the [Parallel ATA] setting on the [Main] menu of the BIOS Setup Utility. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Stuck Key	Keyboard error. Check whether the keyboard is connected
Keyboard error	properly. If the message still appears, the keyboard must be replaced.

table: List of POST Errors

Message	Description
Keyboard controller error	Keyboard controller error. Release any keys held down on the keyboard. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
System RAM Failed at offset: ******h	Memory error. Power off the server and turn it back on. If the
Shadow RAM Failed at offset: ******h	message still appears, check the error log and replace the faulty memory module.
Extended RAM Failed at address line: ****h	
Memory type mixing detected	The installation configuration of the memory is wrong. Verify that the same types of memory modules are installed in the slots of the same bank. If the message displays even though the installation is correct, replace the memory module.
Memory decreases in Size	Memory error. Due to a memory failure, available memory capacity is less than the capacity of the installed memory. Check the error log and replace the faulty memory module. If the message still appears after the replacement, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Non Fujitsu Siemens Memory Module detected - Warranty restricted!	Memory error. Check that the jumper pin settings and BIOS Setup Utility settings are correct. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
System battery is dead - Replace and run SETUP	Battery error. Contact an office listed in the "Contact Information" of "Start Guide".
System CMOS checksum bad - Default configuration used	The CMOS setting is invalid. Correct the current settings with the BIOS Setup Utility or restore the settings to the initial values. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
System timer error	System clock error. Power off the server and turn it back on. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Real time clock error	Real Time Clock (RTC) error. Start the BIOS Setup Utility and enter the current time. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Check date and time settings	The set date and time are invalid. Start the BIOS Setup Utility and enter the current date and time. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Previous boot incomplete - Default configuration used	 POST did not complete during the last startup. Be sure to perform the following operation. Failure to do so can result in the OS not starting or the server not operating correctly. 1. Start the BIOS Setup Utility. 2. From the [Exit] menu, select [Save Changes & Exit] and press the [Enter] key. The message "Save configuration changes and exit now?" is displayed. 3. Select [Yes] and press the [Enter] key. The BIOS Setup Utility closes and the server restarts.

Message	Description
CPU had been changed - Run SETUP	The CPU has been replaced. If the correct CPU is installed and this message is displayed, select [Yes] for the [Reset Configuration Data] setting on the [Advanced] menu of the BIOS Setup Utility. If the message still appears, the CPU or baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
CPU mismatch detected Available CPUs do not support the same bus frequency- system halted!	The CPU frequency has changed. If the correct CPU is installed and this message is displayed, update the BIOS using the BIOS Update Utility supplied with the CPU. If the message still appears after the update, select [Yes] for the [Reset Configuration Data] setting on the [Advanced] menu of the BIOS Setup Utility. If the message still appears, the CPU or baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Baseboard Management Controller Error	BMC error. Power off the server and turn it back on. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Diskette drive A error	Floppy disk drive error. Check whether the floppy disk drive
Diskette drive B error	cable is connected properly. Also check the settings of [Diskette A] or [Diskette B] on the [Main] menu of the BIOS
Incorrect Drive A type - run SETUP	Setup Utility.
Incorrect Drive B type - run SETUP	
System cache Error - Cache disabled	System cache error. Power off the server and turn it back on. If the message still appears, check the error log and replace the CPU if it is faulty. Else, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Verify CPU Frequency selection in Setup	CPU error. Power off the server and turn it back on. If the message still appears, check the error log and replace the CPU if it is faulty. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
CPU runtime error (IERR#) detected	Installed CPU error. Check the error log and replace the CPU. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Correctable memory error in module X	Memory error. Check the error log and replace the memory
Uncorrectable memory error	module. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information of "Start Guide".
Memory configuration has changed - Run SETUP	DRAM error. The DRAM size has changed since the last startup. Check the error log and replace the memory module. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
No usable system memory	Memory error. No memory modules available to the system are detected. Check the error log and replace the memory module. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide". After the replacement, enable the use of the memory in the BIOS Setup Utility.

9

table:	List of POST Errors
Message	Description
Memory module disabled! This module is no longer available for the operating system.	Memory error. Turn off the server and check whether the memory module is installed correctly. If the message still appears, check the error log and replace the memory module. If the message still appears after the replacement, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Manually-operated Retention Latch is not closed at Hot-Plug PCI slot x	The card guide is not closed. Check whether the card guide is closed. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
No usable CPU	Installed CPU error. Replace the CPU. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide". After the replacement, enable the CPU in the BIOS Setup Utility.
Patch for installed CPU not loaded. Please run the bios flash update diskette.	Check that the correct CPU is installed. If the correct CPU is installed and the message is displayed, select [Yes] for the [Reset Configuration Data] setting on the [Advanced] menu of the BIOS Setup Utility. If the message still appears, the CPU or baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
CPU disable! CPU is no longer available for the operating system.	CPU error. No CPUs available to the system are detected. Check the error log and replace the CPU. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide". After the replacement, enable the use of the CPU in the BIOS Setup Utility.
Invalid System Configuration Data	The system configuration is invalid. Select [Yes] for the [Reset Configuration Data] setting on the [Advanced] menu of the BIOS Setup Utility.
Resource Conflict	IRQ, DMA, or I/O address conflicts between an onboard device and an expansion card. Check and modify the configuration using the BIOS Setup Utility. If the message still appears, the expansion card or baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
IRQ not configured	The IRQ for an onboard device or an expansion card is not configured. Check and modify the configuration using the BIOS Setup Utility. If the message still appears, the expansion card or baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Expansion ROM not initialized	Initialization error of the PCI extended ROM. Disconnect the initialized device/card on the screen and replace the card. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Allocation error static node #	An onboard device or an expansion card cannot be used. Disconnect the device/card and replace the card. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
Baseboard Management Controller has detected an Error	BMC error. The error log needs to be checked and the relevant part(s) replaced. Contact an office listed in the "Contact Information" of "Start Guide".

Message	Description
iRMC reports sensor status: CRITICAL temp	Abnormal temperature. Check the operating environment. If the message still appears, the error log needs to be checked and the relevant part(s) replaced. Contact an office listed in the "Contact Information" of "Start Guide".
iRMC reports sensor status: WARNING temp	
iRMC reports sensor status: CRITICAL Volt- ages	Power voltage error. Turn off the server and unplug the power cable from the outlet. Then, reconnect the power cable and turn on the server. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
iRMC reports sensor status: CRITICAL Battery	Voltage of a battery error. Turn off the server and unplug the power cable from the outlet. Then, reconnect the power cable and turn on the server. If the message still appears, the baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
iRMC reports sensor status: WARNING Battery	
iRMC reports sensor status: CRITICAL FAN1 SYS	System fan error. Check whether there are any obstacles interfering with the rotation of the system fan. If the message still appears, the system fan or baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".
RMC reports sensor status: CRITICAL FAN PSU1	PSU fan error. Check whether there are any obstacles interfering with the rotation of the PSU fan. If the message still appears, the PSU fan or baseboard must be replaced. Contact an office listed in the "Contact Information" of "Start Guide".

Server Management Tools Error Messages

The following error messages may appear while executing Server Management Tools. In such cases, perform the corresponding resolutions. If messages other than the following are displayed, contact an office listed in the "Contact Information" of "Start Guide".

Message	Description
Write protect error writing drive A. Abort, Retry, Fail?	The inserted floppy disk is write-protected. Disable the write-protect, and then press the [R] key.
Not ready writing drive A. Abort, Retry, Fail?	The floppy disk is not inserted into the floppy disk drive. Insert the proper floppy disk ("Server Management Tools" disk), and then press the [R] key.
ERROR:Fail to create data file.	The following are possible causes. Check the floppy
ERROR:Fail to write 1st CMOS data into data file. nn	disk status again. • The floppy disk is write-protected. Disable the
ERROR:Fail to write 2nd CMOS data into data file. nn	write-protect and retry.
ERROR:Fail to write ESCD data into the data file. nn	• The floppy disk is not inserted into the floppy disk
ERROR:Fail to write SEEPROM data into the data file. nn	 drive. Insert the proper floppy disk, and then retry. There is an error in the contents of the floppy disk. Create "Server Management Tools" again. If this occurred while recovering BIOS information, configure the information using the BIOS Setup Utility. Then store the BIOS information.
ERROR:Fail to open data file.	The file for recovering the BIOS information does not exist on this floppy disk. Insert the floppy disk on which the BIOS information was stored, and then retry.
ERROR:Fail to write 1st CMOS data into system. nn	The following are possible causes. Check the floppy
ERROR:Fail to write 2nd CMOS data into system file.	 disk status again. The floppy disk is not inserted into the floppy disk drive. Insert the proper floppy disk, and then retry.
ERROR:Fail to write ESCD data into system file. nn	• A different model or an unsupported version of
ERROR:Fail to write SEEPROM data into system. nn	 BIOS information. Insert the proper floppy disk, and then retry. The floppy disk contains abnormal contents. Create "Server Management Tools" again. If this occurred while recovering BIOS information, configure the information using the BIOS Setup Utility. Then store the BIOS information.
Other messages	Contact an office listed in the "Contact Information" of "Start Guide".

table: List of Server Management Tools Error Messages

9.2.3 Software Troubleshooting

This section explains software related troubleshooting. For troubles during OS installation or system operation, refer to the following contents.

Trouble at a ServerStart Startup

After a boot from the ServerStart CD-ROM, nothing is displayed on the screen.

This problem may occur if the hard disk drive still contains previous information. In that case, this problem will still occur when the Windows Server 2003 Installation CD-ROM is inserted. To eliminate this problem, physically format the hard disk drive to delete the previous information and start up ServerStart.

Trouble during OS Installation

Automatic logon fails during Windows 2000 setup.

During OS installation, ServerStart installs applications and hardware utilities supplied with the OS. Installation and subsequent restart and logon are performed automatically as necessary. In rare cases, however, automatic logon is not performed and the logon window appears. In this window, use the user name and password you have set before starting installation. After logon, the setup procedures are continued.

Error Messages during Installation

The following error messages may appear during installation using ServerStart. Check the corrective action against the relevant error.

"WzDiskAdmin: System Error!, Last Error: The device is not ready." appears

Optional SCSI devices (e.g., hard disk cabinet, MO disk unit, or DAT unit) may be connected. Disconnect the optional SCSI devices and perform installation again. Connect the optional devices after the installation completes.

"Operating System not found" appears when the system restarts after file copy from the CD-ROM

The following are possible causes. Please check.

- The array controller card comes later than the onboard SAS in order of device startup.
- The Active flag is specified.

• "Missing Operating System" appears during installation

The installation partition size may be too large. Specify the installation partition size correctly. For details on the installation partition size, refer to "2.3.1 Installation Partition Size" (\rightarrow Pg.47).

"Error 1920. Service (PXE Services) failed to start" appears during preconfigured installation

The system installed with the preconfigured settings (PXE server) may not be connected to the network. Check the LAN cable connection and click [Rerun].

An application where the tftp client function (tftp.exe) is used does not operate properly

In the system in which Windows Server 2003 is installed, the tftp client function (tftp.exe) is not installed by default, and the application where the tftp client function (tftp.exe) is used does not operate properly.

To use the tftp client function (tftp.exe), install "tftp.exe" from the OS CD-ROM according to the following procedures.

1 Insert the OS CD-ROM into the CD-ROM drive.

The OS CD-ROM must be either Windows Server 2003 CD that has applied SP1, Windows Server 2003 x64 CD or Windows Server 2003 R2 Disc 1 CD.

- **2** Move to the i386 folder of CD-ROM drive.
- 3 Start the command prompt and execute the following commands to extract "tftp.exe" in the "%Systemroot%\system32" folder. [CD-ROM drive]:\i386>expand -r:tftp.exe TFTP.EX_ %Systemroot%\system32
- **4** Confirm that "tftp.exe" exists in the "%Systemroot%\System32" folder.

Error Window Appears after Installing or Uninstalling ServerView (on Windows Server 2003)

If Windows Server 2003 Service Pack 1 is applied, the following message may appear on restarting after installing/uninstalling ServerView. There is no problem with operations. Click [Close Message] to close the message.

```
In order to protect the computer, this program is terminated by Windows.
Name: SNMP Service
```

Error Window Appears after LAN Driver Installation (on Windows Server 2003)

The following window may appear when the installation of the LAN driver to the [Ethernet controller] under [Other devices] starts.

Hardware Update Wizard		
	Cannot Start this Hardware	
	There was a problem installing this hardware:	
	Intel(R) PRO/1000 MT Desktop Adapter	
- And	This device cannot start. (Code 10)	
	Click Finish to start a troubleshooter that can help you resolve the problem.	
	KBack Finish Cancel	

This is because the LAN driver for the network adapter recognized immediately after the OS installation is not updated.

Clicking [Finish] in this window displays the [Help and Support Center] window. Click [X] to close this window.

The "!" mark is displayed at the LAN device name in Device Manager. Device names are displayed properly when all LAN drivers are installed and the system is restarted.

For details on LAN driver installation, refer to "4.3.2 Installing the LAN Driver (Windows Server 2003 / SBS 2003)" (→Pg.131).

LAN Operation Fails or Error Message Appears during LAN Driver Installation

A conflict may have occurred between system resources including the LAN and other expansion cards. Delete all LAN drivers and check that conflicts between system resources do not exist. Then, restart the system and reinstall the LAN drivers again. For the LAN driver installation procedure, refer to "4.3 Installing the LAN Driver" (\rightarrow Pg.128).

Event Log Errors after Installation

After installation, the following events may be displayed in Event Viewer. Check and perform the corrective action against the relevant event.

ID	Description	Cause and corrective action
62	This computer is a domain PDC at the root of forest. Use the net command "net time / setsntp: <server name="">" to configure it for synchronization from an external time source.</server>	 Cause: An NTP was selected as a component. Corrective action: ServerStart cannot configure the NTP server due to the absence of items for specifying it. After OS installation, perform the following procedure to specify the time server. 1. Start SNTP server operation on another machine. Assume that the SNTP server address is <172.22.78.246>. 2. Enter the following at a command prompt. net time /setsntp:172.22.78.246 w32tm -s 172.22.78.246
1000	The user or computer name cannot be identified. The return value is "1722".	 Cause: The primary DNS server address may be invalid or the server cannot be connected. Corrective action: Perform the following procedure to correct the DNS address in Internet protocol (TCP/IP) properties. 1. Right-click [My Network] and click [Properties]. 2. Right-click [Local Area Connection] and click [Properties]. 3. Click [Internet Protocol (TCP/IP)] and click [Properties]. 4. Enter the correct DNS address in the [Primary DNS server] box.

table: List of Event Log Errors That Can Occur after Installation

Cannot Collect the Memory Dump

If the memory dump file cannot be created, perform the following procedures.

• Correcting the settings

If the memory dump cannot be collected, check the settings of the paging file and memory dump file. For setting procedures, refer to "5.1 Memory Dump/Paging File Setting" (\Rightarrow Pg.136).

• Collecting memory dump to other than the system drive

If the memory dump was set to be collected to the system drive (C:\), change the settings so that the memory dump can be saved to a drive other than the system drive.

For setting procedures, refer to "5.1 Memory Dump/Paging File Setting" (\rightarrow Pg.136).

If only the system drive exists, or if there is no free space in any of the drives, perform one of the following:

- Adding a hard disk
- · Replacing with a larger hard disk

Reducing the installed memory to collect the memory dump

There must be enough free disk space that matches the size of the installed memory; therefore, reduce the installed memory to a collectable size.

Check the memory dump settings when changing the installed memory size.

For setting procedures, refer to "5.1 Memory Dump/Paging File Setting" (→Pg.136).

Changing the write type of the debugging information

If the memory dump cannot be collected, select a write type of debugging information within the range of free space of the volume size.

If the above does not provide a solution, try increasing the size of the hard disk or adding an additional hard disk.

Restoring the System

In the event where the system file, system configuration, or environment changes during startup are corrupted, use the repair information stored on the repair disk created at the installation to restore the system.

For restoration procedures, refer to the following:

- "9.6.1 For Windows Server 2003" (→Pg.262)
- "9.6.2 For a Windows 2000 Server" (→Pg.263)

■ Failed in Remote Installation

If remote installation fails, check the following.

• Checking Services

Check that the DHCP, PXE Service, and TFTP Service are running. For checking procedures, refer to "3.4 Remote Installation" (\rightarrow Pg.88).

Setting TFTP

To access TFTP Service, add a Guest account to the TFTP folder and set appropriate access rights. For setting procedures, refer to "3.4 Remote Installation" (\rightarrow Pg.88).

Checking Network Function Settings

The server must support network startup (PXE). Network startup must be enabled in advance. For setting procedures, refer to "2.1.2 Hardware Settings" (\rightarrow Pg.43).

Checking the MAC Address

Check that the current MAC address is the correct MAC address of the server. For the MAC address checking procedure, refer to "2.1.2 Hardware Settings" (→Pg.43).

Checking LAN Cable Connection

Check that the LAN cable is connected to the LAN card corresponding to the specified MAC address and that the LAN card is connected to the network.

SNMP Service Startup Fails

If the Simple Network Management Protocol (SNMP) is installed, but has not started, perform the following procedure to start the service.

• For Windows Server 2003

- **1** Click [Start] \rightarrow [Computer Management] in this order.
- 2 Select [Services] from the [Services and Applications] menu.
- **3** From the details, select [SNMP Service].
- **4** Select [Start] from the [Action] menu.

For Windows 2000 Server

- Right-click the [My Computer] icon on the desktop and click [Manage] from the displayed menu.
- 2 Select [Services] from the [Services and Applications] menu.
- **3** From the details, select [SNMP Service].
- **4** Select [Start] from the [Action] menu.

POINT

To have the service automatically start each time the OS starts, double-click [SNMP Service] from the details, and select [Automatic] for the [Startup type] setting of the [SNMP Service Properties] window.

Time Display in Linux OS Environment

• Difference in Time between the OS and the Hardware Clock

During OS operation in a Linux environment, the software clock on the OS, rather than the hardware clock in the server, is used to display the time.

This may cause a difference in time between the OS and the hardware clock.

When you want to see the accurate time on the OS, it is recommended to use the NTP service to periodically correct the time displayed on the OS.

• Changing the Time Settings for the OS and Hardware Clock

In a Linux environment, the time displayed on the OS (the software clock value on the OS) is written to the hardware clock in the server when the OS is shut down.

 Procedure for prohibiting the time on the OS from being written to the hardware clock When you do not want the time on the OS to be written to the hardware clock at an OS shutdown, comment the following line out in /etc/rc0.d/S01halt.

runcmd \$"Syncing hardware clock to system time" /sbin/hwclock \$CLOCKFLAGS \downarrow

#runcmd \$"Syncing hardware clock to system time" /sbin/hwclock \$CLOCKFLAGS

• Procedure for reflecting the hardware clock value to the time on the OS To reflect the hardware clock value to the software clock value on the OS, run the following command.

>hwclock --hctosys

9.3 System Event Log

To operate system event log, use Server Management Tools.

POINT

When the area for writing to the system event log is full, new event log cannot be recorded. To overwrite older event logs automatically, start up the BIOS Setup Utility, select the [IPMI] submenu from the [Advanced] menu and set [Event Log Full Mode] to [Overwrite]. [Wrap Around] is an initial value. For details on this setting, refer to "8.2.10 IPMI Submenu" (→Pg.225).

9.3.1 How to Use Server Management Tools

This section explains how to use Server Management Tools.

Server Management Tools perform the following to the system event log.

- Viewing the system event log
- Saving the system event log
- Deleting the system event log

When a system event log occurs, save the log using Server Management Tools and contact an office listed in the "Contact Information" of "Start Guide".

Notes

- The "Server Management Tools" disk supplied with this server is for use with this server only. Do not use those tools on other systems. If it is used, the system can be damaged.
- Make sure to perform this operation only when the server is started with the "Server Management Tools" disk. Do not run Server Management Tools on the server started from the hard disk or by the other floppy disk. Otherwise, the system may be damaged.
- Do not eject the floppy disk when the Floppy disk access LED is on. Doing so may destroy the data
 on the floppy disk.

Starting Server Management Tools

MPORTANT

 Before rebooting the system, first check that the ServerView "OS Boot Monitoring" function has been disabled (default setting is "Disabled").

If the system is started with this function enabled, the server may automatically turn off or restart improperly.

If the "OS Boot Monitoring" function is needed, it should be reset to "enabled" before resuming normal server operation. For details about ServerView, refer to the "ServerView User's Guide".

1 Turn on the server and insert the "Server Management Tools" disk into the floppy disk drive.

The window for selecting a keyboard appears.

Please select: 1 = JP Keyboard 2 = US Keyboard Your selection


2 Select a keyboard.

Select [1] for Japanese keyboard or select [2] for English keyboard. Japanese keyboard is selected by default.

3 Enter the following command and press the [Enter] key.

A:\SMT\>IPMIVIEW.EXE

The IPMI Tool window appears.



4 Select [System Event Log (SEL)] and press the [Enter] key. The list of system event logs is appears.

FUJITSU SIEMENS SYSTEM EVENT LOG (SEL) COMPUTERS	
004 MMM-DD-YYYY HH:MM:SS [*****] XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	
<\$↔,PgUp/Dn,(Ctrl-)Home/End> Move <f2> SaveToFile <f3> Clear <esc> Ex</esc></f3></f2>	it)

253

Exiting Server Management Tools

1 Press the [Esc] key in the SYSTEM EVENT LOG window. The power can be turned off when the DOS prompt is displayed.

9.3.2 Saving/Deleting the System Event Log

Saving the Log

- **1** Start Server Management Tools to display the SYSTEM EVENT LOG window.
- 2 Press the [F2] key.
- **3** Enter the name of the file to save the log to, and press the [Enter] key. The log is saved to the floppy disk under the specified file name.

Deleting the Log

- **1** Start Server Management Tools to display the SYSTEM EVENT LOG window.
- 2 Press the [F3] key.
- **3** Press the [Enter] key. This deletes the log.

9.4 Security

Security features are provided in order to protect the server hardware and software from theft. Additional security functions, which prevent unauthorized use, provided by the BIOS Setup Utility are also available to help maintain a highly reliable data security system.


9.4.1 Hardware Security

This section describes security function of hardware.

Locking the drive cover

Lock the drive cover to protect the hardware (hard disk units and 5-inch internal options) in the server from theft or tampering.

Turn the key clockwise to lock the cover.




POINT

- Do not lose the drive cover key. If the key is lost, contact an office listed in the "Contact Information" of "Start Guide".
- ► For instructions on opening the drive cover, refer to "1.4.1 Sliding the Drive Cover" (→Pg.30).

Rack Type

Lock the rack door to protect the hardware in the rack from theft.

To close the rack door, shut the door and return the rack handle, and turn the rack key.



POINT

- Do not lose the rack key. If the key is lost, contact an office listed in the "Contact Information" of "Start Guide".
- For instructions on opening the rack door, refer to "1.4.2 Opening the Rack Door" (→Pg.31).
- The above explanation is based on the 40U standard rack. For details on other rack systems, refer to their respective manuals.

9.4.2 Security against Unauthorized Use

A password can be set to prevent unauthorized use of the server.

Setting a password makes it necessary to enter the password in order to access the server. Without the password, the server cannot be used.

Password Types

There are two types of passwords that define the privileges of server operations.

User Password (System Password)

The password required to use the server. Unless the set password is entered, part of the BIOS setup cannot be accessed and the OS cannot be booted.

Administrator Password (Setup Password)

This is the password that only allows the administrator to set up this server. Unless the set password is entered, the BIOS setup cannot be accessed and the OS cannot be booted.

Setting a Password

The password is set in the BIOS Setup Utility. For details on the BIOS Setup Utility, refer to "8.2.11 Security Menu" (→Pg.227).


1 Start the BIOS Setup Utility.

→"8.2.1 Starting and Exiting the BIOS Setup Utility" (Pg.213)

2 Select the [Security] menu and select the type of password to set.

- For the administrator password, select [Set Setup Password] and press the [Enter] key.
- For the user password, move the cursor to [Set System Password] and press the [Enter] key.

3 When the password input window is displayed, enter the password to set.



4 Enter the password again to confirm it.


5 Press the [Enter] key.

This sets the password.

Changing / Deleting Passwords

If a password is already set, perform the above password setting operations to display the password change window.

• To change the password, perform the following settings and press the [Enter] key.



• To delete the password, enter the current password, and then press the [Enter] key without entering anything in the second and third fields. The status of "Setup (System) Password" changes to "Not installed".



- The system shuts down after three invalid password entries. If this happens, turn off the server, turn it back on, and then enter the correct password.
- If you forgot your password and cannot start the server, change the jumper setting on the baseboard to reset the passwords. For jumper settings, refer to "8.1 Jumper Settings" (→Pg.212).

9.4.3 Security When Disposing of the Server

Notes regarding the Deletion of Data from the Hard Disk When Disposing of or Transferring the Server

When disposing of or transferring a server that has been used, the data in the hard disk may be read and used unscrupulously. To prevent confidential or important data from leaking out, the data on the hard disk must be wiped before disposal or transfer.

However, wiping the hard disk is not an easy task. Simply initializing (formatting) the hard disk or deleting the files may give the pretense that the data no longer exists, but in reality the data is simply no longer accessible to the OS, and it is still accessible to malicious individuals that can restore the data. Therefore, if confidential or important data is saved to the hard disk, in addition to the operations mentioned above, it is recommended to use third-party tools or services to wipe the data completely from the disk to prevent its restoration.

When disposing of or transferring the server, it is the customer's responsibility to wipe data contained in the hard disk in order to prevent such important data from leaking.

Also, if software license agreements prohibit unauthorized distribution of software (OS or application software), transferring the server without removing the software may violate the license agreements. These issues must be taken into consideration.

9.5 Backup

This server utilizes high-reliability components and hard disks, however, as a precautionary measure, it is recommended that periodic backups be taken of the data.

9.5.1 Importance of Backups

A backup of data stored on the server is required for data restoration in the event of server trouble resulting in a system failure or accidental data loss due to operational errors. If the data on the server is backed up, it can be restored from the backup in the event of hardware failures or data corruption in hard disks due to operational errors. If backups are not made, restoration is impossible and data will be permanently lost. To prepare for unexpected problems, be sure to perform periodic backups of the system.

9.5.2 Backup Devices, Software and Their Operations

Backup operations differ depending on network operating systems, applications, and system operations. Contact an office listed in the "Contact Information" of "Start Guide" and make backups using the following items.

- Backup device (e.g., Tape Drv DAT72)
- Backup software (Standard backup software supplied with the OS, e.g., ARCserve, Changer Option)
- Backup operations (schedules)
 Use our genuine backup devices and software. Observe the backup medium (tape) storage conditions.

POINT

Mirroring/disk array systems To improve system reliability, a mirroring or disk array system using an array controller, in addition to periodic backup creation, is recommended.

Notes on Operating Backups

Notes on operating backups are as follows. For details, refer to the device manuals.

Head Cleaning

Airborne dust and dust from the magnetic media can collect on the head of the magnetic tape device. To remove this dust, head cleaning must be implemented. Implement head cleaning when the device displays a cleaning request. Particularly DDS devices require periodic head cleaning, otherwise dust can cling to the magnetic head, creating a situation that cannot be cleaned with standard head cleaning methods, and eventually render the device useless.

Also note that the cleaning media has a limit on how many times it can be used. Using cleaning media that exceeded its lifespan will have no cleaning effect. Note these points especially when performing automatic backups with library devices.

Managing Media Lifespan

Media is a consumable product that must be replaced regularly.

Continued use of media exceeding its lifespan can have negative effects on the device (e.g. increase the speed of dust accumulation). The lifespan of media varies depending on the environment and operation condition of the device, the type of backup software used, and other operation conditions, however, it is recommended that they be replaced sooner than later.

To manage the lifespan, write the use start date on the media.

Rotating Media

When using a single media cartridge repeatedly, backup data can be temporarily lost in the event the backup fails. Also if the hard disk fails during backup, the backup data cannot be recovered. Perform backup operations using multiple mediums on a rotating basis.

Avoid Leaving Media in Devices

Because the magnetic recording surface of the device is exposed, media can easily affected by airborne dust when left inserted for a long period of time. Insert the media before using it, and remove the media after use, and restore it in its case.

Also note that some tape devices write management information to the tape when ejecting the media. If the power were to go out when the media is still in the device, this writing process will not be performed and the media may become corrupted.

To avoid this, remove the media from the device when turning off the server/device.

Verifying Data after a Backup

Some backup software products provide data verification functions after a backup is completed. Such functions will read and verify the data written to the media after a backup is completed. This will increase the usage of the media, thus reducing the number of times it can be used for backups. Depending on the hardware being used, some devices perform "read after write" operations on data; note the points of this section as necessary.

• Ejecting Media after a Backup

Some backup software products provide functions for ejecting media after a backup is completed. Such functions will rewind the tape after a backup is completed and then eject the media from the drive. Be sure to execute this function for autoloader/library devices. Depending on the structure of some servers, this function may cause the media to eject from an internal device of the server and hit the chassis door. If this is the case, open the door when ejecting, or do not eject the media.

Media Label Types and Positions

When writing information such as the name on media, use the label that came with the media. The area in which a label can be posted on the media of each device varies. Failing to post labels in the designated area can damage the device.

Data Storage

When storing data for long periods of time, store the media in a location least affected by temperature, humidity and magnetic fields.

9.6 Restoring the System

In the unfortunate event where the system file, system configuration, or environment changes during startup are corrupted, use the repair information stored on the recovery disk created at the installation to restore the system.

POINT

- Create a recovery disk when you have installed an OS or changed the system configuration. Refer to "5.2 Creating a Disk for System Recovery" (→Pg.146).
- If the procedures of restoring the system are described in the manual of the backup devices or Readme.txt of the device drivers, refer to these procedures.

9.6.1 For Windows Server 2003

• Items Required

- · Windows Server 2003 CD-ROM
- Automated System Recovery (ASR) floppy disk (created beforehand)
- Backup media (created beforehand)
- Driver disk (for an onboard array controller / for an array controller card)
 For details about required driver disk and how to create a drive disk, refer to "4.1 Creating Driver Disks" (→Pg.112).
 - **1** Turn on the server and insert the Windows Server 2003 CD-ROM immediately. Check there are no floppy disks in the floppy disk drive.
 - **2** When the active area is specified on the hard disk, the following message appears. Press any key while this message is displayed.

Press any key to boot from CD....

Setup window for Windows Server 2003 x64 appears.

3 The following message appears at the bottom of the window. Press the [F6] key.

```
Press F6 if you need to install a third party SCSI or RAID driver ...
```

MPORTANT

- This message will be displayed for a short time after the setup window (blue screen) appears. Press the [F6] key immediately after the window turns blue.
- **4** When a message prompts you to press the [F2] key, press the [F2] key.

A message prompts you to insert the ASR floppy disk.

5 Insert the ASR floppy disk and follow the window instructions.

6 Install the driver.

For details on how to install the driver, refer to "4.2.1 Installing Windows Server 2003 x64" (\rightarrow Pg.117) or "4.2.2 Installing Windows Server 2003 / SBS 2003" (\rightarrow Pg.120).

7 Follow the window instructions to restore the system.

- When prompted to change the floppy disk, follow the instructions and change it.
- If a message appears indicating that the driver has not passed Windows Logo testing to verify its compatibility with Windows, select [Yes] to continue the installation procedure.
- When prompted to insert media, set the backup media created beforehand and follow the messages to continue.

POINT

Notes on Automated System Recovery

• Automated System Recovery does not restore data files.

9.6.2 For a Windows 2000 Server

Items Required

- Windows 2000 Server CD-ROM
- Windows 2000 Server system recovery disk (created beforehand)
 - Insert the Windows 2000 Server CD-ROM immediately after the server is turned on .

Confirm that there is no floppy disk in the floppy disk drive.

- **2** From the [Welcome to Setup] window of the Windows 2000 Server Setup program, press the [R] key to select restoration.
- **3** Follow the message on the setup window to restore the system.

POINT

Notes on system restoration

- The system may return to the initial installation conditions depending on the restoration information used. In this case, the system must be configured after system restoration.
- Windows 2000 Server may have to be reinstalled if system files or system information are severely damaged. If this is the case, reinstall it. Refer to "9.7 Reinstalling the OS" (→Pg.264).
- The message "The file XXXXXXXXXX is not the original file copied when Windows 2000 was installed." appears during file restoration. Press the [Enter] or [A] key to restore the file.

9.7 Reinstalling the OS

This section explains the procedure for reinstalling the OS.

9.7.1 Checking before OS Reinstallation

Removing the Optional Devices

Remove the following optional devices before reinstalling the OS. Install or connect them after OS installation.

- Optional SCSI devices (e.g., hard disk cabinet or DAT unit) connected via a SCSI card (e.g., hard disk cabinet or DAT unit)
- · Internal hard disk units that do not contain the OS installation folder
- 5-inch internal devices
- USB devices

Deletion of Data from the Disc

Reinstalling a disk will delete all the contents of that disk. Please be careful. Save the necessary data and system configuration in a different location.

Some drivers and software are not installed together with the OS. Install them after OS installation.

Other Notes

Other notes are the same as those that apply for first time installation. Please check in advance.

9.7.2 Reinstallation Using ServerStart

When the previous installation was performed in guide or preparation mode, the ServerStart floppy disk used in that installation can be used again. When the reinstallation is performed with the same configuration as that for the previous installation, you do not have to edit the configuration file on the ServerStart floppy disk. You do not have to configure setting on wizards. After ServerStart starts up, click [Start (OS) Installation] to perform installation.

Use the expert mode when you want to perform reinstallation while maintaining the existing partitions.

9.8 Maintenance Service

This section explains the details of the maintenance service. If the cause of the failure is uncertain or if the original condition cannot be restored, contact the seller or an office listed in the "Contact Information" of "Start Guide".

9.8.1 Contacting Maintenance Support

Before contacting maintenance support, check the following.

POINT

Fill in the "Configuration Sheet" and "Accident Sheet" of "Configuration Sheets".

Item

- Model name and product ID of the server They are described on the label on the server. For the label location, refer to "Start Guide".
- Hardware configuration (Types and locations of internal options)
- Configuration information (BIOS Setup Utility, SCSI Setup Utility settings)
- OS
- LAN/WAN system configuration
- Phenomena (what happened when doing what, what was displayed, etc.)
- Date and time of an accident
- Environmental settings of the server
- LED statuses

Chapter 9 Operation and Maintenance

Appendix

This appendix explains the specifications for the server and for its internal options.

А	Server Specifications	268
В	Specifications for Internal Options	269
С	Remote Control Function	273
D	Remote Management Controller	278
Е	Recycling	283

A Server Specifications

This section explains the specifications for the server.

A.1 Diskless Type

		table: Server Spec	cifications - Diskless Type				
	Item	Functions and Specifications					
Product ID		PGUT1551A	PGUT1554A	PGUT1552A			
CDU	Standard	Intel [®] Celeron [®] D 346 Processor 3.06GHz	Intel [®] Xeon [®] 3040 Processor 1.86GHz	Intel [®] Pentium [®] D 925 Processor 3GHz			
CPU modules	Level 2 cache	256KB	2MB	$2 \times 2MB$			
modules	Number of multiplication		1				
	Standard	512MB (I	512MB (DDR2 533 Unbuffered Lowprofile DIMM × 1)				
Memory	Adding size		512MB / 1GB / 2GB				
	Maximum		$8GB(2GB \times 4)$				
Graphics			in iRMC 640x480, 800x600, 1024x7 colors: Differ depending on resolution				
CD-ROM	drive	4	8x ATAPI CD-ROM drive (Standard)			
5-inch sto	rage bay	3 bay (including the standard bay)					
3.5-inch storage bay		4 bays (Adding hotplug for all bays)					
Standard		Optional					
	Adding size	73GB / 146.8GB					
Expansion			ot \times 1,PCI-X slots \times 2, PCI Express sl				
Floppy disk drive		3.5-inch (2 mode 1.44MB/720KB) (Standard)					
Interface		LAN (1Gbit Ethernet) × 2(Standard, 1 port is used only for Remote Management Controller), Serial × 2(1port id optional), Parallel × 1(optional), Keyboard, Mouse, Monitor, USB × 3					
Keyboard	and Mouse	Optional					
	ns (Width × Height (mm))	$205 \times 602 \times 444$ When the Rack Conversion kit for TX150S5 is used:					
Weight		482 (including protrusion) × 597 (including protrusion) × 221.2 (5U) 27kg (29kg for rack type)					
0	lock precision	2 / kg (29 kg for rack type) $\pm 2 \text{ to 3 minutes/month}$					
Internal clock precision Power consumption		± 2 to 5 minutes/month Max 280W (1008kJ/h)					
Power		Max. 280W (1008KJ/h) 100-240 VAC (50-60Hz)					
Power supply unit		1 (Standard)					
Fan		1 (Standard)					
OS		Windows Server 2003 R2 St Windows Small Busine	2 Standard Edition / Windows Server andard x64 Edition / Windows Serve ses Server 2003 R2 / Windows Small Windows 2000 Server / SS (v.4 for x86) / Red Hat Enterprise	r 2003 Standard x64 Edition / Business Server 2003 /			

The specifications for this server are liable to be updated without any notice. Please be forewarned.

B Specifications for Internal Options

This section explains the specifications for internal options for the server. When you have bought an internal option as a standard option, check that the package contains the following items before use. Should it happen that items are missing, contact an office listed in the "Contact Information" of "Start Guide".

B.1 Memory

Package

• Memory modules (1)

Specifications

Item	Function and Specifications				
Product Name	Memory Module-512MB	Memory Module-512MB Memory Module-1GB Memory Module-2C			
Models	PG-RM51BE PG-RM1BE PG-RM2BE				
Capacity	512MB	1GB	2GB		
Clock frequency	533MHz (Dual edge)				
PIN count	240PIN				

table: Memory Specifications

B.2 Internal Hard Disk Units

Package

• Hard disk unit (1)

Specifications

table: Internal Hard Disk Unit Specifications Item Function and Specification Models PG-HDB75A PG-HDB45A Interface SAS (Serial Attached SCSI) Storage media 3.5-inch hard disk Memory capacity *1 73.4GB 146.8GB Maximum data transfer speed 3Gbit/s Average latency speed 2.00ms Rpm 15,000rpm Dimensions *2 $101.6 \times 146.0 \times 25.4$ (mm) Weight *2 0.8kg

*1:The value indicates memory capacity of the formatted hard disk ($1GB = 1000^3$ bytes).

*2:A Hot plug carrier is not included.

B.3 Parallel Port Option

Package

• Parallel Port Option (1)

Specifications

table: Parallel Port Option Specifications

Item	Function and Specification
Product Name	Parallel Port Option
Model	PG-PP06

B.4 Serial Port

Package

- Serial Port (1)
- Serial Port cable

Specifications


table: Serial Port Specifications

Item	Function and Specification
Product Name	Serial Port
Model	PG-COM04

B.5 Power Cord Selection

The power cord for this unit has been packed separately and has been selected according to the country of destination. It must be used to prevent electric shock. Use the following guidelines if it is necessary to replace the original cord set.

The female receptacle of the cord set must meet CEE-22 requirements (see Figure).



For the United States and Canada

Use a UL listed and CSA labeled cord set consisting of a three conductor cord with a maximum length of 15 feet.

For units which stand on a desk or table, type SVT or SJT cord sets should be used.


For units which stand on the floor, only SJT type cord sets should be used.

The cord set must be selected according to the current rating for your unit.

Please consult the table below for the selection criteria for power cords used in the United States and Canada.


Cord Type	Size of Conductors in Cord	Maximum Current Rating of Unit
SJT	18 AWG 16 AWG 14 AWG	10 Amps 12 Amps 12 Amps
SVT	18 AWG 17 AWG	10 Amps 12 Amps

table: Selection	Criteria for Power	Cords	Used in the	United	States and	Canada
		Oorus	Obcu in the	United	Olaics and	Ganada



Use a parallel blade, grounding type

attachment plug rated 15 A, 125 V.



For units set at 230 V: Use a tandem blade, grounding type attachment plug rated 15 A, 250 V.

For units set at 230 V (outside of the United States and Canada):

Use a cord set consisting of a minimum AWG according to the table above and a grounding type attachment plug rated 15 A, 250 V. The cord set should have the appropriate safety approvals for the country in which the equipment will be installed and should be marked HAR.

For the United Kingdom

Should the plug on the flexible cord not be of the type for your socket outlets, do not use an adapter but remove the plug from the cord and discard. Carefully prepare the end of the supply cord and fit a suitable plug.

This appliance must be earthed.

POINT

- The wires in this mains lead are colored in accordance with the following code:
 - · Green and Yellow: Earth
 - · Blue: Neutral
 - Brown: Live

As the colors of the wires in the mains lead of this appliance may not correspond with the colored markings identifying the terminals in your plug, proceed as follows:

- The wire which is colored Green and Yellow must be connected to the terminal in the plug which is marked with the letter E or by the earth symbol or colored Green or Green and Yellow.
- The wire which is colored Blue must be connected to the terminal which is marked with the letter N or colored Black.
- The wire which is colored Brown must be connected to the terminal which is marked with the letter L or colored Red.

C Remote Control Function

This server supports the Remote Control function.

When a personal computer (PC) is connected to the serial port of this server with an RS-232C cross cable, the PC can be used to control the server power supply (turn on/off and reset) remotely.

C.1 Preparation for Using Remote Control Function

To enable the remote control function, perform the following procedure.

- · Configuring the BIOS
- Connecting the Server to a PC
- Configuring terminal software communication settings on the PC


Configuring the BIOS

To use the function of the server management port, perform the following setting using the BIOS Setup Utility.

- **1** Turn on the server. Press the [F2] key during POST to start up the BIOS Setup Utility.
- 2 Select the [Advanced] menu → the [Peripheral Configuration] submenu, and set [Serial Multiplexer] to [iRMC].
- **3** From the [Exit] menu, select [Saving Changes & Exit] to exit the BIOS Setup Utility.

Connecting the Server to a PC

Connect the server to a PC using an RS-232C cross cable.



■ Configuring the Terminal Software (PC)

Perform settings for the remote control function using terminal software on the PC.

• Port Configuration

Configure the port on the PC as follows:

table: Port Settings			
Item	Contents		
Bits per second	9600		
Data bits	8		
Parity	None		
Stop bits	1		
Flow control	None		

(Window example)

C	OM	1 Properties				<u>?</u> ×
	Po	rt Settings				
		<u>B</u> its per second:	9600		•	
		<u>D</u> ata bits:	8		•	
		Parity:	None		•	
		<u>S</u> top bits:	1		•	
		Elow control:	None		•	
				<u>R</u> estore	Defaults	
		0	К	Cancel	App	dy

C.2 Remote Power Supply Control

This section explains how to control the server power supply remotely. The server power supply can be remote-controlled with the terminal software on the PC.

■ Starting Up the Remote Controller

1 Start up the terminal software.

The remote control window appears.

Welcome to PRIMERGY Remote Manager	*
Firmware Revision x.xxA (x.xx)	*
SDRR *.** ID 0203 TX150S5	*
Firmware built xxx xx xxxx xx:xx:xx	*
******	**
stem Type : PRIMERGY TX150 S5	
stem ID : xxxxxxxx	
stem Name : TX150S5-2 (xxx.xxx.xxx.	xxx)
stem OS : xxxxxxxx	
vstem Status: OK	
ower Status : On	
ease enter user name :	
ease enter pass phrase :	

Power state is displayed next to "Power Status:".

table: Meaning of [Power Status]

Display	Description	
On	The server is powered on.	
Off	The server is powered off.	


2 When "Please enter user name:" appears, enter the user name and press the [Enter] key.

3 When "Please enter pass phrase:" appears, enter the password and press the [Enter] key.

Note that the password is case-sensitive. As shown below, the characters you have entered are displayed as asterisks.

Please enter pass phrase: ******

The remote control main menu appears.



4 Press the [2] key and select "Power Management".

The Power Management menu appears.

```
*****
* Welcome to PRIMERGY Remote Manager *
* Firmware Revision x.xxA (x.xx)
* SDRR *.** ID 0203 TX150S5
* Firmware built xxx xx xxxx xx:xx:xx *
****
System Type : PRIMERGY TX150 S5
System ID : xxxxxxx
System Name : TX150S5-2 (xxx.xxx.xxx)
System OS
           : XXXXXXXX
System Status: OK
Power Status : On
   Power Management Menu
(1) Immediate Power Off
(2) Immediate Reset
(3) Power Cycle
(*) Power On
(*) Graceful Power Off (Shutdown)
(*) Graceful Reset
                    (Reboot)
Enter selection or (0) to quit:
```

5 Select a menu and press the corresponding number key.

"*" is displayed in the bracket of unavailable menu.

table: Remote Control Menu		
Menu name	Key	Operation
Immediate Power Off	[1]	Turns the server off.
Immediate Reset	[2]	Resets the server.
Power Cycle	[3]	Turns the server off and back on again. When Windows is operating, the server restarts after the OS is shut down.
Power On	[4]	Turns the server on.
Graceful Power Off (Shutdown)	[5]	Shuts down the OS and turns the server off. When Windows is operating, the server is turned off after the OS is shut down.
Graceful Reset	[6]	Shuts down the OS and resets the server. When Window is operating, the server is reset after the OS is shut down.
-	[0]	Exits the remote controller.

6 If pressing the [1], [2], [3], [4], [5] or [6] key, perform the following operation. When "Do you really want rebot (Yes/No)?" appears, enter "Yes" and press the [Enter] key. For [3], [5] or [6], the pop-up window "System shutdown due to <software command> in 60 seconds! Press Cancel to abort!" appears when Windows is operating. Select [OK].

D Remote Management Controller

This section explains functions and features of the Remote Management Controller (iRMC) and the optional Remote Management Controller Upgrade (PG-RMCU1).

D.1 Overview of the Remote Management Controller

PRIMERGY TX150 S5 has the Remote Management Controller on the baseboard. The Remote Management Controller makes the high-quality, high-reliability remote service board function possible. To use the console redirection function and the remote storage function, the license key of optional Remote Management Controller Upgrade (PG-RMCU1) is necessary. For details of Remote Management Controller Upgrade (PG-RMCU1), refer to "D.4 Remote Management Controller Upgrade (PG-RMCU1)" (→pg.281).

Features of the Remote Management Controller

- The Remote Management Controller and LAN are provided on the baseboard. This makes possible to control power supply and reset of the server without depending on the state of the server.
- The console redirection function and the remote storage function can be used by optional Remote Management Controller Upgrade (PG-RMCU1).
- It provides with LAN interface.
- It has the server monitoring function (monitoring server's hang/temperature/voltage).
- It has the server abnormality notification function (it is possible to notify abnormally at the server hang).
- It is possible to display the server status and control power supply/reset of the server by using the Web interface.

MPORTANT

When the baseboard is replaced, the Remote Management Controller may have to be set again. In case of reconfiguration, write down the set values in configuration sheets.

D.2 Preparation for Using Remote Management Controller

To enable the Remote Management Controller, perform the following procedure.

- Configuring the BIOS
- Connecting the Server to a PC

Configuring the BIOS

To use the function of the Remote Management Controller, perform the following setting using the BIOS Setup Utility.

- 1 Turn on the server. Press the [F2] key during POST to start up the BIOS Setup Utility.
- 2 Select the [Advanced] menu → [IPMI] → the [LAN Settings] submenu, and set the each item.

.For setting items, refer to "■ LAN Settings Submenu" (→pg.226).


3 From the [Exit] menu, select [Saving Changes & Exit] to exit the BIOS Setup Utility.

MPORTANT

Save the setting information of set parameters using the Server Management Tools. For details, refer to "5.3 Storing the System Configuration Information"(→ pg.148).

Connecting the Server to a PC

Connect the server to a PC using a LAN cable.



D.3 Window of the Remote Management Controller

The Remote Management Controller uses the Web interface function.

The following window appears when starting the Remote Management Controller.

FUĴĨTSU	and the second s	RemoteView
We make sure		
PRIMERGY	RemoteView@iRMC Web Server	
Please select	System Information	
System Information iRMC Information Power On/Off	System Status	
Sensors Fans Temperature Voltages Power Supply	Error LED ON Identify LED off Toggle	
Component Status System Event Log	System Board Information	
Server Management Network Settings Ethernet Ports DHCP DNS Alerting	System Type PRIMEROY RX300 83 Chassis Type RX30053R Serial Y9ML000000 Bloc Version 4,06 Rev. 1.00A,2119 System GUID 0000000-0000-0000-003005A047Cp	
SNMP Traps		
Serial/Modem Email	Operating System Information	
User Management Console Redirection BIDS Text Console Video Redirection Remote Storage	System Name RX30053W2V3R2 System C/S Windows Sarver 2003 R2 (x64 Edition) System IP 10.2:1.136.56 / 10.21.136.65 System Loation System Contact	
Refresh	. <u> </u>	
e 2000-2006 Euiitsu Siem	ers Constitute All rights reserved. EVAI HATION COPY - NOT FOR RI	SALE

The following functions are available.

Item	Description
System Information	Displays the system information.
iRMC Information	Displays Remote Management Controller information and configures the license key.
Power On/Off	This is used to turn the server power ON/OFF or restart.
Sensors	Displays the status of each server sensor (fan, temperature, voltage and power supply).
System Event Log	Displays the system event log.
Server Management	Displays and configures the server management information.
Network Settings	Configures the network settings.
Alerting	Sends alert.
User Management	Displays and configures the user information.
Advanced Video Redirection	Starts up the console redirection.

POINT

For usage of the Remote Management Controller, refer to "ServerView User's Guide".

Comparison with server management function of ServerView

ServerView, software provided with the server, can manage the server remotely if OS is normally operating. The Remote Management Controller can operate even in the state of the server hang, therefore, it is effective when the server cannot be monitored by ServerView.

D.4 Remote Management Controller Upgrade (PG-RMCU1)


This option is a license key to make Remote Management Controller's console redirection function and remote storage function effective.

Item	Specifications
Product Name	Remote Management Controller Upgrade
Model	PG-RMCU1
Function	Console redirection function / Remote storage function

table: Specifications of	Pemote Manao	ement Controller	Ingrado
	I CHIULE Manay		Opyraue

• Console Redirection Function


The server can be remotely operated by using console redirection function. Remote operation such as the keyboard and mouse operation, and seeing the contents of the display of the server are possible. By using console redirection function, it makes possible to achieve the function of the KVM switching in the environment where multiple servers are used. The composition of the multiple servers' environment is shown in the figure below.



Remote Storage Function

This is a function to recognize the external memory device connected by using the console redirection function as a remote device of the server.

The configuration of the remote storage function is shown in the figure below.



POINT

- The following devices can be used in the remote storage connection. However, the writing into the DVD drive is not supported.
 - · Internal floppy disk drive
 - ATAPI CD-ROM drive
 - ATAPI DVD drive
 - · USB floppy disk drive
 - · USB CD-ROM drive

License Key Settings

Enter the license key from the Web to make effective the console redirection function and the remote storage function.

For details of the setting method, refer to the manual supplied with PG-RMCU1.

License Key
You do have a valid permanent licence key installed. Please enter your license key into the area below!
Upload Clear License

E Recycling

This section explains how to recycle this server.

Disposing of the Server

When scrapping this server, contact an office listed in the "Contact Information" of "Start Guide". This server must be disposed of as industrial waste.

Furthermore, if the server is disposed of as it is, someone else may gain access to the information contained on the hard disks. It is therefore recommended that all drives be formatted before disposal. However, just formatting or deleting files may not avoid the risk that the data is restored and used for wrongful purposes. If confidential or private information is saved, in order to make it impossible to be restored, it is recommended to use third-party data wiping tools.

Disposing of Used-up Batteries

Used-up batteries must be disposed of as industrial waste and therefore require special processing. Let a licensed industrial waste disposal company take care of disposal.

Disposing of Liquid Crystal Displays

Liquid crystal displays must be disposed of as industrial waste and therefore require special processing. Let a licensed industrial waste disposal company take care of disposal.

E Recycling

Index

А

Advanced Uninterruptible Power Supply 15	;9
Application wizard	
Expert mode 8	5
Guided mode 7	'1
ASR 14	6
Automated System Recovery Set	
Windows Server 2003	6
Auto-run Function from CD-ROM Drives 15	8

В

Backup
BACS 161
Installing 161
LAN driver advanced setup 161
VLAN 163
BIOS Information
Recovering 150
BIOS Setup Utility 213
Advanced Menu 219
Advanced System Configuration Submenu
Boot Menu
Boot Options Submenu
Console Redirection Submenu 231
CPU Status Submenu 230
Exit Menu 232
Exiting
IPMI Submenu
Key operations 214
Main Menu 216
Memory Status Submenu
PCI Configuration Submenu 222
Peripheral Configuration Submenu 220
Power On/Off Submenu 224
Security Menu
Server Menu
Standard IDE submenu
Starting 213
Boot monitoring setting

С

Changing Passwords	257
Cleaning	234
Cleaning the floppy disk drive	236
Cleaning the keyboard	235
Cleaning the server	234
Cleaning the server interior	235

Component Names
Configuration file
Close/save
Open/create62
Configuring a network19
Creating Driver Disks112

D

Deleting Passwords
Disk Manager
DOS Diskette
Drive cover
Slide
Drive Letter Assignment
Driver types
Latest drivers
Windows Server 2003 / SBS 2003 113
Windows Server 2003 x64
Windows 2000 Server
DSNAP
Installation
Usage

Е

Error Messages	 245
Event logs	
Expansion cards	
Expert mode	
External SCSI devices	

F

G

Guided mo	de .																						.5	8
-----------	------	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	----	---

Η

Hardware Configuration Tool	.152
Hardware features	14
High Reliability Tools	20
How to install.	21
Hotfix	.157

I

Installable expansion cards	.190
Installable internal hard disk unit	.193
Installable 5-inch internal device	.199

Installation
DSNAP 175
RAID Management Tool
ServerStart
ServerView
Installation (on multiple servers) 107
Guided mode
Preparation mode
Installation Partition Size
Installing a CPU internal devices 198
5-inch bays
Installing a CPU internal hard disk units 192
Installing the LAN Driver
Error window after installation
Windows Server 2003 / SBS 2003 131
Windows Server 2003 x64
Windows 2000 Server
Intel(R) PROSet
Cautions for the LAN driver
Installation 166
LAN driver advanced setup
Teaming
VLAN
Internal Hard Disk Unit Specifications 270
iRMC

L

Log deleting.												254
Log saving	• •											254

Μ

0

Open the Rack Door 3	31
Operating the Server	
Precautions	57
Order of expansion card installation 19	0
OS installation	
Installation method 4	-5
Precautions 4	7
Preparation 4	1
OS installation wizard	
Expert mode8	4
Guided mode 6	6

Ρ

Paging File Setting.	136
Windows Server 2003	139
Windows 2000 Server	144
Password settings	257
POST	239
Error Messages	239
Power supply monitoring	174
Preparation mode	. 75

R

Rack key
RAID configuration
Notes
RAID error monitoring 173
RAID Management Tool 20, 172
Installation
RAID wizard
Reinstalling the OS 264
Remote Installation 19, 88
Configuring a remote floppy 103
Failure
Preparation of remote resources 99
Preparation of the PXE server 91
PXE server requirements
Remote resource server requirements 89
Starting installation (for a PXE server) 99
Starting installation (for a remote resource
server)
Remote Management Controller 278
Remote Management Controller Information
Recovering
Removing and attaching covers 180
Required Driver Disks 112
Restoring the system
For Windows Server 2003
For Windows 2000 Server

S

Security		255
Decoverd cottings		256
Password settings		
Server disposal	• •	258
Server disposal		
Server Management Tools 14	48,	252
Cautions		148
Server Monitoring Tool	20,	173
Installation		174
ServerStart		. 16
Cautions		. 49
Features		. 16
Installation		. 52
Supported expansion cards		. 50
Uninstallation		. 54
ServerView	20,	173
Installation		174
SNMP service		250
Solving problems		175
System diagnosis support tools		. 20
System Event logs		252
System Recovery Disk		
Windows Server 2003		
Windows 2000 Server		147

Т

Temperature monitoring 1	73
Troubleshooting 2	37
Turning off the server	34
Turning on the server	33
Turning the Power On via a LAN 1	59

U

Uninstallation ServerStart UPS	
V	
Voltage monitoring	173
W	
	450

vvakeup	On	LAN					·		•	•	•	•	•	•	1	59
Wakeup	On	LAN	fun	ct	io	n.				•	•				•	44

PRIMERGY TX150 S5

User's Guide B7FH-4611-01EN-01

Issued on December, 2006 Issued by FUJITSU LIMITED

- The contents of this manual may be revised without prior notice.
- Fujitsu assumes no liability for damages to third party copyrights or other rights arising from the use of any information in this manual.
- No part of this manual may be reproduced in any without the prior written permission of Fujitsu.