

Areas Covered

<hr/>	
Before Reading This Manual	
	This section explains the notes for your safety and conventions used in this manual.
<hr/>	
Chapter 1	Overview
	This chapter describes an overview, configuration precautions for the disk array, and the array configuration flow.
<hr/>	
Chapter 2	Array Configuration and Management [BIOS Utility]
	This chapter explains the procedure to set up BIOS Utility. BIOS Utility is a basic utility to set up and manage the array controller.
<hr/>	
Chapter 3	Preparations
	This chapter explains how to update device drivers and apply hotfix.
<hr/>	
Chapter 4	Array Configuration and Management [ServerView RAID]
	This chapter explains an overview of and requirements for ServerView RAID Manager, and how to install and use it.
<hr/>	
Chapter 5	Array Configuration and Management [GAM]
	This chapter explains the overview and requirements of GAM, and how to install and use it.
<hr/>	
Chapter 6	Replacing Hard Disk
	This chapter explains maintenance related issues, such as hard disk replacement. Since the procedure varies depending on the management tools used, read the description concerning your management tool.
<hr/>	
Appendix	
	This section explains the event codes for ServerView RAID and GAM, and the notes on the array controller usage.
<hr/>	



Before Reading This Manual

This manual is a guide for using the array controller (Integrated Mirroring SAS).

Remarks

■ Symbols

Symbols used in this manual have the following meanings:

	These sections explain prohibited actions and points to note when using this software. Make sure to read these sections.
	These sections explain information needed to operate the hardware and software properly. Make sure to read these sections.
→	This mark indicates reference pages or manuals.

■ Key descriptions / operations

Keys are represented throughout this manual in the following manner:

E.g.: [Ctrl] key, [Enter] key, [→] key, etc.

The following indicate the pressing of several keys at once:

E.g.: [Ctrl] + [F3] key, [Shift] + [↑] key, etc.

■ CD/DVD drive descriptions

In this manual, both CD-ROM and DVD-ROM drives are described as CD/DVD drives. Select a proper drive depending on your environment.

■ Entering commands (keys)

Command entries are written in the following way:

```
diskcopy a: a:
      ↑  ↑
```

- In the spaces indicated with the "↑" mark, press the [Space] key once.
- In the example above, the command entry is written in lower case, but upper case is also allowed.
- CD/DVD drive letters are shown as [CD/DVD drive]. Enter your drive letter according to your environment.

[CD/DVD drive]:\setup.exe

■ Screen shots and figures

Screen shots and figures are used as visual aids throughout this manual. Windows, screens, and file names may vary depending on the OS, software, or configuration of the server used. Figures in this manual may not show cables that are actually connected for convenience of explanation.

■ Consecutive operations

Consecutive operations are described by connecting them with a dash (–).

Example: For the operation to click the [Start] button, point to [Programs], and click [Accessories]



Click the [Start] button – [Programs] – [Accessories].

■ Abbreviations

The following expressions and abbreviations are used throughout this manual.

table: Abbreviation of product name

Product name	Expression and abbreviation		
Integrated Mirroring SAS	the array controller, this array controller		
Microsoft® Windows Server® 2003, Standard Edition	Windows Server 2003	Windows	
Microsoft® Windows Server® 2003, Enterprise Edition			
Microsoft® Windows Server® 2003 R2, Standard Edition			
Microsoft® Windows Server® 2003 R2, Enterprise Edition			
Microsoft® Windows Server® 2003, Standard x64 Edition	Windows Server 2003 x64 [Note 1]		
Microsoft® Windows Server® 2003, Enterprise x64 Edition			
Microsoft® Windows Server® 2003 R2, Standard x64 Edition			
Microsoft® Windows Server® 2003 R2, Enterprise x64 Edition			
Microsoft® Windows® 2000 Server	Windows 2000 Server		
Microsoft® Windows® 2000 Advanced Server			
Microsoft® Windows® 2000 Professional	Windows 2000 Professional		
Microsoft® Windows® XP Professional	Windows XP		
Red Hat Enterprise Linux 5 (for x86)	Red Hat Linux	Linux	
			RHEL5 (x86)
Red Hat Enterprise Linux 5 (for Intel64)	RHEL5 (Intel64)		
Red Hat Enterprise Linux AS (v.4 for x86)	RHEL-AS4 (x86)		
Red Hat Enterprise Linux ES (v.4 for x86)	RHEL-ES4 (x86)		
Red Hat Enterprise Linux AS (v.4 for EM64T)	RHEL-AS4(EM64T)		
Red Hat Enterprise Linux ES (v.4 for EM64T)	RHEL-ES4 (EM64T)		
Red Hat Enterprise Linux AS (v.3 for x86)	RHEL-AS3 (x86)		
Red Hat Enterprise Linux ES (v.3 for x86)	RHEL-ES3 (x86)		
SUSE™ Linux® Enterprise Server 9	SLES9 or SUSE Linux		

[Note 1]: Unless otherwise noted, Windows Server 2003 can also mean Windows Server 2003 x64.

■ Information for PRIMERGY

For the latest information on PRIMERGY, update modules, drivers and the software, refer to the Fujitsu PRIMERGY website.

<http://www.fujitsu.com/global/services/computing/server/ia/driver/>

Regarding BIOS and FW, contact to Fujitsu Support Office.

Refer to the website (http://www.fujitsu.com/global/contact/computing/PRMRGY_index.html).

■ PRIMERGY Startup Disc

"PRIMERGY Startup Disc" referred in this manual is supplied with a PRIMERGY server. Depending on your PRIMERGY type, "PRIMERGY Document & Tool CD" may be supplied instead. Then "PRIMERGY Startup Disc" also means "PRIMERGY Document & Tool CD" in this manual.

■ Trademarks

Microsoft, Windows, and Windows Server are trademarks or registered trademarks of Microsoft Corporation in the USA and other countries.

Linux is a trademark or registered trademark of Linus Torvalds in the USA and other countries.

Red Hat and all Red Hat-based trademarks and logos are trademarks or registered trademarks of Red Hat, Inc. in the USA and other countries.

SUSE is a trademark of Novell, Inc. in the United States and other countries.

LSI Logic, Global Array Manager (GAM), and Integrated Mirroring are trademarks or registered trademarks of LSI Logic Corp.

All other hardware and software names used are trademarks or registered trademarks of their respective manufacturers.

Other product names are copyrights of their respective manufacturers.

All Rights Reserved, Copyright© FUJITSU LIMITED 2008

Screen shot(s) reprinted with permission from Microsoft Corporation.

Contents

Chapter 1 Overview

1.1 Array Controller Work Flow	10
1.2 Overview of the Disk Array Configuration	12
1.2.1 Array controller specifications	12
1.2.2 What is Disk Array?	13
1.2.3 RAID Levels	13
1.2.4 Logical Drive	14
1.2.5 Checking Hard Disk Status	14
1.3 Disk Array Configuration Features	16
1.3.1 Logical Drive Initialization	16
1.3.2 Rebuild	16
1.3.3 Media Verification	17
1.3.4 Hard Disk Failure Prediction Function (PFA / S.M.A.R.T.)	17
1.4 Notes before Operation	18
1.4.1 Cautions When Using This Product	18
1.4.2 Notes on Hard Disk to Be Used	18
1.5 Notes on Operation	19
1.5.1 Notes on Using Array Controller	19
1.5.2 Using ServerView RAID under Windows 2000 Server Environment	19

Chapter 2 Array Configuration and Management [BIOS Utility]

2.1 Starting and Exiting BIOS Utility	24
2.1.1 Starting BIOS Utility	24
2.1.2 Exiting BIOS Utility	25
2.2 BIOS Utility Screen Layout	27
2.3 Viewing Information	28
2.3.1 Viewing Information on Array Controller	28
2.3.2 Viewing Information on Logical Drive and Hard Disk	31
2.4 Creating and Deleting Logical Drive	36
2.4.1 Creating and Initializing Logical Drive	36
2.4.2 Deleting Logical Drive	42
2.5 Low Level Formatting of Hard Disks	45

Chapter 3 Preparations

3.1 Updating Device Drivers	50
3.1.1 Creating Driver Disks	50
3.1.2 Updating Drivers (Windows Server 2003)	50
3.1.3 Updating Drivers (Windows 2000 Server)	52

3.2 Applying Hotfix	54
----------------------------------	-----------

Chapter 4 Array Configuration and Management [ServerView RAID]

4.1 Requirements for ServerView RAID	56
4.1.1 ServerView RAID Overview	56
4.1.2 Requirements for ServerView RAID	57
4.1.3 Access Privileges to ServerView RAID	58
4.1.4 Using ServerView RAID in Linux Environment	59
4.1.5 Operation via Network	59
4.1.6 When Using ServerView RAID and GAM	61
4.2 Installing ServerView RAID [Windows]	62
4.2.1 How to Install ServerView RAID	62
4.2.2 How to Uninstall ServerView RAID	63
4.3 Starting and Exiting ServerView RAID Manager	65
4.3.1 Preparations and Precautions for using ServerView RAID Manager . . .	65
4.3.2 Starting ServerView RAID Manager	66
4.3.3 Exiting ServerView RAID Manager	68
4.4 ServerView RAID Manager Window Layout	69
4.4.1 Startup Window Layout and Functions	69
4.4.2 Menu Layout and Functions	71
4.4.3 Tree View Layout	73
4.5 Setting ServerView RAID	76
4.6 Rebuild	79
4.7 Checking Status [ServerView RAID Manager]	80
4.7.1 Checking Server Condition	80
4.7.2 Checking Array Controller Status	81
4.7.3 Checking Hard Disk Status	82
4.7.4 Checking Logical Drive Status	84
4.7.5 Checking Progress of Background Task	86

Chapter 5 Array Configuration and Management [GAM]

5.1 Overview and Requirements for GAM	90
5.1.1 GAM Overview	90
5.1.2 Requirements for GAM	91
5.1.3 Access Privileges to GAM	92
5.1.4 Using GAM in Linux Environment	93
5.1.5 Using GAM in Network Environment	94
5.1.6 When Using Both ServerView RAID and GAM	96
5.2 Installing GAM [Windows]	97
5.2.1 How to Install GAM	97
5.2.2 Uninstalling GAM	100

5.3 Starting and Exiting GAM	102
5.3.1 Starting GAM and Signing On	102
5.3.2 Exiting GAM	103
5.4 GAM Window Layout	104
5.4.1 Startup Window Layout and Functions	104
5.4.2 Menu Layout and Functions	106
5.4.3 Toolbar Icons	108
5.4.4 Starting Controller View and the Window Layout	109
5.5 Server Group and Server Setting	111
5.6 Viewing Information [GAM]	112
5.6.1 Events	112
5.6.2 Viewing Array Controller Information	114
5.6.3 Viewing Hard Disk Information	115
5.6.4 Viewing Logical Drive Information	118
5.6.5 Checking Progress of Background Tasks	120
5.7 Rebuild	121

Chapter 6 Replacing Hard Disk

6.1 How to Replace Hard Disk [ServerView RAID]	124
6.1.1 Checking Hard Disk to be Replaced [ServerView RAID]	124
6.1.2 Replacing Failed Hard Disk [ServerView RAID]	125
6.1.3 Preventive Replacement of Hard Disk [ServerView RAID]	127
6.2 How to Replace Hard Disk [GAM]	131
6.2.1 Checking Hard Disk to be Replaced [GAM]	131
6.2.2 Replacing Failed Hard Disk [GAM]	132
6.2.3 Preventive Replacement of Hard Disk [GAM]	134

Appendix

A A List of ServerView RAID Event Logs	138
B A List of GAM Event Logs	158
C Notes on Usage for the Array Controller	171
C.1 When Replacing Array Controllers	171

Chapter 1

Overview

This chapter describes an overview, configuration precautions for the disk array, and the array configuration flow.

1.1	Array Controller Work Flow	10
1.2	Overview of the Disk Array Configuration	12
1.3	Disk Array Configuration Features	16
1.4	Notes before Operation	18
1.5	Notes on Operation	19

1.1 Array Controller Work Flow

The work flow when using a disk array controller is as follows:

■ For Windows

1. Designing the Disk Array



Set the operation pattern of the disk array configuration. Design the RAID level and the logical drive configuration.

- 1.2 Overview of the Disk Array Configuration
- 1.3 Disk Array Configuration Features

2. Configuring the Disk Array



Configure the disk array using BIOS Utility before installing the OS.
→ Chapter 2 Array Configuration and Management [BIOS Utility]

3. Installing the OS



- "User's Guide" provided with the server
- 3.2 Applying the Hotfix

4. Installing the Management Tools



Install the following management tools.
• ServerView RAID *
• Global Array Manager(GAM) *

- Chapter 4 Array Configuration and Management [ServerView RAID]
- Chapter 5 Array Configuration and Management [GAM]

ServerStart will help you set up Steps from **2** to **4**.

* Either one tool can be installed. For details, see ReadmeEN.html on the "Array Controller Document & Tool CD".

5. Updating the Device Drivers



Update the device drivers to the latest version stored on the "Array Controller Document & Tool CD".

- 3.1 Updating the Device Drivers

6. Preparing the Environment for the Management Tools

Register the user account with the OS to use the management tools. (This is not required if it is set at the installation of the management tools.)

- Chapter 4 Array Configuration and Management [ServerView RAID]
- Chapter 5 Array Configuration and Management [GAM]

■ For Linux

For Linux information, see the PRIMERGY page on the Fujitsu website (<http://primergy.fujitsu.com/>).

1. Designing the Disk Array



Set the operation pattern of the disk array configuration. Design the RAID level and the logical drive configuration.

→ 1.2 Overview of the Disk Array Configuration

→ 1.3 Disk Array Configuration Features

2. Configuring the Disk Array



Configure the disk array using WebBIOS before installing the OS.

→ Chapter 2 Array Configuration and Management [BIOS Utility]

3. Installing the OS



→ "Installation Guide"

4. Installing the Management Tools



Install the following management tools.

→ "Installation Guide"

• ServerView RAID *

• Global Array Manager(GAM) *

* Either one tool can be installed. For details, see ReadmeEN.html on the "Array Controller Document & Tool CD".

5. Preparing the Environment for the Management Tools

Register the user account with the OS to use the management tools. (This is not required if it is set at the installation of the management tools.)

→ "Installation Guide"

1.2 Overview of the Disk Array Configuration

This section describes an overview of the disk array (RAID levels and logical drives) and its function.

1.2.1 Array controller specifications

The specifications of the array controller described in this manual are as follows:

table: Specifications

Item	Contents		
Product name	No model name (LSI SAS 1068)	No model name (LSI SAS 1064E)	RAID 0/1 SAS 4P (LSI SAS 1064E)
Where to be installed in the server	Onboard [Note 1]	Onboard [Note 1]	PCI-E Slot installable card
Interface	SAS (Serial Attached SCSI)		
The number of ports	8 ports	4 ports	4 ports
Cache memory and capacity	Not available		
Supported OS	OS supported by the server		
Management Tools	<p>Available tools are: (1) BIOS Utility which configures disk arrays before installing the OS and (2) ServerView RAID or GAM which monitors or manages array controllers on the OS.</p> <p>Make sure to install management tools before using the array controller.</p> <p>Install either ServerView RAID or GAM, but not both at a time. For which to use, see ReadmeEN.html on Array Controller Document & Tool CD.</p> <ul style="list-style-type: none"> • BIOS Utility BIOS Utility in the array controller. →"Chapter 2 Array Configuration and Management [BIOS Utility]" (pg.23) • ServerView RAID →"Chapter 4 Array Configuration and Management [ServerView RAID]" (pg.55) • Global Array Manager (GAM) →"Chapter 5 Array Configuration and Management [GAM]" (pg.89) 		

[Note 1]: It is installed on the baseboard of the server.

1.2.2 What is Disk Array?

A disk array or RAID (Redundant Array of Independent Disks) is a system that uses an array controller and multiple hard disks to achieve better performance and higher reliability than when using a single hard disk.

An array controller controls the access to each hard disk. There are different types of control methods that are defined as RAID levels.

By using a redundant RAID level, system operation can be continued without data loss in the event of a hard disk failure.

1.2.3 RAID Levels

There are several types of RAID levels, with different characteristics.

This array controller only supports RAID 1.


table: Characteristics of each RAID level

RAID Level	Number of hard disks	Available total capacity	Redundancy
RAID 1	2	Capacity of one hard disk	Yes

■ RAID 1 (Mirroring)

Mirroring is a function in which data is written into two hard disks in duplicate. When operating in RAID 1 disk array configuration, the system always writes the same data in the two hard disks using the redundancy feature. Operation continues even when one of the hard disks fails and loses redundancy (Critical).

RAID 1 always consists of two hard disks and the actual capacity you can use is the capacity of one hard disk.



IMPORTANT

- ▶ With RAID 1, operation continues even if one of the hard disks fails (critical). However, the data could be lost if both hard disks fail. If the status of a logical drive becomes critical, replace the failed hard disk as soon as possible to recover the redundancy.
See "Chapter 6 Replacing Hard Disk" (→pg.123) for how to replace hard disks.


POINT

- ▶ Backup the data as frequently as possible just in case even with redundancy.

1.2.4 Logical Drive

A logical drive is a logical hard disk space created when a disk array is configured. The OS recognizes it as same as a single hard disk.

As shown in the following figure, with RAID 1, two hard disks compose one logical drive, but the OS recognizes it as if a single hard disk was connected.



IMPORTANT

- ▶ Hard disks in a logical drive should be of the same model (with the same capacity and speed).
- ▶ This array controller can support only one logical drive.
- ▶ Right after the creation of a logical drive using this array controller, the logical drive does not have redundancy. To use it with redundancy, initialization of the logical drive is required. For details, see "1.3.1 Logical Drive Initialization" (→pg.16).

■ Status during hard disk failure

If one of the hard disks fails, the logical drive loses its redundancy, and the status becomes critical.

If the other drive also fails, the logical drive status becomes "Offline" (unavailable).

1.2.5 Checking Hard Disk Status

Hard disks and logical drives should be regularly monitored, and be replaced if there is a failure or indication of a failure.

POINT

- ▶ Status indicators differ depending on a management tool. For the status information, see the appropriate section in your management tool's documents.
 - BIOS Utility
 - "2.3.2 Viewing Information on Logical Drive and Hard Disk" (pg.31)
 - ServerView RAID
 - "4.4.3 Tree View Layout" (pg.73)
 - GAM
 - "5.4.4 Starting Controller View and the Window Layout" (pg.109)
- ▶ When ServerView RAID or GAM operates properly, information is logged as an event if an error occurs in the logical drive or hard disk.
 - "Appendix A A List of ServerView RAID Event Logs" (pg.138)
 - "Appendix B A List of GAM Event Logs" (pg.158)

■ Logical drive status

Logical drive statuses are shown in the table below.

table: Logical drive status

Status	Description
Online	The logical drive is operating normally.
Critical	A redundant logical drive (RAID 1) is currently operating without redundancy due to a hard disk failure. Replace the failed hard disk as soon as possible and perform a rebuild to restore the online status. See "Chapter 6 Replacing Hard Disk" (→pg.123) for how to replace hard disks and rebuild.
Offline	This indicates that the logical drive is not operating. Two or more hard disk failure in a logical drive leads to offline state. The data in the logical drive will be lost.

■ Hard disk status

Hard disk statuses are shown in the table below.

table: Hard disk status

Status	Description
Online	The hard disk is configured in the disk array and operating normally.
Unused	It is out of operation as the hard disks are not configured in the disk array. The hard disk is operating normally.
Failed	The disk is damaged and data read/write is disabled. Replace the hard disk and perform a rebuild. See "Chapter 6 Replacing Hard Disk" (→pg.123) for how to replace a hard disk.
Offline	Data read/write is disabled by the array controller. Perform a rebuild to use the hard disk again.
Rebuild	The hard disk is currently being rebuilt.
Failure Predicted	The hard disk is currently operating normally, but may fail in the near future (failure predicted status). See "Chapter 6 Replacing Hard Disk" (→pg.123) and replace the hard disk as soon as possible.



- ▶ If there is a hard disk with failure status, there may be a hard disk failure and the disks may be operating without redundancy. The hard disk must be replaced as soon as possible. See "6.1.2 Replacing Failed Hard Disk [ServerView RAID]" (→pg.125) and "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) for how to replace a hard disk.



- ▶ This array controller sets the redundancy management priority as primary or secondary for each hard disk in the logical drive.
When one hard disk has failed, the other operating drive is set as primary, and the rebuild is performed using the primary drive for the secondary drive.

1.3 Disk Array Configuration Features

This section explains the features in disk array configuration.

1.3.1 Logical Drive Initialization

To enable a logical drive to operate with redundancy, initialization is required to make the hard disks in the logical drive consistent.

Right after the creation of a logical drive using this array controller, the logical drive does not have redundancy and data is only stored on the primary hard disk. The initialization can be done with a rebuild. For details about rebuild, see "1.3.2 Rebuild" (→pg.16).



- ▶ The logical drive does not have redundancy until the initialization is completed. So if the primary hard disk fails, the data will be lost.
- ▶ Before the initialization, the secondary hard disk cannot be used and its failure LED remains lit.
- ▶ The initialization is done with a rebuild, which means that the hard disk failure LED of the secondary drive keeps blinking during the initialization.

1.3.2 Rebuild

Even if a hard disk in a logical drive fails, if there is redundancy (RAID 1), the logical drive continues to operate in critical. However, if another hard disk in the same logical drive also fails, the status of the logical drive becomes unavailable (offline). Rebuild is a operation to recover a logical drive from critical to normal (online).

The rebuild process is performed in the background in parallel with normal I/O access. During rebuilding, if a logical drive becomes critical, the redundancy of the logical drive remains lost. Once the rebuild is complete, it is restored to online.

You can start a rebuild by executing [Synchronize] in BIOS Utility or by executing [Rebuild] in the array management tool (ServerView or GAM).

■ Estimated time for rebuild

The estimated time for rebuild differs depending on I/O load from the server. The table below shows the estimated time when the I/O load is none and high.

It also differs depending on such factors as the server configuration and the availability of hard disks to be used. Use them only as a reference.

table: Estimated time for rebuild

Hard disk capacity	No load	High load
73GB	approx. 4 hrs	approx. 7 hrs
147GB	approx. 7 hrs	approx. 14 hrs
300GB	approx. 15 hrs	approx. 30 hrs

 **POINT**

- ▶ The rebuild is performed in parallel with regular I/O operation. Therefore, I/O performance for the logical drives can be degraded during rebuild. With this array controller, the I/O performance degrades about 50% at maximum.
- ▶ If the system restarts or shuts down during rebuild, the rebuild is resumed from where it was stopped the next time.

1.3.3 Media Verification

Media verification is a function that detects media errors on a hard disk in advance and restores data using the data on the other hard disks.

This array controller always performs media verification when the logical drive is in online state.

If there are media errors on the hard disks that were not replaced, the rebuild cannot restore their data.

Media verification reduces the risk of data loss at rebuild, by correcting media errors in advance.

1.3.4 Hard Disk Failure Prediction Function (PFA / S.M.A.R.T.)

The PFA/S.M.A.R.T. function is a failure prediction function for hard disks, which determines the failure risk in advance and issues a warning when the risk is high.

Although a hard disk will still operate normally even when a risk of a failure is predicted, that hard disk may fail in the near future and should be replaced as soon as possible. See "6.1.3 Preventive Replacement of Hard Disk [ServerView RAID]" (→pg.127) or "6.2.3 Preventive Replacement of Hard Disk [GAM]" (→pg.134) for the replacement procedure. The hard disk for which failure is predicted can be identified by management tools or event logs.

1.4 Notes before Operation

Check the following before starting the operation.

1.4.1 Cautions When Using This Product

The usage may be limited depending on the server to be installed in.

1.4.2 Notes on Hard Disk to Be Used

The following notes apply to the hard disks to be used. Please read them in advance.

● Usable hard disk

Use the hard disks of the same model (with the same capacity and speed) in a logical drive. Check that the installed hard disks have the same capacity and speed. Also, check that the hard disks are installable on the server.

● Reusing hard disk

Hard disks containing data may have partition information or array configuration information. Using such disks without taking the proper measures may cause unexpected problems. When using a previously used hard disk, erase the data by performing low level format on the system that was using the hard disk before installing it to the array controller.

The same caution applies when using hard disks used by this product on another system. See "2.5 Low Level Formatting of Hard Disks" (→pg.45) and completely erase the information on the hard disk before using it on another system.

● Removing hard disk

When the server is running, do not remove hard disks except for the following situations:

- When replacing a failed hard disk
- When replacing a hard disk as a preventive measure

● Notes on connecting device

Do not connect any devices other than Fujitsu-supported hard disks to this array controller.

1.5 Notes on Operation

This section contains notes concerning system operation when using this array controller.

1.5.1 Notes on Using Array Controller

When using Windows in a disk array configuration, one of the following events may be recorded in the Event Viewer's system log:

```
Source       : lsi_sas
Type        : Warning
Event ID    : 129
Description: The description for Event ID (129) in Source (lsi_sas) cannot
              be found.
              (The rest is omitted.)
```

```
Source       : lsi-sas
Type        : Error
Event ID    : 11
Description: The driver detected a controller error on ¥Device¥RaidPortN
              (The rest is omitted.)
```

These logs entry means that an internal reset has been issued in the device driver, but since the event has been restored by the OS retry, you can continue the operation.

However, if this event occurs repeatedly (about twice in every 10 minutes), there is a possibility of hardware failure. Contact an office listed in the "Contact Information" of "Start Guide" and check the array controller and hard disks.

1.5.2 Using ServerView RAID under Windows 2000 Server Environment

Under the conditions below, at the restart of Windows 2000 Server, events reporting abnormalities of hard disks or logical drives may be recorded.

- When restarting Windows 2000 Server after installing Windows 2000 Server and ServerView RAID using ServerStart.
- When restarting Windows 2000 Server after applying the hotfix KB904374 of Windows 2000 Server with ServerView RAID installed in it.

The details of the recorded events are as follows.

Note that the [Array Controller Name], Logical drive [%s], Disk [%s], and [Server Name] in the messages are different according to the types of array controller that is installed, the number of created logical drives, the number of installed hard disks, and the setting values of the server name.

- **For events via ServerView**

Source	Fujitsu ServerView Services
ID	3
Message	ServerView received the following alarm from server [Server Name]: Adapter [Array Controller Name]: Disk [%s] missing after reboot (Server [Server Name])
Description	Unable to find the hard disk at the restart of the server.
Example	ServerView received the following alarm from server PRIMERGY03: Adapter LSI 1068SASIME-2399 (0): Disk (0) missing after reboot (Server PRIMERGY03)

Source	Fujitsu ServerView Services
ID	3
Message	ServerView received the following alarm from server [Server Name]: Adapter [Array Controller Name]: Logical drive [%s] missing after reboot (Server [Server Name])
Description	Unable to find the logical drive at the restart of the server.
Example	ServerView received the following alarm from server PRIMERGY03: Adapter LSI 1068SASIME-2399 (0): Logical drive (0) missing after reboot (Server PRIMERGY03)

- **Source: For ServerView RAID events, or ServerView RAID Manager event window**

Source	ServerView RAID
ID	10476
Message	Adapter %s: Disk (%s) missing after reboot
Description	Unable to find the hard disk at the restart of the server.
Example	Adapter LSI 1068SASIME-2399 (0): Disk (0) missing after reboot

Source	ServerView RAID
ID	10477
Message	Adapter %s: Logical drive %s missing after reboot
Description	Unable to find the logical drive at the restart of the server.
Example	Adapter LSI 1068SASIME-2399 (0): Logical drive (0) missing after reboot

When the events above are recorded, check the state of the array using ServerView RAID Manager. If the array is recognized as the normal state, ignore the events.

 **POINT**

- ▶ Information that Windows SCSI mini port driver outputs will be changed by applying the hotfix. So, the information is different from what ServerView RAID had until then. So, the events above occur at the first restarting after applying the hotfix.
- ▶ The events will not occur if the state of the array is normal after the next startups.
- ▶ The events are recorded when restarting the server after installing Windows 2000 Server since the hotfix is automatically applied if you install the server using ServerStart.

Chapter 2

Array Configuration and Management [BIOS Utility]

This chapter explains the procedure to set up BIOS Utility. BIOS Utility is a basic utility to set up and manage the array controller.

2.1	Starting and Exiting BIOS Utility	24
2.2	BIOS Utility Screen Layout	27
2.3	Viewing Information	28
2.4	Creating and Deleting Logical Drive	36
2.5	Low Level Formatting of Hard Disks	45

2.1 Starting and Exiting BIOS Utility

This section explains how to start up and exit BIOS Utility. BIOS Utility starts from BIOS at system startup, regardless of whether the OS has been installed or not on the computer to be used.

IMPORTANT

- ▶ The terms "logical drive" and "array controller" used in this manual are displayed as "Array" and "Adapter" respectively in BIOS Utility. Read the manual by replacing the terms with those used in BIOS Utility when necessary.

2.1.1 Starting BIOS Utility

Follow the procedure below:

- 1 After turning on the server, press the [Ctrl] + [C] keys while the following messages are displayed on the screen.

```
LSI Logic Corp. MPT SAS BIOS
MPTBIOS-x.xx.xx.xx (xxxx.xx.xx)
Copyright xxxx-xxxx LSI Logic Corp.
```

Press Ctrl C to start LSI Logic Configuration Utility

Press the [Ctrl]+[C] keys while the message "Press Ctrl C to start LSI Logic Configuration Utility" is displayed on the screen.

The following message appears and BIOS Utility starts up after the POST of the server is complete.

```
Please wait, invoking SAS Configuration Utility.
```


IMPORTANT

- ▶ If the following message appears, the hard disk may have a failure.

```
xxxx enter the LSI Logic Configuration
Utility to investigate!
```

In this case, see "Chapter 6 Replacing Hard Disk" (→pg.123) to check the hard disk status. If there is a failed hard disk, replace the disk and perform rebuild.

BIOS Utility starts and the [Adapter List] screen appears.



POINT


- For this array controller, "SAS1068" or "SAS1064E", depending on a server and a card, appears on [Adapter] of the above screen.

2.1.2 Exiting BIOS Utility

Follow the procedure below to exit BIOS Utility.


1 Display the [Adapter List] screen.

If another screen is displayed, press the [Esc] key several times until the [Adapter List] screen appears.



2 Press the [Esc] key.

The [Exit Menu] appears.




3 Select [Exit the Configuration Utility and Reboot] and press the [Enter] key.

BIOS Utility closes and the system restarts.

2.2 BIOS Utility Screen Layout

BIOS Utility screen consists of three areas.

The displayed contents vary depending on functions to be selected.



POINT

- ▶ In BIOS Utility, press the [Esc] key to return to the previous screen.

■ Header area

The upper row shows the name and the version number of this utility. The lower row shows the name of the current screen.

■ Main area

The main area for each screen. Configurable items and menus are displayed in yellow and can be configured by moving the cursor using the keyboard.

■ Footer area

A help message for the current screen appears. Explanation of function keys is displayed.

2.3 Viewing Information

With BIOS Utility, you can see information on the array controller, a logical drive, and hard disks.

- Viewing Information on Array Controller (→pg.28)
- Viewing Information on Logical Drive and Hard Disk (→pg.31)

2.3.1 Viewing Information on Array Controller

Information about the array controller is displayed on the [Adapter Properties] and the [Global Properties] screens.

■ Adapter Properties

1 Start up BIOS Utility.

→"2.1.1 Starting BIOS Utility" (pg.24)

POINT

- ▶ If BIOS Utility is already running and another screen is displayed, press the [Esc] key several times until the [Adapter List] screen appears.

2 Check that the [Adapter List] menu is selected and press the [Enter] key.

POINT

- ▶ This screen is for selecting an array controller to be accessed, but only one controller is shown. So, simply press the [Enter] key.

The [Adapter Properties] screen appears.




table: Array controller information on the [Adapter Properties] screen

Item	Description
Adapter	Displays the name of the array controller.
PCI Slot	Displays the PCI slot number where the array controller is installed.
PCI Address	Displays the array controller's PCI address configured by the server BIOS. Displays, from left to right, the bus number, the device number, and the function number.
MPT Firmware Revision	Displays the firmware revision of the array controller.
SAS Address	Displays the SAS address of the array controller.
NVDATA Version	Displays the NVRAM revision of the array controller.
Status	Displays the status of the array controller.
Enabled	Indicates that the array controller BIOS is available.
Disabled	Indicates that the array controller BIOS is unavailable.
Error	Indicates that the array controller's BIOS is not operating due to failures.
Boot Order	Displays the boot order of the array controllers when multiple array controllers are installed. With this array controller, this item is always "0" because only one controller can be installed on the server.
Boot Support	Displays the control configuration for this array controller. For this array controller, this item is set as "Enabled BIOS & OS" (i.e. this array controller is controllable from either BIOS or the OS driver) and the configuration cannot be changed.

POINT

- ▶ Press the [Esc] key to return to the [Adapter List] screen. If you have changed settings, the confirmation screen appears. Select [Discard changes then exit this menu].

■ Global Properties

1 Start up BIOS Utility.


→ "2.1.1 Starting BIOS Utility" (pg.24)

POINT

- ▶ If BIOS Utility is already running and another screen is displayed, press the [Esc] key several times until the [Adapter List] screen appears.

- 2** Check that the [Adapter List] menu is selected and press the [Alt] + [N] keys to select the [Global Properties] menu.

The [Global Properties] screen appears.



 **IMPORTANT**

- ▶ Do not change the default values of the items on this screen. If you have changed them by mistake, select [Restore Defaults] and press the [Enter] key to restore the default values.

table: Array controller information on the [Global Properties] screen

Item	Description
Pause When Boot Alert Displayed	Indicates whether or not to pause operation when a failure is detected during the array controller's Power On Self Test (POST). The default value is "No".
Boot Information Display Mode	Displays the scope of the information that is displayed during the array controller's POST (e.g. hard disks). The default value is "Display adapter & installed devices".
Set Interrupt	Indicates whether or not to accept INT 13h interrupts. The default value is "Hook interrupt, the default".

 **POINT**

- ▶ Press the [Esc] key to return to the [Adapter List] screen. If you have changed settings, the confirmation screen appears. Select [Discard changes then exit this menu].

2.3.2 Viewing Information on Logical Drive and Hard Disk

You can see the information on logical drive and hard disks on the [View Array] screen.

1 Start up BIOS Utility.

→ "2.1.1 Starting BIOS Utility" (pg.24)

POINT

- ▶ If BIOS Utility is already running and another screen is displayed, press the [Esc] key several times until the [Adapter List] screen appears.

2 Check that the [Adapter List] menu is selected and press the [Enter] key.


POINT

- ▶ This screen is for selecting an array controller to be accessed, but only one controller is shown. So, simply press the [Enter] key.

The [Adapter Properties] screen appears.


3 Select [RAID Properties] and press the [Enter] key.

The [Select New Array Type] screen appears.



4 Select [View Existing Array] and press the [Enter] key.

The [View Array] screen appears, which displays the information about a logical drive and the hard disks that belong to the logical drive.



POINT

- ▶ When no logical drives exist, [View Existing Array] is not displayed.

See "■ Information on logical drives" (→pg.32) for information on logical drives, and "■ Information on hard disks" (→pg.33) for details on hard disks.

5 Press the [Esc] key to close the screen.

The display returns to the [Adapter Properties] screen.

■ Information on logical drives

This section explains each item in the information on logical drives.

POINT

- ▶ The information on logical drives is displayed at the top of the main area of the [View Array] screen.

● Array

The total number of logical drives existing on the array controller and the number of the logical drives for which information is currently shown are displayed. Since this array controller only supports one logical drive, "1 of 1" always appears.

● Identifier

The name to identify the logical drive if displayed. It is usually displayed as "LSILOGICLogical Volume 3000".

● Type

The type of logical drive is displayed. It is always displayed as "IM".

● Scan Order

The scan order among multiple logical drives is displayed. Since this array controller only supports one logical drive, "0" always appears .

● Size (MB)

The total capacity of the logical drive is displayed.

● Status

The current status of the logical drive is isplayed. The meaning of each status is shown below:

table: Logical drive status

Status Indicator	Description
Optimal	The logical drive is operating normally.
Degraded	The logical drive is operating without redundancy because one of the hard disks has failed. See "Chapter 6 Replacing Hard Disk" (→pg.123) and immediately replace the failed hard disk.
Failed	The logical drive is unavailable because multiple hard disks have failed. See "Chapter 6 Replacing Hard Disk" (→pg.123) and immediately replace the failed hard disks.
xx% Syncd	The logical drive is being rebuilt or initialized. The progress is displayed as a percentage.
Inactive	The logical drive cannot be used because it has been used in another system and the hard disks still contain the previous system information. See "2.5 Low Level Formatting of Hard Disks" (→pg.45) to format the hard disks, and then configure a new logical drive.

■ Information on hard disks

This section explains each item of the hard disk information.

POINT

- ▶ The information on hard disks is displayed at the bottom of the [View Array] screen.

● Slot Num

The number of a physical slot in which the hard disk is installed is displayed.

● Device Identifier

The hard disk vendor name, the model name, and the firmware version of the hard disk are displayed from left to right.

● RAID Disk

It indicates whether or not a hard disk is contained in the logical drive with "Yes" or "No".

● Hot Spr

It indicates whether or not a hard disk is assigned as a hot spare drive with "Yes" or "No". This is always "No", because this array controller does not support the hot spare function.

● Drive Status

It displays the current status of the hard disk. The meaning of each status is shown below:

table: Hard disk status

Status Indication	Description
-----	The hard disk is operating normally but does not belong to a logical drive.
Primary	The hard disk is operating normally and is configured as the primary disk of RAID 1.
Secondary	The hard disk is operating normally and is configured as the secondary disk of RAID 1.
Missing	The hard disk has failed and there is no response. See "Chapter 6 Replacing Hard Disk" (→pg.123), and replace the failed hard disk.
Failed	The hard disk has a failure. See "Chapter 6 Replacing Hard Disk" (→pg.123), and replace the failed hard disk.
Offline	The hard disk is offline state and data read/write is disabled. See "Chapter 6 Replacing Hard Disk" (→pg.123) and replace the hard disk in the offline state.
Initing	The hard disk is being formatted.
Inactive	The hard disk cannot be used because it contains information of another system. See "2.5 Low Level Formatting of Hard Disks" (→pg.45) to format the hard disk before using it. There is also a possibility that the detected hard disk has a failure. See "Chapter 6 Replacing Hard Disk" (→pg.123), and if the hard disk has a failure, immediately replace the drive.
Not Syncd	The hard disk is included in a logical drive, but the initialization or the rebuild is not complete. If the hard disk is in this status even though initialization or rebuild is complete, the drive must have a failure. See "Chapter 6 Replacing Hard Disk" (→pg.123) to replace the failed hard disk.
Wrg Type	The hard disk cannot be used as a part of logical drive because the drive is the wrong type or is not an appropriate product. If the hard disk is in this status, the drive may have a failure. See "Chapter 6 Replacing Hard Disk" (→pg.123) to replace the failed hard disk.
Too Small	The hard disk cannot be used as a part of logical drive because its capacity is too small. If the hard disk is in this status, the drive may have a failure. See "Chapter 6 Replacing Hard Disk" (→pg.123), and replace the failed hard disk.
Max Dskd	The number of hard disks exceeds the maximum possible number that can be configured in a logical drive. If the hard disk is in this status, the drive may have a failure. See "Chapter 6 Replacing Hard Disk" (→pg.123) to replace the failed hard disk.
No SMART	The hard disk cannot be used because it does not support S.M.A.R.T. failure prediction function. If the hard disk is in this status, the drive may have a failure. See "Chapter 6 Replacing Hard Disk" (→pg.123) to replace the failed hard disk.
Wrg Intfc	The hard disk cannot be used as a part of logical drive because its interface is not SAS. If the hard disk is in this status, the drive may have a failure. See "Chapter 6 Replacing Hard Disk" (→pg.123) to replace the failed hard disk.

● Pred Fail

It displays with "Yes" or "No" whether or not the hard disk is operating with the PFA (S.M.A.R.T.) over the threshold.



- ▶ A hard disk with [Pred Fail] "Yes" is exceeding the PFA (S.M.A.R.T.) threshold and may fail in the near future. See "Chapter 6 Replacing Hard Disk" (→pg.123) to replace the hard disk as soon as possible as a preventive measure.

- **Size**

The capacity of the hard disk is displayed in MB.

2.4 Creating and Deleting Logical Drive

To use a logical drive with redundancy (RAID 1), create and initialize it with BIOS Utility.

When deleting a logical drive, the hard disks configured in the logical drive can be restored unconfigured.

2.4.1 Creating and Initializing Logical Drive

Follow the procedure below to create a logical drive.

After creating a logical drive, initialize it to make it redundant.

POINT

- ▶ For how to initialize a logical drive, see "1.3.1 Logical Drive Initialization" (→pg.16).

1 Start up BIOS Utility.

→"2.1.1 Starting BIOS Utility" (pg.24)

POINT

- ▶ If BIOS Utility is already running and another screen is displayed, press the [Esc] key several times until the [Adapter List] screen appears.

2 Check that the [Adapter List] menu is selected and press the [Enter] key.


POINT

- ▶ This screen is for selecting an array controller to access, but only one controller is shown. So, simply press the [Enter] key.

The [Adapter Properties] screen appears.

3 Select [RAID Properties] and press the [Enter] key.

The [Select New Array Type] screen appears.




4 Select [Create IM Volume] and press the [Enter] key.

POINT

- ▶ This array controller does not support [Create IME Volume] and [Create IS Volume] functions. Do not select them.

The [Create New Array] screen appears.




- 5** Move the cursor to the [RAID Disk] field of the hard disk to be configured as the primary disk and press the [Space] key.

POINT

- ▶ The drive with [Slot Num] "0" is usually configured as the primary disk.

The methods to make a logical drive are displayed.




- 6** Press the [M] key to select a method from the upper row.

IMPORTANT


- ▶ Do not press the [D] key here. This array controller does not support the method selected with the [D] key.

A list of the installed hard disks is displayed. Check that the [Drive Status] of the drive selected in the step 4 is displayed as "Primary".




- 7** Move the cursor to the [RAID Disk] field of another drive and press the [Space] key.

The [Drive Status] becomes "Secondary".



- 8** Press the [C] key.

The confirmation screen to create a logical drive appears.



- 9** Select [Save changes then exit this menu] and press the [Enter] key.

The creation of the logical drive starts. It may take from several seconds to up to a minute to create a logical drive.

When the creation is complete, the [Adapter Properties] screen appears.



- ▶ The created logical drive does not have redundancy. Make sure to make it redundant by initializing it.

- 10** Initialize the logical drive. Select [RAID Properties] and press the [Enter] key.
The [Select New Array Type] screen appears.

```
LSI Logic Config Utility          v6.08.04.00 (2006.07.13)
Select New Array Type -- SAS1068

  View Existing Array_           View the existing configuration.

  Create IM Volume               Create Integrated Mirror Array of 2
                                disks plus an optional hot spare. Data
                                on the primary disk may be migrated.

  Create IME Volume              Create Integrated Mirrored Enhanced
                                Array of 3 to 8 disks including an
                                optional hot spare.
                                ALL DATA on array disks will be DELETED!

  Create IS Volume               Create Integrated Striping array of
                                2 to 8 disks.
                                ALL DATA on array disks will be DELETED!

Esc = Exit Menu      F1/Shift+1 = Help
Enter = Choose array type to create
```

- 11** Select [View Existing Array] and press the [Enter] key.
The [View Array] screen appears.

```
LSI Logic Config Utility          v6.08.04.00 (2006.07.13)
View Array -- SAS1068
  Array                          1 of 1
  Identifier                     LSILogicLogical Volume 3000
  Type                           IM
  Scan Order                     0
  Size(MB)                       69618
  Status                         Degraded


  Manage Array_

Slot Num  Device Identifier      RAID Disk  Hot Spr  Drive Status  Pred Fail  Size (MB)
0         FUJITSU MAX3073RC      5204   Yes   No   Primary   No        69618
1         FUJITSU MAX3073RC      5204   Yes   No   Not Syncd No        69618

Esc = Exit Menu      F1/Shift+1 = Help
Enter=Select Item  Alt+N=Next Array  C=Create an array
```


12 Select [Manage Array] and press the [Enter] key.

The [Manage Array] screen appears.

**13** Select [Synchronize Array] and press the [Enter] key.

- This array controller does not support the [Manage Hot Spare] function. Do not select it.

The confirmation screen to initialize a logical drive appears.



14 Press the [Y] key.

The [Manage Array] screen appears and the initialization of the logical drive starts.

 **IMPORTANT**

- ▶ The logical drive does not have redundancy until the completion of the initialization. And if the primary hard disk fails, data will be lost.
- ▶ Before the initialization, the secondary hard disk cannot be used and its failure LED remains lit.
- ▶ The initialization is done with a rebuild, which means that the hard disk failure LED of the secondary drive flashes during the initialization.

 **POINT**

- ▶ This array controller supports background initialization. If you exit BIOS Utility and restart the server, initialization is performed in parallel with the OS installation.

15 Press the [Esc] key twice to return to the [Adapter Properties] screen.

2.4.2 Deleting Logical Drive

To delete the logical drive and restore the hard disks to their original state (not belonging to a logical drive), follow the procedure below.

 **IMPORTANT**

- ▶ Note that the data on hard disks are deleted when the logical drive is deleted.

1 Start up BIOS Utility.

→ "2.1.1 Starting BIOS Utility" (pg.24)

 **POINT**

- ▶ If BIOS Utility is already running and another screen is displayed, press the [Esc] key several times until the [Adapter List] screen appears.

2 Check that the [Adapter List] menu is selected and press the [Enter] key.


 **POINT**

- ▶ This screen is for selecting an array controller to access, but only one controller is shown. So, simply press the [Enter] key.

The [Adapter Properties] screen appears.


3 Select [RAID Properties] and press the [Enter] key.

The [Select New Array Type] screen appears.




4 Select [View Existing Array] and press the [Enter] key.

The [View Array] screen appears.




5 Select [Manage Array] and press the [Enter] key.

The [Manage Array] screen appears.

**6** Select [Delete Array] and press the [Enter] key.

The confirmation screen to delete the logical drive appears.

**7** Press the [Y] key.

The deletion of the logical drive starts. It may take from several seconds to up to a minute to delete the logical drive.

When the deletion is finished, the [Adapter Properties] screen appears.

2.5 Low Level Formatting of Hard Disks

This section explains how to perform a low level formatting of hard disks in BIOS Utility.

When you reuse a hard disk that was previously used in another system, follow the procedure below to format it.

IMPORTANT

- ▶ All the data on a hard disk are deleted when the drive is formatted.
- ▶ Do not turn off or restart the server during formatting. The hard disk will fail and become unusable.
- ▶ Hard disk formatting takes a long time. The time required depends on the type of the hard disk, but approximately 1.5 minutes per GB. (For example, it takes about 110 minutes to format a 73GB hard disk.) Make sure you have enough time before performing formatting, as the formatting cannot be interrupted once it has been started.

POINT

- ▶ Hard disk formatting can only be done for hard disks that are not contained in a logical drive.
- ▶ To format the hard disks contained in a logical drive, delete the logical drive first, referring to "2.4.2 Deleting Logical Drive" (→pg.42) , and then format the hard disk with the following procedure.
- ▶ It is not possible to format multiple hard disks at the same time.

1 Start up BIOS Utility.

→"2.1.1 Starting BIOS Utility" (pg.24)

POINT

- ▶ If BIOS Utility is already running and another screen is displayed, press the [Esc] key several times until the [Adapter List] screen appears.

2 Check that the [Adapter List] menu is selected and press the [Enter] key.


POINT

- ▶ This screen is for selecting an array controller to access, but only one controller is shown. So, simply press the [Enter] key.

The [Adapter Properties] screen appears.


- 3** Select [SAS Topology] and press the [Enter] key.

The [SAS Topology] screen appears.




- 4** Select [Direct Attached Devices] and press the [Enter] key.


A list of the connected hard disks is displayed.



- 5** Select the hard disk you wish to format and press the [Alt] + [D] keys.
The [Device Properties] screen appears.




- 6** Select [Format] and press the [Enter] key.
The [Device Format] screen appears.



7 Press the [F] key.

Hard disk formatting starts and a progress bar is displayed at the bottom of the screen. Formatting is complete when the progress bar reaches 100% (the end).

**8** Press the [Esc] key three times to return to the [Adapter Properties] screen.

Chapter 3

Preparations

3

This chapter explains how to update device drivers and apply hotfix.

3.1	Updating Device Drivers	50
3.2	Applying Hotfix	54

3.1 Updating Device Drivers

This section explains how to update the device drivers installed in the server.
The driver update operation varies depending on the OS to be used.
Before the update, create driver disks using "Array Controller Document & Tool CD".



- ▶ Even if the OS is newly installed in the server, the drivers need to be updated when those included on "Array Controller Document & Tool CD" are the latest version.
For the latest information on the software supplied with the array controller, such as "Array Controller Document & Tool CD", refer to the Fujitsu PRIMERGY website (<http://primergy.fujitsu.com>).

3.1.1 Creating Driver Disks

Before updating the device drivers, create driver disks with "Array Controller Document & Tool CD" by following the procedure below.

- 1** Prepare formatted floppy disks.
- 2** Insert "Array Controller Document & Tool CD" into the CD/DVD drive.
- 3** Copy the drivers for the OS to be used from the following folder on the CD-ROM to the floppy disks.

Label the floppy disks with the floppy disk names in the following table.

table: Driver disks

OS	Folder Name	Floppy Disk Name
Windows 2000 Server	\Drivers\IM-SAS\W2K	Integrated Mirroring SAS Windows 2000 Drivers Disk
Windows Server 2003	\Drivers\IM-SAS\W2K3	Integrated Mirroring SAS Windows Server 2003 Drivers Disk
Windows Server 2003 x64	\Drivers\IM-SAS\W2K3x64	Integrated Mirroring SAS Windows Server 2003 for x64 Edition Drivers Disk



- ▶ For the device driver version, see ReadmeEN.html on "Array Controller Document & Tool CD".

3.1.2 Updating Drivers (Windows Server 2003)

- 1** Log on to Windows with Administrator privileges.
- 2** Exit all programs before updating.

- 3** Select [System] from [Control Panel].
- 4** Select the [Hardware] tab and click [Device Manager].
- 5** Double-click [SCSI and RAID Controller].
The SCSI adapter list appears.
- 6** Double-click [LSI Logic Adapter, SAS 3000 series, 8-port with 1068 -StorPort] or [LSI Logic Adapter, SAS 3000 series, 4-port 1064E-StorPort].
The [Properties] window appears.
- 7** Select the [Driver] tab and click [Update Driver].
The [Hardware Update Wizard] window appears.
- 8** Select [No, not this time] and click [Next].
- 9** Select [Install from a list or specific location] and click [Next].
- 10** Select [Don't search. I will choose the driver to install.] and click [Next].
- 11** Insert the following floppy disk in the floppy disk drive and click [Have Disk].
 - For Windows Server 2003
"Integrated Mirroring SAS Windows Server 2003 Drivers Disk"
 - For Windows Server 2003 x64
"Integrated Mirroring SAS Windows Server 2003 for x64 Edition Drivers Disk"
- 12** Enter "A:\\" in [Copy manufacturer's file from] and click [OK].
- 13** Select [LSI Logic Adapter, SAS 3000 series, 8-port with 1068 -StorPort] or [LSI Logic Adapter, SAS 3000 series, 4-port 1064E-StorPort] in the model field and click [Next].
The files are copied.
- 14** When file copying is finished, click [Done] and close the [Hardware Update Wizard] window.
- 15** Click [Close] to close the [Properties] window.

POINT

- ▶ If the [Change System Settings] window appears, click [No].

- 16** Restart the system.

POINT

- ▶ To confirm if the device driver is correctly read, check that either of the following controllers is displayed in [SCSI and RAID controller] of the Device Manager.

- LSI Logic Adapter, SAS 3000 series, 8-port with 1068 -StorPort
or
- LSI Logic Adapter, SAS 3000 series, 4-port 1064E-StorPort

Also, to check the version of the device driver that is being read, double-click the above controller name, select the [Driver] tab and see the version information.

3.1.3 Updating Drivers (Windows 2000 Server)

- 1** Log on to Windows with Administrator privileges.
- 2** Exit all programs before updating.
- 3** Select [System] from [Control Panel].
- 4** Select the [Hardware] tab and click [Device Manager].
- 5** Double-click [SCSI and RAID Controller].
The SCSI adapter list appears.
- 6** Double-click [LSI Adapter, SAS 3000 series, 8-port with 1068] or [LSI Adapter, SAS 3000 series, 4-port with 1064E].
The [Properties] window appears.
- 7** Select the [Driver] tab and click [Update Driver].
The [Device Driver Upgrade Wizard] window appears.
- 8** Click [Next].
- 9** Select [Display known drivers for this device and select a driver from the list.] and click [Next].
- 10** Click [Have Disk] and insert the "Integrated Mirroring SAS Windows 2000 Drivers Disk" in the floppy disk drive.
- 11** Enter "A:\\" in [Copy manufacturer's file from] and click [OK].
- 12** Select [LSI Adapter, SAS 3000 series, 8-port with 1068] or [LSI Adapter, SAS 3000 series, 4-port with 1064E] in the model field and click [Next].
The device driver installation starts.
- 13** When the installation is finished, click [Done] and close the [Device Driver Update Wizard] window.
- 14** Click [Close] to close the [Properties] window.



- ▶ If the [Change System Settings] window appears, click [No].

15 Restart the system.



- ▶ To confirm if the device driver is correctly read, check that either of the following controllers is displayed in [SCSI and RAID controller] of the Device Manager.
 - LSI Adapter, SAS 3000 series, 8-port with 1068
 - or
 - LSI Adapter, SAS 3000 series, 4-port with 1064E

Also, to check the version of the device driver that is being read, double-click the above controller name, select the [Driver] tab and see the version information.

3.2 Applying Hotfix

In order to use this array controller in a Windows environment, hotfix needs to be applied.



- ▶ For the hotfix, use "PRIMERGY Startup Disc" or "ServerStart Disc 1 CD-ROM" supplied with the server. Make sure to apply hotfix when using this array controller with a newly installed OS in a Windows environment.

■ Application procedure

- 1** Log on to Windows with Administrator privileges.
- 2** Close all applications.
- 3** Insert "PRIMERGY Startup Disc" or "ServerStart Disc 1 CD-ROM" into the CD/DVD drive.
- 4** Run the following program to apply the hotfix.
 - For Windows 2000 Server
[CD/DVD drive]:\HOTFIX\W2K\ENU\Windows2000-KB904374-x86-ENU.EXE
 - For Windows Server 2003 Service Pack 1
[CD/DVD drive]:\HOTFIX\W2K3\WindowsServer2003-KB916048-x86-ENU.exe
 - For Windows Server 2003 x64 Service Pack 1
[CD/DVD drive]:\HOTFIX\W2K3x64\WindowsServer2003.WindowsXP-KB916048-x64-ENU.exe

4

Chapter 4

Array Configuration and Management [ServerView RAID]

This chapter explains an overview of and requirements for ServerView RAID Manager, and how to install and use it.

4.1	Requirements for ServerView RAID	56
4.2	Installing ServerView RAID [Windows]	62
4.3	Starting and Exiting ServerView RAID Manager	65
4.4	ServerView RAID Manager Window Layout	69
4.5	Setting ServerView RAID	76
4.6	Rebuild	79
4.7	Checking Status [ServerView RAID Manager]	80

4.1 Requirements for ServerView RAID

This section describes ServerView RAID.

ServerView RAID is to monitor, manage, maintain, and configure array controllers and the hard disks and logical drives that are connected to the array controller.

4.1.1 ServerView RAID Overview

This software runs on the OS to monitor and manage the array controller.

ServerView RAID is an application software that allows you to manage a disk array system connected to the array controllers (RAID controllers).

Using ServerView RAID, which is a client-server application, you can manage array controllers via a network as well as in a standalone environment.

ServerView RAID includes the ServerView RAID service and ServerView RAID Manager.


The ServerView RAID service and ServerView RAID Manager use HTTPS to communicate with each other.

● ServerView RAID service

Installed on the server, this program operates as an OS service and monitors the operation of the array controller.

● ServerView RAID Manager

It is a graphical user interface that uses a Web browser and Java. You manage and configure array controller with ServerView RAID Manager.



IMPORTANT

- ▶ To ensure stable operation of PRIMERGY, install ServerView RAID (or GAM) when using the array controller. If ServerView RAID (or GAM) is not installed, failures will not be detected. You will also be unable to perform maintenance correctly. Make sure to install ServerView RAID (or GAM).
- ▶ Install either ServerView RAID or GAM, but do not install both. For which to use, see ReadmeEN.html on Array Controller Document & Tool CD. If by mistake you have installed GAM rather than ServerView RAID, you must uninstall GAM, and then install ServerView RAID. Do not operate the server with both ServerView RAID and GAM installed.
- ▶ Only start ServerView RAID Manager when management or maintenance of arrays is necessary. From a security point of view, it is not recommended to run ServerView RAID Manager continuously. If the accessed server shuts down while you are logged in to ServerView RAID Manager, ServerView RAID Manager cannot communicate with the ServerView RAID service and cannot respond, making it impossible to operate ServerView RAID Manager. In this case, close the Web browser in which ServerView RAID Manager is running.
- ▶ ServerView RAID uses SSL to encrypt communication. Since server certification is not supported, you are responsible for ensuring the reliability of the network server itself.

4.1.2 Requirements for ServerView RAID

An appropriate server environment is required for using ServerView RAID properly.
Make sure that the following requirements are met.

■ ServerView RAID (server requirements)

You must have the following environment to use ServerView RAID.

table: Requirements for ServerView RAID

Category	Description	
	For Windows	For Linux
Hard disk	150MB or more free space in the installation partition of the OS	150MB or more free space under /opt
Application	TCP/IP, SNMP service, and ServerView must be installed.	
OS	OS supporting servers with this array controller installed	
Web browser	Internet Explorer 6 or later	Mozilla Firefox 1.0.4 or later SeaMonkey 1.0.3 or later
Java	Java™ 2 Runtime Environment Standard Edition V1.5.0_06 or later	

IMPORTANT

- ▶ Make sure to install the device drivers and ServerView RAID specified by Fujitsu.
- ▶ Make sure to configure the network settings properly. If there is a problem with the network configuration, you may be unable to monitor the status of arrays by ServerView or events may not be notified.
- ▶ To monitor the array controllers, see the OS event log notified by ServerView (Source: Fujitsu ServerView Services). For the list of logs notified by ServerView, see "Appendix A A List of ServerView RAID Event Logs" (→pg.138).

■ ServerView RAID Manager (when managed from client PC)

When ServerView RAID Manager is used on a client PC different from the server, the following environment is required for the client PC.

table: Requirements for ServerView RAID Manager

Category	Description
Network	Network connection with TCP/IP available
Input device	A mouse or other pointing device
Processor	Pentium® 500MHz or higher (1GHz or higher recommended)
Memory	512MB or more (1GB or more recommended)
Monitor	800 × 600 or better resolution (1024× 768 or more recommended), 256 or more colors
OS	Windows Server 2003 SP1 or later Windows XP Windows 2000 Server Service Pack 4 or later Windows 2000 Professional Service Pack 4 or later
Web browser	Internet Explorer 6 or later
Java	Java™ 2 Runtime Environment Standard Edition V1.5.0_06 or later

4.1.3 Access Privileges to ServerView RAID

To use the ServerView RAID functions, you need to log in to ServerView RAID Manager.

When you log in, user authentication is performed against your user account registered with the OS. The available functions depend on the user account. The two levels of access privileges are shown below:

■ User privilege

The User privileges are mainly used to see the status of the array controllers, hard disks, and logical drives. To use the User privileges, log in to ServerView RAID Manager with any of the user names and passwords registered with the OS. With User privileges, you can see the detailed information, settings, and status of the RAID subsystems such as the array controllers, hard disks, and logical drives.

However, you cannot rebuild hard disks, or modify the parameters for ServerView RAID.

POINT

- ▶ Some operation such as rebuild cannot be performed with User privileges. We recommend that you log in with User privileges unless you need to operate the array or modify the settings.

■ Administrator privilege

This privileges are for management, maintenance, and configuration of the array controllers, hard disks, and logical drives. To use the Administrator privilege, log in to ServerView RAID Manager as a user belonging to the "raid-adm" group or the Administrators group. In addition to the functions available with User privileges, you can use all the other functions such as rebuilding hard disks, and changing the hard disk status.

IMPORTANT

- ▶ When using ServerView RAID with Administrator privileges, certain operations may cause loss of data in the array controller. Read this chapter and use ServerView RAID properly.

POINT

- ▶ Make sure to create the "raid-adm" group and name it "raid-adm".

4.1.4 Using ServerView RAID in Linux Environment

To use ServerView RAID in Linux environment, install device drivers for Linux and ServerView RAID.

POINT

When using the software in an RHEL-AS4 (EM64T) or RHEL-ES4 (EM64T) environment

- ▶ The Java plug-ins do not work on the servers with the RHEL-AS4 (EM64T) or RHEL-ES4 (EM64T) system. You cannot manage the array controllers with ServerView RAID Manager running directly on these servers.


If you want to manage the array controllers on servers with the RHEL-AS4 (EM64T) or RHEL-ES4 (EM64T) system, run ServerView RAID Manager on a Windows server or client PC, and manage the array controllers remotely.

For the remote management configuration, see "4.1.5 Operation via Network" (→pg.59).

4.1.5 Operation via Network

In a network environment, an array on a server can be monitored and managed from a server or a Windows client PC connected to the network.

When you manage the disk array on the server with ServerView RAID installed from ServerView RAID Manager on another server or a client PC, the configuration is as follows:




POINT

- ▶ Each ServerView RAID Manager program can manage only one server.
When you want to manage disk arrays on multiple servers from a single client PC or server, start one ServerView RAID Manager program for each server.
- ▶ If there is an intervening firewall in the environment, you need to configure the network settings so that the port used by the ServerView RAID will not be blocked.
ServerView RAID uses the TCP port 3173.

■ Interaction with ServerView AlarmService

ServerView RAID logs the events of the array controllers in the OS event log on the server using ServerView AlarmService. When you want to monitor the disk array remotely, you can also log the events of the array controllers in the OS event log on the client PC by installing ServerView Console or ServerView AlarmService on the client PC. When you install ServerView AlarmService on the client PC, the configuration is as follows:




IMPORTANT

- ▶ Make sure to install ServerView on the server.

4.1.6 When Using ServerView RAID and GAM

When using both ServerView RAID and GAM on a network, you can use ServerView RAID Manager and GAM Client simultaneously on the management client PC or Windows server.

The configuration is as follows:



If ServerView is installed on the management client PC or Windows server, you can start the ServerView RAID Manager or GAM Client program for a server managed by ServerView by making use of ServerView's interaction with the RAID Manager. For details about the RAID Manager linking, see "RAID Manager Linking" in the "ServerView User's Guide".

IMPORTANT

- ▶ When you want to install GAM Client on a Windows server where ServerView RAID is already installed, install only GAM Client. Do not install GAM Server.
- ▶ One GAM Client can manage up to a maximum of 100 GAM Servers.
When managing more than 100 servers at the same time, one Windows server or one client PC to be used as GAM Client is necessary per 100 servers.
- ▶ If different versions of GAM Servers coexist, use the newer version of GAM Client than GAM Server.

4.2 Installing ServerView RAID [Windows]

This section explains how to install ServerView RAID on a Windows server.



- ▶ ServerView RAID cannot be installed by overwriting an existing installation. Make sure to uninstall any existing version of ServerView RAID before updating or reinstalling ServerView RAID.
- ▶ To record events that occur in the array controllers in the OS event log, make sure to install ServerView and configure the event log settings. For details, see the "ServerView User's Guide".

4.2.1 How to Install ServerView RAID

Follow the procedure below to install ServerView RAID.

- 1** Log on to Windows with Administrator privileges.
- 2** Before installing ServerView RAID, complete the following preparations:

- Make sure that ServerView is installed and working properly.
- Insert Array Controller Document & Tool CD provided with this product into the CD/DVD drive.
- Exit all applications.



- ▶ Exit all applications before starting the installation. In particular, if you install the software while Event Viewer, Services, or Computer Management is running, the installation may fail.

- 3** Click the [Start] button – [Run...]. Enter the following path and click [OK].
[CD/DVD drive]:\RAIDTOOL\SVRAID\Windows\install.bat

The message "Installation of ServerView RAID has started." is displayed at the command prompt, and the installation of ServerView RAID begins.

- 4** When the message "Installation of ServerView RAID has finished." is displayed at the command prompt, press the [Enter] key.

The command prompt window closes.

- 5** Restart the system.

- 6** Once the system is up and running, create and configure a Windows user account.

User Account for Administrator Privileges

1. Create a user account for the Administrator privileges of ServerView RAID.
2. Create the "raid-adm" disk group.
3. Configure the user account for the Administrator privileges so that it belongs to the "raid-adm" group or the Administrators group.

User Account for User Privileges

1. Create a user account for the User privileges of ServerView RAID.
Do not include the user account for the User privileges in the "raid-adm" group.

IMPORTANT

- ▶ When creating the account for ServerView RAID, uncheck [User must change password at next logon].
Generally, [Password never expires] should be checked. Unless the account is configured as above, you may be unable to log in to ServerView RAID Manager properly, because the program will consider the user account invalid if the password of the account has expired or has not been set, without displaying any warning message.

POINT

- ▶ Create each user account as an OS user account.
- ▶ Make sure to create the "raid-adm" group. Make sure to create the group with the name "raid-adm".

4.2.2 How to Uninstall ServerView RAID

Follow the procedure below to uninstall ServerView RAID.

IMPORTANT

- ▶ Do not uninstall ServerView RAID unless you need to update ServerView RAID or in other special cases.

- 1** Log on to Windows with Administrator privileges.

IMPORTANT

- ▶ Exit all programs before starting the uninstallation.
If uninstalling the software while Event Viewer, Services, or Computer Management is running, the uninstallation will fail. Make sure to exit all the programs.

- 2** Click the [Start] button – [Settings] – [Control Panel].
- 3** Double-click [Add or Remove Applications] (or [Add or Remove Programs] depending on the OS).
- 4** Select [ServerView RAID] from the application list and click [Delete] (or [Change/Remove] depending on the OS).

The message "Are you sure you want to remove ServerView RAID from your computer?" is displayed.

5 Click [Yes].

The uninstallation process starts.

6 When the following message appears after the uninstallation, click [Yes].

You must restart your system for the configuration changes made to
ServerView RAID to take effect...

The system restarts.

4.3 Starting and Exiting ServerView RAID Manager

This section explains how to start and exit ServerView RAID Manager.

4.3.1 Preparations and Precautions for using ServerView RAID Manager

Configure the necessary Web browser before using ServerView RAID Manager. Also, note the following precautions:

- **General precautions**

- ServerView RAID Manager needs Java plug-in. Install Java on the server or client PC on which you use ServerView RAID Manager. If Java is not installed, install Java by referring to "Installing Java™ 2 Runtime Environment Standard Edition" under "Chapter 2 Installation" in "ServerView User's Guide" on PRIMERGY Startup Disc.
- On servers with the RHEL-AS4 (EM64T) or RHEL-ES4 (EM64T) system, Java plug-ins do not work. Therefore, when you want to manage the array controllers in an RHEL-AS4 (EM64T) or RHEL-ES4 (EM64T) environment, you need a separate Windows server or client PC to run ServerView RAID Manager.
- When you use ServerView RAID Manager on the server, do not use proxy servers for the IP address and localhost.
- Do not use the [Back], [Forward], and [Refresh] buttons in the Web browser.

- **When using internet explorer as your web browser**

- Set SSL enable.
Select [Tools] – [Internet Options] – [Advanced] – [Security], and set SSL 2.0 and SSL 3.0 enable.
- If you use Windows 2003 Internet Explorer as the Web browser, start the Web browser and add the Web site as follows:
 1. In Internet Explorer, select [Tools] – [Internet Options].
 2. Click the [Security] tab and select [Local intranet] or [Trusted sites].
 3. Click [Sites] (or [Advanced] in Windows 2000) and add the following URL of the server where you installed ServerView RAID: <https://<the name or IP address of the server>>.
 4. Click [Close].
 5. Click [Custom Level].
 6. Set [Enable] for [Run ActiveX controls and plug-ins].

● When using Mozilla Firefox / SeaMonkey as your web browser

Select [Edit] – [Configuration], and set the following items enable in the configuration window:

- "SSL 2.0" and "SSL 3.0"
- "Enable Java"

4.3.2 Starting ServerView RAID Manager

Follow one of the procedures below to start ServerView RAID Manager:

● From the [Start] button

Start ServerView RAID Manager from the [Start] button.

This method can only be used on the Windows server on which ServerView RAID is installed.

● From ServerView

Start ServerView RAID Manager with the RAID Manager linking function of ServerView.

For how to start ServerView RAID Manager from ServerView, see "RAID Manager Linking" in "ServerView User's Guide" on PRIMERGY Startup Disc.

● From the server name or IP address

Start ServerView RAID Manager by directly specifying the host name or the IP address of the server.

Using this method, you can manage the array controllers on the server from a remote client PC.

1 Start the ServerView RAID Manager.

Starting from the [Start] button

1. Click [Start] button – [All Programs] (or [Program]) – [Fujitsu Siemens] – [ServerView RAID Manager Start].

Starting by directly specifying the server name or IP address

1. Start the Web browser.
2. Type the following URL and press the [Enter] key.
https://<the name or the IP address of the server>:3173/


POINT

- ▶ If a "Security Alert" message appears, click [Yes] to continue.
- ▶ If the following message appears on the startup of Java, click [Yes] to continue.
 - "The web site's certificate is invalid. Do you want to continue?"
 - "The web site's certificate cannot be verified. Do you want to continue?"
- ▶ If the message "The name of the site does not match the name on the certificate. Do you want to run the application?" appears on the startup of Java, click [Run] to continue.

When ServerView RAID Manager is started, the login window appears.



- ▶ If you leave the Java startup popup window open for a long time when starting ServerView RAID Manager, the following window may appear and ServerView RAID Manager cannot be started. In this case, close the Web browser, and then start ServerView RAID Manager again.



2 Enter the user name in [Username].


- When logging in with Administrator privileges
Enter the user name that belongs to the "raid-adm" or Administrators group.
- When logging in with User privileges
Enter a user name that does not belong to the "raid-adm" or Administrators group.

3 Enter a password in [Password].

4 Click [Login].

The main window of ServerView RAID Manager appears.

POINT

- ▶ If you type the wrong password for logging in, you may not be able to enter the password again. In this case, click [Username:], and then enter the user account and the correct password.
- ▶ In ServerView RAID Manager, the available functions are limited by the access privileges. For details about access privileges, see "4.1.3 Access Privileges to ServerView RAID" (→pg.58).
- ▶ Do not change the status of the language selection button in the login window. Leave it as .

4.3.3 Exiting ServerView RAID Manager

This section explains how to exit ServerView RAID Manager.

- 1** In the ServerView RAID Manager menu bar, click [File] – [Exit].

The login window appears.




- 2** Exit the Web browser.

4.4 ServerView RAID Manager Window Layout

This section explains the windows, buttons, and menu items displayed when using ServerView RAID Manager.

4.4.1 Startup Window Layout and Functions

When ServerView RAID Manager is started, the following main window appears.



■ Object window

The window displays information about the object (device) selected in the tree view. Use the tabs at the top of the object window to switch the information displayed.

- [General] Tab
This tab displays information about the object, such as the IP address, the OS, and the capacities of the HDDs and LDs.
- [Settings] Tab
This tab displays the settings of the object. It also allows you to change the settings of the object.
- [Layout] Tab
This tab allows you to see the configuration of the object.

- [Background activities] Tab

This tab allows you to see the status of the background tasks currently running for the object.

POINT

- ▶ The information displayed in each tab of the object window varies with the selected object. The [Background activities] tab is not displayed when no background tasks are running.


■ Menu bar

Menu bar provides menus for performing various function of ServerView RAID Manager.

For details on the ServerView RAID Manager menus, see "4.4.2 Menu Layout and Functions" (→pg.71).

■ Toolbar

The toolbar contains the following buttons:

-  (Back/Forward)

These buttons allow you to go back/forward in the object selection history for the tree view.

-  (Change Access Mode)

This button allows you to switch the access mode of the object. Access modes represent the operation privileges for ServerView RAID Manager. The following access modes are available:

- Read only access

You can only see the information.


- Write access

You can make any modifications.

When you want to operate the disk array or modify the settings for the controller and logical drives, you must set the [Write access] mode.

POINT

- ▶ You can use the [Write access] mode only when you log in to ServerView RAID with Administrator privileges. When you log in with User privileges, you can only use the [Read only access] mode.
→"4.3.2 Starting ServerView RAID Manager" (pg.66)
- ▶ When you log in with Administrator privileges in the [Read only access] mode and perform any modification such as modifying the settings, the following popup window appears. Click [Yes] to make the access mode automatically switched to the [Write access] mode.



■ Tree view

The tree view displays all the objects related to the array controller as icons in a tree.




For details, see "4.4.3 Tree View Layout" (→pg.73).

■ Event window

ServerView RAID monitors the operation of the array controllers and hard disks connected to the controllers.

When any behavior that is considered as an event (for example, a failure of a hard disk or the completion of the rebuild) occurs, ServerView RAID Manager is notified of it and displays it in the event window. The following information is displayed.

table: Event window

Event	Description
Severity	Priority level of the event. The following icons are used:  Information  Warning  Error
Date	Date and time when the event occurred.
Source	Object (device) where the event occurred.
ID	ID of the event
Event	Event description



- ▶ For monitoring the array controllers, use the OS event log (the application log; Source: Fujitsu ServerView Services).
ServerView RAID Manager displays only the last 100 events in the event window.
For example, if you start ServerView RAID Manager after a long interval, you may lose the events for that period, because the old events are overwritten by new events.

4.4.2 Menu Layout and Functions

This section explains the layout and functions of ServerView RAID Manager menu items.

■ [File] menu

table: [File] menu

Menu	Function
Exit	Select this item to close the current session and return to the login window.

■ [Actions] menu



- ▶ The items in the [Actions] menu vary with the object selected in the tree view and the status of the object. Note that grayed out menu items are unavailable.
- ▶ The [Actions] menu is the same as the right-clicked menu when the object is selected in the tree view.

● When an array controller is selected

table: [Actions] menu (When an array controller selected)

Menu	Function
Scan configuration	Select this item to redetect all devices connected to the array controller.
Create logical drive	Not supported. Do not use it.
Delete all logical drives	Not supported. Do not use it.
Delete last logical drive	Not supported. Do not use it.
Clear configuration	Not supported. Do not use it.

● When a hard disk is selected

table: [Actions] menu (When a hard disk is selected)

Menu	Function
Locate device	It turns on the hard disk failure LED to indicate the drive's location.
Stop location	It turns off the hard disk failure LED that was turned on with [Locate Device].
Create global hot spare	Not supported. Do not use it.
Delete global hot spare	Not supported. Do not use it.
Make online	Not supported. Do not use it.
Make offline	It changes the status of the hard disk to offline (Failed). Note: ▶ Do not use this function unless you are instructed to do so, for example during preventive replacement of a hard disk or during maintenance. This operation may cause data loss.
Start rebuild	Starts a rebuild ([Rebuild]) for the selected hard disk.

● When a logical drive is selected

table: [Actions] menu (When a logical drive is selected)

Menu	Function
Delete logical drive	Not supported. Do not use it.
Locate logical drive	Turns on the failure LEDs of the hard disks that make up the selected logical drive to indicate their locations.
Stop location	Turns off the hard disk failure LEDs that were turned on with [Locate Logical Drive].
Start rebuild	Starts a rebuild ([Rebuild]) for the selected logical drive.

● When a file log is selected

table: [Actions] menu (When a file log is selected)

Menu	Function
Clear log	Deletes the event log file. Note: ▶ Do not use it. Event log files are used when analyzing failures. If you delete event log files, the analysis may become difficult.

■ [Help] menu


table: [Help] menu

Menu	Function
Info about ServerView RAID	Displays the version information of ServerView RAID.
Contents and index	Not supported.

4.4.3 Tree View Layout

This section explains the icons in the tree view shown at the left of the main ServerView RAID Manager window.

In the tree view, you can see the status of the hard disks and the logical drive.



● Server

At the top of the tree, the names of the connected servers are displayed.

● Controller

The array controllers installed on the server are displayed.

Each controller number is shown in ().

● Port

The ports of an array controller are displayed.

Each port number is shown in ().








● Hard disk

The vendor names and product names of the hard disks connected to the array controller are displayed.

The device number of each hard disk is shown in ().

You can also see the status of each hard disk with icons.

table: hard disk status icon

Icon	Displayed in	Status	Description
	Gray	Online (Operational)	Configuring an array and operating normally
	White	Unused (Available)	Unused or available
	Gray with an "x" mark	Failure/Offline (Offline)	The hard disk configuring the array is being failed, or unwritable
	White (dotted frame) with "x"	Unrecognizable (Failed (Missing))	Not recognized, or failed.
	Gray	Rebuild (Rebuilding)	Rebuild is in progress
	Gray with "!"	Failure Prediction (S.M.A.R.T. Error)	A failure is expected
	Yellow background	Locating	[Locate Device] function is running

POINT





- ▶ When you select the icon of each hard disk, more detailed information is displayed in the object window. Note that you cannot see some information on unrecognizable hard disks. For details, see "4.7.3 Checking Hard Disk Status" (→pg.82).
- ▶ S.M.A.R.T. Error may appear with another status.

● Logical drive

The logical drives created under the array controller are displayed. Each logical drive number is shown in ().

You can also see the status of each logical drive with icons.

table: Logical drive status icons

Icon	Status	Description
	Online (Operational)	Operating normally.
	Critical (Degraded)	Operating without redundancy
	Offline (Failed)	Not available
	Locating	[Locate Logical Drive] function is running on the logical drive.

POINT

- ▶ When you select the icon of each logical drive, more detailed information is displayed in the object window. For details, see "4.7.4 Checking Logical Drive Status" (→pg.84).

- **File log, System log, and Plug-in**


You can configure the log files and the OS event log for ServerView RAID.
For details, see "4.5 Setting ServerView RAID" (→pg.76).

4.5 Setting ServerView RAID

This section explains how to change each parameter for event logging. You can configure the log files and the OS event log for ServerView RAID.

- 1** Start ServerView RAID and log in with Administrator privileges.
→ "4.3 Starting and Exiting ServerView RAID Manager" (pg.65)


- 2** In the tree view, select the icon you want.




- 3** Click the [Settings] tab in the object window.

The current settings are displayed in the tab.

When you select File log in the tree view:



When you select System logging in the tree view:



- 4** Click [Edit] to set each item.

A setting window appears. For the items that can be set, see the following:

- When you set File log:
→ "■ File log" (pg.77)
- When you set System log:
→ "■ System log" (pg.78)



- ▶ Setting for ServerView RAID, the Multiplexer and the LSISStorelibIR-Plugin are not supported, Do not use them.

5 Click [OK].

You will see the change reflected on the [Settings] tab in the object window.

■ File log

table: File log

Options	Setting		Description
Logging	Enabled	Cannot be changed	Sets event logging to the log file enable. Always set this option Enabled.
Log level	Information	Cannot be changed	Sets a priority level for events that execute logging. Events that have a priority level equal to or greater than the one set here will be logged in the log file. Do not change from the Information.
File name	RAIDLog.xml	Cannot be changed	Log file name.
File size	10	Cannot be changed	Sets the log file size limit.
Log method	Rotation	Cannot be changed	Sets the method of log rotation.
Max. save files	5	Default	The maximum number of log files. We recommend that you set this value equal to or greater than the default value.

 **IMPORTANT**

- ▶ The log files for ServerView RAID are stored as RAIDLog.xml (or RAIDLog<number>.xml) in the following folders:

For Windows 2000 server/ Windows Server 2003	C:\Program Files\Fujitsu Siemens\RAID\web\public\
For Windows Server 2003 x64	C:\Program Files (x86)\Fujitsu Siemens\RAID\web\public\
For Linux	/opt/SAW/RAID/web/public/

Do not delete or edit the log files since they may be used for failure analysis. The available maximum file size ranges from 20MB to 110MB, depending on the settings. Browsing or monitoring the log files is not supported.

■ **System log**




table: System log

Options	Setting		Description
Logging	Enabled	Default	Sets event logging to the OS event log enable.
Log level	Information	Default	Sets a priority level of events that are logged in the OS event log. Events that have a priority level equal to or greater than the one set here will be logged. Debug is not supported.

 **POINT**

- ▶ ServerView RAID logs events that occur in the array controller in the OS application log as events of the "Source: ServerView RAID". However, when ServerView is installed, events that occur in the array controller are logged also as events of the "Source: Fujitsu ServerView Services".
- ▶ The event log whose settings you can change under System Log is "Source: ServerView RAID".

4.6 Rebuild

This section explains how to rebuild hard disks.


Rebuild is an operation to recover a logical drive in "Critical" status (Degraded) to "Online" (Operational) status. For details on rebuild, see "1.3.2 Rebuild" (→pg.16).


To manually execute a rebuild, follow the procedure below.



- ▶ Disk array operations require logging in to ServerView RAID Manager with Administrator privileges. They also require that the access mode is set to [Write access].
For details about access modes, see "■ Toolbar" (→pg.70).
- ▶ Just replacing a hard disk does not execute a rebuild. Make sure to perform the rebuild operation. For how to replace the hard disk and perform a rebuild, see "Chapter 6 Replacing Hard Disk" (→pg.123).

1 Start the ServerView RAID Manager and log in with Administrator privileges.
→"4.3 Starting and Exiting ServerView RAID Manager" (pg.65)

2 In the tree view, right-click the replaced hard disk (), and [Start rebuild] from the displayed menu.
A confirmation window appears.



3 Click [Yes].
When the rebuild starts, [Rebuilding] appears in [Activity] of the object window, and the progress of the rebuild is displayed. When the progress bar reaches 100% and the window closes, the rebuild is complete.

4.7 Checking Status [ServerView RAID Manager]

The following information can be checked using ServerView RAID Manager.

- Information on events or errors that have occurred: "Appendix A A List of ServerView RAID Event Logs" (→pg.138)
- Server information: "4.7.1 Checking Server Condition" (→pg.80)
- Array configuration or controller information: "4.7.2 Checking Array Controller Status" (→pg.81)
- Hard disk information: "4.7.3 Checking Hard Disk Status" (→pg.82)
- Logical drive information: "4.7.4 Checking Logical Drive Status" (→pg.84)
- Information on tasks running in the background: "4.7.5 Checking Progress of Background Task" (→pg.86)

4.7.1 Checking Server Condition

Selecting a server name displayed on the top of the tree view displays information on the server that ServerView RAID is installed in.

- 1** Start ServerView RAID Manager and log in.
→"4.3 Starting and Exiting ServerView RAID Manager" (pg.65)
- 2** Click the server you want to check in the tree view.
Detailed information on the selected server is displayed.




table: Detailed information on servers

Item	Category	Description
System	Name	Server name.
	IP address	Displays the server IP address. The loopback address (127.0.0.1) may be displayed depending on the server network settings.

table: Detailed information on servers

Item	Category	Description
Operation System	Vendor	OS vendor name.
	Version	OS type and version.
	Edition	OS edition.
	Service pack	Service pack applied to OS.
	Processor architecture	CPU type of OS.

[Note]: Not all of the items may be displayed depending on the OS types or settings.

4.7.2 Checking Array Controller Status

Selecting an array controller in the tree view displays detailed information on the array controller in the object window.

- 1 Start ServerView RAID Manager and log in.
→ "4.3 Starting and Exiting ServerView RAID Manager" (pg.65)
- 2 Click the array controller () you want to check in the tree view.
Detailed information on the selected array controller is displayed in the [General] tab.




table: Detailed information about array controllers

Item	Category	Description
Adapter	Name	Model name of the array controller.
	ID	The number of the array controller.
	Vendor	Vendor name of the array controller.
	Product	Product name of the array controller.
	Serial number	Serial number of the array controller.
	NVRAM size	Size of the array controller NVRAM.
	Firmware version	Firmware version of the array controller.
	BIOS version	BIOS version of the array controller.
	Driver name	Driver name of the array controller.
	Driver version	Driver version of the array controller.
PCI Location	Bus	Bus number for the array controller.
	Function	Function number for the array controller.
	Device	Device number for the array controller.
Ports	Number	Number of ports on the array controller.
	Protocol	Protocol supported by the array controller.
Devices (max)	Physical	Logical maximum number of physical devices.
	Logical	Logical maximum number of logical devices.
Properties	Auto rebuild	Indicates whether auto rebuild is enabled or disabled.
	Alarm present	Indicates whether the alarm is present or not.
	Correctable errors	Not supported.
	Uncorrectable errors	These counters indicate the number of recovery attempts made by the array controller for temporary or minor errors. They can be ignored unless the hard disk receives a failure status.
	Coercion mode	Indicates whether or not coercion of the hard disk capacity is performed.
Status		Displays the current status of the array controller.
Additional status		Displays the details of the current status of the array controller

POINT

- ▶ The [Background activities] tab is displayed if a background task is running.
- ▶ Regarding the information displayed in the [Background activities] tab, see "■ Checking with Background activities from array controller" (→pg.87).

4.7.3 Checking Hard Disk Status

Detailed information on hard disks connected to the controller is displayed in the object window.

1 Start ServerView RAID Manager and log in.

→"4.3 Starting and Exiting ServerView RAID Manager" (pg.65)

2 Click the hard disk () you want to check in the tree view.

Detailed information about the selected hard disk is displayed.



The screenshot shows a 'Disk' tab with the following information:

Name	FUJITSU MAX3073RC (0)
Device number	0
Slot	0
SAS address 00	0x500000E0122DF9D2
Vendor	FUJITSU
Product	MAX3073RC
Type	SAS
Serial number	DQD7P660029Y
Firmware version	5205
Transfer speed	300 [MB/s]
Transfer width	1 [bit(s)]
Physical size	70007 [MB]
Config. size	69618 [MB]
Foreign configuration	No
S.M.A.R.T. errors	0
Activity	Idle
Status	Operational

table: Detailed information on hard disks

Item	Category	Description
Disk	Name	Hard disk model name. The number in parentheses is the device number of the hard disk.
	Device number	Device number of the hard disk.
	Slot	Number of the slot where the hard disk is installed.
	SAS address 00	SAS address of the hard disks.
	Vendor	Hard disk vendor name.
	Product	Hard disk product name.
	Type	Protocol type of the hard disk.
	Serial number	Serial number of the hard disk.
	Firmware version	Version of the hard disk's firmware.
	Transfer speed	Transfer speed between the hard disk and the controller.
	Transfer width	Data transfer width of the hard disk is displayed.
	Physical size	Physical capacity of the hard disk.
	Config. size	Available hard disk capacity when connected to the array controller.
	Foreign configuration	Not supported.
	S.M.A.R.T. errors	Counts S.M.A.R.T. failure predictions for the hard disk.
	Activity	Displays running tasks for the hard disk. <ul style="list-style-type: none"> • Idle: No running tasks. • Rebuilding: A rebuild is in progress.
	Status	Displays current status of the hard disk.

4.7.4 Checking Logical Drive Status

Detailed information on logical drives is displayed in the object window.

You can change the displayed information by switching the tabs at the top of the object window.

- 1** Start ServerView RAID Manager and log in.

→ "4.3 Starting and Exiting ServerView RAID Manager" (pg.65)

- 2** In the tree view, click the logical drive you want to check ().

Detailed information about the selected logical drive is displayed in the object window.

- 3** Click the tab you want to check in the object window.

When you select the [General] tab:

General \ Settings \ Layout	
Logical drive	
Name	LogicalDrive_0
Logical drive number	0
RAID level	RAID-1
Stripe size	64 [K]
Logical size	69618 [MB]
Physical size	139236 [MB]
Activity	Idle
Status	Operational
Cache	
Write mode	Write-through
Read mode	No read-ahead
Disk cache mode	Disabled
Misc. properties	
Operating system device name	Disk 0

table: Detailed information about logical drives

Item	Category	Description
Logical Drive	Name	Logical drive name.
	Logical drive number	Logical drive number.
	RAID level	RAID level set for the logical drive.
	Stripe size	Striping size used by the logical drive.
	Logical size	Logical size of the logical drive.
	Physical size	Physical size of the logical drive.
	Activity	Running tasks for the logical drive. When background tasks are running, the running tasks and their progress are displayed on the progress bar. For details, see "4.7.5 Checking Progress of Background Task" (→pg.86).
	Status	Current status of the logical drive.
Cache	Write mode	Current write policy status of the logical drive.
	Read mode	Not supported.
	Disk cache mode	
Misc. properties	Operating system device name	Overview of HDD devices used in the OS.

When you select the [Layout] tab:




table: Logical drive layout information

Item	Category	Description
Overview	Disk	Displays the hard disks composing the target logical drive.
	Used capacity	Displays the capacity of hard disks used in the target logical drive.
	Partitions	Displays the overview of HDD devices used in the OS

4.7.5 Checking Progress of Background Task


ServerView RAID Manager allows you to view the progress of rebuild tasks with progress bars. From the pace of the progress bar, you can figure out approximately how long the task will take from start to finish.

table: Background task


Background task	Activities	How to check background tasks
Rebuild	Rebuilding	<ul style="list-style-type: none">• With detailed information on logical drives• With background activities from array controllers• With detailed information on hard disks

■ Checking with detailed information on logical drives

You can check the background tasks running on the selected logical drive.

- 1 Start ServerView RAID Manager and log in.
→ "4.3 Starting and Exiting ServerView RAID Manager" (pg.65)
- 2 In the tree view, click the logical drive ().
- 3 Click the [General] tab.

You can check the type and progress of the background tasks running in [Activity].



■ Checking with Background activities from array controller


You can check all the background tasks running in the selected array controller.

- 1** Start ServerView RAID Manager and log in.
→ "4.3 Starting and Exiting ServerView RAID Manager" (pg.65)


- 2** In the tree view, click the controller ().

- 3** Click the [Background activities] tab.

The logical drives where background tasks are running are displayed in [Logical Drive], and you can check the type and progress of the background tasks running in [Activity].




POINT

- ▶ When you click the button () to the right of the information for each hard disk or logical drive, the target hard disk or logical drive is selected in the tree view, so that you can view detailed information about the hard disk or logical drive.
- ▶ During rebuild, both the progress for the logical drive and the hard disk are displayed.

■ Checking with detailed information on hard disk


You can check rebuild running on the selected hard disk.

- 1** Start ServerView RAID Manager and log in.
→ "4.3 Starting and Exiting ServerView RAID Manager" (pg.65)

- 2** In the tree view, click a hard disk ().

- 3** Click the [General] tab.

You can check the progress of the rebuild being executed in [Activity].



■ How to calculate estimated time for background task

For on-going background tasks, you can figure out approximate time a task will take referring to the progress bar.

- 1** Measure the period of time taken for a progress bar to advance 1%.
- 2** Calculate the approximate time that the task takes from start to finish, using the following formula.
(Period measured in Step 1) × 100

POINT

- ▶ Use the calculated time only as a guideline. The actual time may be different from the calculated time depending on the system load and other factors.

Chapter 5

Array Configuration and Management [GAM]

This chapter explains the overview and requirements of GAM, and how to install and use it.

5.1	Overview and Requirements for GAM	90
5.2	Installing GAM [Windows]	97
5.3	Starting and Exiting GAM	102
5.4	GAM Window Layout	104
5.5	Server Group and Server Setting	111
5.6	Viewing Information [GAM]	112
5.7	Rebuild	121

5.1 Overview and Requirements for GAM

This section explains GAM (Global Array Manager).

GAM is used to monitor, manage, maintain, and configure an array controller and hard disks and the logical drive that are connected to the array controller.

5.1.1 GAM Overview

GAM is an application software that monitors and manages the array controller on the OS.

GAM also allows you to manage a disk array system connected to an array controller (RAID controller).

The GAM functions require the interaction between the GAM Server and the GAM Client.

- **GAM Server (monitoring function)**

GAM Server monitors, collects, and notifies information about the status and the resource usage of the disk array.

- **GAM Client (management function)**

GAM Client provides fault management, highly reliable messaging, and excellent OS support.

You can manage the maintenance of disk arrays and hard disks from the server or from a client PC connected to the network.



- ▶ To ensure stable operation of PRIMERGY, install GAM (or ServerView RAID) when using the array controller. If GAM (or ServerView RAID) is not installed, failures will not be detected. You will also be unable to perform maintenance correctly.
- ▶ Install either GAM or ServerView RAID, but do not install both. For which to use, see ReadmeEN.html on Array Controller Document & Tool CD. If by mistake you have installed ServerView RAID rather than GAM, uninstall ServerView RAID, and then install GAM. Do not operate the server with both ServerView RAID and GAM installed.
- ▶ Only start GAM Client when management or maintenance of arrays is necessary. From a security point of view, it is not recommended to run GAM Client continuously. While signing on from GAM Client, if the accessed server shuts down, GAM Client cannot communicate with GAM Server and cannot respond, which prevents the user from operating it. In that case, wait for the GAM Server that is to be accessed to start up again, or forcibly exit GAM Client.

5.1.2 Requirements for GAM

An appropriate server environment is required for GAM Server and GAM Client. Use hardware and software that meet the following conditions:

■ GAM Server

You must have the following environment to use GAM-Server.

table: Requirements for GAM Server

Item	Contents
Hard disk	<ul style="list-style-type: none"> For Windows 64MB or more free space in the partition in the OS. For Linux 64MB or more free space under /usr and /var
Appication	TCP/IP, SNMP service, and ServerView must be installed.
OS	A supported OS of the server that the array controller is installed in.



- ▶ Apply the latest Service Pack for the OS.
- ▶ Make sure to install the Fujitsu-specified device drivers and GAM.
- ▶ Make sure to configure the network properly. If there is a problem with the network configuration, you may not be able to monitor the status of arrays by ServerView or events may not be notified.

■ GAM Client (when managed from client PC)

When GAM Client is installed on a client PC different from the server, the following environment is required for the client PC.

table: Requirements for GAM Client

Item	Contents
Network	Network connection with available TCP/IP
Input device	A mouse or other pointing devices
Processor	Pentium® or later
Memory	256MB or more
Hard disk	32MB or more free space
Monitor	800×600 or better resolution (1024 ×768 or more recommended)
OS	Windows Server 2003 Windows XP Windows 2000 Server Service Pack 4 or later Windows 2000 Professional Service Pack 4 or later

5.1.3 Access Privileges to GAM

You need to sign on to GAM to use the GAM functions. User authentication is based on the user accounts registered in the OS. Note that the available functions vary depending on the user account used to sign on. There are three levels of access privileges as shown below:

■ Guest privileges

When using GAM with Guest privileges, it is not necessary to sign on. With Guest privileges, only the RAID status and occurring events can be checked. It is not possible to set or change parameters.

■ User privileges

This is mainly used to monitor the status of controllers, hard disks, and logical drives. To use User privileges, sign on with a user name and a password registered in the OS. With User privileges, in addition to using the functions made available with Guest privileges, several parameters can be changed. It is also possible to view the detailed status of the selected controller and RAID subsystem. Note that it is not possible to perform management operations such as changing disk array configurations, rebuilding drives, and changing parameters related to controllers and drivers.

POINT

- ▶ RAID cannot be configured with User privileges. We recommend that you sign on with User privileges when only monitoring RAID or checking its status.

■ Administrator privileges

This function is used for management, maintenance, and configuration of controllers, hard disks, and logical drives. To use Administrator privileges, sign on as "gamroot". In addition to the monitoring functions made available with Guest or User privileges, it is possible to use all other functions including creating/changing a RAID configuration, rebuilding drives, making logical drive data consistent, and changing a drive status.

IMPORTANT

- ▶ When using GAM with Administrator privileges, data may be lost in the array controller depending on the operation. Read this Chapter and use GAM accordingly.
- ▶ If GAM information cannot be monitored from ServerView, the network settings may be incorrect. In this case, check the network settings again.

5.1.4 Using GAM in Linux Environment


To use GAM in a Linux environment, you need to install device drivers and GAM.

For using Linux, see the Linux manual on the Fujitsu website (<http://primergy.fujitsu.com/>).

POINT

- ▶ GAM Client can only be installed on servers or PCs running Windows. Even when monitoring array controllers on Linux servers using GAM Client, GAM Client cannot be installed on Linux servers. Prepare a Windows server or client PC and install GAM Client on it.

The following figure shows a system configuration that GAM Client on a Windows server or on a client PC manages a Linux server.




POINT

- ▶ On Linux servers, install GAM Server and edit the configuration file to set the GAM event recipient and enable storing event logs after the installation. For details, see the Linux manual on the URL cited above.
- ▶ If there is an intervening firewall in the environment, you need to configure the network settings so that the port used by the GAM protocol is not blocked. GAM uses the TCP port 157 and 158.

5.1.5 Using GAM in Network Environment

In a network environment, arrays on multiple servers can be monitored and managed from a Windows client connected to the network.

The following figure shows a system configuration that GAM Client on the other Windows client manages GAM Server.




POINT

- ▶ You need to configure the server receiving GAM events during GAM installation. For details, see step 11 in "5.2.1 How to Install GAM" (→pg.97).
- ▶ If there is an intervening firewall in the environment, you need to configure the network settings so that the port used by the GAM protocol is not blocked.
GAM uses the TCP port 157 and 158.
- ▶ One GAM Client can manage up to 100 GAM Servers.
When managing more than 100 servers at the same time, one Windows server or one client PC to be used as GAM Client is necessary per 100 servers.
- ▶ If different versions of GAM Servers coexist, use the newer version of GAM Client than GAM Server.

■ Interaction with ServerView AlarmService

The following figure shows the interaction with ServerView AlarmService when GAM Client on the other Windows servers (client) manage GAM Server. OS event logs can be stored both on the GAM Server and on the Windows server (client).

● When storing OS event logs on the GAM client server/PC



POINT

- ▶ ServerView must be installed on the GAM Client server/PC as well.


IMPORTANT

- ▶ Make sure to install ServerView on the server.

5.1.6 When Using Both ServerView RAID and GAM

When using both ServerView RAID and GAM on a network, you can use ServerView RAID Manager and GAM Client simultaneously on the management client PC or Windows server.

You can use the following configuration:



If ServerView is installed on the management client PC or Windows server, you can start the ServerView RAID Manager or GAM Client program for a server managed by ServerView by making use of ServerView's interaction with the RAID Manager. For details about the RAID Manager linking, see "RAID Manager Linking" in the "ServerView User's Guide".

IMPORTANT

- When you want to install GAM Client on a Windows server where ServerView RAID is already installed, install only GAM Client. Do not install GAM Server.

5.2 Installing GAM [Windows]

This section explains how to install GAM on a Windows server.



- ▶ GAM cannot be installed by overwriting an existing installation. Make sure to uninstall any existing version of GAM before reinstalling GAM.
- ▶ Restart the OS after installing or uninstalling GAM.
- ▶ If Service Pack 1 of Windows Server 2003 has been applied, the following message may pop up when restarting the system just after installing or uninstalling GAM.

A problem has been detected and Windows has shut down to prevent damage to your computer.
Name: SNMP Service

There will be no problem with operations. Click [Close] to close the message.

- ▶ To record events in OS event logs, make sure to install ServerView and configure the event-logging settings. For details, see "ServerView Users Guide".

5.2.1 How to Install GAM

Follow the procedure below to install GAM.

- 1** Log on to Windows with Administrator privileges.
- 2** Before installing GAM, complete the following preparation:
 - Check that TCP/IP is installed and working properly.
 - Check that ServerView is installed and working properly.
 - Insert "Array Controller Document & Tool CD" provided with this product into the CD/DVD drive.
 - Exit all applications.




- ▶ Exit all applications before starting the installation. In particular, if you install the software while Event Viewer or Computer Management is running, the installation may fail.

- 3** Click the [Start] button – [Run...]. Enter the following path and click [OK].
[CD/DVD drive]:\RAIDTOOL\GAM\Windows\install.bat
The [Global Array Manager Setup] wizard starts up.
- 4** On the [Welcome] screen, click [Next].
The [Software License Agreement] screen appears.


5 Click [Yes].

The [Select Components] screen appears.

Make sure the boxes next to [Global Array Manager Server] and [Global Array Manager Client] are checked.

**6** Select [Global Array Manager Server] and click [Change].

The [Select Sub-components] screen appears.



Make sure [Program Files] and [SNMP] are checked.

7 Confirm the settings and click [Continue].

The [Select Components] screen appears again.

8 Click [Next].

The [Choose Destination Location] screen appears.

9 Click [Next].

The installation location for GAM is displayed.

 **POINT**


- If GAM is already installed, a warning message will appear to confirm overwriting. After clicking [Cancel] to close the warning message box, click [Cancel] and then [Exit Setup] to quit the GAM setup. If the command prompt is displayed, click the [X] button to close the command prompt. After uninstalling GAM Client and GAM Server, perform the installation again.

10 Confirm the installation location and click [Next].

The files are copied.

11 Specify the client receiving events from GAM Server.

In the text box, enter the name of the computer where GAM Client is being installed and click [Next].



The [Server Event Logging] screen appears.

POINT

- ▶ If GAM Client is installed on the same computer as GAM Server, enter the name of the server.
- ▶ To specify multiple clients receiving events, enter the servers' computer names or IP addresses separated by spaces. You can specify up to 25 clients receiving events at a time.

IMPORTANT

- ▶ If the IP address or computer name of the Client is changed after GAM Server has been installed, events cannot be correctly notified. In this case, GAM Server needs to be first uninstalled and then reinstalled.
If the IP address is automatically obtained from the DHCP server, the IP address may be changed depending on the timing when the system is turned on/off or restarted. If DHCP is being used, specifying a computer name is recommended.

12 Make sure [Enable event logging on the server machine] is checked and click [Next].**IMPORTANT**

- ▶ This option must be enabled.

13 When the full path name of the configuration file appears, click [OK].

The [Setup Complete] screen appears.

14 Click [Finish] to exit.

Following the message displayed at the command prompt, press the [Enter] key and carry on processing until the command prompt closes.

15 Restart the system.

- 16** After the restart, create the user account "gamroot" with GAM Administrator privileges and a user account with GAM User privileges (e.g. gamuser) as Windows user accounts.

Assign the user account "gamroot" to the Administrators group.

 **IMPORTANT**

- ▶ When creating the account with GAM Administrator privileges, uncheck the [User must change password at next logon] checkbox.
Also check the [Password never expires] checkbox.
If you do not make the above settings, you may be unable to sign on to GAM.

 **POINT**

- ▶ Create each user account as an OS user account.

5.2.2 Uninstalling GAM

Follow the procedure below to uninstall GAM.

 **IMPORTANT**

- ▶ Uninstall GAM only when reinstalling or updating it. Do not operate the server without GAM in general.

■ Uninstalling GAM client

- 1** Log on to Windows with Administrator privileges.

 **POINT**

- ▶ Exit all programs before starting the uninstallation.
If uninstalling the software while [Event Viewer] or [Computer Management] is running, the uninstallation will fail. Make sure to exit all programs.

- 2** Click the [Start] button – [Settings] – [Control Panel].
- 3** Double-click [Add or Remove Applications] (or [Add or Remove Programs] depending on the OS).
- 4** Select [Mylex Global Array Manager Client v.x.xx-xx] from the application list and click [Change/Remove].

The message "Are you sure you want to completely remove 'Mylex Global Array Manager Client vx.xx-xx' and all of its components?" appears.

- 5** Click [Yes].
The uninstallation process starts.
- 6** When the uninstallation is finished, click [OK].

■ Uninstalling GAM server

- 1 Log on to Windows with Administrator privileges.

POINT

- ▶ Exit all programs before starting the uninstallation.
If uninstalling the software while Event Viewer or Computer Management is running, the uninstallation will fail. Make sure to exit all programs.

- 2 Click the [Start] button – [Settings] – [Control Panel].
- 3 Double-click [Add or Remove Applications] (or [Add or Remove Programs] depending on the OS).
- 4 Select [Mylex Global Array Manager Server v.x.xx-xx] from the application list and click [Change/Remove].
The message "Are you sure you want to completely remove 'Mylex Global Array Manager Server vx.xx-xx' and all of its components?" appears.
- 5 Click [Yes].
The uninstallation process starts.
- 6 When the uninstallation is finished, click [OK].
- 7 Select [LSI 1030 Storage SNMP Agent] from the application list and click [Remove].
The message "Are you sure you want to remove LSI 1030 Storage SNMP Agent vx.xx.xxxx from your computer?" appears.
- 8 Click [Yes].
The uninstallation process starts.
- 9 Select [LSI SWR IDE Storage SNMP Agent] from the application list and click [Remove].
The message "Are you sure you want to remove LSI SWR IDE Storage SNMP Agent v3.00.0000 from your computer?" appears.
- 10 Click [Yes].
The uninstallation process starts.
- 11 Restart the system.

5.3 Starting and Exiting GAM

This section explains how to start and exit GAM.

5.3.1 Starting GAM and Signing On

GAM requires user authentication to limit the availability of functions according to uses. You have to sign on to GAM to obtain User access privileges or higher.



- ▶ When GAM is started for the first time after the installation, the [Define Server Groups] window appears. See "5.5 Server Group and Server Setting" (→pg.111) to make the settings.
- ▶ Only start GAM Client when management or maintenance of arrays is necessary. From a security point of view, it is not recommended to run GAM Client continuously. While signing on from GAM Client, if the accessed server shuts down, GAM Client cannot communicate with GAM Server and cannot respond, which prevents the user from operating it. In that case, wait for the GAM Server that is to be accessed to start up again, or forcibly exit GAM Client.

- 1** To start GAM, click the [Start] button – [Programs] (or [All Programs] in Windows Server 2003) – [Mylex Global Array Manager Client].

If a server group or server is already defined, [Global Status View] appears.



- ▶ GAM starts with Guest privileges. To use User or Administrator privileges, you have to sign on.

- 2** When you double-click the server icon in the [Global Status View] window, or perform operations that require the sign on.



- ▶ You can also open the [Sign On] window by selecting [Sign on] from the [Administration] menu.
- ▶ If the GAM Client and GAM Server are installed on different servers (for a Linux system, etc.), enter the password for the GAM Server.

- 3** Sign on to GAM.

1. Enter your user name.

- When signing on with User privileges
Enter a user name in [Username].
 - When signing on with Administrator privileges
Enter "gamroot" in [Username].
2. Enter a password in [Password].
If [Remember password for this session] is checked, uncheck it.

 **POINT**

- ▶ Note that if this option is checked, you can automatically sign on to different servers with the same password. To avoid automatically accessing servers, it is recommended to keep this option unchecked.
Even if this option is checked, you need to sign on again when GAM Client is exited once.

3. Click [Sign-on].

 **POINT**

- ▶ GAM restricts the availability of functions according to access privileges. For access privileges, see "5.1.3 Access Privileges to GAM" (→pg.92).

5.3.2 Exiting GAM


To exit GAM, click [Exit] from [File] in the GAM menu bar.

5.4 GAM Window Layout

The following provides a description of the windows, buttons, and menu items displayed when using GAM.

5.4.1 Startup Window Layout and Functions

When GAM is started, a window consisting of [Global Status View] and [Log Information Viewer] appear.



■ Menu bar

Allows you to perform GAM functions such as [Controller View] and [RAID Assist].

For details on the GAM menus, see "5.4.2 Menu Layout and Functions" (→pg.106).

■ Toolbar

Buttons for frequently used GAM functions.

For details on the toolbar, see "5.4.3 Toolbar Icons" (→pg.108).

■ Server group selection box




The server group names which are registered in GAM Client are displayed. Clicking ▼ switches the server groups to be managed.

● Controller icons

Indicates the array controller status on the servers.

Controller Icons are displayed to the right of the server icons. The numbers in the parentheses show the numbers of connected array controllers. The array controllers have the following statuses.

table: Array controller status

Icon	Color	Array Controller Status
	Green	The array controller and the logical drives under the controller are operating normally.
	Yellow	The array controller and the logical drives under the controller are in Critical status, or there is trouble with the connected hard disks.
	Red	The array controller or the logical drive under the controller is not operating properly.

■ Log Information Viewer

Displays events on the array controller.

table: Log Information Viewer

Events	Details
Event ID	The level of the event to be reported is indicated with an icon that signifies Information, Caution, Warning, or Others. The ID assigned to the event being reported is also displayed.
Severity	Priority level of the event.
Source	IP address or name of the server that sent the event.
Source Time	Time when the event occurred.
Device Address	Other data regarding the addresses of related devices, operations in question, and the reason why the event was sent.
Description	Event description
Sequence (Seq)	Event sequence number
Local Time	Time when the event occurrence was signaled to GAM Client.



- ▶ Log Information Viewer only shows events that occur while the GAM Client is running. To see all the events that have occurred on the array controller, refer to the event log for the operating system.

5.4.2 Menu Layout and Functions

This section describes the function of the GAM menu items.

■ [File] menu

table: [File] menu

Menu	Function
Open Configuration	Not supported.
Save Configuration	Not supported.
Clear Configuration	Not supported.

■ [View] menu

table: [View] menu

Menu	Function
Global Status View	Displays the [Global Status View] window. With the default settings, [Global Status View] opens automatically when GAM starts up.
Controller View	Displays the [Controller View] window. Displays information for each device and the status of hard disks or logical drives connected to the controller.
Log Information Viewer	Displays the [Log Information Viewer] window. This window shows events or errors that occurred in the array controller. [Log Information Viewer] opens automatically when GAM Client starts up.
Foreground Initialize Status	Not supported.
Background Initialize Status	Not supported.
Rebuild Status	Shows the rebuild progress. This can only be selected while a rebuild is in progress.
Make Data Consistent Status	Not supported.
Expand Capacity Status	Not supported.
Patrol Read Status	Not supported.
Error Table	Not supported.

■ [Administration] menu

table: [Administration] menu

Menu	Function
Sign On	Allows you to sign on when using GAM's monitoring and setting functions. Signing on with a User account registered on the server enables you to use the monitoring function (available with User privileges). Signing on with "gamroot" enables you to use GAM's setting and management functions (available with Administrator privileges).
Define Server Groups	Sets a server group and the names or IP addresses of servers in the group.
Select Current Server Group	Selects a server group. Functions in the same manner as when the [Server Selection] box is operated directly. Note: ▶ Make sure to select a server group registered with [Define Server Group].
Select Current Controller	Selects a controller to be managed. Functions in the same manner as when the [Controller Selection] box is operated directly.
RAID Assist	Not supported..
Initialize Logical Drives	Not supported.
Controller Information	Displays the main information for the currently selected array controller.
Enclosure Information	Not supported.
Controller Options	Not supported.
Physical Device Options	Not supported.
Intelligent BBU	Not supported.
Scan Devices	Redetects the hard disks connected.
Advanced Functions	Not supported.
Settings	Not supported.

table: [Administration] menu








Menu	Function
Alarm Sound	Not supported.
Consistency Check with Restoration	Not supported.

5.4.3 Toolbar Icons

The toolbar icons at the top of the [GAM] window enable you to start up frequently used functions.



table: Toolbar icons


Icon	Function
	Not supported.
	Rescans the devices. Functions in the same manner as when [Scan Devices] is executed from the [Administration] menu.
	Displays array controller information. Functions in the same manner as when [Controller Information] is selected from the [Administration] menu.
	Not supported.
	Opens the [Sign On] window. Functions in the same manner as when [Sign On] is selected from the [Administration] menu.
	Not supported.
	Displays Help.

5.4.4 Starting Controller View and the Window Layout

The [Controller View] window enables you to monitor the status of hard disks or logical drives.

To open the [Controller View] window, select [Controller View] from the GAM [View] menu (→pg.107). If the [Sign On] window opens, sign on referring to "5.3.1 Starting GAM and Signing On" (→pg.102).


The following window appears.



The [Controller View] window shows the information below regarding the controller currently selected in the [Controller Selection] box.

● Hard disks

Displays information about each hard disk.



The hard disk status icon is displayed as follows.

table: Hard disk status icon


Icon	Color	Status	Description
	Green	Online (OnLine)	Normal
	Red	Failure / Offline (Dead / Offline)	The hard disk has a failure, cannot be recognized, or cannot be read and written.
	Yellow	Rebuild (Rebuilding)	Rebuild in progress
	Yellow	Failure expected (Critical)	Failure expected
	Not applied	Unused (Unconfigured)	Unused or available

POINT

- ▶ Double-click the icon for each hard disk to see more detailed information. For more details, see "5.6.3 Viewing Hard Disk Information" (→pg.115).
- ▶ If a hard disk is in an unrecognizable state, detailed information may not be displayed even when double-clicking its hard disk icon.

● Logical drives

Displays information about each logical drive.



The logical drive status icon is displayed as follows.

table: Logical drive status icon


Icon	Color	Status	Description
	Green	Online	Normal
	Yellow	Critical	Operating without redundancy
	Red	Offline	Not available

POINT

- ▶ Double-click the icon of each logical drive to see more detailed information. For more details, see "5.6.4 Viewing Logical Drive Information" (→pg.118).

5.5 Server Group and Server Setting

The [Server Group Setting] window automatically opens when the GAM Client is started for the first time. Add a server group and servers according to the following procedures:



- 1** Click the [Add] button below the [Server Groups] area.
- 2** Enter a name for the server group to be added using the [Adding Item] window.
- 3** Click [OK].
The added server group name is displayed in the [Server Groups] area.
- 4** Select the added server group and click the [Add] button below the [Servers] area.
The [Adding Item] window is displayed.
- 5** Enter the name or the IP address of the server computer that you want to monitor in the [Adding Item] window.

POINT

- ▶ Do not specify "localhost" or the loopback address "127.0.0.1" as the computer name or the IP address of the server to be monitored.

- 6** Click [OK].
The entered server name is added in the [Server] area.
- 7** Click [OK] to close the [Define Server Groups] window.
Confirm that the registered server appears in [Global Status View].

POINT

- ▶ You can also set a server group by selecting [Define Server Groups] from the [Administration] menu (→pg.107).

IMPORTANT

- ▶ The maximum number of the servers to be monitored that can be set is 100.

5.6 Viewing Information [GAM]

The following information can be viewed using GAM.

- Information about events or errors that have occurred: "Appendix B A List of GAM Event Logs" (→pg.158)
- Array configuration or controller information: "5.6.2 Viewing Array Controller Information" (→pg.114)
- Hard disk information: "5.6.3 Viewing Hard Disk Information" (→pg.115)
- Logical drive information: "5.6.4 Viewing Logical Drive Information" (→pg.118)
- Information about tasks running in the background: "5.6.5 Checking Progress of Background Tasks" (→pg.120)

5.6.1 Events

GAM monitors the operation of array controllers and hard disks connected to the controllers. If a behavior that should be treated as an event (a serious event such as a hard disk failure or an event such as the completion notice of the rebuild) is found, GAM is notified of that event.

Events such as disk array system errors, information, or management tasks are displayed in the [Log Information Viewer].



- ▶ For monitoring array controllers, use the OS event log (the application log; Source: Fujitsu ServerView Services). However, if the GAM Client has not been started, or if the network has a failure, [Log Information Viewer] cannot monitor the log for events that occur in the array controller.
- ▶ Although the event log notified by GAM (source: gamevlog) is recorded, ignore it since it is not supported. Also, if there are logs for the array controller which are notified by ServerView around the event log, refer to them. For the list of logs notified by ServerView, see "Appendix B A List of GAM Event Logs" (→pg.158).



- ▶ To write events or errors on the event logs in the OS, you need to install ServerView. See the "ServerView User's Guide" bundled with ServerView for the installation and settings.
- ▶ The GAM Server records detailed information about occurred events in the file "GAMEVLOG.LOG". This file may be used when investigation is necessary. (Viewing or monitoring of this file is not supported.) The path where "GAMEVLOG.LOG" is stored is as follows, depending on the OS:

For Windows 2000 Server	C:\WINNT\system32\GAMSERV\GAMEVLOG.LOG
For Windows Server 2003	C:\Windows\system32\GAMSERV\GAMEVLOG.LOG
For Windows Server 2003 x64	C:\Windows\SysWOW64\GAMSERV\GAMEVLOG.LOG
For Linux	/var/log/gamevlog.log

- ▶ While GAM Client is running, if the IP address of the server to be monitored is changed or the LAN connection is disconnected, the "Lost connection to server, or server is down" message will be recorded every 10 minutes. In such cases, confirm the network status and that the GAM Server is working properly, and then restart the GAM Client.

■ Log Information Viewer

Log Information Viewer is automatically displayed when the GAM Client is started and an array controller is detected.

POINT

- ▶ The event histories displayed in the Log Information Viewer are stored in the file GAM2CL.LOG. This file may be used when investigation is necessary. (Viewing or monitoring of this log file is not supported.)

GAM2CL.LOG is stored in the following locations.


For Windows Server 2003, Windows 2000 Server	C:\Program Files\Mylex\Global Array Manager Client\gam2cl.log
For Windows Server 2003 x64	C:\Program Files (x86)\Mylex\Global Array Manager Client\gam2cl.log

To manually open the Log Information Viewer, select [Log Information Viewer] from the [View] menu. For the meaning of each item displayed in the Log Information Viewer, see "5.4.1 Startup Window Layout and Functions" (→pg.104).

■ Displaying detailed information about each event

When detailed information about an event displayed in Log Information Viewer is needed, open the [Event Information] window.

To open the [Event Information] window, double-click the event in the Log Information Viewer.



Detailed information about the selected event is displayed.

POINT

- ▶ Click [OK] to close the window.


5.6.2 Viewing Array Controller Information

■ Using Controller View

Using Controller View, you can view the status of the array controller and the hard disks or logical drives connected to the controller. For how to start Controller View, and for details about its icons, see "5.4.4 Starting Controller View and the Window Layout" (→pg.109).

■ Displaying detailed information about the array controller

- 1** Start up GAM and sign on.
→"5.3 Starting and Exiting GAM" (pg.102)
- 2** Select [Controller Information] from the [Administration] menu.
The [Controller Information] window appears.



- ▶ Click [Close] to close the window.

■ Detailed information about the array controller

The following information is displayed.

table: Detailed information about the array controller

Item	Description
Model	The model name of the array controller.
Firmware Version	The version of the array controller's firmware.
Intelligent BBU	Not supported.
Package Version	Not supported.
BIOS Version	The version of the array controller's BIOS.
Cache Size	Not supported.
FlashROM Size	Not supported.
Bus Type	The type of the host-side bus.
Channels	Not supported.
Physical Devices	The number of hard disks connected to the array controller.
Max. Physical Devices	Not supported.
Logical Drives	The number of the logical drives controlled by this array controller.
Max. Logical Drives	Not supported.
Bus	The bus number for the array controller.
Device #	The device number for the array controller.
IRQ	The IRQ number.

5.6.3 Viewing Hard Disk Information

Using Controller View, you can view detailed information about the hard disks connected to the controller.

1 Start up GAM and sign on.

→ "5.3 Starting and Exiting GAM" (pg.102)

2 Select [Controller View] from the [View] menu.

→ "5.4.4 Starting Controller View and the Window Layout" (pg.109)

 **POINT**

- ▶ Each drive column indicates the hard disks connected to each enclosure or to each channel of the controller.

- 3** Double-click the icon for the hard disk to see the information about it.
Detailed information about the selected hard disk is displayed.

Disk Device Information (Channel:0 Target:1 Lun:0)

Device Inquiry Data

Vendor : FUJITSU Product : MAX3147RC Revision : 5202

Bus Width : 0 Bits Sync : No Linked : No Soft Reset : No

ANSI Version : SCSI-3 CmdQue : Yes

Serial : DQ12P5B0000E@#43CC

Device State

Nego. Transfer Speed : 0 MB/Sec Status : On Line

Nego. Bus Width : 0 Bits Sector Size : 512 Bytes

Physical Capacity : 140014 MB Config. Size : 139236 MB

Device Errors

Soft Errors : soft Parity Errors : parity Reset Errors

Hard Errors : hard Misc Errors : misc PFA Count : None

Rebuild Make Hot Spare Make Online Make Offline Locate... Close

ReplaceMissing



- ▶ The Channel, Target and Lun information displayed in the title bar is not supported.
- ▶ Click [Close] to close the window.

■ Detailed information about hard disks

The following information is displayed.

table: Detailed information about hard disks

Item	Description
Vendor	Information about the hard disk vendor.
Product	Model number of the hard disk.
Revision	The version of the hard disk's firmware.
Bus Width	The bus width. The value for this array controller is "Serial".
Sync / Linked / Soft Reset / CmdQue / ANSI Version	Not supported.
Serial	Serial number of the hard disk.
Slot	The number of the slot where the hard disk is installed.
Nego. Transfer Speed	Not supported.
Nego. Bus Width	Not supported.
Sector Size	The sector size.
Physical Capacity	The physical capacity of the hard disk.
Config. Size	The hard disk's available capacity when connected to this array controller.
Status	The current status of the hard disk. For details about the status, see "● Hard disks" (→pg.110).

table: Detailed information about hard disks

Item	Description
Soft Errors / Parity Errors / Hard Errors / Misc Errors	Not supported. (The number of recovery attempts made by the array controller for temporary or minor errors. This can be ignored unless the hard disk gets a failure status.)
PFA Count	The counter for the S.M.A.R.T. failure predictions for the hard disk.

■ Function buttons

You can perform the following operations using the buttons.

- [Rebuild] button
This button is enabled only when the status of the hard disk is Failure. Click this button to perform a rebuild of the hard disk. → "5.7 Rebuild" (pg.121)

- [Make Ready] button
Not supported.



- ▶ Do not use the [Make Ready] button unless you are instructed to do so by your maintenance engineer.

- [Make Offline] button
Forcibly changes the status of the hard disk to "Offline".



- ▶ Do not use the [Make Offline] button unless you are instructed to do so by your maintenance engineer.


- [Make Online] button
Not supported.
- [Locate] button
Blinks the failure LED of the hard disk to indicate the drive's location.
- [ReplaceMissing] button
Not supported.
- [Close] button
Closes the detailed hard disk information window.

5.6.4 Viewing Logical Drive Information

Using Controller View, you can view detailed information about the defined logical drives.

The logical drives are displayed to the right in the [Controller View] window. Each icon represents one logical drive.

- 1** Start up GAM and sign on.
→ "5.3 Starting and Exiting GAM" (pg.102)
- 2** Select [Controller View] from the [View] menu.
→ "5.4.4 Starting Controller View and the Window Layout" (pg.109)
- 3** Double-click the icon of a logical drive to see the information about it.
Detailed information about the selected logical drive is displayed.



POINT

- ▶ The logical drive number is displayed on the title bar.
- ▶ Click [Close] to close the window.

■ Detailed information about logical drives

The following information is displayed.

table: Detailed information about logical drives

Item	Description
RAID Level	The RAID level set for the logical drive.
Fault Tolerant	Indicates whether the logical drive has a redundancy feature or not.
Optimized for Speed	The setting whether the priority of logical drive's RAID level is placed on speed or not.
Optimized for Capacity	The setting whether the priority of logical drive's RAID level is placed on capacity or not.
Logical Size	The logical size of the logical drive.
Physical Size	The physical size of the logical drive.
Stripe Size	The striping size used by the logical drive.
Status	The current status of the logical drive. For details about the status, see "● Logical drives" (→pg.110).
Write Cache	Not supported.
Used Array Capacity	Displays the ratio of the logical drive's capacity to the hard disk's total capacity.

■ Function buttons

You can perform the following operations using the buttons.

- [Locate] button
Blinks the failure LED of all the hard disks that compose the logical drive to indicate their locations.
- [Close] button
Closes the detailed logical drive information window.


5.6.5 Checking Progress of Background Tasks

GAM enables you to check the progress of these tasks with progress bars.

From the pace of the progress bar, you can figure out approximately how long the task will take from start to finish.

■ Rebuild Status

When a rebuild is in progress, you can check its progress by selecting [Rebuild Status] from the [View] menu.



Click [Close] to close the [Rebuild Status] window.



- ▶ Do not cancel the rebuild.

■ Calculating the approximate time needed for a background task

For rebuild, you can figure out approximate time that the task takes from start to finish from the pace of the progress bar.

- 1** Measure the period of time required for the progress bar to advance 1%.
- 2** Calculate the approximate time that the task takes from start to finish, using the following formula.

$$(\text{Period measured in Step 1}) \times 100$$



- ▶ Use the calculated time only as a guideline. The actual time may be different from the calculated time depending on the system load and other factors.

5.7 Rebuild

To execute a rebuild manually, follow the procedure below.



- ▶ Just replacing the hard disk does not execute a rebuild. Make sure to perform the rebuild operation. For how to replace the hard disk and how to perform a rebuild, see "Chapter 6 Replacing Hard Disk" (→pg.123).

1 Start up GAM and sign on with Administrator privileges.

→"5.3 Starting and Exiting GAM" (pg.102)

2 Select [Controller View] from the [View] menu.

→"5.4.4 Starting Controller View and the Window Layout" (pg.109)

3 Double-click the icon of a hard disk with "Failure" state () in the [Controller View] window.

The detailed information about the hard disk is displayed in the [Disk Device Information] window.

4 Click [Rebuild].

The [Rebuild Status] window appears and a rebuild starts.

When the rebuild is finished, the following window appears and the hard disk and the related logical drives are restored to Online status.



5 Click [OK] to exit.

Chapter 6

Replacing Hard Disk

This chapter explains maintenance related issues, such as hard disk replacement. Since the procedure varies depending on the management tools used, read the description concerning your management tool.

6.1	How to Replace Hard Disk [ServerView RAID]	124
6.2	How to Replace Hard Disk [GAM]	131



6.1 How to Replace Hard Disk [ServerView RAID]


This section explains maintenance related issues, such as replacing hard disks using ServerView RAID.

6.1.1 Checking Hard Disk to be Replaced [ServerView RAID]

Check the target hard disk number before replacing it.

- 1** Start the ServerView RAID Manager and log in.
→ "4.3 Starting and Exiting ServerView RAID Manager" (pg.65)
- 2** Verify that the hard disk icon is displayed in the tree view.

A failed hard disk is indicated with the  /  icon.


A hard disk that has been predicted to fail is indicated with the  icon.

The slot number can be confirmed at the following location on the hard disk icon.



Verify the hard disk number here.
In this case, it is "2".

IMPORTANT

- ▶ If there are any hard disks being rebuilt (indicated with ) , wait until the rebuild is finished. After the rebuild has finished, check the hard disk status again.

- 3** To get detailed information, refer to the [General] tab of the object window.
Detailed information about the selected hard disk is displayed.
If "S.M.A.R.T. Error" is displayed in the [Status] field, you will be informed of a failure prediction warning (S.M.A.R.T.).

POINT

- ▶ The detailed information may not be displayable depending on the failure condition of the hard disk.

- 4** If there is a failed hard disk or a hard disk that is predicted to fail, replace it using the following procedures.

If there is a failed hard disk

See "6.1.2 Replacing Failed Hard Disk [ServerView RAID]" (→pg.125) to replace the hard disk.

If there is a hard disk that is predicted to fail

See "6.1.3 Preventive Replacement of Hard Disk [ServerView RAID]" (→pg.127) to replace the hard disk with the failure prediction warning.



When a hard disk failed and another is predicted to fail

- ▶ First, replace the failed hard disk and perform a rebuild. After that, confirm that the failure indication of the replaced hard disk has disappeared, i.e. that the logical drive status is "Operational", and then replace the hard disk that is predicted to fail, as a preventive measure. If the hard disk that is predicted to fail is replaced before the failed hard disk, rebuild cannot be performed and data will be lost.

POINT

- ▶ Failed hard disks can also be confirmed using BIOS Utility. Start BIOS Utility and check the [View Array] view. For more details, see "2.3.2 Viewing Information on Logical Drive and Hard Disk" (→pg.31).

6.1.2 Replacing Failed Hard Disk [ServerView RAID]

If a hard disk fails, it must be replaced with a new one as soon as possible.

POINT

- ▶ For how to remove and install hard disks, see "User's Guide" located on "PRIMERGY Startup Disc supplied with the server.



- ▶ Replace the failed hard disk with a new one of the same model (with the same capacity and speed) as a rule.
- ▶ Never remove any hard disks while the server is turned on, except to replace a failed drive.

1 Confirm the drive number of the failed hard disk and locate the drive.

Adding one to the slot number identified in steps 1 to 2 in →"6.1.1 Checking Hard Disk to be Replaced [ServerView RAID]" (pg.124) results in the bay number.

Example: If the slot number is 2, the location of the drive is bay 3.

2 Confirm that the hard disk failure LED is lit for the bay corresponding to the failed hard disk on the server.


For the locations of the bays and of the hard disk failure LED, see "User's Guide" located on "PRIMERGY Startup Disc supplied with the server.

- 3** Pull out the failed hard disk about an inch (1 to 3 cm) to disconnect it from the connector.


For how to remove hard disks, see "User's Guide" located on "PRIMERGY Startup Disc" supplied with the server.



- ▶ Do not pull out the hard disk completely from the server at this point.

- 4** Wait at least one minute until the hard disk motor has stopped spinning.
- 5** Pull out the failed hard disk completely from the hard disk bay.
- 6** Install a new hard disk at the same location where the failed hard disk was previously installed.
- 7** In the tree view, select the newly installed hard disk () in Degraded status, right-click, and then click [Start rebuild] from the displayed menu.

A confirmation window appears.



- 8** Click [Yes].

A rebuild is automatically started.

When the rebuild is started, the hard disk's failure LED that was lit starts flashing, and then turns off when the rebuild is complete.

After the rebuild is completed, in the tree view of the ServerView RAID Manager, select the icon of the replaced hard disk to verify that "Operational" is displayed in the [Status] field of the object window.



- ▶ When the following event is recorded in the OS event log, or in the Event Window of the ServerView RAID Manager, the rebuild is complete.
("X" indicates the number of the hard disk where the rebuild was performed.)

- In the Event Window

```
ID: 10267
Event: <Type and number of the controller>: Rebuild complete
on disk X
```

- For OS Event Log

```
Source      : Fujitsu ServerView Services
Type        : Information
Event ID    : 1
Description: <Type and number of the controller>: Rebuild
complete on disk X
```

- ▶ For the approximate time to complete the rebuild, see "■ Estimated time for rebuild" (→pg.16) or "■ How to calculate estimated time for background task" (→pg.88).
- ▶ If the system restarts or shuts down during rebuild, the rebuild is resumed from where it was stopped the next time.

6.1.3 Preventive Replacement of Hard Disk [ServerView RAID]

When the hard disk failure prediction function (PFA/S.M.A.R.T.) reports a hard disk as "S.M.A.R.T. Error", it means that the drive may fail in the near future. If the hard disk status becomes "S.M.A.R.T. Error", replace that drive as a preventive measure.

POINT


- ▶ For how to remove and install hard disks, see "User's Guide" located on "PRIMERGY Startup Disc supplied with the server.

IMPORTANT

- ▶ Replace the failed hard disk with a new one of the same model (with the same capacity and speed) as a rule.
- ▶ We recommend that you back up the data before performing preventive replacement of a hard disk.
- ▶ When two or more hard disks are predicted to fail, replace one drive at a time.
- ▶ If any hard disk is being rebuilt, wait until the rebuild process is finished.

■ Preventive replacement of hard disk with RAID 1 configuration

If the target hard disk for the preventive replacement belongs to a RAID 1 logical drive, follow the procedure below as a preventive measure.


- 1 Using ServerView RAID Manager, check the drive number of the hard disk that has a failure prediction warning () and locate that drive.

Adding one to the slot number identified in steps 1 to 2 in "6.1.1 Checking Hard Disk to be Replaced [ServerView RAID]" (→pg.124) results in the bay number.

Example: If the slot number is 2, the location of the drive is bay 3.

IMPORTANT

- ▶ If there is a failed hard disk at this point, replace that drive first, referring to "6.1.2 Replacing Failed Hard Disk [ServerView RAID]" (→pg.125). If any hard disk is being rebuilt, wait until the rebuild process is finished.

- 2** In the tree view, select the hard disk () with a failure prediction warning.

Detailed information about the selected hard disk is displayed in the object window.

If "S.M.A.R.T. Error" is displayed in the [Status] field, you will be informed of a failure prediction warning (S.M.A.R.T.).



- 3** In the tree view, select the target hard disk, right-click, and then click [Locate device] from the displayed menu to check the location of the target hard disk on the server.

The hard disk failure LED corresponding to the hard disk starts to flash or light up.

POINT

- ▶ The hard disk confirmed here has received a failure prediction warning (the target hard disk for preventive replacement).
We recommend that you put some kind of mark on this drive to identify it.

- 4** After checking the location, in the tree view, select the target hard disk, right-click, and then click [Stop location] from the displayed menu.

The failure LED turns off.

- 5** In the tree view, select the target hard disk, right-click, and then click [Make offline] from the displayed menu.

The following message appears.

Are you sure you want to set this physical disk to offline?

- 6** Enter "yes" and click [OK].

7 Verify that the [Status] field for the target hard disk has changed to "Offline" in the object window.

8 Pull out the hard disk identified in Step 3 about an inch (1 to 3 cm) to disconnect it from the connector.

For how to remove hard disks, see "User's Guide" located on "PRIMERGY Startup Disc" supplied with the server.

IMPORTANT

- ▶ Do not remove a hard disk that is in good condition. Doing so may cause loss of data.
- ▶ Do not pull out the hard disk completely from the server at this point.


POINT

- ▶ The hard disk failure LED for the drive to be replaced is now lit.


9 Wait at least one minute until the hard disk motor has stopped spinning.

10 Pull out the hard disk that is predicted to fail completely from the hard disk bay.

11 Install a new hard disk at the same location where the removed hard disk was previously installed.

12 In the tree view, select the newly installed hard disk () in Degraded status, right-click, and then click [Start rebuild] from the displayed menu.

A confirmation window appears.



13 Click [Yes].

A rebuild is automatically started.

When the rebuild is started, the hard disk's failure LED that was lit starts flashing, and then turns off when the rebuild is completed.

After the rebuild is completed, in the tree view of the ServerView RAID Manager, select the icon of the replaced hard disk to verify that "Operational" is displayed in the [Status] field of the object window.

 **POINT**

- ▶ When the following event is recorded in the OS event log, or in the Event Window of the ServerView RAID Manager, the rebuild is completed.
(“X” indicates the number of the hard disk where the rebuild was performed.)

- In the Event Window

```
ID: 10267
Event: <Type and number of the controller>: Rebuild complete
on disk X
```

- For OS Event Log

```
Source      : Fujitsu ServerView Services
Type       : Information
Event ID    : 1
Description: <Type and number of the controller>: Rebuild complete
on disk X
```

- ▶ If the system restarts or shuts down during rebuild, the rebuild is resumed from where it was stopped the next time.
- ▶ For the approximate time to complete the rebuild, see "■ Estimated time for rebuild" (→pg.16) or "■ How to calculate estimated time for background task" (→pg.88).

6.2 How to Replace Hard Disk [GAM]


This section explains maintenance related issues, such as hard disk replacement in GAM.

6.2.1 Checking Hard Disk to be Replaced [GAM]


Check the slot number of the target hard disk before replacing it.

- 1** Start up GAM and sign on.
→ "5.3 Starting and Exiting GAM" (pg.102)
- 2** Select [Controller View] from the [View] menu.
→ "5.4.4 Starting Controller View and the Window Layout" (pg.109)
- 3** Check the displayed icon for the hard disk.


A failed hard disk is indicated with the  icon.

A hard disk that has been predicted to fail is indicated with the  icon.

The slot number can be confirmed at the following location on the hard disk icon.

Slot ID 
In this case, the Slot ID is "4".

IMPORTANT

- ▶ If there are any hard disks being rebuilt (indicated with ) , wait until the rebuild is finished. After the rebuild has finished, check the hard disk status again.

- 4** Double-click the hard disk icon to confirm detailed information.

Detailed information about the selected hard disk is displayed.

If the [PFA Count] in the [Device Errors] field is displayed as "Found", a failure prediction warning (S.M.A.R.T.) has been detected.

POINT

- ▶ The detailed information may not be displayable depending on the failure condition of the hard disk.

- 5** If there is a failed hard disk or a hard disk that is predicted to fail, replace it using the following procedures.

If there is a failed hard disk

See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk.

If there is a hard disk that is predicted to fail

See "6.2.3 Preventive Replacement of Hard Disk [GAM]" (→pg.134) to replace the hard disk with the failure prediction warning.



When a hard disk failed and another is predicted to fail

- ▶ First, replace the failed hard disk and perform a rebuild. After that, confirm that the failure indication of the replaced hard disk has disappeared, i.e. that the logical drive status is "Online", and then replace the hard disk that is predicted to fail, as a preventive measure.
If the hard disk that is predicted to fail is replaced before the failed hard disk, rebuild cannot be performed and data will be lost.

POINT

- ▶ Failed hard disks can also be confirmed using BIOS Utility. Start BIOS Utility and check the [View Array] view. For more details, see "2.3.2 Viewing Information on Logical Drive and Hard Disk" (→pg.31).

6.2.2 Replacing Failed Hard Disk [GAM]

If a hard disk fails, it must be replaced with a new one as soon as possible.

POINT

- ▶ For how to remove and install hard disks, see "User's Guide" located on "PRIMERGY Startup Disc supplied with the server.



- ▶ Replace the failed hard disk with a new one of the same model (with the same capacity and speed) as a rule.
- ▶ When connecting a hard disk that has previously been used in a disk array configuration on a general host adapter, perform a low level format of the hard disk on the host adapter in advance.
- ▶ Never remove any hard disks while the server is turned on, except to replace a failed drive.

1 Confirm the slot number of the failed hard disk and locate the drive.

Adding one to the slot number identified in steps 1 to 3 in "6.2.1 Checking Hard Disk to be Replaced [GAM]" (→pg.131) results in the bay number.

Example: If the slot number is 4, the location of the drive is bay 5.

2 Confirm that the hard disk failure LED is lit for the bay corresponding to the failed hard disk on the server.

For the location of the bays and of the hard disk failure LED, see "User's Guide" located on "PRIMERGY Startup Disc supplied with the server.

- 3** Pull out the failed hard disk about an inch (1 to 3 cm) to disconnect it from the connector.

For how to remove hard disks, see "User's Guide" located on "PRIMERGY Startup Disc" supplied with the server.



- ▶ Do not pull out the hard disk completely from the server at this point.

- 4** Wait at least one minute until the hard disk motor has stopped spinning.

- 5** Pull out the failed hard disk completely from the hard disk bay.

- 6** Install a new hard disk at the same location where the failed hard disk was previously installed.

- 7** Double-click the icon for the newly installed hard disk on the [Controller View] window.

The [Disk Device Information] window appears.

- 8** Click [Rebuild].

A rebuild is automatically started.

When the rebuild is started, the hard disk's failure LED that was lit starts flashing, and then turns off when the rebuild is completed.

When the rebuild is finished, make sure that the status of the replaced hard disk has changed to "Online" in the [Disk Device Information] window (→pg.115) of GAM.



- ▶ When the following event is recorded in the OS event log, or in the Log Information Viewer of the GAM Client, the rebuild is complete.
([ctl] indicates the controller number and [chn] indicates the slot number of the hard disk.)
 - For Log Information Viewer

```
I-7   ctl:x chn:y tgt:z   Rebuild is over.
```

- For OS Event Log

```
Source      :Fujitsu ServerView Services
Type        : Information
Event ID    : 1
Description: [ctl:x chn:y tgt:x] Rebuild is over.
```

To confirm the completion of rebuild in GAM Client, do not close GAM Client until the rebuild is completed.

- ▶ For the approximate time to complete the rebuild, see "■ Estimated time for rebuild" (→pg.16) or "■ Calculating the approximate time needed for a background task" (→pg.120).
- ▶ If the system restarts or shuts down during rebuild, the rebuild is resumed from where it was stopped the next time.

6.2.3 Preventive Replacement of Hard Disk [GAM]

When the hard disk failure prediction function (PFA/S.M.A.R.T.) reports a hard disk as "Critical", it means that the drive may fail in the near future. If the hard disk status becomes "Critical", replace that drive as a preventive measure.

POINT


- ▶ For how to remove and install hard disks, see "User's Guide" located on "PRIMERGY Startup Disc supplied with the server.

IMPORTANT

- ▶ Replace the failed hard disk with a new one of the same model (with the same capacity and speed) as a rule.
- ▶ We recommend that you back up the data before performing preventive replacement of a hard disk.
- ▶ If any hard disk is being rebuilt, wait until the rebuild process is finished.

■ Preventive replacement a hard disk with a RAID 1 configuration

If the target hard disk for the preventive replacement belongs to a RAID 1 logical drive, follow the procedure below for the preventive replacement.

- 1 Using GAM, check the slot number of the hard disk with a failure prediction warning () and locate the drive.

Adding one to the slot number identified in steps 1 to 3 in "6.2.1 Checking Hard Disk to be Replaced [GAM]" (→pg.131) results in the bay number.

Example: If the slot number is 4, the location of the drive is bay 5.


IMPORTANT

- ▶ If there is a failed hard disk at this point, replace that drive first, referring to "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132). If any hard disk is being rebuilt, wait until the rebuild process is finished.

2 Double-click the icon of the hard disk with the failure prediction warning.

Detailed information about the selected hard disk is displayed.

Make sure that its [Status] is indicated as "Critical".



3 Click [Locate] and check the location of the target hard disk on the server.

The hard disk failure LED corresponding to the hard disk starts to flash or light up.

For the location of the bays and of the hard disk failure LED, see "User's Guide" located on "PRIMERGY Startup Disc supplied with the server.

POINT

- ▶ The hard disk confirmed here has received a failure prediction warning (the target hard disk for preventive replacement). We recommend that you put some kind of mark on this drive to identify it.

4 Click [OK] when the location is confirmed.

The failure LED turns off.

5 Click the [Make Offline] button. When the [WARNING] window appears, enter [YES] and click [OK].

6 Confirm that the following log entry is displayed in the GAM Log Information Viewer.

```
Event ID      : E-50
Description: Physical disk status changed to offline
```

7 Pull out the hard disk identified in Step 3 about an inch (1 to 3 cm) to disconnect it from the connector.

For how to remove hard disks, see "User's Guide" located on "PRIMERGY Startup Disc supplied with the server.

 **IMPORTANT**

- ▶ Do not remove a hard disk that is in good condition. Doing so may cause loss of data.
- ▶ Do not pull out the hard disk completely from the server at this point.

 **POINT**

- ▶ Although a pop-up of "Error returned by firmware." may appear when the hard disk is replaced during executing the Locate function, the operation is not affected. Click [OK] to close the pop-up window.

8 Wait at least one minute until the hard disk motor has stopped spinning.

9 Pull out the hard disk that is predicted to fail completely from the hard disk bay.

10 Install a new hard disk at the same location where the removed hard disk was previously installed.

11 Double-click the icon for the newly installed hard disk on the [Controller View] window.

The [Disk Device Information] window appears

12 Click [Rebuild].

A rebuild is automatically started.

When the rebuild is started, the hard disk's failure LED that was lit starts flashing, and then turns off when the rebuild is completed.

When the rebuild is finished, make sure that the status of the replaced hard disk has changed to "Online" in the [Disk Device Information] window (→pg.115) of GAM.

 **POINT**

- ▶ If the system restarts or shuts down during rebuild, the rebuild is resumed from where it was stopped the next time.
- ▶ If the [Controller View] display is not updated, execute [Scan Devices] from the [Administration] menu.

Appendix

This section explains the event codes for ServerView RAID and GAM, and the notes on the array controller usage.

A	A List of ServerView RAID Event Logs	138
B	A List of GAM Event Logs	158
C	Notes on Usage for the Array Controller	171

A A List of ServerView RAID Event Logs

With ServerView installed, occurred events are recorded in the OS event logs by ServerView.

- For Windows
Events are recorded by the Event Viewer application log from the source "Fujitsu ServerView Services".
- For Linux
Events are recorded in the system log from the source "Fujitsu ServerView Services".

The log also records the location of the device. Types of locations are as follows.

table: Meaning of event log strings

Character String ^[Note 1]	Meaning
Server %s	Name of the server
Adapter %s	Type and number of the controller As for this product, the names are "LSI 1068SASIME ...", "LSI 1064ESASIME ...", and "RAID 0/1 SAS 4P".
Disk %s	Number of the hard disk
Logical Drive %s	Number of the logical drive

[Note 1]: %s is replaced with a number or a character string.



- ▶ Unless ServerView is installed, logging into the OS event logs from the source "Fujitsu ServerView Services" will not be possible. See "User's Guide" located on "PRIMERGY Startup Disc" supplied with the server to install and configure ServerView.

The relationship between the severity of each ServerView RAID event (SNMP TRAP) and the type of event log displayed in the event window of the ServerView RAID Manager is as follows:

table: Event log types and descriptions

Severity	Description	Severity with the ServerView RAID Manager		OS Event Log Type	
CRITICAL	Severe error		Error		Error
MAJOR	Error		Error		Error
MINOR	Warning		Warning		Warning
INFORMATIONAL	Information (No action required)		Informational		Information

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
1	INFORMATIONAL	Undefined event (Server %s)	An unknown event has occurred.	If there is an error before or after an event, perform the proper recovery action for that error.
10000	INFORMATIONAL	Unknown event (Server %s)	An unknown event has occurred.	If there is an error before or after an event, perform the proper recovery action for that error. If there is no error, no action required.
10002	MINOR	Write access to ServerView RAID revoked by user %s (%s) (Server %s)	Write Access mode has been canceled. Another client has obtained Write Access mode.	None.
10017	INFORMATIONAL	Adapter %s: SCSI sense data on disk (%s) available: %s (Server %s)	A hard disk reported sense information.	There is no problem as long as the target hard disk is online because the controller has performed a recovery.
10021	INFORMATIONAL	Adapter %s: Disk (%s) marked online (Server %s)	The hard disk status is now online.	None.
10022	CRITICAL	Adapter %s: Disk (%s) marked offline (Server %s)	The hard disk status is now offline.	None.
10023	MAJOR	Adapter %s: Disk (%s) timed out (Server %s)	The hard disk has been timed out.	Check that the hard disk is connected properly. If the hard disk has failed, replace it and perform a rebuild.
10024	INFORMATIONAL	Adapter %s: Global hot spare created on disk (%s) (Server %s)	A global hot spare has been created.	None.
10025	MINOR	Adapter %s: Global hot spare deleted on disk (%s) (Server %s)	A global hot spare has been disabled.	None.
10026	INFORMATIONAL	Adapter %s: Dedicated hot spare created on disk (%s) (Server %s)	A dedicated spare disk drive has been created.	Dedicated spare disks are not supported. Make sure to properly set a spare disk.
10027	MINOR	Adapter %s: Dedicated hot spare deleted on disk (%s) (Server %s)	The dedicated spare disk has been disabled.	None.
10028	INFORMATIONAL	Adapter %s: Disk (%s) marked available (Server %s)	The hard disk status is now available.	None.
10029	INFORMATIONAL	Adapter %s: Rebuild on disk (%s) started (Server %s)	Rebuilding of the hard disk has started.	None.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10030	MAJOR	Adapter %s: Rebuild on disk (%s) failed (Server %s)	Rebuilding the hard disk has failed.	Check the present status of the logical drive. <ul style="list-style-type: none"> • If in the critical state: Replace the failed hard disk and perform a rebuild again. • If in the offline state: Contact an office listed in the "Contact Information" of the "Start Guide".
10032	INFORMATIONAL	Adapter %s: New disk (%s) detected (Server %s)	A new hard disk has been detected.	None.
10033	MINOR	Adapter %s: Disk (%s) removed (Server %s)	A hard disk was removed.	Replace and rebuild the hard disk.
10038	MAJOR	Adapter %s: Error on disk (%s) detected (Server %s)	An error has been detected on a hard disk.	Replace the hard disk failure, and perform a rebuild.
10039	INFORMATIONAL	Adapter %s: Channel %s was reset (Server %s)	A channel has been reset.	None.
10040	MAJOR	Adapter %s: Retry I/O on disk (%s) (Server %s)	I/O retry for the hard disk has been performed.	There is no problem as long as there is no hard disk failure, because the firmware has performed a recovery.
10041	MAJOR	Adapter %s: ECC Error on disk (%s) (Server %s)	An ECC error on the hard disk has been detected.	There is no problem as long as the target hard disk is online because the controller has performed a recovery.
10043	MAJOR	Adapter %s: Media error on disk (%s) (Server %s)	A media error has been detected on the hard disk.	There is no problem as long as the target hard disk is online because the controller has performed a recovery.
10044	MINOR	Adapter %s: S.M.A.R.T. warning on disk (%s) (Server %s)	A failure has been predicted for a hard disk.	Replace the hard disk as a preventive measure.
10045	MINOR	Adapter %s: S.M.A.R.T. error on disk (%s) (Server %s)	A failure has been predicted for a hard disk.	Replace the hard disk as a preventive measure.
10055	INFORMATIONAL	Adapter %s: Rebuild started on logical drive %s (Server %s)	Rebuilding of the logical drive has started.	None.
10056	INFORMATIONAL	Adapter %s: Rebuild finished on logical drive %s (Server %s)	Rebuilding of the logical drive has been completed.	None.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10057	MAJOR	Adapter %s: Rebuild failed on logical drive %s (Server %s)	Rebuilding of the logical drive has failed.	Check the present status of the logical drive. <ul style="list-style-type: none"> If in the critical state: Replace the failed hard disk and perform a rebuild again. If in the offline state: Contact an office listed in the "Contact Information" of the "Start Guide".
10058	MINOR	Adapter %s: Rebuild aborted on logical drive %s (Server %s)	Rebuilding of the logical drive has been aborted.	Perform the rebuild again.
10059	INFORMATIONAL	Adapter %s: Rebuild paused on logical drive %s (Server %s)	Rebuilding of the logical drive has paused.	None.
10078	MAJOR	Adapter %s: Logical drive %s degraded (Server %s)	The logical drive status is now degraded.	Replace and rebuild the failed hard disk.
10079	CRITICAL	Adapter %s: Logical drive %s failed (Server %s)	The logical drive status is now offline.	Contact an office listed in the "Contact Information" of "Start Guide".
10080	INFORMATIONAL	Adapter %s: Logical drive %s created (Server %s)	The logical drive has been created.	None.
10081	MINOR	Adapter %s: Logical drive %s deleted (Server %s)	A new logical drive has been deleted.	None.
10082	INFORMATIONAL	Adapter %s: Logical drive %s operational (Server %s)	The logical drive status is now online.	None.
10085	INFORMATIONAL	Adapter %s: Initialization started on logical drive %s (Server %s)	Foreground initialization of the logical drive has started.	None. (Foreground Initialization is not supported.)
10086	INFORMATIONAL	Adapter %s: Initialization finished on logical drive %s (Server %s)	Foreground Initialization of the logical drive has been completed.	None. (Foreground Initialization is not supported.)
10087	INFORMATIONAL	Adapter %s: BGI started on logical drive %s (Server %s)	Background initialization of the logical drive has started.	None.
10088	INFORMATIONAL	Adapter %s: BGI finished on logical drive %s (Server %s)	Background initialization of the logical drive has been completed.	None.
10089	MINOR	Adapter %s: BGI canceled on logical drive %s (Server %s)	Background initialization of the logical drive has been canceled.	None. (Background initialization resumes automatically after a certain period of time.)
10090	MINOR	Adapter %s: Initialization canceled on logical drive %s (Server %s)	Foreground initialization of the logical drive has been canceled.	None. (Foreground Initialization is not supported.)
10095	INFORMATIONAL	Adapter %s: Alarm enabled (Server %s)	An alarm has been enabled.	An alarm is not supported. Check array controller settings.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10096	MINOR	Adapter %s: Alarm disabled (Server %s)	An alarm has been disabled.	None.
10108	INFORMATIONAL	Adapter %s: Automatic rebuild enabled (Server %s)	Auto Rebuild has been enabled.	None.
10109	INFORMATIONAL	Adapter %s: Automatic rebuild disabled (Server %s)	Auto Rebuild has been disabled.	None.
10114	INFORMATIONAL	Adapter %s: BIOS enabled (Server %s)	BIOS has been enabled.	None.
10115	INFORMATIONAL	Adapter %s: BIOS disabled (Server %s)	BIOS has been disabled.	None.
10116	INFORMATIONAL	Adapter %s: BIOS stop on error enabled (Server %s)	Stop on Error has been enabled.	None.
10117	INFORMATIONAL	Adapter %s: BIOS stop on error disabled (Server %s)	Stop on Error has been disabled.	None.
10131	INFORMATIONAL	Adapter %s: S.M.A.R.T. poll interval changed (Server %s)	S.M.A.R.T. Poll Interval has been changed.	None.
10132	INFORMATIONAL	Adapter %s: Configuration rescanned (Server %s)	Rescan of the array configuration has been performed.	None.
10133	INFORMATIONAL	Adapter %s: Configuration cleared (Server %s)	The array configuration has been deleted.	None.
10168	INFORMATIONAL	Adapter %s: Logical drive %s: Name changed (Server %s)	The name of the logical drive has been changed.	None.
10170	MAJOR	Reboot required (Server %s)	Reboot is required.	Restart the system.
10171	INFORMATIONAL	User %s (%s) logged in (Server %s)	The user has logged in.	None.
10172	INFORMATIONAL	User %s (%s) logged out (Server %s)	The user has logged out.	None.
10204	CRITICAL	Adapter %s: Fatal firmware error: %s (Server %s)	A fatal error has occurred in the firmware.	Contact an office listed in the "Contact Information" of "Start Guide".
10205	INFORMATIONAL	Adapter %s: Factory defaults restored (Server %s)	Factory default has been restored.	Check the controller's settings and change them to the correct values.
10206	MAJOR	Adapter %s: Flash downloaded image corrupt (Server %s)	The downloaded firmware image is corrupted.	Update the firmware again by using a correct image.
10207	MAJOR	Adapter %s: Flash erase error (Server %s)	The Flash erasure has failed.	Update the firmware again.
10208	MAJOR	Adapter %s: Flash timeout during erase (Server %s)	A timeout has occurred during the Flash erasure.	Update the firmware again.
10209	MAJOR	Adapter %s: Flash error (Server %s)	The Flash has failed.	Update the firmware again.
10210	INFORMATIONAL	Adapter %s: Flashing image: %s (Server %s)	A Flash of the image has been performed.	None.
10211	INFORMATIONAL	Adapter %s: Flash of new firmware image(s) complete (Server %s)	A Flash of the new firmware image has been completed.	None.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10212	MAJOR	Adapter %s: Flash programming error (Server %s)	An error has occurred during the Flash programming.	Update the firmware again.
10213	MAJOR	Adapter %s: Flash timeout during programming (Server %s)	Timeout has occurred during the Flash programming.	Update the firmware again.
10214	MINOR	Adapter %s: Flash chip type unknown (Server %s)	The chip type of the Flash is unknown.	Update the firmware again using the correct image. Check to see if the target controller that needs to be updated is correct.
10215	MAJOR	Adapter %s: Flash command set unknown (Server %s)	The Flash command is not recognized.	Update the firmware again by using the correct tool.
10216	MAJOR	Adapter %s: Flash verification failure (Server %s)	The Flash verification has failed.	Update the firmware again.
10217	INFORMATIONAL	Adapter %s: Flush rate changed to %s seconds (Server %s)	The Flush Rate has been changed in seconds.	None.
10218	INFORMATIONAL	Adapter %s: Hibernate command received from host (Server %s)	The hibernation command was received from the server.	None.
10219	INFORMATIONAL	Adapter %s: Event log cleared (Server %s)	The event log has been cleared.	None.
10220	INFORMATIONAL	Adapter %s: Event log wrapped (Server %s)	The event log has reached the maximum capacity and old log entries have been deleted.	None.
10221	MAJOR	Adapter %s: Multi-bit ECC error: ECAR=%s	A multi-bit error has been detected.	Replace the cache memory or the battery backup unit. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
10222	MAJOR	Adapter %s: Single-bit ECC error: ECAR=%s	A single-bit error has been detected.	Replace the cache memory or the battery backup unit. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
10223	MAJOR	Adapter %s: Not enough adapter memory (Server %s)	There is not a sufficient amount of Controller memory.	Contact an office listed in the "Contact Information" of "Start Guide".
10226	INFORMATIONAL	Adapter %s: Shutdown command received from host (Server %s)	The shutdown command was received from the server.	None.
10227	INFORMATIONAL	Adapter %s: Test event: '%s' (Server %s)	A test event has been issued.	None.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10228	INFORMATIONAL	Adapter %s: Time established as %s; (%s seconds since power on) (Server %s)	The system time has been set.	None.
10229	INFORMATIONAL	Adapter %s: User entered firmware debugger (Server %s)	The firmware has entered the debug mode.	None.
10235	INFORMATIONAL	Adapter %s: Logical drive %s: %s changed (Server %s)	A property of the logical drive has been changed.	None.
10240	MAJOR	Adapter %s: Initialization failed on logical drive %s (Server %s)	Foreground initialization has failed.	None. (Foreground initialization on the OS is not supported.)
10241	INFORMATIONAL	Adapter %s: Initialization progress on logical drive %s is %s (Server %s)	Foreground initialization is in progress.	None. (Foreground initialization on the OS is not supported.)
10243	INFORMATIONAL	Adapter %s: Full initialization started on logical drive %s (Server %s)	Full initialization has started.	None.
10244	INFORMATIONAL	Adapter %s: Logical drive %s: Property %s updated (Server %s)	A property of the logical drive has been changed.	None.
10249	INFORMATIONAL	Adapter %s: State change on logical drive %s from operational to operational (Server %s)	The logical drive status is now online.	None.
10255	MAJOR	Adapter %s: Error on disk (%s) (error %s) (Server %s)	An error has occurred on the hard disk.	Replace and rebuild the failed hard disk.
10259	MAJOR	Adapter %s: Disk (%s) is not supported (Server %s)	An unsupported hard disk has been detected.	Use a supported hard disk.
10263	MINOR	Adapter %s: Predictive failure: Disk (%s) (Server %s)	A failure has been predicted for a hard disk.	Replace the hard disk as a preventive measure.
10264	MAJOR	Adapter %s: Puncturing bad block on disk (%s) at LBA %s (Server %s)	A media error has been detected in the source hard disk during the rebuild.	If an unreadable file is found during operation, restore the file from the backup.
10265	MINOR	Adapter %s: Rebuild aborted by user on disk (%s) (Server %s)	The rebuild has been canceled.	Perform the rebuild again.
10266	INFORMATIONAL	Adapter %s: Rebuild complete on logical drive %s (Server %s)	The rebuild of the logical drive has been completed.	None.
10267	INFORMATIONAL	Adapter %s: Rebuild complete on disk (%s) (Server %s)	The rebuild of the hard disk has been completed.	None.
10268	INFORMATIONAL	Adapter %s: Rebuild progress on disk (%s) is %s (Server %s)	The rebuild is in progress.	None.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10269	INFORMATIONAL	Adapter %s: Rebuild resumed on disk (%s) (Server %s)	The rebuild has resumed.	None.
10270	INFORMATIONAL	Adapter %s: Rebuild automatically started on disk (%s) (Server %s)	The rebuild of the hard disk has started automatically.	None.
10272	MAJOR	Adapter %s: Reassign write operation failed on disk (%s) at LBA %s (Server %s)	The reassign operation has failed.	Replace and rebuild the failed hard disk.
10273	MAJOR	Adapter %s: Unrecoverable medium error during rebuild on disk (%s) at LBA %s (Server %s)	An unrecoverable media error has been detected during the rebuild.	If an unreadable file is found during operation, restore the file from the backup.
10274	INFORMATIONAL	Adapter %s: Corrected medium error during recovery on disk (%s) at LBA %s (Server %s)	A media error has been recovered.	None.
10275	MAJOR	Adapter %s: Unrecoverable medium error during recovery on disk (%s) at LBA %s (Server %s)	An unrecoverable media error has been detected.	If an unreadable file is found during operation, restore the file from the backup.
10276	INFORMATIONAL	Adapter %s: Unexpected sense: Disk (%s)	Sense information of the hard disk has been reported.	There is no problem as long as the target hard disk is online because the controller has performed recovery.
10277	INFORMATIONAL	Adapter %s: State change on disk (%s) from available to available (Server %s)	The hard disk is now available.	None.
10278	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from available to available (Server %s)	The hard disk status is now available.	None.
10282	MINOR	Adapter %s: SAS topology error: Loop detected (Server %s)	A loop has been detected in the SAS topology.	Check the connections of the hard disk and cables. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
10283	MINOR	Adapter %s: SAS topology error: Unaddressable device (Server %s)	A device is unaddressable with the SAS topology.	Check the connections of the hard disk and cables. If the system connections are correct, yet a hard disk has failed, replace the hard disk and perform a rebuild. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10284	MINOR	Adapter %s: SAS topology error: Multiple ports to the same SAS address (Server %s)	Multiple ports are connected to the same SAS address in the SAS topology.	Check the connection configuration. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
10285	MINOR	Adapter %s: SAS topology error: Expander error (Server %s)	An error has been detected in the Expander.	Contact an office listed in the "Contact Information" of "Start Guide".
10286	MINOR	Adapter %s: SAS topology error: SMP timeout (Server %s)	An SMP timeout has been detected.	Contact an office listed in the "Contact Information" of "Start Guide".
10287	MINOR	Adapter %s: SAS topology error: Out of route entries (Server %s)	Route entries cannot be found.	Contact an office listed in the "Contact Information" of "Start Guide".
10288	MINOR	Adapter %s: SAS topology error: Index not found (Server %s)	Index cannot be found.	Contact an office listed in the "Contact Information" of "Start Guide".
10289	MINOR	Adapter %s: SAS topology error: SMP function failed (Server %s)	An error has been detected in an SMP function.	Contact an office listed in the "Contact Information" of "Start Guide".
10290	MINOR	Adapter %s: SAS topology error: SMP CRC error (Server %s)	A CRC error has been detected in SMP.	Contact an office listed in the "Contact Information" of "Start Guide".
10291	MINOR	Adapter %s: SAS topology error: Multiple subtractive (Server %s)	An error has been detected in the SAS topology.	Contact an office listed in the "Contact Information" of "Start Guide".
10292	MINOR	Adapter %s: SAS topology error: Table to table (Server %s)	An error has been detected in the SAS topology.	Contact an office listed in the "Contact Information" of "Start Guide".
10293	MINOR	Adapter %s: SAS topology error: Multiple paths (Server %s)	Multiple paths exist.	Check the connections of the hard disk and cables. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
10294	MAJOR	Adapter %s: Unable to access disk (%s) (Server %s)	The hard disk cannot be accessed.	Replace and rebuild the failed hard disk.
10297	MINOR	Adapter %s: Marking logical drive %s inconsistent due to active writes at shutdown (Server %s)	The consistency of the logical drive has been lost due to the shutdown during the Write operation.	None. Automatically restored with Write Journaling.
10336	MINOR	Adapter %s: Disk (%s) too small to be used for auto rebuild (Server %s)	There is not a sufficient amount of hard disk capacity to perform a rebuild.	Replace the hard disk with sufficient capacity.
10339	INFORMATIONAL	Adapter %s: Bad block table on disk (%s) is 80% full (Server %s)	The Bad Block Table use rate has exceeded 80%.	Replace the hard disk as a preventive measure.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10340	MINOR	Adapter %s: Bad block table on disk (%s) is full; unable to log Block %s (Server %s)	The Bad Block Table is full.	Replace the hard disk as a preventive measure.
10344	MINOR	Adapter %s: Single-bit ECC error: ECAR=%s	A single-bit error has been detected.	Replace the cache memory or the battery backup unit. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
10345	MINOR	Adapter %s: Single-bit ECC error: ECAR=%s	A single-bit error has been detected.	Replace the cache memory or the battery backup unit. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
10346	INFORMATIONAL	Adapter %s: Single-bit ECC error: ECAR=%s	A single-bit error has been detected.	Replace the cache memory or the battery backup unit. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
10353	INFORMATIONAL	Adapter %s: Retention test started on previous reboot (Server %s)	The NVRAM retention test has started.	None.
10354	INFORMATIONAL	Adapter %s: NVRAM retention test passed (Server %s)	The NVRAM retention test has been completed.	None.
10355	MINOR	Adapter %s: NVRAM retention test failed! (Server %s)	The NVRAM retention test has failed.	Contact an office listed in the "Contact Information" of "Start Guide".
10356	INFORMATIONAL	Adapter %s: %s test finished %s passes successfully (Server %s)	The test has been completed.	None.
10357	MINOR	Adapter %s: %s test failed on %s pass. fail data: errorOffset=%s goodData=%s badData=%s (Server %s)	The test has failed.	Contact an office listed in the "Contact Information" of "Start Guide".
10358	INFORMATIONAL	Adapter %s: Self-check diagnostics finished (Server %s)	The self-test has been completed.	None.
10359	INFORMATIONAL	Adapter %s: Foreign configuration detected (Server %s)	Foreign Configuration has been detected.	None. (Replace and rebuild the failed hard disks.)
10360	INFORMATIONAL	Adapter %s: Foreign configuration imported (Server %s)	Foreign Configuration has been imported.	None.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10361	INFORMATIONAL	Adapter %s: Foreign configuration cleared (Server %s)	Foreign Configuration has been cleared.	None.
10362	MINOR	Adapter %s: NVRAM is corrupt; reinitializing (Server %s)	The NVRAM had a failure and re-initialization is in progress.	Contact an office listed in the "Contact Information" of "Start Guide".
10363	MINOR	Adapter %s: NVRAM mismatch occurred (Server %s)	An NVRAM mismatch has occurred.	Contact an office listed in the "Contact Information" of "Start Guide".
10364	MINOR	Adapter %s: SAS wide port %s lost link on PHY %s (Server %s)	The SAS wide port has lost its link.	Check the connections of the system, and replace the failed hard disk and perform a rebuild. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
10365	INFORMATIONAL	Adapter %s: SAS wide port %s restored link on PHY %s (Server %s)	The SAS wide port has restored its link.	None.
10366	MINOR	Adapter %s: SAS port %s	The errors in the SAS port have exceeded the threshold.	Contact an office listed in the "Contact Information" of "Start Guide".
10367	MINOR	Adapter %s: Bad block reassigned on disk (%s) from LBA %s to LBA %s (Server %s)	A bad block of the hard disk has been relocated.	None.
10368	INFORMATIONAL	Adapter %s: Adapter hot plug detected (Server %s)	A controller has been detected.	None.
10371	INFORMATIONAL	Adapter %s: Time duration provided by host is not sufficient for self-checking (Server %s)	The system has not provided enough time for self-checking.	Contact an office listed in the "Contact Information" of "Start Guide".
10372	INFORMATIONAL	Adapter %s: Disk (%s) on array %s row %s marked missing (Server %s)	The hard disk has been marked as missing.	Replace and rebuild the failed hard disk.
10377	MINOR	Adapter %s: Disk (%s) is not certified (Server %s)	The hard disk is not a certified drive.	Replace the hard disk with a certified drive.
10378	MINOR	Adapter %s: Dirty cache data discarded by user (Server %s)	Dirty cache data has been discarded by the user's operation.	Perform Make Data Consistent.
10379	MINOR	Adapter %s: Disks missing from configuration at boot (Server %s)	An undetected hard disk during startup exists.	Replace and rebuild the failed hard disk.
10380	MINOR	Adapter %s: Logical drives missing drives and will go offline at boot: %s (Server %s)	The logical drive status was offline during startup.	Replace and rebuild the failed hard disk.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10382	MINOR	Adapter %s: Previous configuration completely missing at boot (Server %s)	The previous configuration cannot be found during startup.	Turn off the server and check the connection of the hard disks, cables, the power supply, etc.. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
10386	INFORMATIONAL	Adapter %s: Disk (%s) rebuild not possible as SAS/SATA is not supported in an array (Server %s)	Rebuilding of the hard disk is not possible because SAS/SATA is not supported.	None. (SATA HDD is not supported.)
10388	MAJOR	Adapter %s: Logical drive %s partially degraded (Server %s)	The logical drive status is now degraded.	Replace and rebuild the failed hard disk.
10390	INFORMATIONAL	Adapter %s: Coercion mode changed (Server %s)	The coercion mode has been changed.	None.
10401	MINOR	Adapter %s: Logical drive %s disabled because SAS drives are not supported by this RAID key (Server %s)	The logical drive has been disabled because the SAS hard disks are not supported by the RAID key.	Contact an office listed in the "Contact Information" of "Start Guide".
10402	MINOR	Adapter %s: Disks missing (Server %s)	hard disks do not exist.	Replace and rebuild the failed hard disk.
10403	INFORMATIONAL	Adapter %s: Rebuild rate changed to %s%% (Server %s)	Rebuild Rate has been changed.	None.
10405	INFORMATIONAL	Adapter %s: S.M.A.R.T. poll interval changed to %s min (Server %s)	S.M.A.R.T. Poll Interval has been changed.	None.
10412	MAJOR	Adapter %s: State change on logical drive %s from operational to degraded (Server %s)	The logical drive status has changed from online to degraded.	Replace and rebuild the failed hard disk.
10413	MAJOR	Adapter %s: State change on logical drive %s from operational to partially degraded (Server %s)	The logical drive status has changed from online to critical.	Replace and rebuild the failed hard disk.
10414	CRITICAL	Adapter %s: State change on logical drive %s from operational to failed (Server %s)	The logical drive status has changed from online to offline.	Contact an office listed in the "Contact Information" of "Start Guide".
10415	INFORMATIONAL	Adapter %s: State change on logical drive %s from degraded to operational (Server %s)	The logical drive status has been restored from degraded to online.	None.
10416	MAJOR	Adapter %s: State change on logical drive %s from degraded to degraded (Server %s)	The logical drive status is now degraded.	Replace and rebuild the failed hard disk.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10417	MAJOR	Adapter %s: State change on logical drive %s from degraded to partially degraded (Server %s)	The logical drive status is now degraded.	Replace and rebuild the failed hard disk..
10418	CRITICAL	Adapter %s: State change on logical drive %s from degraded to failed (Server %s)	The logical drive status has changed from degraded to offline.	Contact an office listed in the "Contact Information" of "Start Guide".
10419	INFORMATIONAL	Adapter %s: State change on logical drive %s from partially degraded to operational (Server %s)	The logical drive status has been restored from degraded to online.	None.
10420	MAJOR	Adapter %s: State change on logical drive %s from partially degraded to degraded (Server %s)	The logical drive status is now degraded.	Replace and rebuild the failed hard disk.
10421	MAJOR	Adapter %s: State change on logical drive %s from partially degraded to partially degraded (Server %s)	The logical drive status is now degraded.	Replace and rebuild the failed hard disk.
10422	CRITICAL	Adapter %s: State change on logical drive %s from partially degraded to failed (Server %s)	The logical drive status has changed from degraded to offline.	Contact an office listed in the "Contact Information" of "Start Guide".
10423	INFORMATIONAL	Adapter %s: State change on logical drive %s from failed to operational (Server %s)	The logical drive status has changed from offline to online.	None.
10424	MAJOR	Adapter %s: State change on logical drive %s from failed to degraded (Server %s)	The logical drive status has changed from offline to degraded.	Replace and rebuild the failed hard disk.
10425	MAJOR	Adapter %s: State change on logical drive %s from failed to partially degraded (Server %s)	The logical drive status has changed from offline to degraded.	Replace and rebuild the failed hard disk.
10426	CRITICAL	Adapter %s: State change on logical drive %s from failed to failed (Server %s)	The logical drive status is now offline.	Contact an office listed in the "Contact Information" of "Start Guide".
10427	CRITICAL	Adapter %s: State change by user on disk (%s) from available to failed (Server %s)	The hard disk status has changed from available to failed.	Replace the failed hard disk.
10428	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from available to hot spare (Server %s)	The hard disk has changed from unused to a spare disk.	None.
10429	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from available to rebuilding (Server %s)	The hard disk status has changed from available to rebuilding.	None.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10430	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from available to operational (Server %s)	The hard disk status has changed from available to operational.	None.
10431	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from failed to available (Server %s)	The hard disk status has changed from failed to available.	None.
10432	CRITICAL	Adapter %s: State change by user on disk (%s) from failed to failed (Server %s)	The hard disk status is now failed.	Replace and rebuild the failed hard disk.
10433	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from failed to hot spare (Server %s)	The hard disk has changed from the failed to a spare disk.	None. (HotSpare is not supported.)
10434	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from failed to rebuilding (Server %s)	The hard disk status has changed from failed to rebuilding.	None.
10435	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from failed to operational (Server %s)	The hard disk status has changed from failed to operational.	None.
10436	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from hot spare to available (Server %s)	The hard disk has changed from a spare disk to the available.	None. (HotSpare is not supported.)
10437	CRITICAL	Adapter %s: State change by user on disk (%s) from hot spare to failed (Server %s)	The hard disk has changed from a spare disk to the failed.	Replace the failed hard disk and configure the new drive as a HotSpare drive. (HotSpare is not supported.)
10438	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from hot spare to hot spare (Server %s)	The hard disk is now a spare disk.	None. (HotSpare is not supported.)
10439	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from hot spare to rebuilding (Server %s)	The hard disk has changed from a spare disk to rebuild.	None. (HotSpare is not supported.)
10440	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from hot spare to operational (Server %s)	The hard disk status has changed from a spare disk to operational.	None. (HotSpare is not supported.)
10441	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from rebuilding to available (Server %s)	The hard disk status has changed from rebuilding to available.	None.
10442	CRITICAL	Adapter %s: State change by user on disk (%s) from rebuilding to failed (Server %s)	The hard disk status has changed from rebuilding to failed.	Replace and rebuild the failed hard disk.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10443	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from rebuilding to hot spare (Server %s)	The hard disk status has changed from rebuilding to a spare disk.	None. (HotSpare is not supported.)
10444	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from rebuilding to rebuilding (Server %s)	The hard disk status is now rebuilding.	None.
10445	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from rebuilding to operational (Server %s)	The hard disk status has changed from rebuilding to operational.	None.
10446	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from operational to available (Server %s)	The hard disk status has changed from operational to available.	None.
10447	CRITICAL	Adapter %s: State change by user on disk (%s) from operational to failed (Server %s)	The hard disk status has changed from operational to failed.	Replace and rebuild the failed hard disk.
10448	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from operational to hot spare (Server %s)	The hard disk status has changed from operational to a spare disk.	None.
10449	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from operational to rebuilding (Server %s)	The hard disk status has changed from operational to rebuilding.	None.
10450	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from operational to operational (Server %s)	The hard disk status is now operational.	None.
10451	CRITICAL	Adapter %s: State change on disk (%s) from available to failed (Server %s)	The hard disk status has changed from available to failed.	Replace the failed hard disk.
10452	INFORMATIONAL	Adapter %s: State change on disk (%s) from available to hot spare (Server %s)	The hard disk status has changed from available to a spare disk.	None.
10453	INFORMATIONAL	Adapter %s: State change on disk (%s) from available to rebuilding (Server %s)	The hard disk status has changed from available to rebuilding.	None.
10454	INFORMATIONAL	Adapter %s: State change on disk (%s) from available to operational (Server %s)	The hard disk status has changed from available to operational.	None.
10455	INFORMATIONAL	Adapter %s: State change on disk (%s) from failed to available (Server %s)	The hard disk status has changed from failed to available.	None.
10456	CRITICAL	Adapter %s: State change on disk (%s) from failed to failed (Server %s)	The hard disk status is now failed.	Replace and rebuild the failed hard disk.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10457	INFORMATIONAL	Adapter %s: State change on disk (%s) from failed to hot spare (Server %s)	The hard disk status has changed from failed to a spare disk.	None. (HotSpare is not supported.)
10458	INFORMATIONAL	Adapter %s: State change on disk (%s) from failed to rebuilding (Server %s)	The hard disk status has changed from failed to rebuilding.	None.
10459	INFORMATIONAL	Adapter %s: State change on disk (%s) from failed to operational (Server %s)	The hard disk status has changed from failed to operational.	None.
10460	INFORMATIONAL	Adapter %s: State change on disk (%s) from hot spare to available (Server %s)	The hard disk status has changed from a spare disk to available.	None.
10461	CRITICAL	Adapter %s: State change on disk (%s) from hot spare to failed (Server %s)	The hard disk status has changed from a spare disk to failed.	Replace the failed hard disk and configure the new drive as a spare disk drive. (HotSpare is not supported.)
10462	INFORMATIONAL	Adapter %s: State change on disk (%s) from hot spare to hot spare (Server %s)	The hard disk status is now a spare disk.	None. (HotSpare is not supported.)
10463	INFORMATIONAL	Adapter %s: State change on disk (%s) from hot spare to rebuilding (Server %s)	The hard disk status has changed from a spare disk to rebuilding.	Replace and rebuild the failed hard disk. (HotSpare is not supported.)
10464	INFORMATIONAL	Adapter %s: State change on disk (%s) from hot spare to operational (Server %s)	The hard disk status has changed from a spare disk to operational.	None (HotSpare is not supported.)
10465	INFORMATIONAL	Adapter %s: State change on disk (%s) from rebuilding to available (Server %s)	The hard disk status has changed from rebuilding to available.	None.
10466	CRITICAL	Adapter %s: State change on disk (%s) from rebuilding to failed (Server %s)	The hard disk status has changed from rebuilding to failed.	Replace and rebuild the failed hard disk.
10467	INFORMATIONAL	Adapter %s: State change on disk (%s) from rebuilding to hot spare (Server %s)	The hard disk status has changed from rebuilding to a spare disk.	None. (HotSpare is not supported.)
10468	INFORMATIONAL	Adapter %s: State change on disk (%s) from rebuilding to rebuilding (Server %s)	The hard disk status is now rebuilding.	None.
10469	INFORMATIONAL	Adapter %s: State change on disk (%s) from rebuilding to operational (Server %s)	The hard disk status has changed from rebuilding to operational.	None.
10470	INFORMATIONAL	Adapter %s: State change on disk (%s) from operational to available (Server %s)	The hard disk status has changed from operational to available.	None.
10471	CRITICAL	Adapter %s: State change on disk (%s) from operational to failed (Server %s)	The hard disk status has changed from operational to failed.	Replace and rebuild the failed hard disk.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10472	INFORMATIONAL	Adapter %s: State change on disk (%s) from operational to hot spare (Server %s)	The hard disk status has changed from operational to a spare disk.	None. (HotSpare is not supported.)
10473	INFORMATIONAL	Adapter %s: State change on disk (%s) from operational to rebuilding (Server %s)	The hard disk status has changed from operational to rebuilding.	None.
10474	INFORMATIONAL	Adapter %s: State change on disk (%s) from operational to operational (Server %s)	The hard disk status is now operational.	None.
10476	MAJOR	Adapter %s: Disk (%s) missing after reboot (Server %s)	A hard disk was not found during startup.	At the OS restart after adding and removing option cards, this event may occur. Check the condition of the array using ServerView RAID Manager. If it is OK, then there is no problem. Also, the problem described at "1.5.2 Using ServerView RAID under Windows 2000 Server Environment" (→pg.19) is not a problem. When there are failed hard disks, replace and rebuild them.
10477	MAJOR	Adapter %s: Logical drive (%s) missing after reboot (Server %s)	A logical drive cannot be found during startup.	At the OS restart after adding and removing option cards, this event may occur. Check the condition of the array using ServerView RAID Manager. If it is OK, then there is no problem. Also, this event occurs after the array configuration or the problem described at "1.5.2 Using ServerView RAID under Windows 2000 Server Environment" (→pg.19) occurs, there is no problem. When it occurs during regular operation, contact an office listed in the "Contact Information" of "Start Guide".
10478	INFORMATIONAL	Adapter %s: Disk (%s) appeared new after reboot (Server %s)	A new hard disk has been found after the reboot.	None.
10479	INFORMATIONAL	Adapter %s: Logical drive %s appeared new after reboot (Server %s)	A new logical drive has been found after the reboot.	None.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10485	INFORMATIONAL	Adapter %s: State change on disk (%s) from available to offline (Server %s)	The hard disk status has changed from available to offline.	None.
10486	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from available to offline (Server %s)	The hard disk status has changed from available to offline.	None.
10487	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from failed to offline (Server %s)	The hard disk status has changed from failed to offline.	None.
10488	MINOR	Adapter %s: State change by user on disk (%s) from hot spare to offline (Server %s)	The hard disk status has changed from a spare disk to offline.	Replace and rebuild the failed hard disk.
10489	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from offline to available (Server %s)	The hard disk status has changed from offline to available.	None.
10490	MAJOR	Adapter %s: State change by user on disk (%s) from offline to failed (Server %s)	The hard disk status has changed from offline to failed.	Replace and rebuild the failed hard disk.
10491	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from offline to hot spare (Server %s)	The hard disk status has changed from offline to a spare disk.	None.
10492	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from offline to offline (Server %s)	The hard disk status has changed from offline to offline.	None.
10493	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from offline to operational (Server %s)	The hard disk status has changed from offline to operational.	None.
10494	INFORMATIONAL	Adapter %s: State change by user on disk (%s) from offline to rebuilding (Server %s)	The hard disk status has changed from offline to rebuilding.	None.
10495	MINOR	Adapter %s: State change by user on disk (%s) from operational to offline (Server %s)	The hard disk status has changed from operational to offline.	Replace and rebuild the failed hard disk.
10496	MINOR	Adapter %s: State change by user on disk (%s) from rebuilding to offline (Server %s)	The hard disk status has changed from rebuilding to offline.	Replace and rebuild the failed hard disk.
10497	INFORMATIONAL	Adapter %s: State change on disk (%s) from failed to offline (Server %s)	The hard disk status has changed from failed to offline.	None.
10498	MINOR	Adapter %s: State change on disk (%s) from hot spare to offline (Server %s)	The hard disk status has changed from a spare disk to offline.	Replace and rebuild the failed hard disk.
10499	INFORMATIONAL	Adapter %s: State change on disk (%s) from offline to available (Server %s)	The hard disk status has changed from offline to available.	None.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10500	MAJOR	Adapter %s: State change on disk (%s) from offline to failed (Server %s)	The hard disk status has changed from offline to failed.	Replace and rebuild the failed hard disk.
10501	INFORMATIONAL	Adapter %s: State change on disk (%s) from offline to hot spare (Server %s)	The hard disk status has changed from offline to a spare disk.	None.
10502	INFORMATIONAL	Adapter %s: State change on disk (%s) from offline to offline (Server %s)	The hard disk status has changed from offline to offline.	None.
10503	INFORMATIONAL	Adapter %s: State change on disk (%s) from offline to operational (Server %s)	The hard disk status has changed from offline to operational.	None.
10504	INFORMATIONAL	Adapter %s: State change on disk (%s) from offline to rebuilding (Server %s)	The hard disk status has changed from offline to rebuilding.	None.
10505	MINOR	Adapter %s: State change on disk (%s) from operational to offline (Server %s)	The hard disk status has changed from operational to offline.	Replace and rebuild the failed hard disk.
10506	MINOR	Adapter %s: State change on disk (%s) from rebuilding to offline (Server %s)	The hard disk status has changed from rebuilding to offline.	Replace and rebuild the failed hard disk.
10509	INFORMATIONAL	Adapter %s: Rebuild on disk (%s) resumed (Server %s)	Rebuilding of the hard disk has resumed.	None.
10511	INFORMATIONAL	Adapter %s: BGI restarted on logical drive %s (Server %s)	Background initialization has restarted on the logical drive.	None.
10513	INFORMATIONAL	Adapter %s: Rebuild on logical drive %s resumed (Server %s)	Rebuilding of the logical drive has resumed.	None.
10518	MAJOR	Adapter %s: SAS port %s lost link (Server %s)	SAS link has disconnected.	None.
10519	INFORMATIONAL	Adapter %s: SAS port %s restored link (Server %s)	SAS link has restored.	None.
10526	CRITICAL	Adapter %s: Adapter missing after reboot (Server %s)	A controller is missing.	None.
10527	INFORMATIONAL	Adapter %s: Adapter appeared new after reboot (Server %s)	A controller is newly detected.	None.
10528	MINOR	Adapter %s: Rebuild aborted on disk (%s) (Server %s)	Rebuilding has stopped.	None.
10536	CRITICAL	Adapter %s: Command timeout on disk (%s), CDB: %s (Server %s)	A timeout occurred during a command processing.	None.
10537	MINOR	Adapter %s: Disk (%s) reset (type %s) (Server %s)	A hard disk is prompted to reset.	None.

table: A list of ServerView RAID event logs

ID	Severity	Log Entry	Description	Recovery Action
10540	MAJOR	Adapter %s: Uncorrectable medium error logged for logical drive %s at LBA %s (on disk (%s) at LBA %s) (Server %s)	An uncorrectable medium error is detected.	None.
10541	MINOR	Adapter %s: Medium error corrected on logical drive %s at LBA %s (Server %s)	A medium error has been corrected.	None.
10544	CRITICAL	Adapter %s: Adapter needs replacement, faulty IOP detected (Server %s)	A failure has detected on IO processor of a controller.	None.
10559	INFORMATIONAL	Adapter %s: Additional information for failed disk (%s) - firmware version: %s, serial number %s, first use: %s, total running time: %s days	Additional information for a failed hard disk is displayed.	None.

B A List of GAM Event Logs

With ServerView installed, occurred events are recorded in the OS event logs by ServerView.

- For Windows
Events are recorded by the Event Viewer application log from the source "Fujitsu ServerView Services".
- For Linux
Events are recorded in the system log from the source "Fujitsu ServerView Services".

The device address is filled in at the beginning of the event log (the bracketed part). The device address indicates where the event occurred.

table: Meaning of Event Log Strings





Character String	Meaning
ctl:	Controller ID
chn:	Slot number of hard disk
tgt:	Not used by this array controller.
logdrv:	Logical drive number



- Unless ServerView is installed, event logging to Event Viewer will not occur. See "User's Guide" located on "PRIMERGY Startup Disc" supplied with the server to install and configure ServerView.

The correspondence between Severity for GAM events (SNMP TRAP), Severity for GAM Client, and the event log type is shown in the table below.

table: Event log types and descriptions

Severity	Description	Severity in GAM Client	OS event log type	
CRITICAL	Severe error	1		Error
MAJOR	Error	2		Error
MINOR	Warning	3		Warning
INFORMATIONAL	Information (No action required)	4		Information

The number within the parentheses of the GAM ID is displayed in hexadecimal format.

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
1 (0x001)	Info/1	A physical disk has been placed online.	A hard disk has become operational.	None.
2 (0x002)	Info/1	Physical disk added as hot spare.	A hard disk has been set as a hot spare.	None.
3 (0x003)	Error/3	Physical disk error found.	<ul style="list-style-type: none"> A bad sector was found on the media. A mechanical failure of the device. The host device detected an invalid sequence. The target device is missing. 	Check the state of the target hard disk. If it has a failure, see "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace it and perform a rebuild. If the error occurred only temporarily and does not occur again, the hard disk is recovered and no action is required. However, if this error occurs frequently, we recommend that you replace the drive as a precautionary measure, referring to "6.2.3 Preventive Replacement of Hard Disk [GAM]" (→pg.134).
4 (0x004)	Error/3	Physical disk PFA condition found; this disk may fail soon.	A failure has been predicted for the hard disk.	See "6.2.3 Preventive Replacement of Hard Disk [GAM]" (→pg.134) and replace the hard disk as a preventive measure.
5 (0x005)	Info/1	An automatic rebuild has started.	Rebuild started automatically.	None.
6 (0x006)	Info/1	A rebuild has started.	Rebuild started via a command.	None.
7 (0x007)	Info/1	Rebuild is over.	Rebuild has been completed.	None.
8 (0x008)	Info/1	Rebuild is cancelled.	Rebuild was canceled.	Perform the rebuild again.
9 (0x009)	Error/3	Rebuild stopped with error.	Rebuild terminated abnormally. (When abnormality occurs in the SAS interface, this may be notified not during rebuild processing.)	See "5.6.4 Viewing Logical Drive Information" (→pg.118) to check the current status of the logical drive. <ul style="list-style-type: none"> For Critical state: See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform the rebuild again. For Offline state: Contact an office listed in the "Contact Information" of "Start Guide".
10 (0x00A)	Error/3	Rebuild stopped with error. New device failed.	Rebuild terminated abnormally due to a failure found on the target hard disk for the rebuild.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
11 (0x00B)	Error/3	Rebuild stopped because logical drive failed.	Rebuild terminated abnormally due to failures in multiple hard disks.	Contact an office listed in the "Contact Information" of "Start Guide".

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
12 (0x00C)	Error/3	Physical disk has failed.	A hard disk has failed.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
13 (0x00D)	Info/1	A new physical disk has been found.	A new hard disk was detected.	None.
14 (0x00E)	Info/1	A physical disk has been removed.	A hard disk was removed. A hard disk has become undetectable.	None.
15 (0x00F)	Info/1	A previously configured disk is now available.	A hard disk is now in Unconfigured state.	None.
19 (0x013)	Error/3	SCSI command timeout on hard device.	A command timeout was detected.	Because the controller is performing a recovery, there is no problem as long as there are no failed hard disks.
20 (0x014)	Error/3	SCSI command abort on hard disk.	A SCSI command was aborted.	Because the controller is performing a recovery, there is no problem as long as there are no failed hard disks.
21 (0x015)	Warning/2	SCSI command retried on hard disk.	A SCSI command was retried.	Because the controller is performing a recovery, there is no problem as long as there are no failed hard disks.
23 (0x017)	Warning/2	Soft error found.	An error was detected on a hard disk, but it was resolved.	Because the controller is performing a recovery, no action is required. If this error occurs frequently, see "6.2.3 Preventive Replacement of Hard Disk [GAM]" (→pg.134) to replace the hard disk as a precautionary measure.
24 (0x018)	Warning/2	Misc error found.	An error was detected on a hard disk, but it was resolved.	Because the controller is performing a recovery, no action is required. If this error occurs frequently, see "6.2.3 Preventive Replacement of Hard Disk [GAM]" (→pg.134) to replace the hard disk as a precautionary measure.
25 (0x019)	Info/1	SCSI device reset.	The firmware issued a device reset.	None.
28 (0x01C)	Error/3	Request Sense Data available.	A hard disk reported sense information.	Because the controller is performing a recovery, no action is required as long as the corresponding disk is Online.
29 (0x01D)	Info/1	Initialization started.	A hard disk formatting has started.	Wait until the format is completed.
30 (0x01E)	Info/1	Initialization completed.	The hard disk format has been completed.	None.

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
31 (0x01F)	Error/3	Initialization failed.	The hard disk format failed.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk.
32 (0x020)	Error/3	Initialization canceled.	The hard disk format was canceled.	Format the hard disk again.
33 - 41 (0x021 - 0x029)	Error/3	A physical disk failed because ***	A hard disk has failed.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
42 (0x02A)	Error/3	A physical disk set to failed state by host.	A Make Offline has been executed by the controller.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
43 - 49 (0x02B - 0x031)	Error/3	A physical disk failed because ***	A hard disk has failed.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
50 (0x032)	Error/3	Physical disk status changed to offline.	A hard disk has become offline.	None.
52 (0x034)	Error/3	Physical disk status changed to rebuild.	The hard disk status has become rebuild.	None.
53 (0x035)	Warning/2	Physical device ID did not match.	The hard disk ID does not match.	Check the logs surrounding the process and perform necessary actions.
54 (0x036)	Error/3	Physical disk failed to start.	A hard disk failed to start.	Check that the hard disk is connected properly. If the hard disk has failed, see "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
55 (0x037)	Warning/2	Physical disk negotiated different offset than config.	A hard disk has negotiated an offset different from the configuration.	Check that the hard disk is connected properly. If the hard disk has failed, see "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
56 (0x038)	Warning/2	Physical disk negotiated different bus width than config.	A hard disk has negotiated a bus width different from the configuration.	Check that the hard disk is connected properly. If the hard disk has failed, see "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
57 (0x039)	Error/3	Physical drive missing on startup.	No hard disk was detected during startup.	Check that the hard disk is connected properly. If the hard disk has failed, see "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
58 (0x03A)	Error/3	Rebuild startup failed due to lower disk capacity.	Insufficient hard disk space to perform the rebuild.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk with a drive of the same model (with the same capacity and speed) as the other drives, and then perform a rebuild.
67 (0x043)	Error/3	Physical Disk found on only one disk channel.	A hard disk is connected to only one disk channel.	Check that the hard disk is connected properly. If the hard disk has failed, see "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
68 (0x044)	Info/1	Physical disk type is not approved by vendor.	An installed hard disk is not vendor approved.	Use a vendor supported hard disk.
69 (0x045)	Error/3	Physical disk has acquired an inappropriate loop ID. Enclosure disk-slot operations are disabled while this condition persists.	A hard disk has acquired an inappropriate loop ID.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
70 (0x046)	Error/3	Physical disk port has failed or cannot operate at the configured channel speed.	<ul style="list-style-type: none"> • A hard disk has failed. • The hard disk is not compatible with the system. • The enclosure slot hardware failed. 	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
72 (0x048)	Error/3	Controller parameters checksum verification failed - restored default.	A mistake was found in the checksum of the controller parameters.	Check and correct the parameters in the [Adapter Properties] (→pg.28) of WebBIOS. If the message still appears, contact an office listed in the "Contact Information" of "Start Guide".
73 (0x049)	Info/1	Online controller firmware upgrade has started.	An online controller firmware upgrade has started.	None.
74 (0x04A)	Info/1	Online firmware upgrade has completed successfully.	An online firmware upgrade has been completed successfully.	None.
75 (0x04B)	Error/3	Online firmware upgrade has failed.	An online firmware upgrade has failed.	Perform the online controller firmware upgrade again. If the message still appears, contact an office listed in the "Contact Information" of "Start Guide".

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
76 (0x04C)	Info/1	A Configuration On Disk (COD) with unsupported features has been detected.	The array configuration information of the hard disk contains features that are not supported. An array configuration information created by another system was detected.	Connect a compatible hard disk.
80 (0x050)	Error/3	Firmware entered unexpected state at run-time.	The firmware entered unexpected state at run-time.	Check the installation of the cache memory or battery backup unit. If the message still appears, replace the cache memory or the battery backup unit.
85 (0x055)	Info/1	Unable to recover medium error during patrol read.	Recovery of a medium error failed during the Patrol Read operation.	If a corrupted file is found, restore it from the backup.
86 (0x056)	Info/1	Rebuild resumed.	Rebuild restarted.	None.
89 (0x059)	Info/1	Physical disk transfer speed changed.	The transfer speed of the hard disk has changed due to an unknown error.	Check the previous logs and perform necessary steps.
90 (0x05A)	Error/3	Channel is suspended due to some faults.	An abnormal state was found in the channel.	Contact an office listed in the "Contact Information" of "Start Guide".
95 (0x05F)	Info/1	Configured physical disk replaced by user by a smaller capacity disk.	A hard disk has been replaced with a smaller capacity drive than configured.	Reconnect a proper hard disk.
101 (0x065)	Error/3	Error.	An unknown error was detected.	If the hard disk has failed, see "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild. If the message still appears, contact an office listed in the "Contact Information" of "Start Guide".
104 (0x068)	Error/3	Reassign write operation failed.	A Reassign operation failed.	If the hard disk has failed, see "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
105 (0x069)	Error/3	Unrecoverable medium error during rebuild.	An unrecoverable medium error was detected during the rebuild process.	If a corrupted file is found, restore it from the backup.
106 (0x06A)	Info/1	Corrected medium error during recovery.	A medium error was corrected.	None.
107 (0x06B)	Error/3	Unrecoverable medium error during recovery.	An unrecoverable medium error was detected.	If a corrupted file is found, restore it from the backup.

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
119 (0x077)	Warning/2	PD too small to be used for auto-rebuild.	The rebuild could not be started because the capacity of the hard disk is smaller than the other hard disk.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk with a drive of the same model (with the same capacity and speed) as the other drives, and then perform a rebuild.
120 (0x078)	Warning/2	Bad block table on PD is 80% full.	The Bad Block Table use rate has exceeded 80%.	See "6.2.3 Preventive Replacement of Hard Disk [GAM]" (→pg.134) and replace the hard disk as a preventive measure.
121 (0x079)	Error/3	Bad block table on PD is full; unable to log blocks.	The Bad Block Table is full.	See "6.2.3 Preventive Replacement of Hard Disk [GAM]" (→pg.134) and replace the hard disk as a preventive measure.
126 (0x07E)	Info/1	Firmware corrected the 'Read' error.	The media error was corrected.	None.
134 (0x086)	Error/3	Logical drive has been made offline.	The logical drive has been made Offline.	The logical drive(s) cannot continue running in this state. Recreate the array configuration and restore the data from backup.
135 (0x087)	Error/3	Logical drive is critical.	The logical drive is in Critical state due to a hard disk failure.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
136 (0x088)	Info/1	Logical drive has been placed online.	The logical drive has been placed online.	None.
137 (0x089)	Info/1	An automatic rebuild has started on logical drive.	Rebuild started automatically.	None.
138 (0x08A)	Info/1	A manual rebuild has started on logical drive.	Rebuild started manually.	None.
139 (0x08B)	Info/1	Rebuild on logical drive is over.	Rebuild has been completed.	None.
140 (0x08C)	Error/3	Rebuild on logical drive is cancelled.	Rebuild was canceled.	Perform the rebuild again.
141 (0x08D)	Error/3	Rebuild stopped with error.	Rebuild terminated abnormally.	Check the logs surrounding the process and perform necessary actions.
142 (0x08E)	Error/3	Rebuild stopped with error. New physical disk failed.	Rebuild terminated abnormally due to a failure on the target hard disk.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
143 (0x08F)	Error/3	Rebuild stopped because logical drive failed.	The source disk of the rebuild failed.	Contact an office listed in the "Contact Information" of "Start Guide".
144 (0x090)	Info/1	Logical drive initialization started.	An initialization of a logical drive has started.	None.

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
145 (0x091)	Info/1	Logical drive initialization done.	The initialization of the logical drive has been completed.	None.
146 (0x092)	Error/3	Logical drive initialization cancelled.	The initialization of the logical drive was canceled.	Perform the initialization process again.
147 (0x093)	Error/3	Logical drive initialization failed.	The initialization terminated abnormally. The logical drive is now in Offline state.	Backup all the data on the logical drive and see "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk. Recreate the array configuration. Then restore the data from backup.
148 (0x094)	Info/1	A logical drive has been found.	A new logical drive has been detected.	None.
149 (0x095)	Info/1	A logical drive has been deleted.	A logical drive was deleted.	None.
153 (0x099)	Error/3	Bad Blocks found.	A bad block was detected during the Make Data Consistent, rebuild, or capacity expansion process.	<ul style="list-style-type: none"> • During Make Data Consistent/ capacity expansion: The bad block will be repaired, so there is no problem. • During rebuild: If a corrupted file is found, restore it from the backup.
155 (0x09B)	Info/1	System drive type changed.	<ul style="list-style-type: none"> • A new configuration was added. • The capacity expansion has been completed. 	None.
156 (0x09C)	Error/3	Bad data blocks found. Possible data loss.	Bad blocks were found on multiple hard disks at the same location.	If a corrupted file is found, restore it from the backup.
157 (0x09D)	Info/1	Logical drive LUN mapping has been written to config.	Logical drive LUN mapping has been written to config.	None.
158 (0x09E)	Error/3	Attempt to read data from block that is marked in Bad Data Table.	An attempt has been made to read data logged in the BDT table.	If a corrupted file is found, restore it from the backup.
159 (0x09F)	Error/3	Data for Disk Block has been lost due to Logical Drive problem.	Due to a problem with the logical drive, cache data could not be written to the hard disk.	Check the logs surrounding the process and perform necessary actions.
163 (0x0A3)	Error/3	Reconstruct detected uncorrectable double medium errors.	Due to media errors detected in the same position on multiple hard disks, data cannot be recovered.	If a corrupted file is found, restore it from the backup.
164 (0x0A4)	Info/1	Reconstruction resumed.	Reconstruction was resumed.	None.
165 (0x0A5)	Error/3	Reconstruction resume failed due to configuration mismatch.	Reconstruction resume terminated abnormally due to configuration mismatch.	Recreate the array and restore the backup data.

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
166 (0x0A6)	情報 /1	LD Properties updated.	Parameter of the logical drive has been changed.	None.
350 (0x15E)	Error/3	SAS/SATA mixing not supported in enclosure; PD disabled.	The hard disk cannot be used, because SAS and SATA devices are mixed.	Check if any unsupported hard disks are installed. If there is an unsupported hard disk installed, replace it with a supported one.
384 (0x180)	Info/1	Array management server software started successfully.	GAM Server started successfully.	None.
386 (0x182)	Warning/2	Internal log structures getting full, PLEASE SHUTDOWN AND RESET THE SYSTEM IN THE NEAR FUTURE.	Due to many configuration changes, the configuration change table is full.	Shut down the system properly, power off the server and turn it back on. If the same log still appears, contact an office listed in the "Contact Information" of "Start Guide".
388 (0x184)	Error/3	Controller is dead. System is disconnecting from this controller.	The SCSI array controller failed.	Contact an office listed in the "Contact Information" of "Start Guide".
389 (0x185)	Info/1	Controller has been reset.	The controller received a reset command.	Because the firmware is performing a recovery, there is no problem as long as there are no failed hard disks.
390 (0x186)	Info/1	Controller is found.	A controller was detected.	None.
391 (0x187)	Error/3	Controller is gone. System is disconnecting from this controller.	<ul style="list-style-type: none"> The power to the controller was cut off. The controller was removed from the system. 	Contact an office listed in the "Contact Information" of "Start Guide".
395 (0x18B)	Error/3	Controller is gone. System is disconnecting from this controller.	<ul style="list-style-type: none"> The power to the controller was cut off. The controller was removed from the system. 	Contact an office listed in the "Contact Information" of "Start Guide".
396 (0x18C)	Info/1	Controller powered on.	A new controller was installed.	None.
397 (0x18D)	Info/1	Controller is online.	A controller came online.	None.
398 (0x18E)	Error/3	Controller is gone. System is disconnecting from this controller.	<ul style="list-style-type: none"> The power to the controller was cut off. The controller was removed from the system. 	Contact an office listed in the "Contact Information" of "Start Guide".
399 (0x18F)	Warning/2	Controller's partner is gone, controller is in failover mode now.	The controller went Offline.	None.

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
403 (0x193)	Error/3	Installation aborted.	The configuration changed while the system was offline.	Shut down the server and check the hard disk connections. Check that the appropriate hard disks are installed, and remove any inappropriate hard disks.(For example, a hard disk for another system may have been installed by mistake.) If this does not resolve the problem, reconfigure the array and restore the backup data.
404 (0x194)	Error/3	Controller firmware mismatch.	The controller firmware has been replaced with an old version.	Contact an office listed in the "Contact Information" of "Start Guide".
413 (0x19D)	Info/1	Controller device start complete.	The controller device started.	None.
414 (0x19E)	Error/3	Soft ECC error Corrected.	An ECC error was detected in the memory.	Replace the memory module or the battery backup unit.
415 (0x19F)	Error/3	Hard ECC error Corrected.	An ECC error was detected in the memory.	Replace the memory module or the battery backup unit.
425 (0x1A9)	Error/3	Controller boot ROM image needs to be reloaded.	An inappropriate firmware image was loaded.	Contact an office listed in the "Contact Information" of "Start Guide".
426 (0x1AA)	Error/3	Controller is using default non-unique world-wide name.	The controller's MAC address was lost, or not set.	Contact an office listed in the "Contact Information" of "Start Guide".
428 (0x1AC)	Error/3	Mirror Race on critical drive.	The hard disk has a failure.	See "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild.
440 (0x1B8)	Error/3	Error in Mirror Race Table.	An error occurred in the Mirror Race Table.	Check the array configuration. If the array configuration is correct, perform a Make Data Consistent. If the array configuration is invalid, reconfigure the array and restore the data from the backup.
444 (0x1BC)	Info/1	Controller entered 'Write Back' cache mode.	The controller entered 'Write Back' cache mode.	None.
446 (0x1BE)	Info/1	Data in Cache flushed during power up.	Data in the cache memory was flushed at the time of system boot.	None.
447 (0x1BF)	Error/3	Data in Cache not flushed during power up.	Data in the cache memory failed to flush at the time of system boot due to an abnormal configuration.	Check the array configuration. If the array configuration is correct, perform a Make Data Consistent. If the array configuration is invalid, reconfigure the array and restore the data from the backup.
452 (0x1C4)	Info/1	Rebuild rate changed.	The rebuild rate has been changed.	None.
460 (0x1CC)	Info/1	Factory defaults restored.	A factory default was restored.	Reconfigure the controller if necessary.

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
461 (0x1CD)	Info/1	Hibernate command received from host.	A hibernate command was received from the host.	None.
462 (0x1CE)	Info/1	Event log cleared.	The NVRAM log was cleared.	None.
463 (0x1CF)	Info/1	Event log wrapped.	The NVRAM log was wrapped.	None.
700 (0x2BC)	Info/1	Event log empty.	The content of the event log has become blank.	None.
701 (0x2BD)	Info/1	Event log entries lost.	Event Log entries were lost.	None.
702 (0x2BE)	Info/1	Request Sense.	Sense Information was reported.	Because the firmware is performing a recovery, there is no problem as long as there are no failed hard disks.
703 (0x2BF)	Info/1	Set real time clock.	The clock was set.	None.
800 (0x320)	Info/1	New Configuration Received.	A new array configuration was issued.	None.
801 (0x321)	Info/1	Configuration Cleared.	The array configuration was cleared.	None.
802 (0x322)	Warning/2	Configuration Invalid.	The array configuration information is invalid.	Check that the hard disk is connected properly. If this does not resolve the problem, recreate the array and recover the backup data.
803 (0x323)	Warning/2	Configuration On Disk Access Error.	The array configuration information could not be read from the hard disk.	Check the array configuration. If there is a failed hard disk, see "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace it and perform a rebuild. If the array configuration is invalid, reconfigure the array and restore the data from the backup.
804 (0x324)	Warning/2	Configuration on disk converted.	The array configuration information on the hard disk was converted.	None.
805 (0x325)	Warning/2	Configuration On Disk Import Failed.	The array configuration information could not be imported.	Shut down the server and check the hard disk connections. Check that the appropriate hard disks are installed, and remove any inappropriate hard disks. (For example, a hard disk for another system may have been installed by mistake.) If this does not resolve the problem, reconfigure the array and restore the backup data.
806 (0x326)	Info/1	A debug dump exists on this system.	A debug dump exists on this system.	None.

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
807 (0x327)	Info/1	A debug dump exists on this system.	A debug dump exists on this system.	None.
808 (0x328)	Info/1	No valid Configuration On Disk (COD) found.	No valid Configuration On Disk (COD) found.	Check if the hard disk connected was previously used in another system. If a hard disk that was previously used in another system is connected, that hard disk must be formatted completely before use.
810 (0x32A)	Info/1	MegaRAID firmware initialization started.	The initialization of the MegaRAID firmware started.	None.
960 (0x3C0)	Error/3	SAS topology error: Loop detected.	Loop detected in the SAS topology.	Check the condition of the system connections. If this error occurs again, even though the connections are correct, contact an office listed in the "Contact Information" of "Start Guide".
961 (0x3C1)	Error/3	SAS topology error: Unaddressable device.	Device is unaddressable in the SAS topology.	Check the condition of the system connections. If the system connections are correct but there is a failed hard disk, see "6.2.2 Replacing Failed Hard Disk [GAM]" (→pg.132) to replace the hard disk and perform a rebuild. If this error occurs again, contact an office listed in the "Contact Information" of "Start Guide".
962 (0x3C2)	Error/3	SAS topology error: Multiple ports to the same SAS address.	Multiple ports were connected to the same SAS address in the SAS topology.	Check the condition of the system connections. If this error occurs again, even though the connections are correct, contact an office listed in the "Contact Information" of "Start Guide".
963 (0x3C3)	Error/3	SAS topology error: Expander error.	An error was detected in the Expander.	Contact an office listed in the "Contact Information" of "Start Guide".
964 (0x3C4)	Error/3	SAS topology error: SMP timeout.	SMP timeout was detected.	Contact an office listed in the "Contact Information" of "Start Guide".
965 (0x3C5)	Error/3	SAS topology error: Out of route entries.	Route entries cannot be found.	Contact an office listed in the "Contact Information" of "Start Guide".
966 (0x3C6)	Error/3	SAS topology error: Index not found.	Index was not found.	Contact an office listed in the "Contact Information" of "Start Guide".
967 (0x3C7)	Error/3	SAS topology error: SMP function failed.	An error was detected in an SMP function.	Contact an office listed in the "Contact Information" of "Start Guide".

table: A list of GAM event logs

GAM ID	Severity	Description	Details	Corrective action
968 (0x3C8)	Error/3	SAS topology error: SMP CRC error.	A CRC error was detected in SMP.	Contact an office listed in the "Contact Information" of "Start Guide".
969 (0x3C9)	Error/3	SAS topology error: Multiple subtractive.	An error was detected in the SAS topology.	Contact an office listed in the "Contact Information" of "Start Guide".
970 (0x3CA)	Error/3	SAS topology error: Table to table.	An error was detected in the SAS topology.	Contact an office listed in the "Contact Information" of "Start Guide".
971 (0x3CB)	Error/3	SAS topology error: Multiple paths.	Multiple paths exist.	Check the condition of the system connections. If this error occurs again, even though the connections are correct, contact an office listed in the "Contact Information" of "Start Guide".

C Notes on Usage for the Array Controller

This section explains notes on usages for this array controller.

C.1 When Replacing Array Controllers

Changing an array controller due to some kind of troubles when using Integrated Mirroring SAS function (RAID 1) of this array controller will result in the loss of information about hard disk consistency stored in the array controller. In order to make the data consistent again, you need to initialize the logical drive of the array controller.

This is required because the array controller stores the consistency data concerning whether the Write data was properly written into hard disks in the past. The data is stored on a nonvolatile RAM (NVRAM) of the controller. Saving information with a maintenance tool will enable you to restore the information after the controller replacement. With successful data saving and restoration, you do not need to initialize the logical drive.

Depending, however, on what caused the problem like a failure of the system itself, a maintenance tool may not start on the system and the data may not be saved. Then you need to initialize the logical drives to make the data consistent. Even when you succeed in saving and restoring NVRAM information, unsuccessful data consistency result will require you the initialization.

Logical drive initialization described here is the same as a rebuild operation for its identical operation to copy data on the background and make the data consistent between two hard disks.

■ Notes during initialization

- Logical drive initialization of Integrated Mirroring SAS is done through background initialization. You can use the hard disks even during the initialization process. The operation may be slower than on initialized logical drives due to insufficient I/O processing. Operation slow down may account for up to 50% of the full operation.
- During the OS operation, the hard disk failure LED on the front side of the hard disk to be initialized blinks just like at the time of rebuilding operation. With ServerView, maintenance LEDs on the front and back of the controller blink. After the initialization, the LEDs automatically stop blinking. Then check the condition of each device through not only the LEDs but also such devices as ServerView Console.
- Resetting or turning off the server before the completion of the initialization will stop the initialization. The next initialization will start from the point at which the initialization was stopped last time it was reset or shut down.
- RAID 1 logical drive is without redundancy until the completion of the initialization. It regains the redundancy once the initialization is completed.

- You can assure the completion of initialization by displaying logical drive information from ControllerView of GAM utility. Online status means the completion. Critical status means unfinished initialization. → "● Logical drives" (pg.110)
For ServerView RAID, Online status of a logical drive means the completion. Critical status means unfinished initialization. → "● Logical drive" (pg.74)

■ Estimated time for initialization

Estimated time for the initialization without hard disk access is shown below. The time shown below is the total time period for the OS operation without any kind of power shut down.

It takes longer than what shown below when initialization takes place with access to hard disks.

table: Estimated time for initialization

Hard disk capacity	No load	High load
73GB	approx. 4hrs	approx. 7hrs
147GB	approx. 7hrs	approx. 14hrs
300GB	approx. 15hrs	approx. 30hrs

POINT

- ▶ Information in the with load columns is the estimated time for all time high-loaded access from hard disks.
- ▶ The numbers described above are estimates. The actual time may be different depending on your system environment.

Index

A

Actions Menu	71
Adapter Properties	28
Administration Menu	107
Administrator Privileges	58
Array Controller	
Controller Icons	106
Detailed information (GAM)	114
Detailed information (ServerView RAID)	81
Hotfix	54
Notes	19
Specifications	12
Updating the Device Drivers	50
Viewing information in the BIOS Utility	28
Work Flow	10

B

Background Task	86, 120
BIOS Utility	23
Exiting	25
Formatting hard disk	45
Starting	24
Viewing array controller	28
Viewing hard disk	31
Viewing logical drive	31
Window Layout	27

C

Controller Icon	73
Controller Icons	106
Controller Selection Box	105
Controller View	109
Administration Menu	107
File Menu	106
View Menu	107
Viewing Hard Disk Information	115
Viewing Logical Drive Information	118

D

Device Drivers	
Creating Driver Disks	50
Updating the Drivers (Windows Server 2003)	50
Updating the Drivers (Windows 2000 Server)	52
Disk array	13
Disk Groups	
Logical Drives	14

E

Event Window	71
Events	112
GAM	158
ServerView RAID	138

F

File Log	75
File Menu	71, 106

G

GAM	90
Access privileges	92
Events	158
Exiting	103
Installation	97
Log On	102
Requirements	91
Starting	102
Toolbar	108
Uninstallation	100
Window Layout	104
GAM Client	90
Installation	97
Server group and server settings	111
Uninstallation	100
GAM ID	159
GAM Server	90
Installation	97
Uninstallation	101
Global Array Manager	90
Global Properties	29
Global Status View	105
Guest	92

H

Hard disk	
Detailed information (Controller View)	115
Low level formatting	45
Manual Rebuild	79, 121
Notes	18
Preventive Replacement	127, 134
RAID Levels	13
Replacing	125, 132
Status Icon	73, 110
Using Controller View	82
Viewing in the BIOS Utility	31
Logical Drives	14

Hard disk failure prediction function	17
Help Menu	73
Hotfix	54

I

Installation	
GAM.	97
GAM Client.	97
GAM Server.	97
ServerView RAID	62

L

Log Information Viewer	106, 113
Logical drive	14
Deleting	36, 42
Initialization	16
RAID Levels	13
Rebuild.	16
Status.	15
Status Icon	74, 110
Using Controller View.	118
Checking status	84

M

Media Verification.	17
Mirroring	13

P

PFA	17
PFA Count/S.M.A.R.T.	127, 134
Plug-in	75
Ports	73

R

RAID	13
RAID Levels.	13
Rebuild	16, 79, 121
Checking the Progress(GAM).	120
Checking the Progress(ServerView RAID)	
.	86
Rebuild Status	120

S

S.M.A.R.T.	17
SAS	12
Server group and server settings	111
Server Icon	73, 105
Server Selection Box	104
ServerView	91
ServerView AlarmService	60, 95
ServerView RAID	

Access privileges	58
Events	138
Installation	62
Log in.	66
Requirements.	57
Uninstallation	63

ServerView RAID Manager	
Change Access Mode	70
Exiting	68
Starting.	66
Window Layout	69

SNMP TRAP	138
---------------------	-----

Starting	
BIOS Utility	24
Controller View.	109
GAM	102
ServerView RAID Manager	66

Status	
Hard disk	15
Logical Drives	15

Status Icon	
Hard disk	73, 110
Logical Drives	74, 110

System Log	75
----------------------	----

T

Tree View	73
---------------------	----

U

Uninstallation	
GAM	100
GAM Client	100
GAM Server.	101
ServerView RAID.	63
User.	92
User Privileges	58

V

View Menu.	107
--------------------	-----

Integrated Mirroring SAS
User's Guide

B7FY-2311-01ENZ0-00

Issued on January, 2008

Issued by FUJITSU LIMITED

- The contents of this manuals may be revised without prior notice.
- Fujitsu assumes no liability for damages to third party copyrights or other rights arising from the use of any information in this manual.
- No part of this manual may be reproduced in any form without the prior written permission of Fujitsu.