

Fujitsu USB Scanner Installation Procedures with VRS

Windows 2000 / XP

This document is intended for installations of the following products with VRS using the USB interface connection.

FI-4120C/C2
FI-4220C/C2

Fi-4340C
Fi-4530C
Fi-5120C

Fi-5220C
Fi-5530C
Fi-5650C

Fi-5750C
Fi-5900C

Hardware requirements.

You will need a PC system that meets both Fujitsu's and Kofax's recommended specifications. For recommended PC system specifications please reference the [Scanner Hardware Reference](#) page. You may also need your Operating System Disk.

Step A: Installing the VRS drivers.

First boot your PC and install the Kofax VRS driver that shipped with the scanner.

Special note: When installing the VRS driver and any other software that contains Kofax's Image Controls pay close attention to the individual runtimes. **It is strongly recommended that you install the oldest/lower runtime application first.**

Step B: Unlocking the shipping lock.

If your model scanner does not have a flatbed then proceed to Step D.

The flatbed model scanners typically include a lock on the flatbed designed to protect the scanner during shipment. Before the scanner can be used the shipping lock must be unlocked. To unlock it do the following:

1. Located the shipping lock slider tab or knob underneath the end of the scanner.
2. Slide or rotate the lock to the unlock position.

Step C: Connecting the Scanner.

Connect the USB cable to the both the Scanner and the PC. For the Fi-5900C connect the USB cable to the VRS USB port. Ensure all connections are securely fastened.

Connect the power cord to the scanner and a wall outlet. Boot up your PC first and then turn on the scanner. Complete the new hardware found wizard and go to the next step.

Fujitsu USB Scanner Installation Procedures with VRS

Windows 2000 / XP

Step D: Scanning with VCDEMO

1. Go to **Start, Programs, Kofax VRS** or **Kofax Image Controls**, and **select VCDEMO.EXE**.
2. Next go to **Source, Scanner**, and **click on the drop down arrow**; then **select** your scanner model. I.E. **Fujitsu fi-4860C with VRS with AIPE**. Wait a few seconds for the Kofax engine to load, and then place your documents in the scanner.
3. Now go to **Source, Properties** and **select** your **scanning parameters** (i.e. scan source - Flatbed or ADF, resolution, paper size).
4. You may also access the **VRS configuration settings** at this time by clicking on Advance Properties. The **AIPE functions** are access via the Imaging menu.
5. Afterwards go to **Source**, and **click on Process Image** for single page scans or **Process Batch** for multi-page batch scans.

Congratulations! You have successfully completed and tested your VRS scanner installation.

Step E: Installing third party software applications.

After you have successfully installed all the Fujitsu software and hardware, then it is time to install any additional third party scanning software that you wish to use. Please follow the software manufacturer's instructions for installation. Remember when installing any software that contains Kofax's Image Controls pay close attention to the individual runtimes. **It is strongly recommended that you install the oldest/lower runtime application first.**