



# LifeBook

## A3120/ A6020

### Optional Accessories



Optional Accessories  
A3120/ A6020

#### Memory Modules

2GB DDR2-DIMM 667MHz	FPCEM311
1GB DDR2-DIMM 667MHz	FPCEM310
512MB DDR2-DIMM 667MHz	FPCEM309
256MB DDR2-DIMM 667MHz	FPCEM308

#### External Drive

USB Floppy Disk Drive	FPCFDD16
-----------------------	----------

#### Power Options

AC Adapter (19V 80W – 2 pins receptacle)	FPCAC51
AC Adapter (19V 80W – 3 pins receptacle)	FPCAC53
Battery (4-cell Li-Ion 2000mAh)	FPCBP159
Battery - Standard (6-cell Li-Ion 4000mAh)	FPCBP160

#### Display Option

17" TFT XGA LCD Display	PD-TFT17C
-------------------------	-----------

#### Carrying Case


Carrier Case	PG30025
--------------	---------

#### Others

USB Optical Scroll Mouse (Translucent)	HLMSE0002-00
Dicota Notebook Cable Lock	HACCE0001-00
Dicota Notebook Combination Lock	HACCE0002-00
Universal Travel Adapter - NA for AU/NZ	HLADP0001-00



USB Optical Scroll Mouse



Battery



AC Adapter



Carrying Case