

## Note on using PRIMERGY BX600 Advanced KVM Module (PG-KVB103)

Thank you for purchasing our product. Before you start using it, please read carefully the additional notes described below.

July 2008  
FUJITSU LIMITED

### **1. SSL Certificate**

When using Video Viewer/Virtual Media, you need to register the SSL certificate on your client computer. You can obtain the certificate by either of the following methods.

For how to register the certificate, refer to the manual below:

"PRIMERGY BX600 S3 Blade Server System Unit Hardware Guide"

'6.4 Operating Advanced KVM Module (PG-KVB103)'

- 1 Download the certificate from the web site.

<http://www.fujitsu.com/global/services/computing/server/ia/driver/>

- 2 Use the certificate included in PRIMERGY Startup Disc attached to PRIMERGY BX600 S3 Blade Server System Unit.

### **2. Server Blade Name**

The Server Blade name of each slot, which is shown up in Main menu on OSCAR (Please refer to 'PRIMERGY BX600 S3 Blade Server System Unit Hardware guide') and so on, is created as an entry in the factory. This value was created arbitrarily by OS during factory testing.

This value is also put with the value of the Host Name of Blade Info group under the Server Blade group by using Management Blade Web UI.

You can change the Server Blade name of each slot by using this function after installing the Server Blade.

### **3. Names submenu**

This menu is not supported.