

# System Surveillance Equipment (SSE)

## EM and Sub-Network Manager Functionality

### ■ System Surveillance

- Alarm and Status
- Performance Monitoring
  - Line (Submarine Cable) Error Count
  - Tributary B1 Error : BBE, ES, SES, UAS
  - WDM Analog Data : Output/Input Power
  - Performance Monitoring
- DWA Circuit Management

### ■ Repeater Monitoring

- In-service Active Supervisory
  - Input / Output power monitoring
  - Pump LD bias current monitoring

### ■ Report

- Past Summary / Alarm & Status / Events, etc.

### ■ Remote Operation Position (ROP)

- ROP is available at each station.

