

How can I print the logo which was registered in the utility by the ESC/POS command?



Answer: This is the method by using GS (printing logo by L command) after registering the logo in the utility.

Command is the bellow (hex number)

1Dh 28h 4Ch 06h 00h 30h 45h [kc1] [kc2] 01h 01h

Put the key code which is showed when the logo was registered in the utility to [kc1] [kc2].

Example: In case of registering logo to the keycode of "2022" in the utility

1Dh 28h 4Ch 06h 00h 30h 45h 22h 20h 01h 01h

***Note**

The key code is showed as "2022", however, please be careful that the number is opposit way as the "22h 20h" for the command.