

How do I know printer's setting?





Answer:

You can confirm printer's setting without connecting PC.

Special Mode has the function for confirmation of printer's setting.

Special Mode



<u>Memory Switch 1</u>	
Power On Status	Enable
Receive Buffer	64KByte
Busy Condition	Bufferfull
Receive Error	?Print
Auto LF	Disable
DSR(#6)Reset	Disable
INIT(#25)Reset	Disable
USB Soft Reset	Enable
<u>Memory Switch 2</u>	
Cover Open Error	Auto Recovery
Error	Auto Recovery
Batch (COM IF)	Enable
Batch (Other IF)	Disable
Serial Number	Disable
ASB	Enable
Font-B	Model
Korean Font	Mincho
<u>Print</u>	
DPI	203DPI
Paper Width	80mm/48columns
Max Speed	400mm/s
Print Density	100%
Retry at Error	Disable
VT Compression	100%
Language Selection	English(Latin)
<u>Glayscale</u>	
Speed at Glayscale	180mm/s
Glayscale Density	Mode5 (10% - 60%)
<u>Hardware</u>	
Graph/User NV-MEM	896KB/192KB
Cut at CoverClose	Disable
Cutter Mode	Full
PNE Detect	Enable
<u>Buzzer</u>	
Error Alert	None
Buzzer Interval	Pattern 2
Buzzer Repetition	Three
Buzzer after Cut	Disable
<u>Interface</u>	
Baudrate	9600BPS
Format	8NONE1
Protocol	DSR/DTR
USB	Printer
Plug and Play	Disable