

# Fujitsu M10/SPARC M10 Systems Getting Started Guide

## SPARC M10 システム はじめにお読みください

---

### Export Control

Exportation/release of this product and related documentation may require necessary procedures in accordance with the regulations of your resident country and/or US export control laws.

### Accessing the Documentation Files

Documents on SPARC M10 Systems are available on the following websites.

#### SPARC M10 Systems manuals

Global site      <http://www.fujitsu.com/global/services/computing/server/sparc/downloads/manual/>

#### Manuals related to Oracle Solaris or other Oracle software products

<http://www.oracle.com/documentation/>

---

**Note –** For the latest information regarding hardware, software, and documents of the SPARC M10 Systems, see the *Fujitsu M10/SPARC M10 Systems Product Notes* on the websites listed above.

---

**Note –** Fujitsu M10 is sold as SPARC M10 Systems by Fujitsu in Japan. Fujitsu M10 and SPARC M10 Systems are identical products.

---

### Documentation Feedback

If you have a comment or request regarding this manual, please take a moment to share it with us by indicating the manual code, manual title, and page, and stating your points specifically through the following websites.

Global site      <http://www.fujitsu.com/global/services/computing/server/sparc/downloads/manual/>

### SPARC M10 Systems Documentation

For the documents related to the SPARC M10 Systems, see "SPARC M10 Systems Documentation List" in the *Fujitsu M10/SPARC M10 Systems Quick Guide*.

## Activating CPU Core(s) before Receiving CPU Activations

If you activate CPU core(s) before receiving your Key(s), the Interim Permit feature provides a temporary CPU core capacity for up to 30 days on the premise that additional CPU Activation(s) will be purchased.

It is used to activate unused CPU core resource urgently.

For more details on using this feature, please see Appendix K in the *Fujitsu M10/SPARC M10 Systems System Operation and Administration Guide*.

## Obtaining CPU Activation Key(s) by e-mail

Your CPU Activation Key(s) can be obtained by an e-mail. If you cannot use Interim CPU Activation Permit, this method can minimize the time taken to deliver your Key(s).

CPU Activation Key(s) will be delivered a few days after Export Control Check, typically.

### Adding X-option Key(s) or re-issuing your Key(s):

To receive your CPU Activation Key(s), please provide the 8-digit Oracle Order Number indicated in your booking confirmation e-mail. If you do not have this number, please ask your sales representative to provide it to you.

Please use the following template to fill in all of the items in your e-mail.

This delivery process is available for Fujitsu M10 servers in all countries and regions throughout the world.

---

[To:] fujitsum10-activation@ml.css.fujitsu.com

[Subject:] Activation Request

[Mail body]

- Your Name :
- Your E-mail address :

Purchase Order information

- Company Name :
- Date of Order :
- Oracle Order Number (8 digit) :
- Part Number of CPU Activation (select one of the followings, and delete others)
  - 7105574 / Fujitsu M10-1 server: activation permit for 2 processor cores
  - 7107820 / Fujitsu M10-1 server: activation permit for 2 processor cores (for factory installation)
  - 7105575 / Fujitsu M10-4 server: activation permit for 2 processor cores
  - 7107821 / Fujitsu M10-4 server: activation permit for 2 processor cores (for factory installation)
  - 7106201 / Fujitsu M10-4S server module: activation permit for 2 processor cores
  - 7107822 / Fujitsu M10-4S server module: activation permit for 2 processor cores (for factory installation)
- Quantity of ordered CPU Activations :

## 輸出管理規制

本製品および関連するドキュメントを輸出または第三者へ提供する場合は、お客様が居住する国および米国政府の輸出管理規制をご確認のうえ、必要な手続きをおとりください。

## SPARC M10 システムドキュメントファイルへのアクセス

SPARC M10 システムのドキュメントは、以下のウェブサイトからご覧いただけます。

### SPARC M10 システムマニュアル

グローバルサイト <http://www.fujitsu.com/global/services/computing/server/sparc/downloads/manual/>

日本語サイト <http://jp.fujitsu.com/platform/server/sparc/manual/>

### Oracle Solaris などのオラクル社製ソフトウェア関連マニュアル

<http://www.oracle.com/documentation/>

---

**注** - SPARC M10 システムのハードウェア、ファームウェア、ソフトウェア、ドキュメントに関する最新情報は、上述のウェブサイトに掲載された『SPARC M10 システム プロダクトノート』を参照してください。

---

**注** - SPARC M10 システムは、Fujitsu M10 という製品名でも販売されています。SPARC M10 システムと Fujitsu M10 は、同一製品です。

---

## マニュアルへのフィードバック

本書に関するご意見、ご要望がございましたら、マニュアル番号、マニュアル名称、ページおよび具体的な内容を次のウェブサイトからご連絡ください。

グローバルサイト <http://www.fujitsu.com/global/services/computing/server/sparc/downloads/manual/>

日本語サイト <http://jp.fujitsu.com/platform/server/sparc/manual/>

## SPARC M10 システムのドキュメント

SPARC M10 システムに関連するドキュメントの一覧は、『SPARC M10 システム 早わかりガイド』の「ドキュメント一覧」を参照してください。

Copyright © 2007, 2016, Fujitsu Limited. All rights reserved. Oracle and/or its affiliates provided technical input and review on portions of this material.  
Copyright © 2007, 2016, Fujitsu Limited. Tous droits réservés. Entrée et revue technical fournies par Oracle et/ou ses affiliés sur des parties de ce matériel.

Manual Code : C120-E674-07XA  
December 2016