How do I make the bigger font? (Extension Font)

FUJITSU

Answer:

Please see the following method for command of the Extension Font.

>> 📄 [Manual for setting character size (citation from the interface specification)](#)