How do I print with the correct USB port choosing?




<u>Answer</u>: This trouble is not happened if the "Plug and Play" is enable. Default setting is enable.

*Note


- Setting of "Plug and Play" can be changed by the utility or special mode.
- About USB port

Manual for confirmation and changing USB port (citation from the Install Guide)

<Setting "Plug and Play" >



Special Mode



- 1) Start the "Special Mode"
- 2) Setup Menu
- 3) Setting
- 4) Interface
- 5) Plug and Play
- 6) Choose "Disable"
- 7) Save the setting

