

## I don't know how to setup IP address. How do I setup it?



**Answer**: Please follow the following steps.

Starting the Installation of "LAN Setup Tool".





Please see the following manual for installation and setup IP address.



StatusMonitor

Utility

Manual for installation and setup IP address (citation from the LAN manual)