
ScanSnap Manager V5.0L12 README File
PFU LIMITED

- Contents -

1. System requirements
2. Cautions Regarding USB and Your Computer
3. Cautions for Windows Vista(R) Users
4. Cautions Concerning Installation
5. Cautions Concerning the Operation
6. Selecting CardMinder(TM) as the application to link
7. Cautions Concerning Uninstallation
8. Other Cautions
9. Updated features

Use in High-Safety Applications

This product has been designed and manufactured on the assumption that it will be used in office, personal, domestic, regular industrial, and general-purpose applications. It has not been designed and manufactured for use in applications (simply called "high-safety applications" from here on) that directly involve danger to life and health when a high degree of safety is required, for example, in the control of nuclear reactions at nuclear power facilities, automatic flight control of aircraft, air traffic control, operation control in mass-transport systems, medical equipment for sustaining life, and missile firing control in weapons systems, and when provisionally the safety in question is not ensured.

The user should use this product with adopting measures for ensuring safety in such high-safety applications. PFU LIMITED assumes no liability whatsoever for damages arising from use of this product by the user in high-safety applications, and for any claims or compensation for damages by the user or a third party.

1. System requirements

- Operating System

Microsoft(R) Windows(R) 2000 Professional	English Version	
(SP4 or later)		
Microsoft(R) Windows(R) XP Professional	English Version	
(SP2 or later)		
Microsoft(R) Windows(R) XP Home Edition	English Version	
(SP2 or later)		
Microsoft(R) Windows Vista(R) Home Basic	English Version	(32bit/64bit)
Microsoft(R) Windows Vista(R) Home Premium	English Version	(32bit/64bit)
Microsoft(R) Windows Vista(R) Business	English Version	(32bit/64bit)
Microsoft(R) Windows Vista(R) Enterprise	English Version	(32bit/64bit)
Microsoft(R) Windows Vista(R) Ultimate	English Version	(32bit/64bit)

- CPU (Processor)

Intel(R) Pentium(R) 4 1.8GHz or higher
(recommended: Intel(R) Core(TM) 2 Duo 2.2GHz or higher)

- Memory

512MB or more
(recommended: 1GB or more)

- Hard-disk space
450MB of available hard-disk space

2. Cautions Regarding USB and Your Computer

- o Be sure to use the USB cable packaged with ScanSnap for connecting it to your computer.
- o Be sure to wait at least five seconds before re-inserting or re-connecting the USB interface cable.
If the USB cable is re-inserted immediately after it is disconnected, ScanSnap may not function properly.
- o Use the display at High Color or higher setting. The display may sometimes be corrupted at 256 or less colors.

3. Cautions for Windows Vista(R) Users

- o ScanSnap Manager does not support environment-dependent characters (unicode). Do not use environment-dependent characters (unicode) for the following:
 - the name of a folder to install ScanSnap Manager
 - the name of a ScanSnap Manager user
 - characters including the name of folders and files handled in ScanSnap Manager

4. Cautions Concerning Installation

- o The ScanSnap Manager user interface language changes to English if the Windows (R) language is not English, Japanese, German, French, Italian, Spanish, Chinese(simplified), Chinese(traditional), Korean, Russian or Portuguese.
- o Be sure to connect the ScanSnap after installing ScanSnap Manager.
The ScanSnap cannot be registered with the system correctly if ScanSnap Manager is not installed.
- o Do not install ScanSnap Manager in the root directory.
ScanSnap Manager may not function properly. Install ScanSnap Manager on the appropriate directory.
- o The path name for the installation directory must not exceed 80 characters.
When installing ScanSnap Manager, limit the path name for the installation directory to 80 characters.
- o When installing ScanSnap Manager on Windows (R) 2000, Windows (R) XP or Windows Vista (R), first log on as Administrator
(or as a user with administrator privileges on Windows (R) XP Home Edition).
- o Do not use the following characters in the name of the installation directory. ScanSnap Manager may not function properly if these characters are used.

/ ; , . * ? " < > |
- o Be sure to restart your computer after installing ScanSnap Manager.
The re-boot registers ScanSnap to the system.

- o Uninstall ScanSnap Manager before re-installing ScanSnap Manager. ScanSnap Manager is not installed properly if it has not been uninstalled completely.
- o Specify a folder on a local disk as the installation folder.
- o When installing ScanSnap Manager in Windows Vista(R), you will see a "User Account Control" dialog box. Click the [Continue] button on the dialog box.

5. Cautions Concerning the Operation

When Adobe(R) Acrobat(R) or Adobe(R) Reader(R) or Acrobat(R) Reader is the selected application, please be aware of the following.

Even though you select Acrobat(R) Reader or Adobe(R) Reader(R) as the application to view the generated image, when Adobe(R) Acrobat(R) has been activated, the image will be viewed by Adobe(R) Acrobat(R).

Likewise, when Adobe(R) Acrobat(R) is start Acrobat(R) Reader or Adobe(R) Reader(R) already running, the scanned data is passed to Acrobat(R) Reader or Adobe(R) Reader(R).

When the selected application is Adobe(R) Acrobat(R) or or Adobe(R) Reader(R) or Acrobat(R) Reader, always set the file type to "PDF".

When the selected application is Adobe(R) Acrobat(R) or Adobe(R) Reader(R) or Acrobat(R) Reader, and no pages have been saved (i.e, all blank pages, an error occurs at the first page, etc.), Adobe(R) Acrobat(R) or Adobe(R) Reader(R) or Acrobat(R) Reader will start but no images will be displayed.

If you install Adobe(R) Acrobat(R) after installing ScanSnap Manager, the password function of ScanSnap Manager remains disabled. Restart ScanSnap Manager to use the function.

When using the password function, the "Failed to initialize password module" message may appear.

In this case, restart the ScanSnap Manager and perform the operation again.

When scanning the document with "Excellent" selected in the "Image quality" drop-down list on the ScanSnap Manager dialog box, scanning speed may extremely slow down or memory may get exhausted.

If ScanSnap Manager becomes irresponsive as described above, select "Better" or "Best" instead and retry scanning.

If power cable or interface cable of scanner is detached during scanning, this software may be terminated illegally.

So, please do not remove them during the scanner is scanning.

Operations using Terminal Service Client and Remote Desktop Connection Client services are not guaranteed.

6. Selecting CardMinder as the application to link (Application)

- o When CardMinder is started, the "Application" setting automatically becomes CardMinder.
This setting is restored when you exit CardMinder.
- o While the ScanSnap Manager "Scan and Save Settings" screen is displayed, scanning cannot be performed with CardMinder.
Close the "Scan and Save Settings" screen, and try again.

7. Cautions Concerning Uninstallation

- o Perform uninstallation from "Add/Remove Programs" in the control panel.
- o When uninstalling ScanSnap Manager from Windows (R) 2000, Windows (R) XP or Windows Vista (R), first log on as Administrator
(or as a user with administrator privileges on Windows (R) XP Home Edition).
- o Be sure to restart your computer after uninstalling ScanSnap Manager.
- o The Windows (R) "Add New Hardware Wizard" will be started if ScanSnap is connected when restarting your computer after uninstallation.
At uninstallation, either turn ScanSnap off, or disconnect the USB cable.
- o When uninstalling ScanSnap Manager in Windows Vista (R), you will see a "User Account Control" dialog box. If you are logged on to the system with an Administrator account, click the [Continue] button, and if you are not, select an Administrator account, enter a password, and then click the [OK] button.

8. Other Cautions

- o Two or more ScanSnap scanners cannot be connected at the same time.
- o Avoid the following during scanning or while waiting for the scanner initialize (the scan lamp is calibrating).
The system may become unstable.
 - Inserting or disconnecting the USB cable connected to ScanSnap
 - Turning ScanSnap on or off
 - Uninstalling ScanSnap Manager
- o Scanning may not be performed properly if the connected computer has entered power-controlled mode (e.g., standby [suspended], pause [hibernation], or sleep mode).
In such case, retry scanning after turning off the power saving option of the computer.
Scanning may not also be performed properly if the connected computer could not recognize the ScanSnap correctly after having resumed from power-controlled mode, or after you had logged off the computer or changed the logged-in user.
In such case, retry scanning after turning the ScanSnap off and then on again.

9. Updated features

Modifications from V5.0L11 to V5.0L12

- o The malfunction that causes an abnormal termination of ScanSnap Manager, when using the following functions with Intel (R) Pentium (R) Dual-Core Processor

E5200/E5300/E5400, has been modified.

- [Automatic detection]
- [Correct skewed character strings automatically]
- Scanning with Carrier Sheet

- o The malfunction that disables the connection of fi-60F or fi-5110C when ScanSnap S1500 and fi-60F, or ScanSnap S300 and fi-5110C are both connected to the same computer, has been modified.
- o The malfunction, where the ScanSnap is not recognized by ScanSnap Manager in some computers upon resuming from sleep mode or logging in again, has been modified.
- o The malfunction, where clearing the [Use Quick Menu] check box disables the automatic linkage when [The ScanSnap always interacts with the application that is running and has higher priority (when more than one application is running).] is selected in the [Automatic Interaction] tab of the [Preferences] window, has been modified.

=====
ScanSnap and CardMinder are the trademarks of PFU LIMITED.

Microsoft, Windows and Windows Vista are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Intel, Pentium and Celeron are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Adobe, Acrobat, Adobe Reader, and Acrobat Reader are either registered trademarks or trademarks of Adobe Systems Incorporated.

Other company names and product names are the trademarks or registered trademarks of respective companies.

All Rights Reserved, Copyright (C) PFU LIMITED 2001-2009