


# THERMAL PRINTER APPLICATION NOTES

## FTP-600 Series

### Application Notes

#### 1. Power supply

- (1) Use a power supply with the specified specifications. If the power supply is incompatible, normal operation is not guaranteed and failure may occur.
- (2) For a model which requires two power supplies, 5V and 24V, adhere to the following sequence when power is turned ON and OFF.



#### 2. Print head

- (1) As printing progresses, the print head becomes very hot. Do not directly touch the print head and head support plate.
- (2) Do not directly touch the print head. Oil adhering to hands may damage the life of the head.
- (3) If printing is performed without setting paper, heat causes a problem for the platen and print head. Do not print when paper is not set.
- (4) Do not print in head-up status. This may damage the life of the head.
- (5) The head may be abnormally heated due to a drive circuit system loss of control. We recommend to install a temperature fuse so that power is shutdown when an abnormal heating of the head part is detected.

#### 3. Heating of motor

The motor becomes hot, so do not directly touch. Consider heat radiation when designing the case.

#### 4. Paper

- (1) Use specified paper. If unspecified paper is used, printing quality drops and a failure may occur.

# Thermal Printer Application Notes FTP-600 Series

(2) With specified paper, the area outside the roll is the thermo-sensitive face. Set paper such that the thermo-sensitive face contacts the print head.

(3) Keep the paper such that the roll core is parallel with the printer mechanism. If the roll core is held diagonally to the printer mechanism, paper may be fed diagonally or may jam.

(4) Do not print when paper jams, which may cause a failure. When paper jams, remove the paper in head-up status. When paper is removed, be careful not to damage the head and platen.

## 5. Water and foreign substances

(1) If the unit is used when water, other liquids, dust, or such metal objects as needles and pins are inside, a failure may occur, and smoking due to a power supply short may occur.

(2) If printing is performed with condensation present, the print head may be damaged. If condensation occurs, completely dry the unit before printing.

## 6. Shock

The unit is comprised of precision electronic components. Do not drop this unit or hit it with an object, which may cause failure.

## 7. When not using for a long time

When the unit is not used for a long time, set the unit in head-up status. If this unit is left for a long time with the print head down, the platen may become deformed and print quality cannot be guaranteed.

## 8. Operating environment

(1) Avoid using the unit in an area which is exposed to direct sunlight or to dust containing oil

and iron. If the unit is used in such an area, shield this area from direct sunlight by a case, etc., or implement dust proof measures.

(2) Keep the unit away from equipment emitting high radiation noise, such as high voltage equipment and large motors. If the unit is used near such equipment, take such countermeasures as electro-magnetic shielding.

## 9. Other

(1) Install the printer horizontally and use it in an area where excessive vibration and shock are not applied.

(2) We recommend positioning the printer mechanism and interface board on an Frame Ground.

(3) If unspecified paper is used, a paper charge may cause a problem.

(4) To install the unit directly to equipment, ground the body with an earth band prior to operation, in order to prevent static electricity.

(5) Do not connect/disconnect a connector when power is ON, which may cause a failure.

(6) When a cable is disconnected in power ON status, the head may be burnt. Be certain that an unnatural force is not applied to a cable. In particular, be careful when connecting a cable between the printer mechanism and interface board, since this cable moves when the print head is up or down.

(7) When the printer is secured, be careful not to apply an unnatural force on the mechanism body, board and flexible printed board. If an unnatural force is applied, distortion or deformation may cause a diagonal paper feed, jamming, noise, a disconnection in patterns, or peeling.

### Fujitsu Components International Headquarter Offices

**Japan**  
Fujitsu Component Limited  
Gotanda-Chuo Building  
3-5, Higashigotanda 2-chome, Shinagawa-ku  
Tokyo 141, Japan  
Tel: (81-3) 5449-7010  
Fax: (81-3) 5449-2626  
Email: [promothq@ft.ed.fujitsu.com](mailto:promothq@ft.ed.fujitsu.com)  
Web: [www.fcl.fujitsu.com](http://www.fcl.fujitsu.com)

**North and South America**  
Fujitsu Components America, Inc.  
250 E. Caribbean Drive  
Sunnyvale, CA 94089 U.S.A.  
Tel: (1-408) 745-4900  
Fax: (1-408) 745-4970  
Email: [marcom@fcai.fujitsu.com](mailto:marcom@fcai.fujitsu.com)  
Web: [www.fcai.fujitsu.com](http://www.fcai.fujitsu.com)

**Europe**  
Fujitsu Components Europe B.V.  
Diamantlaan 25  
2132 WV Hoofddorp  
Netherlands  
Tel: (31-23) 5560910  
Fax: (31-23) 5560950  
Email: [info.marketing@fceu.fujitsu.com](mailto:info.marketing@fceu.fujitsu.com)  
Web: [www.fceu.fujitsu.com](http://www.fceu.fujitsu.com)

**Asia Pacific**  
Fujitsu Components Asia Ltd.  
102E Pasir Panjang Road  
#04-01 Citilink Warehouse Complex  
Singapore 118529  
Tel: (65) 375-8560  
Fax: (65) 273-3021  
Email: [fcal@fcal.fujitsu.com](mailto:fcal@fcal.fujitsu.com)  
[www.fcal.fujitsu.com](http://www.fcal.fujitsu.com)