

# **Infrastructure Manager / Infrastructure Manager for PRIMEFLEX V2.9.0**

## **Items for Profile Settings (for Profile Management)**

CA92344-5435-04

June 2024

# Preface

---

## Purpose

This manual describes the installation procedure and the general functions of the following operation and management software. This software manages and operates ICT devices such as servers, storages, and switches, as well as facility devices such as PDUs, in an integrated way.

- Infrastructure Manager (hereafter referred to as "ISM")
- Infrastructure Manager for PRIMEFLEX (hereafter referred to as "ISM for PRIMEFLEX")

## Product Manuals

Manual Name	Description
Infrastructure Manager / Infrastructure Manager for PRIMEFLEX V2.9.0 First Step Guide	This manual is for those using this product for the first time. This manual summarizes the procedures for the use of this product, the product system, and licensing.  In this manual, it is referred to as "First Step Guide."
Infrastructure Manager / Infrastructure Manager for PRIMEFLEX V2.9.0 User's Guide	This manual describes the functions of this product, the installation procedure, and procedures for operation. It allows you to quickly grasp all functions and all operations of this product.  In this manual, it is referred to as "User's Guide."
Infrastructure Manager / Infrastructure Manager for PRIMEFLEX V2.9.0 Operating Procedures	This manual describes the installation procedure and usages for the operations of this product.  In this manual, it is referred to as "Operating Procedures."
Infrastructure Manager / Infrastructure Manager for PRIMEFLEX V2.9.0 REST API Reference Manual	This manual describes how to use the required APIs and provides samples and parameter information for using user-created applications that integrate with this product.  In this manual, it is referred to as "REST API Reference Manual."
Infrastructure Manager / Infrastructure Manager for PRIMEFLEX V2.9.0 Messages	This manual describes the messages that are output when using ISM or ISM for PRIMEFLEX and the actions to take for these messages.  In this manual, it is referred to as "ISM Messages."
Infrastructure Manager for PRIMEFLEX V2.9.0 Messages	This manual describes the messages that are output when using ISM for PRIMEFLEX and the actions to take for these messages.  In this manual, it is referred to as "ISM for PRIMEFLEX Messages."
Infrastructure Manager / Infrastructure Manager for PRIMEFLEX V2.9.0 Items for Profile Settings (for Profile Management)	This manual describes detailed information for the items set when creating profiles for managed devices.  In this manual, it is referred to as "Items for Profile Settings (for Profile Management)."
Infrastructure Manager for PRIMEFLEX V2.9.0 Cluster Creation and Cluster Expansion Parameter List	This manual describes Cluster Definition Parameters that are used for the automatic settings in Cluster Creation and Cluster Expansion when using ISM for PRIMEFLEX.  In this manual, it is referred to as "ISM for PRIMEFLEX Parameter List."
Infrastructure Manager / Infrastructure Manager for PRIMEFLEX V2.9.0 Glossary	This document defines the terms that you need to understand in order to use this product.  In this manual, it is referred to as "Glossary."

Manual Name	Description
Infrastructure Manager / Infrastructure Manager for PRIMEFLEX V2.9.0 Plug-in and Management Pack Setup Guide	<p>This manual describes the procedures, from installation to operation as well as precautions and reference information, for the following features of Infrastructure Manager Plug-in.</p> <ul style="list-style-type: none"> <li>- Infrastructure Manager Plug-in for Microsoft System Center Operations Manager</li> <li>- Infrastructure Manager Plug-in for Microsoft System Center Virtual Machine Manager</li> <li>- Infrastructure Manager Plug-in for VMware vCenter Server Appliance</li> <li>- Infrastructure Manager Plug-in for Microsoft Windows Admin Center</li> </ul> <p>In this manual, it is referred to as "ISM Plug-in/MP Setup Guide."</p>

Together with the manuals mentioned above, you can also refer to the latest information about ISM by contacting your local Fujitsu customer service partner.

For the information about managed hardware products, refer to the manuals of the relevant hardware.

For PRIMERGY, refer to "ServerView Suite ServerBooks" or the manual pages for PRIMERGY.

<https://support.ts.fujitsu.com/>

## Intended Readers

This manual is intended for system administrators, network administrators, facility administrators, and service technicians who have sufficient knowledge of hardware and software.

## Notation in this Manual

### Notation

#### Keyboard

Keystrokes that represent nonprintable characters are displayed as key icons such as [Enter] or [F1]. For example, [Enter] means press the key labeled "Enter." [Ctrl]+[B] means hold down the key labeled "Ctrl" or "Control" and then press the B key.

#### Symbols

Items that require particular attention are indicated by the following symbols.



#### Point

Describes the content of an important point.



#### Note

Describes an item that requires your attention.

#### Variables: <xxx>

Represents variables that require replacement by numerical values or text strings in accordance with your usage environment.

Example: <IP address>

#### Abbreviation

This document may use the abbreviation for OS as shown in the following examples.

Official name	Abbreviation	
Microsoft(R) Windows Server(R) 2022 Datacenter	Windows Server 2022 Datacenter	Windows Server 2022 or Windows
Microsoft(R) Windows Server(R) 2022 Standard	Windows Server 2022 Standard	
Microsoft(R) Windows Server(R) 2022 Essentials	Windows Server 2022 Essentials	
Red Hat Enterprise Linux 9.3 (for Intel64)	RHEL 9.3	Red Hat Enterprise Linux or Linux
SUSE Linux Enterprise Server 15 SP5 (for AMD64 & Intel64)	SUSE 15 SP5(AMD64) SUSE 15 SP5 (Intel64) or SLES 15 SP5 (AMD64) SLES 15 SP5 (Intel64)	SUSE Linux Enterprise Server or Linux
SUSE Linux Enterprise Server 15 (for AMD64 & Intel64)	SUSE 15(AMD64) SUSE 15(Intel64) or SLES 15(AMD64) SLES 15(Intel64)	
VMware ESXi™ 8.0	VMware ESXi 8.0	VMware ESXi
VMware Virtual SAN	vSAN	
Microsoft Storage Spaces Direct	S2D	

In this document, VMware by Broadcom is referred to as VMware.

## Terms

For the major terms and abbreviations used in this manual, refer to "Glossary."

## Using PDF applications (Adobe Reader, etc.)

Depending on the specifications of the PDF application you are using, issues (extra spaces and line breaks, missing spaces, line breaks, and hyphens in line breaks) may occur when you perform the following operations.

- Saving to a text file
- Copying and pasting text

## High Risk Activity

The Customer acknowledges and agrees that the Product is designed, developed and manufactured as contemplated for general use, including without limitation, general office use, personal use, household use, and ordinary industrial use, but is not designed, developed and manufactured as contemplated for use accompanying fatal risks or dangers that, unless extremely high safety is secured, could lead directly to death, personal injury, severe physical damage or other loss (hereinafter "High Safety Required Use"), including without limitation, nuclear reaction control in nuclear facility, aircraft flight control, air traffic control, mass transport control, medical life support system, missile launch control in weapon system. The Customer shall not use the Product without securing the sufficient safety required for the High Safety Required Use. In addition, Fsas Technologies Inc. (or other affiliate's name) shall not be liable against the Customer and/or any third party for any claims or damages arising in connection with the High Safety Required Use of the Product.

## To Use This Product Safely

This document contains important information required for using this product safely and correctly. Read this manual carefully before using the product. In addition, to use the product safely, the customer must understand the related products (hardware and software) before using the product. Be sure to use the product by following the precautions on the related products. Be sure to keep this manual in a safe and convenient location for quick reference during use of the product.

## Modifications

The customer may not modify this software or perform reverse engineering through decompiling or disassembly.

## Disclaimers

Fsas Technologies Inc. assumes no responsibility for any claims for losses, damages or other liabilities arising from the use of this product. The contents of this document are subject to change without notice.

## Trademarks

Microsoft, Windows, Windows Vista, Windows Server, Hyper-V, Active Directory, and the titles or names of other Microsoft products are trademarks or registered trademarks of Microsoft Corporation in the United States and other countries.

Linux is a trademark or registered trademark of Linus Torvalds in the United States and other countries.

Red Hat and all trademarks and logos based on Red Hat are trademarks or registered trademarks of Red Hat, Inc. in the United States and other countries.

SUSE and the SUSE logo are trademarks or registered trademarks of SUSE LLC in the United States and other countries.

VMware, VMware logo, VMware ESXi, VMware SMP, and vMotion are trademarks or registered trademarks of VMware, Inc. in the United States and other countries.

Intel and Xeon are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

Java is a registered trademark of Oracle Corporation and its subsidiaries/affiliates in the United States and other countries.

Zabbix is a trademark of Zabbix LLC that is based in Republic of Latvia.

PostgreSQL is a trademark of PostgreSQL in the United States and other countries.

Apache is a trademark or registered trademark of Apache Software Foundation.

Cisco is a trademark of Cisco Systems, Inc. in the United States and other countries.

Elasticsearch is a trademark or registered trademark of Elasticsearch BV in the United States and other countries.

Xen is a trademark of XenSource, Inc.

Trend Micro and Deep Security are trademarks or registered trademarks of Trend Micro Incorporated.

All other company and product names are trademarks or registered trademarks of the respective companies.

All other products are owned by their respective companies.

## Copyright

Copyright 2017 - 2024 Fsas Technologies Inc.

This manual shall not be reproduced or copied without the permission of Fsas Technologies Inc.

## Modification History

Edition	Issue Date	Modification Overview	Section	
01	September 2023	First edition	-	-
02	December 2023 Modification for ISM 2.9.0.010 patch application	Added new parameters	Chapter 1 BIOS/iRMC Setting Items of Profiles for PRIMERGY/ PRIMEQUEST 3000B/4000E Servers	iRMC tab
		Added notes on PRIMEQUEST 4000E	4.1 Card Settings	"Note"
03	March 2024 Modification for ISM 2.9.0.020 patch application	Added description of RAID configuration of profiles for PRIMERGY servers	Chapter 5 RAID Setting Items of Profiles for PRIMERGY Servers	Added new

Edition	Issue Date	Modification Overview	Section	
	March 2024 Major reorganization of the manual and modification of content	Added support range for items that cannot be set due to BIOS change	Chapter 1 BIOS/iRMC Setting Items of Profiles for PRIMERGY/PRIMEQUEST 3000B/4000E Servers	BIOS tab
		Added notes on packages that are not supported for OS installation	3.3 Profiles for Red Hat Enterprise Linux	OS tab - Table of [Note 6] - note in "ServerView Operations Manager"
		Added note for using array controller in the OS installation	3.1 Profiles for Windows Server	OS tab - [Note 3] and [Note 10]
			3.2 Profiles for VMware ESXi	
			3.3 Profiles for Red Hat Enterprise Linux	
			3.4 Profiles for SUSE Linux Enterprise Server	
04	June 2024 Modification for ISM 2.9.0.030 patch application	Added description of RAID configuration of profiles for PRIMERGY servers	Chapter 5 RAID Setting Items of Profiles for PRIMERGY Servers	Chapter title
		Added description of profiles for ETERNUS	6.2 Profiles for ETERNUS NR/ETERNUS AX/ETERNUS HX/ETERNUS AC	"RAID tab" and [Note 2]
	June 2024 Major reorganization of the manual and modification of content	Modified description due to the name change to Fsas Technologies	-	-
		Modified version from ISM 2.9.0.020 to ISM 2.9.0.021	-	-

# Contents

---

Chapter 1 BIOS/iRMC Setting Items of Profiles for PRIMERGY/PRIMEQUEST 3000B/4000E Servers.....	1
Chapter 2 MMB Setting Items of Profiles for PRIMEQUEST 2000 (Partition)/PRIMEQUEST 2000B/PRIMEQUEST 3000E Series Partitions.....	22
Chapter 3 OS Setting Items of Profiles for Servers.....	24
3.1 Profiles for Windows Server.....	24
3.2 Profiles for VMware ESXi.....	29
3.3 Profiles for Red Hat Enterprise Linux.....	33
3.4 Profiles for SUSE Linux Enterprise Server.....	38
Chapter 4 Virtual IO Setting Items of Profiles for PRIMERGY Servers/PRIMEQUEST 3000E/4000E Partitions.....	44
4.1 Card Settings.....	44
4.2 Port Settings.....	45
4.3 Boot Settings.....	46
4.4 CNA Settings.....	48
4.5 Virtual Address Settings.....	48
Chapter 5 RAID Setting Items of Profiles for PRIMERGY Servers (ISM 2.9.0.021 or later).....	51
Chapter 6 Setting Items of Profiles for Storages.....	52
6.1 Profiles for ETERNUS DX.....	52
6.2 Profiles for ETERNUS NR/ETERNUS AX/ETERNUS HX/ETERNUS AC (ISM 2.9.0.030 or later).....	54
Chapter 7 Setting Items of Profiles for Switches.....	57
7.1 Profiles for SR-X.....	57
7.2 Profiles for VDX.....	59
7.3 Profiles for PSWITCH 2048P/T PSWITCH 4032P.....	62
7.4 Profiles for CFX.....	65
Chapter 8 Setting Items of Common Policy.....	69
8.1 Monitoring Policy.....	69

# Chapter 1 BIOS/iRMC Setting Items of Profiles for PRIMERGY/PRIMEQUEST 3000B/4000E Servers

This section describes the items that you can set up with the BIOS/iRMC tab, in profiles.

## Note

You find some items that you are unable to set up or some items with different setting contents, depending on the model of your server. Therefore, set up your servers within the scope of support.

You can select Enable or Disable individually for the setting items in profiles. When you disable a setting item, the disabled item is not changed even after assigning the profile.

There are some cases where profiles and setting items on the actual device type may differ. For details of each item, refer to the manual of the target servers and apply settings to the items corresponding to the profile.

## BIOS tab

Item Name	Description	Parameter
PCI Subsystem Settings		
ASPM Support (PCI-E ASPM Support (Global)) (Disable/L1 only/Auto/Force L0s)	This specifies whether to use Active State Power Management (ASPM) for the power management of PCI Express. Even if this setting enables ASPM entirely, it only becomes enabled for certain links when the applicable PCI Express expansion card and the onboard controller also support ASPM.	Disable = Disable ASPM  L1 only = Sets the power saving mode of the PCI Express link to L1 (Unidirectional)  Auto = Sets to maximize power saving  Force L0s/Limit to L0s = Set the power saving mode of PCI Express link to L0s (Unidirectional)
DMI Control (GEN 1/GEN 2)	Select the bus connection speed between the CPU and the chip set. The slower it is the lower the power consumption, but the system performance is also reduced.	GEN 1 = Sets the bus connection between the CPU and the chip set, and execute with 2.5 GT/s  GEN 2 = Sets the bus connection between the CPU and the chip set, and execute with 5.0 GT/s
Above 4G Decoding (Enable/Disabled)	This specifies whether memory resources beyond the 4 GB address boundary can be allocated to PCI devices.  The option depends on the operating system and the adapter card installed.	Enable = Allocate memory resources beyond 4 GB address boundaries to PCI devices.  Disable = Allocate only memory resources below the 4 GB address boundary to PCI devices.
SR-IOV Support (Enable/Disable)	This specifies whether to enable Single Root IO Virtualization if the system has an SR-IOV capable PCIe device	Enable = Enables function.  Disable = Disables function.
CPU Configuration		
Execute Disable Bit (Enable/Disable)	This specifies Execute Disable Bit behavior of a CPU. Depending on the manual, this function is described as XD (eXecute Disable) bit or NX (No eXecute) bit.	Enable = Function made available  Disable = Function disabled






Item Name	Description	Parameter
Hyper-Threading (Enable/Disable)	This specifies Hyper Threading Technology behavior of a CPU.  If the installed CPU does not support this function, this setting is ignored.	Enable = Function made available  Disable = Function disabled
Active Processor Cores (All/1-64)  (Note: not supported for PRIMERGY M7 series or later. This can be set with profile for each model)	For processors that includes multiple processor cores, specify the number of active processor cores. Processor cores that are not enabled and are not used are hidden from the OS.	All = Enable all processor cores that can be used  1-64 = Enables only the selected processor cores, the other processor cores are disabled
Hardware Prefetcher (Enable/Disable)	This specifies whether to automatically preload the necessary and available memory contents to the cache when a memory bus becomes inactive.  By reading the contents from cache instead of the memory, latency is reduced especially for applications using linear access to data.	Enable = Enable the use of the function  Disable = Disable the use of the function
Adjacent Cache Line Prefetch (Enable/Disable)	This specifies whether to load the added adjacent 64 byte cache line when the processor sends cache requests.  This parameter can be used when the processor is equipped with a mechanism to load the added adjacent 64 byte cache line when the processor sends cache requests. This increases the cache hit ratio for application with high spatial locality.	Enable = The requested cache line and the adjacent cache line are loaded  Disable = The requested cache line is loaded
DCU Streamer Prefetcher (Enable/Disable)	This specifies whether to automatically preload the necessary and available memory contents to the L1 data cache when a memory bus becomes inactive.  By reading the contents from cache instead of the memory, latency is reduced especially for applications using linear access to data.	Enable = Enable the function  Disable = Disable the function
DCU IP Prefetcher (Enable/Disable)	This specifies the DCU IP Prefetch operation of the CPU.	Enable = Enable the DCU IP Prefetch of the CPU  Disable = Disable the DCU IP Prefetch of the CPU
Intel Virtualization Technology (Enable/Disable)	This specifies virtualization support function behavior of a CPU.	Enable = Function enabled  Disable = Function disabled
Intel(R) Vt-d (Enable/Disable)	This specifies Virtualization Technology for Directed I/O function behavior of a CPU.	Enable = Function enabled  Disable = Function disabled
Power Technology (Energy Efficient/Custom/Disable)	This sets up the power source management behavior of a CPU.	Energy Efficient = Behavior optimized for power-saving  Custom = Detailed behavior setup by using additional setting items.

Item Name		Description	Parameter
			Disable = Power source management function disabled
	HWPM Support (Disable/Native Mode/OOB Mode)	<p>This item can only be set when Power Technology is Custom.</p> <p>Specifies the settings of the performance and power saving managed by HWPM (Hardware Power Management).</p>	<p>Disable = Do not use the HWPM function</p> <p>Native Mode = HWPN cooperatively operates with the operating system via the software interface.</p> <p>OOB Mode = The CPU automatically controls the frequency based on the settings in the energy efficiency policy of the operating system</p>
	Enhanced Speed Step (Enable/Disable)	<p>This is the item you can set up only when Power Technology is Custom.</p> <p>This specifies EIST (Enhanced Intel SpeedStep Technology) behavior of a CPU.</p>	<p>Enable = Function enabled</p> <p>Disable = Function disabled</p>
	Turbo Mode (Enable/Disable)	<p>This is the item you can set up only when Enhanced Speed Step is Enable.</p> <p>This specifies Turbo Boost Technology behavior of a CPU.</p> <p>If the installed CPU does not support this function, this function is set to (Disable) regardless of this setting.</p>	<p>Enable = Function enabled</p> <p>Disable = Function disabled</p>
	Override OS Energy Performance (Enable/Disable)	<p>This item can be set up only when Power Technology is Custom.</p> <p>This item specifies whether to prevent the OS from overwriting the settings of the energy efficiency policy of the setup.</p>	<p>Enable = Enable the function</p> <p>Disable = Disable the function</p>
	Energy Performance (Performance/Balanced Performance/Balanced Energy/Energy Efficient)	<p>This item can be set up only when Power Technology is Custom and Override OS Energy Performance is Enabled.</p> <p>This item specifies the energy efficiency policy of the processor in non-legacy operating systems.</p> <p>Depending on the operations, it may be decided to not use this mode.</p>	<p>Performance = Strongly optimizes to increase performance, even if it sacrifices energy efficiency,</p> <p>Balanced Performance = Set to get performance while saving energy at the same time</p> <p>Balanced Energy = Set to save energy while getting good performance</p> <p>Energy Efficient = Strongly optimize energy efficiency, even if this sacrifices performance</p>
	Utilization Profile (Even/Unbalanced)	<p>This item can be set up only when Power Technology is Custom and Override OS Energy Performance is Enabled.</p> <p>Specify the share of energy performance to be optimized for use by a different system.</p>	<p>Even = Optimizes to create a system with balanced energy performance</p> <p>Unbalanced = Optimizes for unbalanced system use prioritizing performance</p>
	CPU C1E Support (Enable/Disable)	<p>This item can be set up only when Power Technology is Custom.</p> <p>Specify whether to stop the processor when it is possible to save power.</p>	<p>Enable = Function enabled</p> <p>Disable = Function disabled</p>



Item Name		Description	Parameter
	Autonomous C-state Support (Enable/Disable)	This item can be set up only when Power Technology is Custom.  Specifies whether to enable the Autonomous C-state Support of the processor.	Enable = Function enabled  Disable = Function disabled
	CPU C3 Report (Enable/Disable)	This item can be set up only when Power Technology is Custom.  Specify whether to transfer the C3 state of the processor to OSPM (OS Power Management) as ACPI C-2 state.	Enable = CPU C3 is transferred to OSPM as ACPI C-2 state  Disable = CPU C3 is not transferred to OSPM as ACPI C-2 state
	CPU C6 Report (Enable/Disable)	This item can be set up only when Power Technology is Custom.  Specify whether to transfer the C6 state of the processor to OSPM as ACPI C-3 state, and to enable Deep Power Down Technology.	Enable = CPU C6 is transferred to OSPM as ACPI C-3 state  Disable = CPU C6 is not transferred to OSPM as ACPI C-3 state
	Package C State Limit (C0/C2/C6/ C6(Retention)/C7/C7s/No Limit/ Auto)	This item can be set up only when Power Technology is Custom.  Specify the upper limit of the C State of the processor.	C0=The upper limit of C State is set to C0 C2=The upper limit of C State is set to C2 C6=The upper limit of C State is set to C6 C6(Retention)=C6 Retention is set to C status limitation C7=The upper limit of C State is set to C7 C7s=The upper limit of C State is set to C7s No Limit=The upper limit for C State is not set Auto=The system decides automatically
	QPI Link Frequency Select (Auto/6.4 GT/s, 7.2 GT/s, 8.0 GT/s, 9.6 GT/s, 10.4 GT/s)	This specifies the frequency to a shared frequency supported by the CPU.	Auto = The fastest is set from BIOS, based on the CPU existing in the system and the chip set.  The speed settings that can be selected depends on the CPU. Select from the following.  6.4 GT/s, 7.2 GT/s, 8.0 GT/s, 9.6 GT/s, 10.4 GT/s
	Uncore Frequency Override (Maximum/Nominal/Disable/Power balanced)	This item specifies the uncore frequency of the processor.  This improves the I/O performance.	Maximum = The maximum value of the frequency is always set in advance  Nominal = To save power, the processor automatically controls the frequency within the range set in advance. The rate frequency will not be exceeded  Disable = To save power, the processor automatically controls the frequency within the range set in advance  Power balanced = To optimize the balance between power and performance, the processor automatically controls the

Item Name		Description	Parameter
			frequency within the range defined in advance
	LLC Dead Line Alloc (Enable/Disable)	This item specifies the dead line processing of LLC (Last Level Cache).  This affects the system performance.	Enable = It easily meets the LLC data dead line  Disable = It does not meet the LLC dead line
	Stale AtoS (Enable/Disable)	This item specifies the directory optimization of data that has become obsolescent in Caching Agent.  This affects the system performance.	Enable = Optimization enabled  Disable = Optimization disabled
	COD Enable (Enable/Auto/Disable)	This item specifies whether the BIOS should configure the added NUMA nodes for each socket and optimizes the performance of operation loads with high NUMA directivity. For this item, a CPU that has two home agents is required. For systems where COD (Cluster-on-Die) is enabled, it is required to disable isochronous applications, and early snooping is not supported.	Enable = Function enabled  Auto = COD is enabled if this is allowed in the system configuration  Disable = Function disabled
	Early Snoop (Enable/Auto/Disable)	This setting specifies whether to enable early snooping. It is not supported if COD is enabled.	Enable = Function enabled  Auto = If this is not allowed in the system configuration and COD is disabled, early snoop mode is enabled  Disable = Function disabled
	Home Snoop Dir OSB (Enable/Auto/Disable)	This setting specifies whether to use Home Snoop Directory with plain OSB (Opportunistic Snoop Broadcast) caching to optimize snooping processes.	Enable = Function enabled  Auto = It is selected automatically based on the CPU configuration  Disable = Function disabled
Memory Configuration			
	NUMA (Enable/Disable)	This specifies whether to use NUMA (Non-Uniform Memory Access) function.  This is rendered meaningless when a multiprocessor configuration is not employed.  For BX920, BX924, RX200, RX300, and RX2520, this settings is supported only the devices on which the BIOS 1.3.0 of BX920 S4, BX924 S4, RX200 S8, RX300 S8, RX2520 M1, and the iRMC firmware 7.19F or later. In other devices, this setting must be disabled.	Enable = NUMA function enabled  Disable = NUMA function disabled
	DDR Performance (Low-Voltage optimized/Energy optimized/Performance optimized/Power balanced)	Memory modules operate with different speeds (Frequencies). The faster the speed, the higher the performance. The slower the speed the more the power saved. The available memory speeds	Low-Voltage optimized = The fastest setting available with low voltage  Energy optimized = The slowest setting available with power-saving

Item Name		Description	Parameter
		differ depending on the installed memory module configurations.	Performance optimized = The fastest setting available for achieving the highest performance  Power balanced = The setting available with reduced speed for achieving balance between power and performance
	Patrol Scrub (Enable/Disable)	This setting specifies whether to regularly screen all memories in the background.	Enable = Background memory screening enabled.  Disable = Background memory screening disabled
	IMC Interleaving (Auto/1-Way/2-Way)	This setting specifies the interleaving of Integrated Memory Controllers (IMC). This option can be used to create system performance depending on the memory configuration.	Auto = Interleaving is automatically selected in the BIOS depending on the memory configurations that can be used  1-Way = 1-Way interleaving is selected 2-Way = 2-Way interleaving is selected
	Sub NUMA Clustering (Enable/Disable/Auto)	Sub NUMA Clustering (SNC) is a function that segments LLC (Last Level Cache) into separate clusters based on the address range. It improves the average latency from the LLC to the local memory.	Enable = Full Sub NUMA Clustering, in other words, 2 clusters of 1-Way interleaving is supported.  Disable = Sub NUMA Clustering disabled  Auto = By selecting IMC interleaving, 1 cluster or 2 clusters are supported. Also if IMC interleaving is in "Auto," 1 cluster of 2-Way interleaving is supported
Onboard Device Configuration			
	Onboard SAS/SATA(SCU) (Enable/Disable)	This specifies Onboard SAS/SATA storage controller unit (SCU) behavior.	Enable = SCU enabled  Disable = SCU disabled
	SAS/SATA OpROM (Enable/Disable)	This item can be set up only when Onboard SAS/SATA (SCU) is Enable.  It specifies the Option ROM behavior of SAS/SATA controller.	Enable = Option ROM enabled  Disable = Option ROM disabled
	SAS/SATA Driver (LSI MegaRAID/Intel RSTe)	This item can be set up only when SAS/SATA OpROM is Enable.  It specifies the Option ROM type of SAS/SATA controller.	LSI MegaRAID = Option ROM for Embedded MegaRAID used  Intel RSTe = Option ROM for Intel RSTe used
	Flexible LOM (Enable/Disable)	This specifies whether to use Flexible LOM (OCP) ports.	Enable = Enable all Flexible LOM ports  Disable = Disable Flexible LOM ports
	Flexible LOM Oprom (Enable/Disable)	This specifies whether to boot Legacy Option ROM of a Flexible LOM adapter.  Only Legacy, that is, non-UEFI Option ROM can be used. UEFI Option ROM is not affected by this setting.	Enable = Boot Legacy Option ROM  Disable = Do not boot Legacy Option ROM
	LAN Controller (LAN 1/LAN 1 & 2/Disable)	This specifies the LAN controllers to use.	LAN 1 = Enable LAN 1 controller and disable LAN 2 controller  LAN 1 & 2 = Enable both of the LAN controllers

Item Name		Description	Parameter
		 <b>Note</b> ..... Depending on the model of the server, the BIOS settings value may be "Disable/Enable." If you want to make the BIOS setting value "Enable," specify "LAN 1" for this item. .....	Disable = Disable both of the LAN controllers
	LAN 1 Oprom (Disable/PXE/iSCSI)	This specifies whether to boot Option ROM. If booting, specify a type of Option ROM.  If the appropriate Option ROM is booted during BIOS POST, LAN controller can be used as a boot device.   <b>Note</b> ..... Depending on the model of the server, the BIOS settings value may be "Disable/Enable." If you want to make the BIOS setting value "Enable," specify "PXE" for this item. .....	Disable = Do not boot Option ROM PXE = Boot PXE Option ROM iSCSI = Boot iSCSI Option ROM
	LAN 2 Oprom (Disable/PXE/iSCSI)	This specifies whether to boot Option ROM. If booting, specify a type of Option ROM.  If the appropriate Option ROM is booted during BIOS POST, LAN controller can be used as a boot device.   <b>Note</b> ..... Depending on the model of the server, there may not be a LAN 2 controller. In this case, disable this item.  Depending on the model of the server, the BIOS settings value may be "Disable/Enable." If you want to make the BIOS setting value "Enable," specify "PXE" for this item. .....	Disable = Do not boot Option ROM PXE = Boot PXE Option ROM iSCSI = Boot iSCSI Option ROM
SATA Configuration			
	SATA Mode (Disable/IDE/AHCI/RAID)	This specifies the operation mode of the SATA interface.	Disable = Disable the operation mode IDE = Operate in IDE mode AHCI = Operate in AHCI mode RAID = Operate in RAID mode
	SATA Controller (Enable/Disable)	This specifies whether to enable SATA controller.	Enable = Enable the SATA controller Disable = Disable the SATA controller
	SSATA Controller (Enable/Disable)	This specifies whether to enable SSATA controller.	Enable = Enable the SSATA controller Disable = Disable the SSATA controller

Item Name		Description	Parameter
Option ROM Configuration			
	Launch Slot X OpROM (Enable/Disable)	<p>This specifies the execution of extended ROM of the option card mounted on each PCI slot.</p> <p>You can specify this for multiple slots in profile. Do not specify this for the slot that does not exist on an actual device.</p>	<p>Enable = Extended ROM executed</p> <p>Disable = Extended ROM not executed [Note 1]</p>
CSM Configuration			
	Launch CSM (Enable/Disable)	<p>This specifies whether to execute CSM (Compatibility Support Module).</p> <p>Your legacy operating system can be booted only when CSM is loaded.</p>	<p>Enable = CSM executed</p> <p>Disable = CSM not executed [Note 2]</p>
	Boot Option Filter (UEFI and Legacy/UEFI only/ Legacy only)	This specifies which drive can be booted first.	<p>UEFI and Legacy = Bootable from UEFI OS drive and Legacy OS drive</p> <p>UEFI only = Bootable only from UEFI OS drive [Note 3]</p> <p>Legacy only = Bootable only from Legacy OS drive [Note 3]</p>
	Launch PXE OpROM Policy (UEFI only/Legacy only/Do not launch)	<p>This specifies the PXE Option ROM to be booted.</p> <p>For PXE boot, there are available normal (Legacy) PXE boot and UEFI PXE boot.</p>	<p>UEFI only = UEFI Option ROM only booted [Note 3] [Note 4]</p> <p>Legacy only = Legacy Option ROM only booted [Note 3]</p> <p>Do not launch = Option ROM not booted [Note 5]</p>
	Launch Storage OpROM Policy (UEFI only/Legacy only/Do not launch)	This specifies the Storage Option ROM to be booted.	<p>UEFI only = UEFI Storage Option ROM only booted</p> <p>Legacy only = Legacy Storage Option ROM only booted</p> <p>Do not launch = Storage Option ROM not booted</p>
	Other PCI Device ROM Priority (UEFI only/Legacy only)	This specifies the Option Rom booted with the devices other than a network, mass storage device and video.	<p>UEFI only = UEFI Option ROM only booted</p> <p>Legacy only = Legacy Option ROM only booted</p>
USB Configuration			
	Onboard USB Controllers (Enable/Disable)	<p>The USB controller of the system board can be enabled and disabled.</p> <p>If the onboard USB controller is disabled, none of the connected USB devices can be used. Locally connected keyboard, mouse, large volume storage, including keyboards, mice, and large volume storage using iRMC, as well as internally connected USB cannot be used.</p>	<p>Disable = Disable Onboard USB Controllers</p> <p>Enable = Enable Onboard USB Controllers</p>
Network Stack			

Item Name		Description	Parameter
	Network Stack (Enable/Disable)	This sets up whether UEFI Network Stack can be used for network access on UEFI.	Disable = Use of UEFI network stack not permitted [Note 2] [Note 4] Enable = Use of UEFI network stack permitted
	IPv4 PXE Support (Enable/Disable)	This specifies whether PXE UEFI Boot with IPv4 can be used with UEFI mode.	Disable = Use of PXE UEFI Boot with IPv4 not permitted Enable = Use of PXE UEFI Boot with IPv4 permitted
	IPv6 PXE Support (Enable/Disable)	This specifies whether PXE UEFI Boot with IPv6 can be used with UEFI mode.	Disable = Use of PXE UEFI Boot with IPv6 not permitted Enable = Use of PXE UEFI Boot with IPv6 permitted
Secure Boot Configuration			
	Secure Boot Control (Enable/Disable)	<p>This specifies whether to allow boot loaders that have not been signed/UEFI OpROM boot.</p> <p> <b>Note</b></p> <p>.....</p> <p>This setting may not be "Disabled" due to the hardware specifications. In this case, specify the value from the BIOS interface of the server.</p> <p>.....</p>	<p>Disable = Execute all boot loaders/OpROM (Legacy/UEFI)</p> <p>Enable = Only execute signed boot loaders/UEFI OpROM</p>
Server Mgmt			
	Sync RTC with MMB (Enable/Disable) (Only PRIMERGY BX series)	This specifies whether to synchronize Real Time Clock with the management blade.	<p>Disable = Does not synchronize</p> <p>Enable = Synchronizes</p>
	Adjust Date Time (Local Time / UTC)	<p>This modifies the time of the server based on the time of management server when the profile is applied.</p> <p>This item can be set up only when Sync RTC with MMB is Disable.</p> <p> <b>Note</b></p> <p>.....</p> <p>This is not a setting item of the BIOS setup utility of the server.</p> <p>This does not change the BIOS setting, but change the time (RTC) of the target server only one time, and this can be used for all PRIMERGY BX series.</p> <p>.....</p>	<p>Local Time = Time according to the time zone of the management server is specified</p> <p>UTC = Time converted to UTC from the time zone of the management server is specified</p>

[Note 1]: Depending on the server model, PXE Boot may fail if Launch Slot X OpROM is "Disabled" for the PCI card slot used for PXE Boot.

[Note 2]: When both Launch CSM and Network Stack are "Disabled," OS installation fails.


[Note 3]: When Boot Option Filter is "UEFI only" or "Legacy only" and Boot Option Filter does not match Launch PXE OpRom Policy, OS installation fails.











[Note 4]: When Launch PXE OpROM Policy is "UEFI only" and Network Stack is "Disable," OS installation fails.




[Note 5]: When Launch PXE OpROM Policy is "Do not launch," OS installation fails.



## iRMC tab




Item Name	Description	Parameter
iRMC GUI		
Default Language (English/German/Japanese)	This performs initial settings for languages.  This is enabled from the next time iRMC Web interface is invoked.	English = English by default German = German by default Japanese = Japanese by default
Power Management		
POST Error Halt (Continue/Halt on errors)	This sets up the operation in response to the occurrence of an error upon server boot.	Continue = Boot continued even after the occurrence of an error Halt on errors = Boot interrupted until the key entry when an error occurs
Power Restore Policy (Restore to powered state prior to power loss/ Always power off/Always power on)	This sets up the power source operation upon power restore operation after interruption of AC power source input.	Restore to powered state prior to power loss = State upon power source interruption maintained (Powered on if a server is powered on upon interruption/ Not powered on if the server is powered off.) Always power off = Always powered off Always power on = Always powered on
Power Control Mode (OS Controlled/Minimum Power)	This sets up the power-saving and noise canceling operations for a server.   <b>Note</b> ..... When you disable Enhanced SpeedStep on BIOS settings, this setting also becomes disabled. .....	OS Controlled = Control with OS followed Minimum Power = Operation where priority is placed on reduction in power consumption (Schedule) = Setup with Profile Management unavailable (Power Limit) = Setup with Profile Management unavailable
Power Monitoring (Enable/Disable) [Note 3]	This specifies enable/disable over time of monitoring for power consumption.	Enable = Power consumption monitored Disable = Power consumption not monitored
Fan Test		
Fan Check Time	This becomes enabled when executing fan tests.	Enter the start time of fan test.
Disable Fan Test	This sets up whether to conduct periodical fan diagnoses.	(Selected) = Fan tests not conducted (Cleared) = Tests conducted every day at the specified time
Software Watchdog		
Software Watchdog (Enable/Disable)	This specifies whether to use software watchdog to perform periodic communication confirmations while an OS is running.	Enable = Communication monitored Disable = Communication not monitored


Item Name	Description	Parameter
	 <b>Note</b> ..... This setting becomes enabled after rebooting the server. .....	
Behavior	This specifies the behavior for the case when communication is disabled.  <b>Note</b> ..... This setting becomes enabled after rebooting the server. .....	Select the item from the pull-down menu. Continue = Nothing executed Reset = Server rebooted Power Cycle = Powered ON after powering OFF the server once
Timeout	This specifies the period for judging communication to be disabled.  <b>Note</b> ..... This setting becomes enabled after rebooting the server. .....	Specify the value from 1 to 100 minutes.
Boot Watchdog		
Boot Watchdog (Enable/Disable)	This specifies whether to monitor the period between POST completion and OS start, with use of Boot Watchdog.  <b>Note</b> ..... This setting becomes enabled after rebooting the server. .....	Enable = Period monitored Disable = Period not monitored
Behavior	This specifies behavior for the case when an OS does not start within the specified time.  <b>Note</b> ..... This setting becomes enabled after rebooting the server. .....	Select the item from the pull-down menu. Continue = Nothing executed Reset = Server rebooted Power Cycle = Powered ON after powering OFF the server once
Timeout	This specifies the period for judging that an OS has failed to start.  <b>Note</b> ..... This setting becomes enabled after rebooting the server. .....	Specify the value from 1 to 100 minutes.
Time		
Time Mode (System RTC/NTP Server)	This specifies whether to obtain the time setting of iRMC from a managed server or to obtain it from an NTP server.	System RTC = Time of iRMC obtained from the system clock of a managed server


Item Name		Description	Parameter
			NTP Server = Time of iRMC synchronized with that of an NTP server which operates based on specific time as its reference time source by using Network Time Protocol (NTP)
	RTC Time Mode (Local Time/UTC)	You can select whether to display iRMC time in UTC (Coordinated Universal Time) format or in local time format.	Local Time = iRMC time displayed in local time format UTC = iRMC time displayed in UTC (Coordinated Universal Time) format
	NTP Server 0	This specifies the IP address or the DNS name of the primary NTP server.	Enter the IP address or DNS strings.
	NTP Server 1	This specifies the IP address or the DNS name of the secondary NTP server.	Enter the IP address or DNS strings.
	Time Zone	You can set up the time zone corresponding to the location where the server is placed.	Select the item from the pull-down menu.
Ports and Network Services Settings			
	Telnet Enabled (Enable/Disable)	This specifies whether to enable Telnet connection.	Enable = Telnet connection enabled Disable = Telnet connection disabled
	Telnet Port (Default: 3172)	This specifies Telnet port number of iRMC.	Enter the port number. 3172 by default
	SSH Enabled (Enable/Disable)	This specifies whether to enable ssh connection.	Enable = ssh connection enabled Disable = ssh connection disabled
	SSH Port (Default: 22)	This specifies Telnet port number of ssh.	Enter the port number. 22 by default
	Session Drop Time (Enable/Disable) [Note 3]	This specifies the drop-out time.	Specify the value from 0 to 120 minutes. 0 = Session timeout disabled
SNMP Generic Configuration			
	SNMP Enabled	This specifies whether to enable SNMP.  <b>Note</b> ..... You cannot set up the setting items that are not shown on the Web UI screen of iRMC. Depending on the firmware versions, you cannot set up some setting items even though the setting items are shown on the Web UI screen of iRMC. Disable the setting items if you fail to assign a profile. .....	Enable = SNMP enabled Disable = SNMP disabled
	SNMP Port (Default: 161)	This specifies a port number where an SNMP service is in an idle state.  <b>Note</b> ..... You cannot set up the setting items that are not shown on the Web UI screen of	Enter the port number. UDP 161 by default

Item Name	Description	Parameter
	<p>iRMC. Depending on the firmware versions, you cannot set up some setting items even though the setting items are shown on the Web UI screen of iRMC. Disable the setting items if you fail to assign a profile.</p> <p>.....</p>	
SNMP Service Protocol (All (SNMPv1/v2c/v3)/ SNMPv3 only)	<p>This specifies the protocol of SNMP services.</p> <p> <b>Note</b></p> <p>.....</p> <p>You cannot set up the setting items that are not shown on the Web UI screen of iRMC. Depending on the firmware versions, you cannot set up some setting items even though the setting items are shown on the Web UI screen of iRMC. Disable the setting items if you fail to assign a profile.</p> <p>.....</p>	<p>All (SNMPv1/v2c/v3) = All protocols (SNMPv1/v2c/v3) supported</p> <p>Only SNMPv3 = Only SNMPv3 supported</p>
SNMP v1/v2c Community	<p>This specifies the community strings in the cases of SNMP v1/v2c.</p> <p> <b>Note</b></p> <p>.....</p> <p>You cannot set up the setting items that are not shown on the Web UI screen of iRMC. Depending on the firmware versions, you cannot set up some setting items even though the setting items are shown on the Web UI screen of iRMC. Disable the setting items if you fail to assign a profile.</p> <p>.....</p>	Enter the community name string
SNMPv3 User Configuration		
SNMPv3 Enabled (Enable/Disable)	<p>This specifies whether to enable SNMPv3 support for users.</p> <p> <b>Note</b></p> <p>.....</p> <ul style="list-style-type: none"> <li>- To create/change SNMPv3 users, it is required to enable SNMP with the [Network Settings] -&gt; [SNMP].</li> <li>- To use SNMPv3, it is required to set a password with at least 8 characters.</li> <li>- You cannot set up the setting items that are not shown on the Web UI screen of iRMC. Depending on the firmware versions, you cannot set up some setting items even though the setting items are shown on the Web UI screen of iRMC. Disable</li> </ul>	<p>Enable = SNMPv3 support enabled</p> <p>Disable = SNMPv3 support disabled</p>

Item Name	Description	Parameter
	the setting items if you fail to assign a profile. .....	
Access Privileges	<p>This specifies user's access privilege.</p> <p> <b>Note</b> .....</p> <ul style="list-style-type: none"> <li>- To create/change SNMPv3 users, it is required to enable SNMP with the [Network Settings] -&gt; [SNMP].</li> <li>- To use SNMPv3, it is required to set a password with at least 8 characters.</li> <li>- You cannot set up the setting items that are not shown on the Web UI screen of iRMC. Depending on the firmware versions, you cannot set up some setting items even though the setting items are shown on the Web UI screen of iRMC. Disable the setting items if you fail to assign a profile.</li> </ul> <p>.....</p>	Always read-only.
Authentication (SHA/MD5/None/SHA256/SHA384/SHA512)	<p>This selects the authentication protocol that SNMPv3 uses for authentication.</p> <p> <b>Note</b> .....</p> <ul style="list-style-type: none"> <li>- To create/change SNMPv3 users, it is required to enable SNMP with the [Network Settings] -&gt; [SNMP].</li> <li>- To use SNMPv3, it is required to set a password with at least 8 characters.</li> <li>- You cannot set up the setting items that are not shown on the Web UI screen of iRMC. Depending on the firmware versions, you cannot set up some setting items even though the setting items are shown on the Web UI screen of iRMC. Disable the setting items if you fail to assign a profile.</li> </ul> <p>.....</p>	<p>SHA = SHA used</p> <p>MD5 = MD5 used</p> <p>None = Authentication disabled</p> <p>SHA256 = SHA256 used</p> <p>SHA384 = SHA384 used</p> <p>SHA512 = SHA512 used</p>
Privacy (AES/DES/None)	<p>This specifies a privacy protocol that SNMPv3 uses for encrypting SNMPv3 traffic.</p>	<p>AES = AES used</p> <p>DES = DES used</p> <p>None = Privacy disabled</p>


Item Name	Description	Parameter
	 <b>Note</b> ..... <ul style="list-style-type: none"> <li>- To create/change SNMPv3 users, it is required to enable SNMP with the [Network Settings] -&gt; [SNMP].</li> <li>- To use SNMPv3, it is required to set a password with at least 8 characters.</li> </ul> ..... <p>You cannot set up the setting items that are not shown on the Web UI screen of iRMC. Depending on the firmware versions, you cannot set up some setting items even though the setting items are shown on the Web UI screen of iRMC. Disable the setting items if you fail to assign a profile.</p>	
SNMP Trap Destination		
SNMP Trap Community Name	This specifies an SNMP trap community.	Enter the SNMP trap community strings
SNMPv3 Selected User	<p>This specifies an SNMPv3 user already defined as an SNMPv3 trap destination.</p>  <b>Note</b> ..... <ul style="list-style-type: none"> <li>- The user specified in this item must have been previously created on the iRMC.</li> <li>- You cannot set up the setting items that are not shown on the Web UI screen of iRMC. Depending on the firmware versions, you cannot set up some setting items even though the setting items are shown on the Web UI screen of iRMC. Disable the setting items if you fail to assign a profile.</li> </ul> .....	Enter the SNMP user strings
Destination SNMP Server 1 to 7	This specifies the DNS name or the IP address of a server which belongs to the community set up as "Trap destination."	Enter the IP address or the DNS strings of an SNMP server.
Protocol	<p>This specifies the Version of SNMP protocol used for receiving traps.</p>  <b>Note</b> ..... <p>You cannot set up the setting items that are not shown on the Web UI screen of iRMC. Depending on the firmware versions, you cannot set up some setting items even though the setting items are shown on the Web UI screen of iRMC.</p>	Select the item from the pull-down menu. SNMPv1, SNMPv2c, SNMPv3


Item Name		Description	Parameter
		Disable the setting items if you fail to assign a profile. .....	
AIS Connect			
	AIS Connect	This specifies whether to enable AIS Connect.	Enable = Enable AIS Connect Disable = Disable AIS Connect
	Service Mode	This specifies whether to enable Service Mode.	Enable = Enable Service Mode Disable = Disable Service Mode
	Country	This specifies Reverse Proxy country when using AIS Connect.	Select a country name from the pull down menu.
	Remote Session	This specifies whether to allow Remote Session.	Allow = Remote session is allowed Deny = Remote session is denied
	Proxy Server	This specifies whether to use HTTP Proxy servers.	(Selected) = Use Proxy server (Cleared) = Do not use Proxy server
Proxy Server			
	Address	This specifies an IP address of the proxy server or the proxy server name.	Enter an IP address or the character string of the proxy server name.
	Port Number (Default: 81)	This specifies the port number of the proxy service.	Enter the port number Default: 81
	User Name	This specifies a user name to be authenticated by the proxy server.	Enter a character string of the proxy user name.
	Password	This specifies a password to be authenticated by the proxy server.	Enter a password string.
DNS			
	DNS	This specifies whether to enable DNS of iRMC.	(Selected) = Enable DNS (Cleared) = Disable DNS
	DNS Configuration	This specifies whether to obtain DNS configuration from the DHCP server.   <b>Note</b> ..... If you set "DNS Domain" "DNS Search Path" "DNS server 1-3," specify (Cleared) for this item.  When enabling this item, enable DHCP in advance. .....	(Selected) = Obtain DNS configuration from the DHCP server  (Cleared) = Do not obtain DNS configuration from the DHCP server
	DNS Domain	This specifies a default domain name for the DNS server.	Enter a DNS domain string.
	DNS Search Path	This specifies a list of DNS search paths.	Enter DNS search path strings.
	DNS Server 1 - 3	This specifies DNS server names.	Enter the IP address of a DNS server.
	DNS Retries	This specifies the number of times of DNS retry.	Specify a number of 1 - 5. Default: 2


Item Name		Description	Parameter
	DNS Timeout	This specifies the timeout value for the DNS response in seconds.	Specify a value between 1 - 30 seconds. Default: 5
DNS Name Registration			
	Register DNS Name	This specifies the setting method for the DNS names of iRMC.	None = Do not register a name on iRMC  Register DHCP Address in DNS via DHCP Server = Enable transfer a DHCP name to the DHCP server  Register Fully Domain Name (FQDN) via DHCP in DNS = Enable transfer FQDN to the DHCP server  DNS Update enabled = Enable updates DNS records using the dynamic DNS
	Use iRMC Name	The character string specified in "iRMC Name" is used instead of the server name.	(Selected) = Use iRMC name (Cleared) = Do not use iRMC name
	iRMC Name	<p>This specifies the iRMC name which is used as a part of the DNS name.</p> <p> <b>Note</b></p> <p>.....</p> <p>This specifies the iRMC name which is used as a part of the DNS name.</p> <p>Do not use a dot (".") except in the following cases because it may cause unexpected behavior.</p> <p>PRIMERGY RX/TX/CX M4 or later, and PRIMEQUEST 3000B</p> <p>.....</p>	Enter an iRMC name string.
	Use MAC Address	Specify whether to add the last three bytes of the MAC address of iRMC to the DHCP name of iRMC.	(Selected) = Add MAC address to DNS name (Cleared) = Do not add MAC address to DNS name
	Use Extension	This specifies whether to add an extension name which is specified as "Extension" to the DHCP name of iRMC.	(Selected) = Add an extension name (Cleared) = Do not add an extension name
	Extension	This specifies an extension name for iRMC.	Enter an extension name string.
Simple Service Discovery Protocol (SSDP)			
	SSDP	This specifies whether to enable automatic discovery via SSDP.	(Selected) = Enable automatic discovery (Cleared) = disable automatic discovery
Central Authentication Service (CAS)			
	CAS Support	This specifies whether to enable CAS.	(Selected) = Enable CAS (Cleared) = Disable CAS
CAS Server [Note 1]			



Item Name	Description	Parameter
Server	This specifies the DNS name or the IP address of the CAS server.	Enter the IP address or the DNS name string.
Network Port	This specifies the Port number which CAS service is standing by.	Enter the Port number. Default: 3170
SSL Certificate Verification	This specifies whether to enable SSL Certificate Verification.	(Selected) = Verify SSL Certificate (Cleared) = Do not verify SSL Certificate
Login Page Display	This specifies whether to always display the Login page.	(Selected) = Always display the login page. (Cleared) = Do not always display the login page.
Login URL	This specifies a Login URL.	Enter a login URL. Default: /cas/login
Logout URL	This specifies a Logout URL.	Enter a logout URL. Default: /cas/logout
Validate URL	This specifies Validate URL.	Enter the Validate URL. Default: /cas/validate
Assign Permission from	This specifies an access permission.	It will always be set to Local.
User Access Configuration [Note 1]		
Privilege Level	This specifies the privilege level of the user.	User = Use User privilege Operator = Use Operator privilege Administrator = Use Administrator privilege OEM = Use OEM privilege
Redfish Role	This specifies a Redfish role.	Administrator = Use Administrator role Operator = Use Operator role ReadOnly = Use ReadOnly role No Access = Do not use Redfish
User Account Configuration	This specifies whether to enable User Account Configuration.	(Selected) = Allow user account configuration (Cleared) = Do not allow user account configuration
iRMC Settings Configuration	This specifies whether to enable iRMC Settings Configuration.	(Selected) = Allow iRMC settings configuration (Cleared) = Do not allow iRMC settings configuration
Video Redirection Usage	This specifies whether to enable Video Redirection Usage.	(Selected) = Allow Video Redirection usage (Cleared) = Do not allow Video Redirection usage
Remote Storage Usage	This specifies whether to enable the Remote Storage Usage.	(Selected) = Allow remote storage usage (Cleared) = Do not allow remote storage usage

Item Name		Description	Parameter
BIOS Backup			
	Automatic BIOS Parameter Backup	This specifies whether to enable Automatic BIOS Parameter Backup.   <b>Note</b> ..... This setting becomes enabled after rebooting the server. .....	(Selected) = Automatic BIOS Parameter Backup enabled  (Cleared) = Automatic BIOS Parameter Backup disabled.
Update [Note 2]			
	Repository Location	This specifies the URL for the update repository that uses eLCM update.	Enter the URL for the update repository.  Default: "https://support.ts.fujitsu.com"
	Proxy Server	This specifies whether to use a proxy server to connect to the update repository.	(Selected) = Use proxy server (Cleared) = Do not use proxy server
	VMware HCL Verification	This specifies whether to skip VMware hardware compatibility verification.	(Selected) = Skip (Cleared) = Do not skip
	SSL/TLS Certificate Verification	This specifies whether to skip SSL/TLS Certificate Verification.	(Selected) = Skip (Cleared) = Do not skip
Deployment [Note 2]			
	Repository Location	This specifies the URL for the deployment repository that uses eLCM update.	Enter the URL of the deployment repository.  Default: "https://webdownloads.ts.fujitsu.com"
	Proxy Server	This specifies whether to use a proxy server to connect to the deployment repository.	(Selected) = Use proxy server (Cleared) = Do not use proxy server
	SSL/TLS Certificate Verification	This specifies whether to skip SSL/TLS Certificate Verification.	(Selected) = Skip (Cleared) = Do not skip
Web Access [Note3]			
	Force HTTPS (Enable/Disable)	This specifies the method to use HTTPS.	Enable = HTTPS connections only Disable = HTTP connections available
	Security Protocols (ISM 2.9.0.010 or later)	This specifies the security protocols.	
	TLS 1.1 (Enable/Disable)	This specifies enable/disable TLS 1.1.	Enable = TLS 1.1 enabled Disable = TLS 1.1 disabled
	TLS 1.2 (Enable/Disable)	This specifies enable/disable TLS 1.2.	Enable = TLS 1.2 enabled Disable = TLS 1.2 disabled
Advanced Video Redirection (AVR) [Note 3]			
	KVM Redirection Type	This specifies KVM redirection type.	JViewer (JAVA) = Use AVR via JAVA HTML5 Viewer = Use AVR via HTML5 VNC = Connect with VNC

Item Name		Description	Parameter
	Window Title (ISM 2.9.0.010 or later)	This specifies the AVR window title.	Enter the parameter to display in the window.  Initial value is "%USER% @ %BMC_NAME% "
BIOS Console Redirection [Note 3]			
	Console Redirection (Enable/Disable)	This specifies enable/disable of the console redirection.	Enable = Enables the console redirection Disable = Disable the console redirection
	Serial Port Baud Rate	This specifies the baud rate for serial port.	Specifies the following baud rate. 9600/19200/38400/57600/115200
	Serial Port Flow Control	This specifies the flow control for serial port.	No flow control imposed = Do not execute flow control CTS/RTS (hardware) = Communication control is executed by hardware
	Serial 1 Multiplexer	This specifies consistency with the multiplexer configuration.	System = Serial iRMC = LAN
User Management (ISM 2.9.0.010 or later) [Note 3]			
	Change Admin Password	This specifies an Admin user password.   <b>Note</b> ..... Specify a user other than admin as the user specified during node registration (communication method). If admin is specified, communication to the node will be failed. .....	Enter a password string.
	LDAP (Enable/Disable)	This specifies the enable/disable of the LDAP.	Enable = enables LDAP Disable = disables LDAP
	LDAP SSL/TLS (Enable/Disable)	This specifies the enable/disable of the LDAP SSL/TLS.	Enable = enables LDAP SSL/TLS Disable = disables LDAP SSL/TLS
	Primary LDAP Server	This specifies the primary LDAP server.	Enter the primary LDAP server strings.
	Authorization Type	This specifies the authorization type.	Select the following: ServerView LDAP Group with Authorization Settings on LDAP Server Standard LDAP Group with Authorization Settings on iRMC
	Domain Name	This specifies the domain name.	Enter the domain name strings.
	Groups Directory as Sub-tree from Base DN	This specifies the group directory under the base DN.	Enter the group directory strings.
	Authorization LDAP Username	This specifies the authorization LDAP username..	Enter the authorization LDAP username strings.
	Authorization LDAP Password	This specifies the authorization LDAP password.	Enter the authorization LDAP user password strings.

Item Name		Description	Parameter
	User Group Name	<p>This specifies the LDAP user group name.</p> <p>This can be specified only if you specify "Standard LDAP Group with Authorization Settings on iRMC" for "Authorization Type".</p> <p> <b>Note</b></p> <p>Specify this option only when no user group has been created on the node. When a user group already exists, no user group is created on the node side.</p>	Enter the LDAP user group strings.
Network Management (ISM 2.9.0.010 or later) [Note 3]			
	IPv6 Protocol (Enable/Disable)	This specifies enable/disable of the IPv6 protocol.	<p>Enable = enables HP SIM Integration</p> <p>Disable = disables HP SIM Integration</p>
Server Management [Note3]			
	HP SIM Integration (Enable/Disable)	This specifies enable/disable of the HP System Insight Manager (HP SIM).	<p>Enable = enables HP SIM Integration</p> <p>Disable = disables HP SIM Integration</p>
	Get System GUID Response Format	This specifies the response format for the Get System GUID command.	<p>Select the following:</p> <p>IPMI specification compatible</p> <p>SMBIOS 2.6 specification compatible</p>

[Note 1]: If you specify "CAS Server" and "User Access Configuration," select (Selected) for this item.

[Note 2]: An eLCM license must be registered on the target server and a SD card must be mounted when setting "Update" or "Deployment."

[Note 3]: PRIMERGY BX series are not supported.

# Chapter 2 MMB Setting Items of Profiles for PRIMEQUEST 2000 (Partition)/PRIMEQUEST 2000B/ PRIMEQUEST 3000E Series Partitions

This section describes the items that you can set up in the MMB tab in profiles.

## MMB Tab

Item Name		Description	Parameter
ASR (Automatic Server Restart)			
	Targeted	Specify whether to set ASR (Automatic Server Restart)	(Selected) = Execute settings (Cleared) = Do not execute settings
	Number of Restart Tries	Set the number of retries to restart the OS if the OS shuts down because of watchdog or a hardware error.	Select whether to use restart and the number of restarts (1 - 10).
	Action after exceeding Restart Tries	Set the action to take after the number of retries set above.	Power OFF = Stop reboot and turn the power of the partitions OFF (Stop rebooting and Power Off) Stop = Stop reboot and stop partitions (Stop rebooting) NMI Interruption = Stop reboot and assert NMI interruption for the partitions (Diagnostic Interrupt assert)
Boot Watchdog			
	Targeted	Specify whether to set the boot watchdog.	(Selected) = Execute settings (Cleared) = Do not execute settings
	Boot Watchdog	This means enable/disable of Boot Watchdog. Specify whether to monitor the time before OS start.	Enable = Time monitored Disable = Period not monitored
	Timeout time (seconds)	If the time set here is exceeded and the OS does not start it is judged to be an error.	Specify a value between 1 - 6000 seconds.
	Action when watchdog expires	Specify the action taken if the OS does not start after the time specified has been exceeded.	Continue = Continue processing Reset = Restart Power Cycle = The power is first turned OFF, then turned ON
Software Watchdog			
	Targeted	Specify whether to set the software watchdog.	(Selected) = Execute settings (Cleared) = Do not execute settings
	Software Watchdog	This means enable/disable of Software Watchdog. Specify whether to execute regular communication checks while the OS is running.	Enable = Communication checked Disable = Communication not checked
	Timeout time (seconds)	If the time set here is exceeded and there is no communication it is judged to be an error.	Specify a value between 1 - 6000 seconds.

Item Name				Description	Parameter
			Action when watchdog expires	Specify the action taken if there is no communication after the time specified has been exceeded.	Continue = Continue processing Reset = Restart Power Cycle = The power is first turned OFF, then turned ON NMI = Make NMI occur

## Chapter 3 OS Setting Items of Profiles for Servers

This section describes the items that you can set up with the OS/OS (for each node) tabs, in profiles. When it comes to the items with "Omittable", you can install the OSes without setup on the profiles. If omitted, no setting is applied, or the default settings of OSes are applied.

By creating policies in advance, you can use them for profile creation, however, you cannot specify items described as "cannot be set by policy setting" by using a policy. Execute setting when you create a profile.

### 3.1 Profiles for Windows Server

For information on which OSs can be specified in the profile, refer to "Support Matrix."


<https://support.ts.fujitsu.com/index.asp>

Select [Select a new Product] on the above site and enter "Infrastructure Manager" in [Product Search:].

Select [DOWNLOADS] and select the target operating system.

The reference procedures are subject to change without notice.

#### OS tab

Item Name	Description	Parameter
Installation Form		
Installation Method	<p>This selects the installation method.</p> <p> <b>Note</b></p> <p>.....</p> <ul style="list-style-type: none"> <li>- An eLCM license must be registered, an SD card must be mounted, and eIM must be downloaded when selecting eLCM.</li> <li>- You cannot select eLCM for PRIMEQUEST2000-Partition, PRIMEQUEST2000B, or PRIMEQUEST3000E-Partition.</li> </ul> <p>.....</p>	Select the item from the pulldown menu.
Installation Image		
Type of Installation	This specifies to install an OS with core installation or with full installation.	Select from the screen.
Type of Installation Media [Note 13] [Note 14]	This selects the type of media used for installation.	<p>Select the item from the pull-down menu.</p> <p>When you select Microsoft Media, then it is required to enter its product key.</p>
ServerView Suite DVD (Install Latest Version/Specify Version)	This specifies the version of ServerView Suite DVD used for installation.	<p>Install Latest Version = The latest version of ServerView Suite registered in the repository used.</p> <p>Specify Version = ServerView Suite with the specified version used</p>
Management LAN network port settings		
Network port specification	This specifies the port of the network used for Management LAN.	(Selected) = Specify the network port for Management LAN.

Item Name		Description	Parameter
	Method to specify	This selects the method of specifying the network port for Management LAN. [Note 1] [Note 2]	Select the item from the pull-down menu.
	Network Card	This is set if you specify "Port Number" in Method to specify.  Select the type of network card that you use.	Select from the screen.  Enter the slot number in which the card is installed.
	Port Number	This is entered if you specify "Port Number" in Method to specify.	Enter the port number that you use.
	MAC Address [Note 13]	This is entered if you specify "MAC address" in Method to specify.	Enter the MAC address of the network that you use.
	Boot mode specification	This specifies boot mode.	(Selected) = Specify the boot type
	Boot Type	This is selected when the boot mode of the server was changed or when specifying it explicitly.	Select the boot type used from the screen.
RAID & Disk Configuration			
	Use Array Controller	This is selected when you use a server-built-in array controller as an OS installation destination.	(Selected) = Array controller used [Note 3]
	Use existing RAID Volume (Select it even though RAID is not used.)	This uses the volume already created on an array controller.	(Selected) = Existing array configuration used
	Create new RAID Volume	This configures a new array and creates a volume in the array to use it.	(Selected) = A new array configured  Additionally, select the type of array controller, RAID level and the number of disks installed in the RAID, from the pull-down menu.
	Do not use Array Controller	This is selected when you use a drive other than the array controller as an OS installation destination.	(Selected) = Drive other than array controller used  Additionally, select the type of the drive that you use from the screen. [Note 4]
Volume 1			
	Volume Label	This specifies a volume name. [Note 5]	Enter the volume name strings. [Note 6]
	File System	This specifies the type of a file system.	Always NTFS
	Partition Size (Automatic/Manual)	This specifies a partition size.	Automatic = Partition with appropriate size automatically created  Manual = Partition with the entered size created
	Quick Format	This specifies whether to use Quick Format in formatting a partition.	Yes = Quick Format performed  No = Usual formatting performed (It takes longer time.)
	Usage	This specifies the purpose of use of a partition.	Always Boot or OS.
Basic Settings			
	Time Zone	This specifies a time zone.	Select the item from the pull-down menu.



Item Name		Description	Parameter
	Region and Language	This specifies a region and language.	Select the item from the pull-down menu.
	Keyboard	This specifies the language and type of keyboard.	Select the item from the pull-down menu.
System Settings			
	Display Resolution [px]	This specifies the display resolution immediately after OS installation.	Select the item from the pull-down menu. [Note 7]  Example: 600x480, 800x600, 1024x768 or 1280x1024
	Refresh Rate [Hz]	This specifies the display refresh rate immediately after OS installation.	Select the item from the pull-down menu. [Note 7]
	# of Colors [bit]	This specifies the number of colors displayed on a screen immediately after OS installation, with bit count.	Select the item from the pull-down menu. [Note 7]
Adding Role and Features			
	Install SNMP Service		This specifies whether to install SNMP services.  (Selected) = SNMP services installed
	SNMP Trap Setting		This specifies the community name and trap destination upon sending SNMP traps.  Select the Add button to set up arbitrary value. [Omittable]
		Community Name	This specifies community name when sending SNMP traps.  Enter the community name strings when sending.
		Trap Destination	This specifies the destination to send SNMP traps.  Enter the character strings of IP address for the destination.
	SNMP Security Service [Note 15]		This specifies the name of an acceptable SNMP community and its privilege.  Select the Add button to set up arbitrary value. [Omittable]
		Accepted Community Name	This specifies the name of an acceptable SNMP community.  Enter the community name strings of acceptable community.
		Community Grant	This specifies the privilege of acceptable SNMP community grant.  Select the item from the pull-down menu.  None = None Read Create = Read, Create Read Write = Read Write Read Only = Read Only Notify = Notification
	Send Authentication Trap		This specifies whether to send authentication traps in response to the SNMP request from an unknown host or community.  (Selected) = Authentication traps sent (Cleared) = Authentication traps not sent
	Acception of SNMP Packets (Accept SNMP Packets from Default Host (LocalHost)/Accept SNMP Packets from These Hosts)		This specifies whether to accept SNMP packets from Localhost.  (Accept SNMP Packets from Default Host (LocalHost)) = SNMP packets accepted from Localhost  (Accept SNMP Packets from These Hosts) = SNMP packets accepted from the following specified host name.

Item Name		Description	Parameter
			Additionally, the host names are described.
	SNMP Setting Agent	Enter a contact and its physical location.	You can use character strings that contain Japanese. [Omittable]
	Service	This specifies the information about SNMP hosts from 5 options.	Arbitrary service checked
Remote Desktop		This specifies whether Remote Desktop is available.	(Selected) = Remote Desktop enabled (Cleared) = Remote Desktop disabled
Remote Assistance (Only when the type of installation is full installation)		This specifies whether Remote Assistance is available.	Specify the permissible scope on the screen. Specify Invitation Ticket Time as required.
Firewall Settings		<p>This creates a firewall exception required in registering a target server with SCVMM.</p> <p>Access from the following applications is enabled.</p> <ul style="list-style-type: none"> <li>- Windows Management Instrumentation(WMI)</li> <li>- File and Printer Sharing</li> </ul>	<p>(Selected) = Firewall exception created</p> <p>(Cleared) = Firewall exception not created</p>
Additional Application			
	Java Runtime Environment	<p>Specify whether to install Java Runtime Environment.</p> <p>You must specify this when you install ServerView RAID Manager.</p>	(Selected) = Install Application [Note 8] [Note 9]
	ServerView Agent	<p>This specifies whether to install ServerView Agent.</p> <p>You can specify it when you install SNMP services.</p>	(Selected) = Install Application [Note 10]
	ServerView Update Agent	<p>This specifies whether to install ServerView Update Agent.</p> <p>You can specify it when you install ServerView Agent.</p>	(Selected) = Install Application [Note 10]
	DSNAP (Japanese Version)	This specifies whether to install DSNAP.	(Selected) = Install Application [Note 11]
	Software Support Guide	This specifies whether to install Software Support Guide.	(Selected) = Install Application [Note 11]
	ServerView RAID Manager	This specifies whether to install ServerView RAID Manager.	(Selected) = Application installed
Execute Script after Installation			
	Execute Script after Installation	This specifies whether to execute a script after installation.	(Selected) = Execute Script after Installation
	The directory forwarded to OS	This specifies the directory forwarded to an OS after installation.	Specify the directory forwarded to the OS after installation.

Item Name		Description	Parameter
	Execute Script after Installation	This specifies the script to be executed. [Note 12]	Specify the script to be executed.

[Note 1]: If the Universal Multi-Channel (UMC) function of the CNA card is enabled, set the MAC address and not the port number.

[Note 2]: For the PRIMEQUEST 2000 (Partition)/PRIMEQUEST 2000B/PRIMEQUEST 3000E series, it cannot be set depending on the port number. If specifying the network port, specify the MAC address.

[Note 3]: If using an array controller, set it so that there are no inconsistencies with the "Onboard Device Configuration" settings for the BIOS. If the server to which the profile is assigned has more than one array controller, disable all but the array controller to be configured.

[Note 4]: Refer to the manuals for the servers and the ServerView Suite DVD for iSCSI support.

[Note 5]: If using ServerView Suite DVD V11.16.04 or later, the volume name might not be set. In this case, set the volume name manually.

[Note 6]: Volume names must be set with one-byte alphanumeric characters/symbols for Windows Server 2016.

[Note 7]: This is installed with default settings when you set up a value unsupported by the OS.

[Note 8]: This is only possible to install when Full Installation has been selected in the "Type of Installation" setting.

[Note 9]: For ServerView Suite DVD V13.18.12 or later, this is not installed even if it is specified.

[Note 10]: The application is installed in Japanese when you select Japanese on "Region and Language" settings. Otherwise, the application is installed in English.

[Note 11]: This can be installed only when you select Japanese on "Region and Language" settings.

[Note 12]: The specified script is executed with Windows "cmd /c" command.

[Note 13]: Product keys and MAC addresses cannot be set with policies. Set these when creating profiles.

[Note 14]: When you log in to the OS after installing Windows Server 2019, the following pop-up window is displayed. Select "This program installed correctly" since the installation completed successfully.

Message: This program might not have installed correctly.

Program: SVIM Messenger

[Note 15]: If you selected "ServerView Agent" in the "Additional Applications" setting, automatically sets the SNMP community (Community Name: public) required for ServerView agent operation. If the community name is "public," set only the specified public.

## OS (for each node) tab

Item Name		Description	Parameter
Type of Installation Media		This selects the type of media used for installation.	Always the installation media specified on OS tab
User Name		A user name is entered.	Enter the user name.
Organization		The organization to which a user belongs is entered.	Enter the organization.
Computer Name [Note 5]		The name of a computer for identifying it on the network is entered.	Enter the computer name.
Administrator Password		A password is entered.	Enter the password.
Work Group/Domain			
	Work Group/Domain	You select one of Work Group or Domain to participate in.	Work Group = Participation in Work Group Domain = Participation in Domain [Note 1]
	Work Group/Domain Name	This specifies the name of Work Group or Domain.	Enter the character string. [Note 2]

Item Name		Description	Parameter
	Domain User Name	A domain user name for the case of Domain is entered.	Enter the character string.
	Domain Password	A password for the case of Domain is entered.	Enter the character string. [Note 3]
Network			
	DHCP	This selects whether to specify a fixed IP address or use DHCP for the IP address of Management LAN.	(Selected) = DHCP used (Cleared) = Fixed IP specified [Note 4]
	IP Address [Note 5]	A fixed IP address is specified when you do not use DHCP.	Enter the IP address in IPv4 format.
	Subnet Mask	A subnet mask is specified when you do not use DHCP.	Enter the subnet mask in IPv4 format.
	Default Gateway	A gateway is specified when you do not use DHCP.	Enter the IP address of the gateway in IPv4 format.
	DNS Server 1	The IP address of DNS server 1 is specified when you do not use DHCP.	Enter the IP address of the DNS server in IPv4 format.
	DNS Server 2	The IP address of DNS server 2 is specified after setting up DNS server 1 when you do not use DHCP.	Enter the IP address of the DNS server in IPv4 format.
	DNS Domain Name	An arbitrary domain name is specified when you do not use DHCP.	Enter the domain name.

[Note 1]: This is set up for Work Group when you are unable to connect to the domain server.

[Note 2]: Set a work group name within 15 characters. A double-byte character is counted as 2 characters and single-byte character is counted as 1 character.

[Note 3]: If the domain user name/domain password are specified incorrectly, the profile assignment ends normally, but domain participation fails. In this case, execute domain participation again.

[Note 4] When using a policy to change "DHCP" from (Selected) or "unspecified" to (Cleared), set the IP address of a linked profile after deleting the link that the policy refers to.

[Note 5]: Computer names and IP addresses cannot be set with policies. Set these when creating profiles.

## 3.2 Profiles for VMware ESXi

For information on which OSs can be specified in the profile, refer to "Support Matrix."

<https://support.ts.fujitsu.com/index.asp>


Select [Select a new Product] on the above site and enter "Infrastructure Manager" in [Product Search:].

Select [DOWNLOADS] and select the target operating system.

The reference procedures are subject to change without notice.

### OS tab

Item Name		Description	Parameter
Installation Image			
	Type of Installation Media	This selects the type of media used for installation.	Select the item from the pull-down menu.

Item Name		Description	Parameter
	ServerView Suite DVD (Install Latest Version/Specify Version)	This specifies the version of ServerView Suite DVD used for installation.	Install Latest Version = The latest version of ServerView Suite registered in the repository used.  Specify Version = ServerView Suite with the specified version used
Installation Information			
	Installation Method	This selects the installation method.   <b>Note</b> ..... - An eLCM license must be registered, an SD card must be mounted, and eIM must be downloaded when selecting eLCM.  - You cannot select eLCM for PRIMEQUEST2000-Partition, PRIMEQUEST2000B, or PRIMEQUEST3000E-Partition. .....	Select the item from the pulldown menu.
Management LAN network port settings			
	Network port specification	This specifies the port of the network used for Management LAN.	(Selected) = Specify the network port for Management LAN.
	Method to specify	This selects the method of specifying the network port for Management LAN. [Note 1] [Note 2]	Select the item from the pull-down menu.
	Network Card	This is set if you specify "Port Number" in Method to specify.  Select the type of network card that you use.	Select from the screen.  Enter the slot number in which the card is installed.
	Port Number	This is entered if you specify "Port Number" in Method to specify.	Enter the port number that you use.
	MAC Address [Note 7]	This is entered if you specify "MAC address" in Method to specify.	Enter the MAC address of the network that you use.
Boot mode specification			
	Boot mode	This specifies boot mode.	(Selected) = Specify the boot type
	Boot Type	This is selected when the boot mode of the server was changed or when specifying it explicitly.	Select the boot type used from the screen.
RAID & Disk Configuration			
	Use Array Controller	This is selected when you use a server-built-in array controller as an OS installation destination.	(Selected) = Array controller used [Note 3] [Note 4]
	Use existing RAID Volume (Select it even though RAID is not used.)	This uses the volume already created on an array controller.	(Selected) = Existing array configuration used
	Create new RAID Volume	This configures a new array and creates a volume in the array to use it.	(Selected) = A new array configured

Item Name		Description	Parameter
			Additionally, select the type of array controller, RAID level and the number of disks installed in the RAID, from the pull-down menu.
	Do not use Array Controller	This is selected when you use a drive other than the array controller as an OS installation destination.	(Selected) = Drive other than array controller used  Additionally, select the type of the drive that you use from the screen. [Note 5]
Basic Settings			
	Keyboard	This specifies the language and type of keyboard.	Select the item from the pull-down menu.
Network			
	Setup	This specifies whether to make a setup with VM Standard Network.	(Selected) = Standard Network created
	VLAN ID to Use	Enter VLAN ID. "0" is entered when you do not use VLAN.	Enter VLAN ID.
Register to Cloud Management Software			
	Register to Cloud Management Software	<p>This specifies whether to automatically register on vCenter subsequently after completion of ESXi installation.</p> <p>Set a fixed IP address as the IP address set by using [OS (for each node)] tab if you perform the automatic registration. Additionally, specify "0" to VLAN ID on the [OS] tab.</p> <p>If you specified the computer name and the DNS domain name in the [OS (for each node)] tab, use FQDN and register it to the Cloud Management Software.</p> <p>If you are using FQDN to register to the Cloud Management Software, it will be registered in all lower case letters.</p>	<p>(Selected) = Register</p> <p>(Cleared) = Do not register</p>
	Cloud Management Software Name to register host with	This specifies the vCenter of the registration destination.	Select [Settings] - [General] - [Cloud Management Software], and then select from the registered destinations on the screen.
	Folder Name or Cluster Name to register host with	This specifies the folder name or the cluster name of the registration destination.	Specify the folder name or the cluster name of the registration destination.
Execute Script after Installation			
	Execute Script after Installation	This specifies whether to execute a script after installation.	(Selected) = Execute Script after Installation
	The directory of Script	This specifies the directory in which the script executed after installation is stored.	Specify the directory in which the script executed after installation is stored.
	Execute Script after Installation	This specifies the script executed after installation. [Note 6]	Specify the script executed after installation.

[Note 1]: If the Universal Multi-Channel (UMC) function of the CNA card is enabled, set the MAC address and not the port number.

[Note 2]: For the PRIMEQUEST 2000 (Partition)/PRIMEQUEST 2000B/PRIMEQUEST 3000E series, it might not be possible to specify this depending on the port number. If specifying the network port, specify the MAC address.

[Note 3]: If using an array controller, set it so that there are no inconsistencies with the "Onboard Device Configuration" settings for the BIOS. If the server to which the profile is assigned has more than one array controller, disable all but the array controller to be configured.

[Note 4]: "Onboard SATA array controllers" cannot be used in VMware ESXi.

[Note 5]: Refer to the manuals for the servers and the ServerView Suite DVD for iSCSI support.

[Note 6]: Describe the script with plain text format in the file. This is executed as %post processing during automatic installation (kickStart). %firstboot --interpreter=busybox description allows it to be executed as %firstboot --interpreter=busybox processing.

[Note 7]: MAC addresses cannot be set with policies. Set these when creating profiles.

## OS (for each node) tab

Item Name		Description	Parameter	
License Agreement		This selects whether to agree with VMware License Agreement.  Make sure to check the box to show that you accept.	(Selected) = Agreement with VMware License  (Cleared) = Not in agreement with VMware License	
Type of Installation Media		This selects the type of media used for installation.	It is always the installation media specified in the OS tab	
Root Password		A password is entered.	Enter the password.	
Network				
	DHCP		This selects whether to specify a fixed IP address or use DHCP for the IP address of Management LAN.  (Selected) = DHCP used (Cleared) = Fixed IP specified  [Note 1]	
		IP Address [Note 2]	A fixed IP address is specified when you do not use DHCP.	Enter the IP address in IPv4 format.
		Subnet Mask	A subnet mask is specified when you do not use DHCP.	Enter the subnet mask in IPv4 format.
		Default Gateway	A gateway is specified when you do not use DHCP.	Enter the IP address of the gateway in IPv4 format.
		DNS Server [Note 3]	The IP address of the DNS server is specified when you do not use DHCP.	Enter the IP address of the DNS server in IPv4 format.
		DNS Domain Name	An arbitrary domain name is specified when you do not use DHCP.	Enter the domain name.
		Get Computer Name Via DNS Server	This specifies whether to use the computer name obtained from DNS.  A computer name is retrieved from the DNS server when you use DHCP.  An arbitrary computer name is specified when you do not use DHCP.	(Selected) = Obtained from DNS (Cleared) = Arbitrary computer name specified  [Note 4]
		Computer Name [Note 2]	Arbitrary computer name (host name) is specified when you do not obtain a computer name (host name) from DNS.	Enter the host name.

[Note 1]: When using a policy to change "DHCP" from (Selected) or "unspecified" to (Cleared), set the IP address of a linked profile after deleting the link that the policy refers to.

[Note 2]: IP addresses and computer names cannot be set with policies. Set these when creating profiles.

[Note 3]: If you want to set multiple DNS servers, set these with the script executed after the installation.

Setup can be made by entering "esxcli network ip dns server add --server=<IP address of the DNS server>."

Example of script entry:

```
#!/bin/sh
%firstboot --interpreter=busybox
esxcli network ip dns server add --server=<IP address of the DNS server>
```

[Note 4]: When using a policy to change "Get Computer Name from DNS Server" from (Selected) or "unspecified" to (Cleared), set the computer name of a linked profile after deleting the link that the policy refers to.

## 3.3 Profiles for Red Hat Enterprise Linux

For information on which OSs can be specified in the profile, refer to "Support Matrix."


<https://support.ts.fujitsu.com/index.asp>

Select [Select a new Product] on the above site and enter "Infrastructure Manager" in [Product Search:].

Select [DOWNLOADS] and select the target operating system.


The reference procedures are subject to change without notice.

### OS tab

Item Name	Description	Parameter
Installation Image		
Type of Installation Media	This selects the type of media used for installation.	Select the item from the pull-down menu.
ServerView Suite DVD (Install Latest Version/Specify Version)	This specifies the version of ServerView Suite DVD used for installation.	Install Latest Version = The latest version of ServerView Suite registered in the repository used.  Specify Version = ServerView Suite with the specified version used
Installation Information		
Installation Method	This selects the installation method.   <b>Note</b> ..... <ul style="list-style-type: none"><li>- An eLCM license must be registered, an SD card must be mounted, and eIM must be downloaded when selecting eLCM.</li><li>- You cannot select eLCM for PRIMEQUEST2000-Partition, PRIMEQUEST2000B, or PRIMEQUEST3000E-Partition.</li></ul> .....	Select the item from the pulldown menu.
Management LAN network port settings		
Network port specification	This specifies the port of the network used for Management LAN.	(Selected) = Specify the network port for Management LAN.
Method to specify	This selects the method of specifying the network port for Management LAN. [Note 1] [Note 2]	Select the item from the pull-down menu.



Item Name			Description	Parameter
		Network Card	This is set if you specify "Port Number" in Method to specify.  Select the type of network card that you use.	Select from the screen.  Enter the slot number in which the card is installed.
		Port Number	This is entered if you specify "Port Number" in Method to specify.	Enter the port number that you use.
		MAC Address [Note 9]	This is entered if you specify "MAC address" in Method to specify.	Enter the MAC address of the network that you use.
	Boot mode specification		This specifies boot mode.	(Selected) = Specify the boot type
		Boot Type	This is selected when the boot mode of the server was changed or when specifying it explicitly.	Select the boot type used from the screen.
Basic Settings				
	Region and Language		This specifies a language.	Select the item from the pull-down menu.
	Keyboard		This specifies the type of a keyboard.	Select the item from the pull-down menu.
	Time Zone		This specifies a time zone.	Select the item from the pull-down menu.
		System clock uses UTC	This specifies the type of time used as System Clock.	(Selected) = UTC used (Cleared) = Local time used
RAID & Disk Configuration				
	Use Array Controller		This is selected when you use a server-built-in array controller as an OS installation destination.	(Selected) = Array controller used [Note 10]
		Use existing RAID Volume (Select it even though RAID is not used.)	This uses the volume already created on an array controller.	(Selected) = Existing array configuration used
		Create new RAID Volume	This configures a new array and creates a volume in the array to use it.	(Selected) = A new array configured  Additionally, select the type of array controller, RAID level and the number of disks installed in the RAID, from the screen.
	Do not use Array Controller		This is selected when you use a drive other than the array controller as an OS installation destination.	(Selected) = Drive other than array controller used  Additionally, select the type of the drive that you use from the screen. [Note 3]
Partition			Specify the items below to each mount point, such as /boot, /var, shown on "Profile" screen.	
	(Checkbox on the left side of each mount point)		This specifies whether to create an independent partition to a mount point.	(Selected) = Partition created (Cleared) = Partition not created
	File System		This specifies the type of file systems.	Select the item from the pull-down menu.  Ex.: ext2, ext3 or ext4
	Size (MB)		This specifies a partition size.	Enter a decimal value.

Item Name		Description	Parameter
	Fill to maximum allowable size	This specifies whether to allocate spare disk capacity to the specified partition.  Specifying this is not required when you create another partition on free space after installing Linux.	(Selected) = Spare capacity allocated to the specified partition to extend the capacity  (Cleared) = Partition with the specified capacity created
Select Package			
	Initialize package selection	This changes the initial choice of a package group shown on the screen as the packages to be installed and a new package.	Minimal system = Minimum required packages  Install everything = all packages [Note 4]  Default package groups = Recommended packages [Note 4]
	Package Group	This specifies the package group to be installed.	(Selected) = Installed (Cleared) = Not installed
	New Package	This individually specifies the package name to be installed.	Enter the package name with the appropriate strings of characters.  Description with more than one line is allowed per one line for one package.
Basic Information			
	X Window System	This specifies whether to start X Window System when the system boots.   <b>Note</b> ..... If you are using ServerView Suite DVD V13.19.12 or earlier, X Window System is always started, regardless of this setting. .....	(Selected) = Start X Window System (Cleared) = Do not start X Window System
Bootloader Options			
	Bootloader	This specifies whether to install a bootloader.	(Selected) = Bootloader installed  This item is always checked.
	Install Bootloader on	This specifies the installation destination of a bootloader.	MBR = Installed on Master Boot Record  This item is always set to "MBR."
	Kernel parameters	This specifies a kernel parameter.	Enter the character strings specified as the kernel parameter.  [Omittable]
Security-Enhanced Linux			
	SE Linux	This specifies whether to use SE Linux.	Select the item from the pull-down menu.  Enforcing, Disabled or Permissive
Authentication			
	Use Shadow Passwords	This specifies whether to use shadow passwords.	(Selected) = Used (Cleared) = Not used [Note 5]
	Use MD5	This specifies whether to use MD5 for password encryption.	(Selected) = Used

Item Name		Description	Parameter
			(Cleared) = Not used
	Enable nscd	This specifies whether to use Name Switch Cache Daemon.	(Selected) = Used (Cleared) = Not used
Application Wizard		Specify the application automatically installed after OS installation.	
	Select Application Wizard (a variety of applications)	This specifies the application to be installed.  The type of applications differs depending on distribution. [Note 6]	(Selected) = Application installed
Execute Script after Installation			
	Execute Script after Installation	This specifies whether to execute a script after installation.	(Selected) = Execute Script after Installation
	The directory forwarded to OS	This specifies the directory forwarded to an OS after installation.	Specify the directory forwarded to the OS after installation.
	Execute Script after Installation	This specifies the script to be executed. [Note 7] [Note 8]	Specify the script to be executed.

[Note 1]: If the Universal Multi-Channel (UMC) function of the CNA card is enabled, set the MAC address and not the port number.

[Note 2]: For the PRIMEQUEST 2000 (Partition)/PRIMEQUEST 2000B/PRIMEQUEST 3000E series, it cannot be specified depending on the port number. If specifying the network port, specify the MAC address.

[Note 3]: Refer to the manuals for the servers and the ServerView Suite DVD for iSCSI support.

[Note 4]: If you use ServerView Suite DVD V11.16.04 or later, some package groups are not installed. In such cases, manually install them.

[Note 5]: "Shadow Passwords" is always enabled regardless of profile settings.

[Note 6]: The applications in the table below show the case where ServerView Suite DVD V11.16.04, V12.16.10 is used. These may be modified in the future in response to the update of ServerView Suite DVD.

Y = Can be specified with ISM, N = Cannot be specified with ISM

Applications	RHEL 6.x (x86)	RHEL 6.x (Intel64)	RHEL 7.x	RHEL 8.x
ServerView Agentless Service	N	Y	Y	Y
ServerView SNMP Agents	Y	Y	Y	Y
ServerView CIM Providers	N	Y	Y	Y
ServerView Update Agent (online flash)	Y	Y	Y	Y
ServerView Operations Manager (Note: Set SELinux to Disabled when you install it)  (Note: No support for PRIMERGY or PRIMEQUEST models with iRMC S6 or later)	Y	Y	Y	Y
ServerView RAID Manager	Y	Y	Y	Y
AIS Connect (Note: This cannot be set up for ServerView Suite DVD V12.16.10 or later)	Y	Y	N	N
Java Runtime Environment  (Note: For ServerView Suite DVD V13.18.12 or later, this is not installed even if it is specified.)	Y	Y	Y	Y

Applications	RHEL 6.x (x86)	RHEL 6.x (Intel64)	RHEL 7.x	RHEL 8.x
Dynamic Reconfiguration utility For PRIMEQUEST 2000/PRIMEQUEST 3000E	N	Y	Y	N
PRIMEQUEST REMCS Option For PRIMEQUEST 2000/PRIMEQUEST 3000E	N	Y	Y	N
HBA blockage function For PRIMEQUEST 2000/PRIMEQUEST 3000E	N	Y	Y	N
SIRMS Agent For PRIMEQUEST 2000/PRIMEQUEST 3000E	Y	Y	Y	N
ServerView Mission Critical Option For PRIMEQUEST 2000/PRIMEQUEST 3000E	N	Y	Y	N

[Note 7]: When you execute a script from another script, assign execution privilege to invoke it.

[Note 8]: This executes the specified script with the sh command.

[Note 9]: MAC address cannot be set with policies. Set it when creating profiles.

[Note 10]: If using an array controller, set it so that there are no inconsistencies with the "Onboard Device Configuration" settings for the BIOS. If the server to which the profile is assigned has more than one array controller, disable all but the array controller to be configured.

## OS (for each node) tab

Item Name		Description	Parameter
Type of Installation Media		This selects the type of media used for installation.	It is always the installation media specified in the OS tab
Root Password		A password is entered.	Enter the password.
Network			
	Get Computer Name Via DNS Server		(Selected) = Obtained from DNS (Cleared) = Arbitrary computer name specified [Note 1]
		Computer Name [Note 3]	Arbitrary computer name (host name) is specified when you do not obtain a host name from DNS. Enter the host name.
	DHCP		(Selected) = DHCP used (Cleared) = Fixed IP specified [Note 2]
		IP Address [Note 3]	A fixed IP address is specified when you do not use DHCP. Enter the IP address in IPv4 format.
		Subnet Mask	A subnet mask is specified when you do not use DHCP. Enter the subnet mask in IPv4 format.
		Default Gateway	The default gateway is specified when you do not use DHCP. Enter the IP address of the gateway in IPv4 format.
		DNS Server	The IP address of the DNS server is specified when you do not use DHCP. Enter the IP address of the DNS server in IPv4 format.

[Note 1]: When using a policy to change "Get Computer Name from DNS Server" from (Selected) or "unspecified" to (Cleared), set the computer name of a linked profile after deleting the link that the policy refers to.

[Note 2]: When using a policy to change "DHCP" from (Selected) or "unspecified" to (Cleared), set the IP address of a linked profile after deleting the link that the policy refers to.

[Note 3]: Computer names and IP addresses cannot be set with policies. Set these when creating profiles.

## 3.4 Profiles for SUSE Linux Enterprise Server

For information on which OSs can be specified in the profile, refer to "Support Matrix."


<https://support.ts.fujitsu.com/index.asp>

Select [Select a new Product] on the above site and enter "Infrastructure Manager" in [Product Search:].

Select [DOWNLOADS] and select the target operating system.

The reference procedures are subject to change without notice.

### OS tab

Item Name		Description	Parameter
Installation Image			
Type of Installation Media		This selects the type of media used for installation.	Select the item from the pull-down menu.
ServerView Suite DVD (Install Latest Version/Specify Version)		This specifies the version of ServerView Suite DVD used for installation.	Install Latest Version = The latest version of ServerView Suite registered in the repository used.  Specify Version = ServerView Suite with the specified version used
Installation Information			
Installation Method		This selects the installation method.   <b>Note</b> ..... - An eLCM license must be registered, an SD card must be mounted, and eIM must be downloaded when selecting eLCM.  - You cannot select eLCM for PRIMEQUEST2000-Partition, PRIMEQUEST2000B, or PRIMEQUEST3000E-Partition. .....	Select the item from the pulldown menu.
Management LAN network port settings			
Network port specification		This specifies the port of the network used for Management LAN.	(Selected) = Specify the network port for Management LAN.
Method to specify		This selects the method of specifying the network port for Management LAN. [Note 1] [Note 2]	Select the item from the pull-down menu.
Network Card		This is set if you specify "Port Number" in Method to specify.  Select the type of network card that you use.	Select from the screen.  Enter the slot number in which the card is installed.
Port Number		This is entered if you specify "Port Number" in Method to specify.	Enter the port number that you use.

Item Name			Description	Parameter
		MAC Address [Note 12]	This is entered if you specify "MAC address" in Method to specify.	Enter the MAC address of the network that you use.
		Boot mode specification	This specifies boot mode.	(Selected) = Specify the boot type
		Boot Type	This is selected when the boot mode of the server was changed or when specifying it explicitly.	Select the boot type used from the screen.
Basic Settings				
		Region and Language	This specifies a language.	Select the item from the pull-down menu.
		Keyboard	This specifies the type of a keyboard.	Select the item from the pull-down menu.
		Time Zone	This specifies a time zone.	Select the item from the pull-down menu.
		System clock uses UTC	This specifies the type of time used as System Clock.	(Selected) = UTC used (Cleared) = Local time used
RAID & Disk Configuration				
		Use Array Controller	This is selected when you use a server-built-in array controller as an OS installation destination.	(Selected) = Array controller used [Note 3]
		Use existing RAID Volume (Select it even though RAID is not used.)	This uses the volume already created on an array controller.	(Selected) = Existing array configuration used
		Create new RAID Volume	This configures a new array and creates a volume in the array to use it.	(Selected) = A new array configured Additionally, select the type of array controller, RAID level and the number of disks installed in the RAID, from the screen.
		Do not use Array Controller	This is selected when you use a drive other than the array controller as an OS installation destination.	(Selected) = Drive other than array controller used Additionally, select the type of the drive that you use from the screen. [Note 4]
Partition			Specify the items below to each mount point, such as /boot, /var, shown on "Profile" screen.	
		(Checkbox on the left side of each mount point)	This specifies whether to create an independent partition to a mount point.	(Selected) = Partition created (Cleared) = Partition not created
		File System	This specifies the type of file systems.	Select the item from the pull-down menu. Ex.: ext2, ext3 or ext4 [Note 5] [Note 13]
		Size (MB)	This specifies a partition size.	Enter a decimal value.
		Fill to maximum allowable size	This specifies whether to allocate spare disk capacity to the specified partition.	(Selected) = Spare capacity allocated to the specified partition to extend the capacity

Item Name		Description	Parameter
		Specifying this is not required when you create another partition on free space after installing Linux.	(Cleared) = Partition with the specified capacity created
Select Package			
	Initialize package selection	This changes the initial choice of a package group shown on the screen as the packages to be installed and a new package.	Minimal system = Minimum required packages Install everything = All the packages Default package groups = Recommended packages
	Package Group [Note 6] [Note 11] [Note 14]	This specifies the package group to be installed.	(Selected) = Installed (Cleared) = Not installed
	New Package	This individually specifies the package name to be installed.	Enter the package name with the appropriate strings of characters. Description with more than one line is allowed per one line for one package.
Bootloader Options			
	Bootloader	This specifies whether to install a bootloader.	(Selected) = Bootloader installed This item is always checked.
	Install Bootloader on	This specifies the installation destination of a bootloader.	MBR = Installed on Master Boot Record This item is always set to "MBR."
	Kernel parameters	This specifies a kernel parameter.	Enter the character strings specified as the kernel parameter. [Omittable]
Security-Enhanced Linux			
	SE Linux	This specifies whether to use SE Linux.	This item is always set to "Disabled."
Authentication			
	Use Shadow Passwords	This specifies whether to use shadow passwords.	This item is always set to "Checked (Used)."
	Use MD5	This specifies whether to use MD5 for password encryption.	This item is always set to "Unchecked (Not Used)."
	Enable nscd	This specifies whether to use Name Switch Cache Daemon.	This item is always set to "Checked (Used)."
Application Wizard		Specify the application automatically installed after OS installation.	
	Select Application Wizard (a variety of applications)	This specifies the application to be installed. The type of applications differs depending on distribution. [Note 7]	(Selected) = Application installed
Executing Script after Installation [Note 8]			
	Execute Script after Installation	This specifies whether to execute a script after installation.	(Selected) = Execute Script after Installation
	The directory forwarded to OS	This specifies the directory forwarded to an OS after installation.	Specify the directory forwarded to the OS after installation.

Item Name		Description	Parameter
	Execute Script after Installation	This specifies the script to be executed. [Note 9] [Note 10]	Specify the script to be executed.

[Note 1]: If the Universal Multi-Channel (UMC) function of the CNA card is enabled, set the MAC address and not the port number.

[Note 2]: For the PRIMEQUEST 2000 (Partition)/PRIMEQUEST 2000B/PRIMEQUEST 3000E series, it cannot be set depending on the port number. If specifying the network port, specify the MAC address.

[Note 3]: If using an array controller, set it so that there are no inconsistencies with the "Onboard Device Configuration" settings for the BIOS. If the server to which the profile is assigned has more than one array controller, disable all but the array controller to be configured.

[Note 4]: Refer to the manuals for the servers and the ServerView Suite DVD for iSCSI support.

[Note 5]: In SLES 11 SP4, ext4 only supports Read. In SLES 12, ext4 can support both the Read/Write. Note, however, that these are not the official support by SLES.

[Note 6]: In SLES 12, even in the case where "X-Windows System" is not specified for the package group, you cannot start it with the console. Pressing [Ctrl] + [Alt] + [F1] allows you to log in from the console.

[Note 7]: The applications in the table below show the case where ServerView Suite DVD V11.16.04, V12.16.10, V12.18.08 is used. These may be changed in the future version upgrades of ServerView Suite DVD.

SLES 15 (1) is for when ServerView Suite DVD V13.19.01 or earlier is used, and SLES 15 (2) is for when ServerView Suite DVD V13.19.04 or later is used.

Y = Can be specified with ISM, N = Cannot be specified with ISM

Applications	SLES 11 SP4(x86)	SLES 11 SP4(Intel64)	SLES 12 type	SLES 15 type (1)	SLES 15 type (2)
ServerView Agentless Service	N	Y	Y	N	N
ServerView SNMP Agents	Y	Y	Y	N	Y
ServerView CIM Providers	N	N	N	N	Y
ServerView Update Agent (online flash)	Y	Y	Y	N	Y
ServerView Operations Manager	N	N	N	N	N
ServerView RAID Manager	Y	Y	Y	Y	Y
AIS Connect (Note: This cannot be set up for ServerView Suite DVD V12.16.10 or later)	N	N	N	N	N
Java Runtime Environment (Note: For ServerView Suite DVD V13.18.12 or later, this is not installed even if it is specified.)	Y	Y	Y	Y	Y
Dynamic Reconfiguration utility For PRIMEQUEST 2000/PRIMEQUEST 3000E	N	N	Y	N	N
PRIMEQUEST REMCS Option For PRIMEQUEST 2000/PRIMEQUEST 3000E	N	N	N	N	N
HBA blockage function For PRIMEQUEST 2000/PRIMEQUEST 3000E	N	N	N	N	N
SIRMS Agent For PRIMEQUEST 2000/PRIMEQUEST 3000E	N	N	N	N	N



Applications	SLES 11 SP4(x86)	SLES 11 SP4(Intel64)	SLES 12 type	SLES 15 type (1)	SLES 15 type (2)
ServerView Mission Critical Option For PRIMEQUEST 2000/PRIMEQUEST 3000E	N	N	N	N	N

[Note 8]: In SLES 12, this does not support the script execution after installation.

[Note 9]: When you execute a script from another script, assign execution privilege to invoke it.

[Note 10]: This executes the specified script with the sh command.

[Note 11]: When using ISM to manage the server that installed SLES, specify "GNOME Basic" and "SAP Application Server Base."

[Note 12]: MAC addresses cannot be set with policies. Set these when creating profiles.

[Note 13]: In SLES 12, you cannot specify "vfat" for the file systems of partition /, /home, /var, /user, /opt, or /tmp. In SLES 15, you cannot specify "vfat" for the file systems of partition /, /var, or /tmp.

[Note 14]: In SLES 12, if you specify "KVM Server" for the package group, an unexpected IP address may be set. In this case, set an IP address manually.

## OS (for each node) tab

Item Name	Description	Parameter
Type of Installation Media	This selects the type of media used for installation.	It is always the installation media specified in the OS tab
Root Password	A password is entered.	Enter the password.
Network		
Get Computer Name Via DNS Server	This specifies whether to use the computer name obtained from DNS.	(Selected) = Obtained from DNS (Cleared) = Arbitrary computer name specified [Note 1]
Computer Name [Note 3]	Arbitrary computer name (host name) is specified when you do not obtain a host name from DNS.	Enter the host name.
DHCP	This selects whether to specify a fixed IP address or use DHCP for the IP address of Management LAN.	(Selected) = DHCP used (Cleared) = Fixed IP specified [Note 2] [Note 4]
IP Address [Note 3]	A fixed IP address is specified when you do not use DHCP.	Enter the IP address in IPv4 format.
Subnet Mask	A subnet mask is specified when you do not use DHCP.	Enter the subnet mask in IPv4 format.
Default Gateway	The default gateway is specified when you do not use DHCP.	Enter the IP address of the gateway in IPv4 format.
DNS Server	The IP address of the DNS server is specified when you do not use DHCP.	Enter the IP address of the DNS server in IPv4 format.

[Note 1]: When using a policy to change "Get Computer Name from DNS Server" from (Selected) or "unspecified" to (Cleared), set the computer name of a linked profile after deleting the link that the policy refers to.

[Note 2]: When using a policy to change "DHCP" from (Selected) or "unspecified" to (Cleared), set the IP address of a linked profile after deleting the link that the policy refers to.

[Note 3]: Computer names and IP addresses cannot be set with policies. Set these when creating profiles.

[Note 4]: In SLES 12, if you specify "KVM Server" for the package group, an unexpected IP address may be set. In this case, set an IP address manually.

# Chapter 4 Virtual IO Setting Items of Profiles for PRIMERGY Servers/PRIMEQUEST 3000E/4000E Partitions

## 4.1 Card Settings

Set for each card that you want to use.

Item Name	Description	Parameter
Number of Onboard Card Slots	Select the number of onboard.	Select the item from the pull-down menu.
Number of Card Slots	Select the number of cards to use.	Select the item from the pull-down menu.
Card Slot		
Onboard <Number>		
Card Type	Select the type to use.	Select from the screen.
Number of Ports	Select the number of ports to use.	Select the item from the pull-down menu.
Card Slot <Number>		
Card Type	Select the type to use.	Select from the screen.
Number of Ports	Select the number of ports to use.	Select the item from the pull-down menu.



### Note

- Assign virtual addresses and to the virtual IO settings for the LAN, FC, CNA cards/boards mounted on the server. Operation where only one part of the cards/boards or one part of the ports has been assigned virtual addresses is not supported.
- Virtual IO settings cannot be used for cards and boards (including items where the number of cards/boards is set to 0) that were removed from the settings when profiles were edited. It will normally not be recognized from the OS (depending on the OS and the drivers it might be recognized and displayed).
- The virtual IO settings are available when the power of the iRMC is on, because they are stored in the iRMC.

When the iRMC loses electrical power (all power cables are disconnected or the data center loses electrical power), the iRMC loses the virtual IO settings. When the AC power is restored and the iRMC is re-booted, assign the virtual IO settings again. If the iRMC loses the electric power, the virtual IO settings in the iRMC are also lost. To make the virtual IO settings effective again, assign the profile again.

- If there are multiple on-board slots with different slot numbers, specify them in the order in which the on-board slot numbers are counted from the beginning. The on-board slot numbers can be found on the [Component] tab in the node details.
- For the PCI card slot of the PRIMEQUEST3000E partition, the actual mounting location of the slot and the slot number are different. For virtual IO settings, specify the slot number instead of the actual mounting location. For their correspondence, refer to "Server PRIMEQUEST 3000 Series Enterprise Model Administration Manual" - "Appendix D Physical Locations and BUS Numbers of Built-in I/O, and PCI Slot Mounting Locations and Slot Numbers."

<https://support.ts.fujitsu.com/>

How to display the manual:

Select "Select a new Product" - [Product search]. Enter "PRIMEQUEST" and select [Continue].

Select the appropriate model for PRIMEQUEST and download the manual from [Documentation] - [Manuals].

- For the PCI card slot of the PRIMEQUEST4000E partition, the actual mounting location of the slot and the slot number are different. For virtual IO settings, specify the slot number instead of the actual mounting location (ISM 2.9.0.010 or later). For correspondence, refer to "iRMC S6 - Web Interface" in PRIMEQUEST 4000.

<https://support.ts.fujitsu.com/index.asp>

How to display the manual:

Select "Select a new Product" - [Product search]. Enter "PRIMEQUEST" and select [Continue].

Select the appropriate model for PRIMEQUEST and download the manual from [Documentation] - [Manuals].

## 4.2 Port Settings

It is required to set it up for the number of cards set in "4.1 Card Settings."

The following settings for each card are described separately for each card type.

Item Name		Description	Parameter
Enter Port Information			
	Use Virtual Address	Select if using a virtual address.	(Selected) = Use virtual address.
	Use SR-IOV	Select if using SR-IOV.	(Selected) = Use SR-IOV
	Disable Boot Menu (F12)	Select to not display the boot menu.	(Selected) = Do not display boot menu
UEFI Boot		Select the boot mode to use. [Note 1]	Select from the screen. [Note 2]
If the card type is CNA			
	Function Type	Select the Function of CNA.	Select the item from the pull-down menu.
	Boot	Select boot method.	Select the item from the pull-down menu.
	SR-IOV	Select if enabling SR-IOV.	(Selected) = Enable SR-IOV
	RoCE	Select the RoCE support. [Note 3] [Note 4] [Note 5]	Select the item from the pull-down menu.
If the card type is LAN			
	Function Type	Select the Function of LAN.	It will always be set to LAN.
	Boot	Select boot method.	Select the item from the pull-down menu.
	SR-IOV	Select if enabling SR-IOV.	(Selected) = Enable SR-IOV
	RoCE	Select the RoCE support. [Note 4] [Note 5]	Select the item from the pull-down menu.
If the card type is FC			
	Function Type	Select the Function of FC	It will always be set to FC.
	Boot	Set boot method.	Select the item from the pull-down menu.
	SR-IOV	Select if enabling SR-IOV.	(Selected) = Enable SR-IOV
SMUX setting [Note 6]		Select SMUX setting	Select from the screen.

[Note 1]: For PRIMERGY M6 series or later, or for PRIMEQUEST 3000E partition, select "UEFI Only."

[Note 2]: The values in this setting will be reflected to the settings for CMS Configuration of BIOS. For detailed settings, refer to the following.

BIOS Settings		Virtual IO [UEFI Boot]			
CSM Configuration		Legacy first	Legacy Only	UEFI First	UEFI Only
	Boot option filter	"UEFI and Legacy" or "Legacy Only" (when "UEFI and Legacy" does not exist in the options)	Legacy only	"UEFI and Legacy" or "UEFI Only" (when "UEFI and Legacy" does not exist in the options)	UEFI only
	Launch PXE OpROM Policy	Legacy only	Legacy only	UEFI only	UEFI only
	Launch Storage	Legacy only	Legacy only	UEFI only	UEFI only
	Other PCI device ROM priority	Legacy only	Legacy only	UEFI only	UEFI only

[Note 3]: This can be set only when the "Function Type" is "LAN."

[Note 4]: If you set this item, select the "Use Virtual Address" checkbox.

[Note 5]: If you set this item, clear the "SR-IOV" checkbox.

[Note 6]: Can only be set if the server is PRIMERGY BX.



### Note

If installing OS on a local disk (SATA or SAS) the Boot setting cannot be used for the virtual IO. Before assigning profiles, manually change the server boot order so that the server PXE boot is prioritized.

## 4.3 Boot Settings

Use the arrow button to the right of each item when changing the boot priority.

Set for the same number of onboard cards or PCI cards/ports that you set in ["4.1 Card Settings"](#) and ["4.2 Port Settings."](#)

The following describes the parameters for the various functions, not regarding whether they are onboard or PCI cards.

Item Name		Description	Parameter
If the function type is LAN			
	Internet Protocol	Selections for Internet protocol	Select from the screen.
If the function type is FCoE			
	Connection speed	Select connection speed.	Select the item from the pull-down menu. Auto, 1 Gbit/s, 2 Gbit/s, 4 Gbit/s, 8 Gbit/s, 16 Gbit/s [Note 1]
	Connection type	Select connection form.	Select from the screen.
1st Target			
	Port Name (WWPN)	Enter WWPN of the storage to start with SAN boot.	Enter WWPN.
	LUN	Enter LUN of the storage to start with SAN boot.	Enter LUN.
2nd Target			
	Port Name (WWPN)	Enter WWPN of the storage to start with SAN boot.	Enter WWPN.
	LUN	Enter LUN of the storage to start with SAN boot.	Enter LUN.
If the function type is iSCSI			

Item Name		Description	Parameter
Initiator Parameters			
Address Settings		Select the procedure for retrieving the address of the initiator.	Select from the screen.
Initiator Name		Enter IQN of the initiator.	Enter IQN.  The character string entered require to start and end with alphanumerical characters, and except for this it should be made up of less than 223 alphanumerical characters or symbols (period ".", colon ":", or hyphen "-").
VLAN ID		Enter the VLAN ID that HBA uses to send requests.	Enter VLAN ID.
IPv4		Enter the IP address used for the initiator if you selected "Fixed" in the address settings.	Enter the IP address.
Subnet Mask		Enter the subnet mask if you selected "Fixed" in the address settings.	Enter the subnet mask.
Gateway Address		Enter the address of the gateway if you selected "Fixed" in the address settings.	Enter the gateway address.
Target Parameters			
IP Address		Select the procedure for retrieving the address of the target.	Select from the screen.
Target Name		Enter the IQN of the target.	Enter IQN.  The character string entered require to start and end with alphanumerical characters, and except for this it should be made up of less than 223 alphanumerical characters or symbols (period ".", colon ":", or hyphen "-").
IPv4		Enter the IP address used by the target if you selected "Fixed" in the IP address settings.	Enter the IP address.
Port [opt]		Enter the target port number if you selected "Fixed" in the IP address settings.	Enter the port number.
LUN		Enter the LUN number of the target if you selected "Fixed" in the IP address settings.	Enter LUN number.
Authentication Method		Select authentication method.	Select from the screen.
Chap Username		Enter authentication user name if you selected "CHAP" or "Mutual CHAP" for the authentication method.	Enter the authentication user name.  The character string entered should consist of less than 127 alphanumerical characters or symbols [Note 2].
Chap Secret		Enter the password used for CHAP authentication if you selected "CHAP" or "Mutual CHAP" for the authentication method.	Enter the password.  The character string entered should consist of between 12 and 16 alphanumerical characters or symbols [Note 2].

Item Name			Description	Parameter
		Mutual Chap Secret	Enter the password used for Mutual CHAP authentication if you selected "Mutual CHAP" for the authentication method.	Enter the password.  The character string entered should consist of between 12 and 16 alphanumerical characters or symbols [Note 2].

[Note 1]: Select "Auto" for the setting value when the connection speed you want to set is not included among the setting values.

[Note 2]: Depending on the hardware model it might not be possible to use symbols. It is recommended that you only use alphanumerical characters.

## 4.4 CNA Settings

Set if you specified "CNA" for onboard or PCI card type in "4.1 Card Settings."

Set for the number of CNA function types set in "4.2 Port Settings."

The following describes the parameters for the various card types.

Item Name		Description	Parameter
If the function type is FCoE			
	Min. Bandwidth[%]	Enter the minimum bandwidth value.	Enter the minimum bandwidth value. [Note 1]
	Max. Bandwidth[%]	Enter the maximum bandwidth value.	Enter the maximum bandwidth value. [Note 1]
If the function is LAN or iSCSI type			
	Min. Bandwidth[%]	Enter the minimum bandwidth value.	Enter the minimum bandwidth value. [Note 1]
	Max. Bandwidth[%]	Enter the maximum bandwidth value.	Enter the maximum bandwidth value. [Note 1]
	VLAN ID	Enter VLAN ID.	Enter VLAN ID.

[Note 1]: Set so that all the totals of one IO channel equals 100.

If the total bandwidth for one IO channel is not 100, internally adjust the bandwidth values accordingly.

## 4.5 Virtual Address Settings

Set it up for the number of card information entered in "4.1 Card Settings."

The following describes the parameters for each card type.

Item Name		Description	Parameter
If the card type is LAN			
	Assign Virtual Address	Select if using virtual address assignment.	(Selected) = Assign Virtual Addresses
	Virtual Address [Note 1]		
	Auto assignment	Select if enabling automatic assignment from Pool Management.	(Selected) = Enable Auto assignment
	MAC [Note 2]	Enter virtual MAC address.	Enter virtual MAC address.  Two rows each of alphanumerical letters separated by a colon (:) or a hyphen (-).

Item Name		Description	Parameter
If the card type is FC			
	Assign Virtual Address	Select if using virtual address assignment.	(Selected) = Assign Virtual Addresses
	Virtual Address [Note 1]		
	Auto assignment	Select if enabling automatic assignment from Pool Management.	(Selected) = Enable Auto assignment
	WWNN [Note 2]	Enter virtual WWNN.	Enter virtual WWNN. Two rows each of alphanumerical letter separated by a colon (:).
	WWPN [Note 2]	Enter virtual WWPN.	Enter virtual WWPN. Two rows each of alphanumerical letter separated by a colon (:).
If the card type is CNA			
	Assign Virtual Address	Select if using virtual address assignment.	(Selected) = Assign Virtual Addresses
	Virtual Address [Note 1]		
	Auto assignment	Select if enabling automatic assignment from Pool Management.	(Selected) = Enable Auto assignment
	WWNN [Note 2]	Enter the virtual WWNN if the application type is "FCoE."	Enter virtual WWNN. Two rows each of alphanumerical letter separated by a colon (:).
	WWPN [Note 2]	Enter the virtual WWPN if the application type is "FCoE."	Enter virtual WWPN. Two rows each of alphanumerical letter separated by a colon (:).
	E-MAC [Note 2]	Enter the virtual E-MAC address if the application type is "FCoE."	Enter virtual E-MAC address. Two rows each of alphanumerical letters separated by a colon (:) or a hyphen (-).
	MAC [Note 2]	Enter the virtual MAC address if the function type is "iSCSI" or "LAN."	Enter virtual MAC address. Two rows each of alphanumerical letters separated by a colon (:) or a hyphen (-).

[Note 1]: Only set if "Assign Virtual Address" was checked.

[Note 2]: Only set if "Auto assignment" was not checked.



## Note

- It is required that the IQN, WWPN and virtual MAC address are unique across the system.

Except for the same card, it is required that the WWNN is unique across the system.

There is a risk that the volume is damaged if overlapping IQN, WWPN or WWNN access the same volume at the same time.

Network communication is not possible if virtual MAC addresses overlap.

- Multicast MAC addresses cannot be used as virtual MAC addresses.

If you set virtual IP addresses arbitrarily, there is a risk that they might overlap with the factory shipping values of other cards.

It is recommended that you set the virtual address within the following range.

- MAC address (00:19:99:3E:D2:A1 - 00:19:99:3F:CC:A1)



- WWN (50:01:99:93:ED:2A:10:00 - 50:01:99:93:FC:C9:FF:FF)



## Chapter 5 RAID Setting Items of Profiles for PRIMERGY Servers (ISM 2.9.0.021 or later)

This section describes the items that you can set up with the RAID tab in the profiles.

### RAID tab

Item Name		Description	Parameter
RAID & Disk Configuration [Note 1]			
	RAID Level	This configures a new RAID	Select the configuring RAID level from the pull-down menu.
	Set Number of Disks Manually (ISM 2.9.0.030 or later)	Selects when specifying the number of disks used for the RAID configuration	(Selected) = to specify number of disks
	Number of Disks (ISM 2.9.0.030 or later) [Note 2]	Specifies the number of disks to use for the RAID configuration	(when selecting other than RAID1+0) Select the number of disks to be added in the RAID from the pull-down menu.  (when selecting RAID1+0) Select the number of disks to be added in one disk group from the pull-down menu.
	Number of Disk Groups (ISM 2.9.0.030 or later)	Specifies the number of disk groups to use for the RAID configuration	(when selecting RAID1+0) Select the number of disk groups from the pull-down menu.

[Note 1]: PRIMERGY BX series are not supported.

[Note 2]: RAID cannot be configured as specified for the number of disks depending on the RAID level. RAID is configured within the support range of the target server.



## Chapter 6 Setting Items of Profiles for Storages



This section describes the items that you can set up in the profiles for storage. Some of selectable items may differ depending on the type of your storage.



For details of each item, refer to the manual for your storage.

### 6.1 Profiles for ETERNUS DX

#### RAID & Disk Configuration tab

Item Name		Description	Parameter
RAID Configuration			
	RAID Group Name	This specifies a RAID group name.   <b>Note</b> ..... You cannot specify the RAID group name already set up for a device. .....	Enter the RAID group names.  You can enter 1 to 16 characters.
	RAID Level	This specifies the RAID level of a disk array to be configured.	Select the item from the pull-down menu.  RAID1, RAID5, RAID6 or RAID1+0
	Number of Disks	This specifies the number of disks built in a disk array.	Specify the number of disks.  The selectable number differs depending on the selected RAID level.
	Disk Inch	This specifies the type of disk drive (drive outer size).	Select the item from the pull-down menu.  2.5 Inch or 3.5 Inch
	Disk Type	This specifies the type of disk drive (interface type) built in a disk array.	Select the item from the pull-down menu.  The selectable type differs depending on the models of ETERNUS and selected disk inch.  SAS, NL-SAS, SED or SSD
	Disk Size	This specifies the type of disk drive (disk size) built in a disk array.	Select the item from the pull-down menu.  The selectable size differs depending on the selected disk inch and disk type.  300 GB, 450 GB, 1 TB, etc.
Volume			
	Volume Name	This specifies the name of a volume to be created on a RAID group.   <b>Note</b> ..... You cannot specify the volume name already set up for a device. .....	Specify the name of a volume to be created on the RAID group.  You can enter 1 to 16 characters.
	Volume Size	This specifies volume size to be created on a RAID group.	Specify the volume size on the text box to select the item from pull-down menu.

Item Name		Description	Parameter
			<p>Specifying "max" for the last volume size causes all the remaining size of the RAID group to be allocated.</p> <p>For ETERNUS DX60 S2, you cannot specify "max."</p> <p>MB, GB or TB</p>
Global Hot Spare			
	Disk Inch	This specifies the type of disk drive (drive outer size) defined as a hot spare.	<p>Select the item from the pull-down menu.</p> <p>2.5 Inch or 3.5 Inch</p>
	Disk Type	This specifies the type of disk drive (interface type) defined as a hot spare.	<p>Select the item from the pull-down menu.</p> <p>The selectable type differs depending on the models of ETERNUS and selected disk inch.</p> <p>SAS, NL-SAS, SED or SSD</p>
	Disk Size	This specifies the type of disk drive (disk size) defined as a hot spare.	<p>Select the item from the pull-down menu.</p> <p>The selectable size differs depending on the selected disk inch and disk type.</p> <p>300 GB, 450 GB, 1 TB, etc.</p>
Host Affinity			
LUN Group			
	LUN Group Name	<p>This specifies a LUN group name.</p> <p> <b>Note</b></p> <p>.....</p> <p>You cannot specify the LUN group name already set up for a device.</p> <p>.....</p>	Specify the LUN group name strings.
	Volumes		
	Volume Name	This specifies the name of a volume which belongs to a LUN group.	<p>Enter the name of the volume which belongs to the LUN group.</p> <p>Specify the volume created by a profile or the volume already created on a device.</p>
Port Group			
	Port Group Name	<p>This specifies a port group name.</p> <p> <b>Note</b></p> <p>.....</p> <p>You cannot specify the port group name already set up for a device.</p> <p>.....</p>	<p>Specify the port group name.</p> <p>You can enter 1 to 16 characters.</p>
	Ports		
	Port Number	This specifies the port number which belongs to a port group.	Specify the port number which belongs to the port group with a triple-digit number.
Host Group			
	Host Group Name	This specifies a host group name.	<p>Specify the host group name.</p> <p>You can enter 1 to 16 characters.</p>

Item Name		Description	Parameter
		 <b>Note</b> ..... You cannot specify the host group name already set up for a device. .....	
	Host Type	This specifies the type of a host group.	Select the item from the pull-down menu.  iSCSI or FC
	Host		
	Host Name	This specifies the host name which belongs to a host group.   <b>Note</b> ..... You cannot specify the host name already set up for a device. .....	Specify the name of the host which belongs to the host group.  You can enter 1 to 16 characters.
	iSCSI Name	This specifies the iSCSI name which defines a host name.  Can be entered when the host type of a host group is iSCSI name.	Enter iSCSI name.  Enter "iqn." or "eui." at the beginning.
	Host WWN	This specifies the host WWN which defines a host name.  You can enter it when the host type of a host group is FC.	Enter the host WWN.  You can enter 16 hexadecimal characters.
Detail Settings			
	Pre Run Command	The control command to execute on ETERNUS before executing profile assignment (RAID/Hot Spare/Host Affinity settings) is described.  Leave the checkbox cleared unless a special request is made.	Refer to "CLI User Guide" of your device for the described contents.
	Post Run Command	The control command to execute on ETERNUS after completion of profile assignment (RAID/Hot Spare/Host Affinity settings) is described.  Leave the checkbox cleared unless a special request is made.	Refer to "CLI User Guide" of your device for the described contents.



#### Point

- You cannot specify the position of a mounted slot on the disk drive used for the array configuration.
- You cannot specify the position of a mounted slot on the disk drive used for the hot spare configuration.

## 6.2 Profiles for ETERNUS NR/ETERNUS AX/ETERNUS HX/ETERNUS AC (ISM 2.9.0.030 or later)

## SNMP tab

Item Name		Description	Parameter
SNMP Service			
	SNMP Service Setting	This specifies whether to use SNMP service settings.	(Selected) = Enabled (Cleared) = Disabled
	SNMP Agent (ON/OFF)	This specifies whether to enable or disable SNMP agents.	ON = Enable the function OFF = Disable the function
	SNMP Trap (ON/OFF)	This specifies whether to enable or disable SNMP traps.	ON = Enable the function OFF = Disable the function
Community (for Host)			
	Community Name	This specifies an SNMP community name.	Enter the community name as a character string with 3 to 32 characters.
User (for v3 Host)			
	User Name	This specifies an SNMP user name.	Enter the user name as a character string with between 3 and 32 characters.
	Authentication Setting	This specifies whether to enable SNMP authentication settings.	(Selected) = Enabled
	Authentication Protocol	This specifies the SNMP authentication protocol.	Select the following from the pull-down menu. MD5, SHA, SHA2, NoAuth
	Authentication Password	Enter an SNMP authentication password.	Enter the password as a character string with between 8 and 30 characters.
	Privacy Setting	This specifies whether to enable SNMP privacy settings.	(Selected) = Enabled
	Privacy Protocol	This specifies SNMP privacy protocol.	Select the following from the pull-down menu. DES, AES, NoPriv
	Privacy Password	This specifies an SNMP privacy password.	Enter the password as a character string with between 3 and 30 characters.
v3 Host			
	Address	This specifies the IP address of an SNMP host.	Enter the IP address of the host with the strings based on IPv4 or IPv6 address notations.
	User Name	This specifies an SNMP user name.	Select the user already set up from the pull-down menu.

## NTP

Item Name		Description	Parameter
Auto Time Adjustment			
	Auto Time Adjustment	This specifies whether to enable auto time adjustment.	(Selected) = Enabled
	Server Setting	This specifies whether to enable the settings for a time-provider server.	(Selected) = Enabled (Cleared) = Disabled

Item Name				Description	Parameter
			Address	This specifies the IP address of a time-provider server.	Enter the IP address of the time-provider server with the character strings based on IPv4 or IPv6 address notations.
			Protocol version	This specifies the NTP protocol version.	3 = NTP protocol version 3, which is based on the RFC#1305 Internet standard 4 = NTP protocol version 4, which is based on the RFC#5905 Internet standard auto(Default) = Select the NTP protocol version in Data ONTAP

## Chapter 7 Setting Items of Profiles for Switches

This section describes the items that you can set up, in the profiles for switches.

For details of each item, refer to the manual of your switch.

### 7.1 Profiles for SR-X

#### SNMP tab

Item Name		Description	Parameter
SNMP Service			
	SNMP Service Setting	This specifies whether to use SNMP service settings.	(Selected) = Enabled (Cleared) = Disabled
	SNMP Agent and Trap (ON/OFF)	This specifies whether to enable or disable SNMP agents and traps.	ON = Function enabled OFF = Function disabled
	SNMP Agent Setting	This specifies whether to use SNMP agent settings.	(Selected) = Enabled (Cleared) = Disabled
	Agent Address	This specifies whether to enable an agent address.	(Selected) = Agent address enabled Additionally, enter the agent address in IPv4 format.
	SNMP Engine ID	This specifies whether to enable an SNMP engine ID.	(Selected) = SNMP engine ID enabled Additionally, enter the SNMP engine ID.
SNMP Host (SNMPv1 or v2c)			
	Number	This specifies an SNMP host definition number.	Select the item from the pull-down menu.
	Address	This specifies the IP address of an SNMP host.	Specify the IP address of the SNMP host in IPv4 format.
	Community Name	This specifies the community name of an SNMP host.	Enter the community name of the SNMP host.
	Trap Type	This specifies whether to send SNMP traps.	Select the item from the pull-down menu. Off, v1 or v2c
	Write	This specifies whether to permit writing from an SNMP manager.	(Selected) = Enabled (Cleared) = Disabled
SNMP User (SNMPv3)			
	Number	This specifies an SNMP user definition number.	Select the item from the pull-down menu.
	User Name	This specifies an SNMP user name.	Enter the SNMP user name.
	Address Setting	This specifies whether to enable an SNMP host address.	(Selected) = Enabled (Cleared) = Disabled
	Host Number	This specifies an SNMP host definition number.	Select the item from the pull-down menu.
	Host Address	This specifies the IP address of an SNMP host.	Enter the IP address strings of the SNMP host.



Item Name		Description	Parameter
	Trap Setting		(Selected) = Enabled (Cleared) = Disabled
	Host Number	This specifies an SNMP host definition number.	Select the item from the pull-down menu.
	Host Address	This specifies the IP address of an SNMP host.	Enter the IP address strings of the SNMP host.
	Authentication Setting		(Selected) = Enabled (Cleared) = Disabled
	Authentication Protocol	This specifies the SNMP authentication protocol.	Select the item from the pull-down menu. None, MD5 or SHA
	Authentication Password	This specifies an SNMP authentication password.	Enter the SNMP authentication password.
	Privacy Setting		(Selected) = Enabled (Cleared) = Disabled
	Privacy Protocol	This specifies the SNMP privacy protocol.	Select the item from the pull-down menu. None or DES
	Privacy Password	This specifies an SNMP privacy password.	Enter the SNMP privacy password.
	Read	This specifies whether to enable SNMP MIB read.	(Selected) = Enabled Additionally, specify the item from the pull-down menu. none: Read not permitted all: Read permitted
	Write	This specifies whether to enable SNMP MIB write.	(Selected) = Enabled Additionally, specify the item from the pull-down menu. none: Write not permitted all: Write permitted
	Notify	This specifies whether to enable SNMP MIB trap notifications.	(Selected) = Enabled Additionally, specify the item from the pull-down menu. none: Read-out not permitted all: Read-out permitted

#### Authentication tab

Item Name		Description	Parameter
Account			
	Change Administrator Password		(Selected) = Administrator password changed
	Password	This specifies a new administrator password.	Enter the password.

**NTP tab**

Item Name			Description	Parameter
Auto Time Adjustment				
	Auto Time Adjustment		This specifies whether to enable auto time adjustment.	(Selected) = Enabled
		Server Setting	This specifies whether to enable the settings for a time-provider server.	(Selected) = Enabled (Cleared) = Disabled
		Protocol (Time/SNTP)	This specifies the protocol to be used.	Time = TCP used SNTP = UDP used
		Address	This specifies the IP address of a time-provider server.	Enter the IP address of the time-provider server.
	Interval Setting		This specifies whether to enable the interval for auto time adjustment.	(Selected) = Enabled (Cleared) = Disabled
	Interval Time (On Startup/Period)	This specifies the interval of auto time adjustment.	On Startup = Adjusted upon startup Period = Execute during arbitrary period. Additionally, enter the period on the screen.	
	Time Zone Setting		This specifies whether to enable time zone setting.	(Selected) = Enabled (Cleared) = Disabled
		Time Zone from GMT	This specifies the time difference the device uses from the Greenwich Mean Time.	Select the item from the pull-down menu.

**STP tab**

Item Name		Description	Parameter
STP (Spanning Tree Protocol) Setting			
	STP	This specifies whether to enable STP settings.	(Selected) = Enabled Additionally, select the item from the pull-down menu.

## 7.2 Profiles for VDX

**SNMP tab**

Item Name		Description	Parameter
SNMP Service			
	SNMP Service Setting	This specifies whether to use SNMP service settings.	(Selected) = Enabled (Cleared) = Disabled
	SNMP Agent and Trap (ON/OFF)	This specifies whether to enable or disable SNMP agents and traps.	ON = Function enabled OFF = Function disabled
Group (for Community and User)			
	Group Name	This specifies a group name.	Enter the group name.
	SNMP Version	This specifies the SNMP version.	Select the item from the pull-down menu.

Item Name		Description	Parameter
			V1, v2c, v3
	v3 Security Level	This specifies the security level for SNMPv3.	(Selected) = Enabled Additionally, select the item from the pull-down menu. auth, noauth or priv
	Read	This specifies whether to enable SNMP MIB read.	(Selected) = Enabled Additionally, specify the item from the pull-down menu. none: Read not permitted all: Read permitted
	Write	This specifies whether to enable SNMP MIB write.	(Selected) = Enabled Additionally, specify the item from the pull-down menu. none: Write not permitted all: Write permitted
	Notify	This specifies whether to enable SNMP MIB trap notifications.	(Selected) = Enabled Additionally, specify the item from the pull-down menu. none: Read-out not permitted all: Read-out permitted
Community (for Host)			
	Community Name	This specifies an SNMP community name.	Enter the community name strings.
	Group	This specifies the group which a community belongs to.	(Selected) = Enabled Additionally, select a selected group from the pull-down menu.
	Write	This specifies whether to enable SNMP community write.	(Selected) = Enabled Additionally, select the item from the pull-down menu. Enabled or Disabled
Host			
	Address	This specifies the IP address of an SNMP host.	Enter the IP address of the host with the strings based on IPv4 or IPv6 address notations.
	Community Name	This specifies an SNMP community name.	Select the community name already set up from the pull-down menu.
	Severity Level	This specifies the SNMP trap level.	Select the item from the pull-down menu.
	Trap Version	This specifies the SNMP trap version.	Select the item from the pull-down menu. v1 or v2c
	UDP Port	This specifies an SNMP trap sending port number.	Enter the SNMP trap sending port number. A value between "0" and "65535" can be specified.
User (for v3 Host)			

Item Name		Description	Parameter
	User Name	This specifies an SNMP user name.	Enter the user name between 1 and 16 characters.
	Group	This specifies an SNMP group name.	Select the group already set up from the pull-down menu.
	Authentication Setting	This specifies whether to enable SNMP authentication settings.	(Selected) = Enabled
	Authentication Protocol	This specifies the SNMP authentication protocol.	Select the item from the pull-down menu. MD5, SHA or NoAuth
	Authentication Password	An SNMP authentication password is entered.	Enter the authentication password between 1 and 32 characters.
	Privacy Setting	This specifies whether to enable SNMP privacy settings.	(Selected) = Enabled
	Privacy Protocol	This specifies SNMP privacy protocol.	Select the item from the pull-down menu. DES, AES128 or NoPriv
	Privacy Password	This specifies an SNMP privacy password.	Enter the privacy password strings between 1 and 32 characters.
v3 Host			
	Address	This specifies the IP address of an SNMP host.	Enter the IP address of the host with the strings based on IPv4 or IPv6 address notations.
	User Name	This specifies an SNMP user name.	Select the user already set up from the pull-down menu.
	Severity Level	This specifies the SNMP trap level.	Select the item from the pull-down menu.
	Notify Type	This specifies an SNMP notification type.	Select the item from the pull-down menu. traps, informs
	Engine ID	This specifies an SNMP engine ID.	Specify the engine ID "0:0:0:0:0:0:0:0" to "FF:FF:FF:FF:FF:FF:FF:FF" with strings. Its character strings pattern is the same as that of MAC address.
	UDP Port	This specifies an SNMP trap sending port number.	Enter the SNMP trap sending port number. A value between "0" and "65535" can be specified.

#### Authentication tab

Item Name		Description	Parameter
Account			
	Change Administrator Password	This specifies whether to change the administrator password.	(Selected) = Administrator password changed
	Password	This specifies a new administrator password.	Enter the password between 8 and 32 characters.

#### NTP tab

Item Name			Description	Parameter
Auto Time Adjustment				
	Auto Time Adjustment		This specifies whether to enable auto time adjustment.	(Selected) = Enabled
		Server Setting	This specifies whether to enable the settings for a time-provider server.	(Selected) = Enabled (Cleared) = Disabled
		Address	This specifies the IP address of a time-provider server.	Enter the IP address of the time-provider server with the character strings based on IPv4 or IPv6 address notations.
	Time Zone Setting		This specifies whether to enable time zone setting.	(Selected) = Enabled (Cleared) = Disabled
		Region City	This specifies region information.	Enter the region information in the form of (Region)/(City).

## 7.3 Profiles for PSWITCH 2048P/T PSWITCH 4032P

### SNMP tab

Item Name		Description	Parameter
SNMP Service			
	SNMP Service Setting	This specifies whether to use SNMP service settings.	(Selected) = Enabled (Cleared) = Disabled
	SNMP Agent and Trap (ON/OFF)	This specifies whether to enable or disable SNMP agents and traps.	ON = Function enabled OFF = Function disabled
Group (for Community and User)			
	Group Name	This specifies a group name.	Enter the group name.
	SNMP Version	This specifies the SNMP version.	Select the item from the pull-down menu. V1, v2c, v3
	v3 Security Level	This specifies the security level for SNMPv3.	(Selected) = Enabled Additionally, select the item from the pull-down menu. auth, noauth or priv
	Read	This specifies whether to enable SNMP MIB read.	(Selected) = Enabled Additionally, specify the item from the pull-down menu. none: Read not permitted Default: Read permitted
	Write	This specifies whether to enable SNMP MIB write.	(Selected) = Enabled Additionally, specify the item from the pull-down menu. none: Write not permitted Default: Write permitted
	Notify	This specifies whether to enable SNMP MIB trap notifications.	(Selected) = Enabled

Item Name		Description	Parameter
			<p>Additionally, specify the item from the pull-down menu.</p> <p>none: Read-out not permitted</p> <p>Default: Read-out permitted</p>
Community (for Host)			
	Community Name	This specifies an SNMP community name.	Enter the community name strings.
	Group	This specifies the group which a community belongs to.	<p>(Selected) = Enabled</p> <p>Additionally, select a selected group from the pull-down menu.</p>
	Write	This specifies whether to enable SNMP community write.	<p>(Selected) = Enabled</p> <p>Additionally, select the item from the pull-down menu.</p> <p>Enabled or Disabled</p>
Host			
	Address	This specifies the IP address of an SNMP host.	Enter the IP address of the host with the strings based on IPv4 or IPv6 address notations.
	Community Name	This specifies an SNMP community name.	Select the community name already set up from the pull-down menu.
	Trap Version	This specifies the SNMP trap version.	<p>Select the item from the pull-down menu.</p> <p>v1 or v2c</p>
	UDP Port	This specifies an SNMP trap sending port number.	<p>Enter the SNMP trap sending port number.</p> <p>A value between "1" and "65535" can be specified.</p>
User (for v3 Host)			
	User Name	This specifies an SNMP user name.	Enter the user name between 1 and 30 characters.
	Group	This specifies an SNMP group name.	Select the group already set up from the pull-down menu.
	Authentication Setting	This specifies whether to enable SNMP authentication settings.	(Selected) = Enabled
	Authentication Protocol	This specifies the SNMP authentication protocol.	<p>Select the item from the pull-down menu.</p> <p>MD5, SHA or NoAuth</p>
	Authentication Password	An SNMP authentication password is entered.	Enter the authentication password between 1 and 32 characters.
	Privacy Setting	This specifies whether to enable SNMP privacy settings.	(Selected) = Enabled
	Privacy Protocol	This specifies SNMP privacy protocol.	<p>Select the item from the pull-down menu.</p> <p>DES, NoPriv</p>
	Privacy Password	This specifies an SNMP privacy password.	Enter the privacy password strings between 1 and 32 characters.
v3 Host			

Item Name		Description	Parameter
	Address	This specifies the IP address of an SNMP host.	Enter the IP address of the host with the strings based on IPv4 or IPv6 address notations.
	User Name	This specifies an SNMP user name.	Select the user already set up from the pull-down menu.
	Notify Type	This specifies an SNMP notification type.	Select the item from the pull-down menu. traps, informs
	UDP Port	This specifies an SNMP trap sending port number.	Enter the SNMP trap sending port number.  A value between "1" and "65535" can be specified.

#### Authentication tab

Item Name		Description	Parameter
Account			
	Change Administrator Password	This specifies whether to change the administrator password.	(Selected) = Administrator password changed
	Password	This specifies a new administrator password.	Enter the password between 8 and 64 characters.

#### NTP tab

Item Name		Description	Parameter
Auto Time Adjustment			
	Auto Time Adjustment	This specifies whether to enable auto time adjustment.	(Selected) = Enabled
	Server Setting	This specifies whether to enable the settings for a time-provider server.	(Selected) = Enabled (Cleared) = Disabled
	Address	This specifies the IP address of a time-provider server.	Enter the IP address of the time-provider server with the character strings based on IPv4 or IPv6 address notations.
	Mode	Set mode.	Broadcast = Time is synchronized by requesting broadcast information from the SNTP server  Unicast = The SNTP client operates in a point to point relationship with the SNTP server.
	Interval Setting	This specifies whether to enable the interval for auto time adjustment.	(Selected) = Enabled (Cleared) = Disabled
	Interval Time[s]	This specifies the interval[s] of auto time adjustment.	Enter the period on the screen.
	Time Zone Setting	This specifies whether to enable time zone setting.	(Selected) = Enabled (Cleared) = Disabled
	Time Zone from GMT	This specifies the time difference the device uses from the Greenwich Mean Time.	Select the item from the pull-down menu.

## 7.4 Profiles for CFX

### SNMP tab

Item Name		Description	Parameter
SNMP Service			
	SNMP Service Setting	This specifies whether to use SNMP service settings.	(Selected) = Enabled (Cleared) = Disabled
	SNMP Agent and Trap (ON/OFF)	This specifies whether to enable or disable SNMP agents and traps.	ON = Function enabled OFF = Function disabled
	SNMP Agent Setting	This specifies whether to use SNMP agent settings.	(Selected) = Enabled (Cleared) = Disabled
	Domain ID	This specifies a domain ID.	Enter the domain ID.
	Agent Address	This specifies whether to enable an agent address.	(Selected) = Agent address enabled Additionally, enter the IP address strings of the agent address.
	SNMP Engine ID	This specifies whether to enable an SNMP engine ID.	(Selected) = SNMP engine ID enabled Additionally, enter the SNMP engine ID.
SNMP Host (SNMPv1 or v2c)			
	Number	This specifies an SNMP host definition number.	Select the item from the pull-down menu.
	Address	This specifies the IP address of an SNMP host.	Enter the IP address of the SNMP host.
	Community Name	This specifies the community name of an SNMP host.	Enter the community name of the SNMP host.
	Trap Type	This specifies whether to send SNMP traps.	Select the item from the pull-down menu. Off, v1 or v2c
	Write	This specifies whether to permit writing from an SNMP manager.	(Selected) = Enabled (Cleared) = Disabled
SNMP User (SNMPv3)			
	Number	This specifies an SNMP user definition number.	Select the item from the pull-down menu.
	User Name	This specifies an SNMP user name.	(Selected) = Enabled Additionally, enter the SNMP user name strings.
	Address Setting	This specifies whether to enable an SNMP host address.	(Selected) = Enabled (Cleared) = Disabled
	Host Number	This specifies an SNMP host definition number.	Select the item from the pull-down menu.
	Host Address	This specifies the IP address of an SNMP host.	Enter the IP address strings of the SNMP host.
	Trap Setting	This specifies whether to enable SNMP trap settings.	(Selected) = Enabled (Cleared) = Disabled



Item Name		Description	Parameter
	Host Number	This specifies an SNMP host definition number.	Select the item from the pull-down menu.
	Host Address	This specifies the IP address of an SNMP host.	Enter the IP address strings of the SNMP host.
	Authentication Setting	This specifies whether to enable SNMP authentication protocol.	(Selected) = Enabled (Cleared) = Disabled
	Authentication Protocol	This specifies the SNMP authentication protocol.	Select the item from the pull-down menu. None, MD5 or SHA
	Authentication Password	This specifies an SNMP authentication password.	Enter the SNMP authentication password.
	Privacy Setting	This specifies whether to enable SNMP privacy settings.	(Selected) = Enabled (Cleared) = Disabled
	Privacy Protocol	This specifies the SNMP privacy protocol.	Select the item from the pull-down menu. None or DES
	Privacy Password	This specifies an SNMP privacy password.	Enter the SNMP privacy password.
	Read	This specifies whether to enable SNMP MIB read.	(Selected) = Enabled Additionally, specify the item from the pull-down menu. none: Read not permitted all: Read permitted
	Write	This specifies whether to enable SNMP MIB write.	(Selected) = Enabled Additionally, specify the item from the pull-down menu. none: Write not permitted all: Write permitted
	Notify	This specifies whether to enable SNMP MIB trap notifications.	(Selected) = Enabled Additionally, specify the item from the pull-down menu. none: Notifications not permitted all: Notifications permitted

#### Interface tab

Item Name		Description	Parameter
Interface Settings			
	Targets	This specifies an ether port.	Specify "chassis ID / ether port number" or "domain ID / switch ID / chassis ID / ether port number."
	Port Type	This specifies whether to set Endpoint.	(Selected) = Endpoint
	LLDP	This specifies whether to enable LLDP.	(Selected) = Enabled Additionally, select the item from the pull-down menu.

Item Name		Description	Parameter
			Disable = LLDP function does not operate  Enable = LLDP information is sent and received  Send = LLDP information is only transmitted  Receive = LLDP information is only received
	Cfab Port Mode	This specifies whether to enable Cfab Port Mode.	(Selected) = Enabled  Additionally, select the item from the pull-down menu.  Auto = Run with the port type automatically detected  External = Run compulsorily as an external port

### Authentication tab

Item Name		Description	Parameter
Account			
	Change Administrator Password	This specifies whether to change the administrator password.	(Selected) = Administrator password changed
	<div> <div>Password</div> </div>	This specifies a new administrator password.	Enter the password.
AAA Configuration			
	AAA Group ID	This specifies AAA Group ID.	Select the item from the pull-down menu. 0-9
	LDAP Function	This specifies whether to enable LDAP function.	Enable = Function enabled  Disable = Function disabled
	LDAP Setting	This specifies whether to enable LDAP client setting.	(Selected) = Enabled  (Cleared) = Disabled
	Client		
	<div> <div>Number</div> </div>	This specifies a client number.	Select the item from the pull-down menu. 0-3
	Server Info Settings	This specifies whether to enable Server Info Settings.	(Selected) = Enabled  (Cleared) = Disabled
	<div> <div>LDAP Server Address</div> </div>	This specifies the IP address of an LDAP server.	Enter the IP address of the LDAP server.
	<div> <div>Source</div> </div>	This specifies whether to enable the information on a sender.	(Selected) = Enabled  (Cleared) = Disabled
	<div> <div>Domain ID</div> </div>	This specifies the Domain ID of a sender.	Select the item from the pull-down menu. 1-32
	<div> <div>Address</div> </div>	This specifies the IP address of a sender.	Enter the IP address strings of the sender.

Item Name				Description	Parameter
				RDN	This specifies whether to enable RDN. (Selected) = Enabled Additionally, enter the RDN. Ex.:CN
				Bind Name except RDN	This specifies whether to enable bind names other than RDN. (Selected) = Enabled Additionally, enter a bind name other than RDN. Ex.: CN=user, DC=local
				Admin	This specifies whether to enable administrator class information. (Selected) = Enabled (Cleared) = Disabled
				Class ID	This specifies Class ID. Select the item from the pull-down menu. 0-3
				Class Value	This specifies administrator class value. Enter the character strings of the administrator class value. Ex.: user


#### NTP tab

Item Name				Description	Parameter
Auto Time Adjustment					
				Auto Time Adjustment	This specifies whether to enable auto time adjustment. (Selected) = Enabled
				Server Setting	This specifies whether to enable the settings for a time-provider server. (Selected) = Enabled (Cleared) = Disabled
				Protocol (Time/SNTP)	This specifies the protocol to be used. Time = TCP used SNTP = UDP used
				Address	This specifies the IP address of a time-provider server. Enter the IP address of the time-provider server.
				Interval Setting	This specifies whether to enable the interval for auto time adjustment. (Selected) = Enabled (Cleared) = Disabled
				Interval Time (On Startup/Period)	This specifies the interval of auto time adjustment. On Startup = Adjusted upon startup Period = Execute during arbitrary period. Additionally, enter the period on the screen.
				Time Zone Setting	This specifies whether to enable time zone setting. (Selected) = Enabled (Cleared) = Disabled
				Time Zone from GMT	This specifies the time difference the device uses from the Greenwich Mean Time. Select the item from the pull-down menu.

## Chapter 8 Setting Items of Common Policy

This section describes the items that can be set in Common Policy that can be created without depending on the target server type.

### 8.1 Monitoring Policy

Item Name		Description	Parameter
Enable the monitoring policy		This specifies whether to enable the monitoring policy.   <b>Note</b> ..... If you are going to use a Monitoring Policy when creating profiles or policies, select (Selected) for this item. .....	(Selected) = Enable  (Cleared) = Disable
Assign the monitoring policy when registering discovered nodes		This specifies whether to assign the monitoring policy when registering discovered nodes.	(Selected) = Enable  (Cleared) = Disable
SNMP Generic Configuration			
	SNMP Enabled	This specifies whether to enable SNMP.	Enable = SNMP enabled  Disable = SNMP disabled
	SNMP Port (Default: 161)	This specifies a port number where an SNMP service is in an idle state.	Enter the port number.  UDP 161 by default
	SNMP v1/v2c Community	This specifies the community strings in the cases of SNMP v1/v2c.	Enter the community strings
SNMP Trap Destination			
	SNMP Trap Community Name	This specifies the community name of the SNMP trap sending destination.	Enter the SNMP trap community strings
	Destination SNMP Server 1 to 7	This specifies the DNS name or the IP address of a server which belongs to the community set up as "Trap destination."	Enter the IP address or the DNS strings of an SNMP server.
	Protocol	This specifies the Version of SNMP protocol used for receiving traps.	Select the item from the pull-down menu.  SNMPv1, SNMPv2c
Time			
	Time Mode	This specifies whether to obtain the time setting from a managed server or to obtain it from an NTP server.	System RTC = Time is obtained from the system clock  NTP Server = Time is synchronized with that of an NTP server which operates based on specific time as its reference time source by using Network Time Protocol (NTP)
	RTC Time Mode	You can select whether to display time in UTC (Coordinated Universal Time) format or in local time format.	Local Time = time displayed in local time format  UTC = time displayed in UTC (Coordinated Universal Time) format

Item Name		Description	Parameter
	NTP Server 1	This specifies the IP address or the DNS name of the NTP server.	Enter the IP address or DNS strings.
	NTP Server 2	This specifies the IP address or the DNS name of the NTP server.	Enter the IP address or DNS strings.
	Time Zone	You can set up the time zone corresponding to the location where the server is placed.	Select the item from the pull-down menu.

The following table describes the profile settings associated with Monitoring Policy.

Type	Association with Monitoring Policy
BIOS	-
iRMC	Y
OS	-

Item Name of Monitoring Policy		Item Name of iRMC Setting
SNMP Generic Configuration		SNMP Generic Configuration
	SNMP Enabled	SNMP Enabled
	SNMP Port	SNMP Port
	SNMP v1/v2c Community	SNMP v1/v2c Community
SNMP Trap Destination		SNMP Trap Destination
	SNMP Trap Community Name	SNMP Trap Community Name
	Destination SNMP Server 1 to 7	Destination SNMP Server 1 to 7
	Protocol	Protocol
Time		Time
	Time Mode	Time Mode
	RTC Time Mode	RTC Time Mode
	NTP Server 1	NTP Server 0
	NTP Server 2	NTP Server 1
	Time Zone	Time Zone