

FUJITSU IPC-3 / Setting M3099EH/GH/EX/GX

- **IPC-3 Pre-setting Function**
 - Type of Image Processing Pattern

No.	Density	Image-emphasis	Gamma-pattern	SDTC (level)	Half-tone	Auto. Sep.
1	---	None	Normal	Yes (4)	None	None
2	---	Small	Sharp	Yes (4)	None	None
3	---	Smooth	Sharp	Yes (6)	None	None
4	---	Smooth	Normal	Yes (2)	None	None
5	136	None	Sharp	None	Ptrn#0	Yes
*	---	Smooth	Normal	Yes (4)	None	None

Common Setting :

DTC : None, Density : 256 steps, build-in gamma pattern, Contrast : 128,

Overlay : None, Photo mode, Outline extraction : None, Mirror Image : None;

* : FUJITSU Deutschland preferred setting.

FUJITSU IPC-2 / Setting M3099EH/GH/EN/CA

- **IPC-2 Pre-setting Function**

- **Type of Image Processing Pattern**

No.	Density	Image-emphasis	Gamma-pattern	SDTC (level)
1	112	Large	Soft	None
2	---	Large	Normal	Yes (5)
3	90	Small	Soft	None
4	100	Large	Normal	None

Common Setting :

DTC : None, Density : 256 steps, build-in gamma pattern, Contrast : 128, Automatic separation : None, Overlay : None, Halftone : None, Linedrawing mode, Outline extraction : None;

- **IPC-3 Pre-setting Function**

- Adjustments in correspondence with document condition
- Setting can be done by operator panel (Setup - Mode : >IPC-3 SET<)
- 5 Pre-defined settings
 - » 1. General document, Separate foreground from background
 - » 2. General document, Capture handwriting
 - » 3. General Forms, Background removal
 - » 4. Documents as NCR or dropout color (NCR = Carbonless Paper)
 - » 5. Mixed letter-and -photo document as magazines, Text and Photo
- Host set ignored