

Fujitsu SCSI Scanner Installation Procedures

Windows 95\98\98SE\ME\2000\XP\Vista

If you are installing the following models by means of the SCSI interface then please use this document.

Fi-5530C2

Fi-6140
Fi-6240

Fi-6670A
Fi-6770A

Hardware requirements.

You will need a PC system that meets our recommended specifications, an appropriate SCSI controller, and a SCSI cable (six foot recommended maximum). For recommended PC system specifications and SCSI controllers please reference the [Scanner Hardware Reference](#) page. You may also need your Operating System Disk.

Step A: Installing the SCSI Host Adapter (Adaptec).

1. Shut down your PC and remove the case cover.
2. Locate a free PCI slot and remove the back plate if necessary.
3. Install the SCSI controller in an open PCI slot.
Make sure that the card is seated completely in the slot and secured in the frame

Warning! Failure to secure the SCSI controller in the PC can result in damage to the SCSI card, scanner, and/or your system.

4. Boot your PC without the scanner attached.

Step B: Installing the SCSI drivers (Adaptec).

5. When the New Hardware wizard comes up, allow Windows to finish installing the hardware files for the SCSI controller.
6. Then either install/update the ASPI drivers from the CD or go to www.adaptec.com, and click on the "search" tab.
7. For **Windows 95\98** or **ME** scroll down to the "Enter key word or quoted phrase" box and type in "**aspi32**".
8. Next scroll down to the drivers section, click on ASPI32 and follow the prompts to download it your desktop or a new folder.
9. Afterwards go to that location and double click on the "aspi32.exe" icon and follow the prompts.
10. When the message "ASPI is up to date" appears, reboot and go to the next step.
11. For **Windows 2000** or **XP** scroll down to the "Enter key word or quoted phrase" box and type in "**aspi**".
12. Next scroll down to the drivers section, click on ASPI_v470 or higher and follow the prompts to download it.
13. Afterwards go to that folder and unzip the file to the default Adaptec\ASPI folder.
14. Then go to start, run, browse to the Adaptec\ASPI folder, select ASPIINST.EXE and run it.
15. When the message "ASPI is up to date" appears, reboot and go to the next step.

Fujitsu SCSI Scanner Installation Procedures

Windows 95\98\98SE\ME\2000\XP\Vista

Step C: Installing the drivers from the Setup CD.

To begin it is recommended that you install the drivers first before connecting the scanner.

Installing the STI-Twain driver.

1. Insert the Scanner Setup CD into your CD Rom.
2. Next please complete the pre-registration box when it appears and click the submit button.
3. Afterwards close your browser and click the **Install Products** button on the Scanner Setup Menu.
4. On the next screen click on **Twain Driver** and you may be presented with the option to install the Error Recovery Guide.
5. After you have installed the Error Recovery Guide (or not) follow the prompts to complete the twain driver installation.
6. **Do not reboot at this time!**

Installing the ASPI-Twain driver.

Some of our scanners are not supported by the STI-Twain drivers. For those units you must install the ASPI-Twain driver. Please refer to the driver download page to see if your model is one of them.

7. Insert the Scanner Setup CD into your CD Rom.
8. Next please complete the pre-registration box when it appears and click the submit button.
9. Afterwards close your browser and click the **Install Products** button on the Scanner Setup Menu.
10. On the next screen click on **Twain Driver** and you may be presented with the option to install the Error Recovery Guide.
11. After you have installed the Error Recovery Guide (or not) follow the prompts to complete the twain driver installation.
12. **Do not reboot at this time!**

Installing the ISIS driver.

13. Next go back to the Scanner Setup Menu and click on **ISIS Driver**.
14. If you didn't install the Error Recovery Guide during the Twain driver installation you will be asked again. Proceed and follow the prompts to complete the ISIS driver installation.
15. **Do not reboot at this time!**

Installing ScandAll Pro.

16. Back to the Scanner Setup Menu and click on **ScandAll Pro**.
17. The ScandAll 21 installation wizard will appear. Click next and follow the prompts to complete the installation.
18. Once all of the above is completed then remove the Scanner Setup CD, **Reboot** your system, and **go to Step E**.

Fujitsu SCSI Scanner Installation Procedures

Windows 95\98\98SE\ME\2000\XP\Vista

Step D: Installing the drivers from our Web Page.

Installing the STI-Twain driver.

1. Create a new folder and name it **Fujitsu Downloads**.
2. Next go to the following link [Drivers and Downloads](#).
3. Fill in the pre-registration box when it pops up and continue to the drivers download page.
4. Afterwards click on **STI Twain Software Drivers**.
5. Scroll down the list of scanner models in the left column and select the appropriate **STI Twain driver** to the right of your scanner model.
6. Double click on the driver file name and the **File Download** box will popup.
7. Click on **Save** and then use the browse (or other folder navigation) button until you have the **Twain Download** folder you created in the Save As box.
8. Click **Save**.
9. When completed close the **Download Complete** window and go to the **Twain Download** folder.
10. Open the folder and you will see the saved driver file. Double click on the file to unzip it and the WinZip* self-extractor box will popup. Click on browse and select the **Fujitsu Downloads** folder, then click on **Extract**. The file will begin to unzip and when finished a message box will report the number of files unzipped. Click on OK and close WinZip.
11. In the **STI Twain Download** folder locate the **setup.exe** file and double click. Afterwards follow the prompts and reboot when finished

Installing the ASPI-Twain driver.

Some of our scanners are not supported by the STI-Twain drivers. For those units you must install the ASPI-Twain driver. Please refer to the driver download page to see if your model is one of them.

1. Create a new folder and name it **Fujitsu Downloads**.
2. Next go to the following link and click on [Drivers and Downloads](#).
3. Fill in the pre-registration box when it pops up and continue to the drivers download page.
4. Afterwards click on **ASPI Twain Software Drivers**.
5. Scroll down the list of scanner models in the left column and select the appropriate **ASPI Twain driver** to the right of your scanner model.
6. Double click on the driver file name and the **File Download** box will popup.
7. Click on **Save** and then use the browse (or other folder navigation) button until you have the **Twain Download** folder you created in the Save As box.
8. Click **Save**.
9. When completed close the **Download Complete** window and go to the **Twain Download** folder.
10. Open the folder and you will see the saved driver file. Double click on the file to unzip it and the WinZip* self-extractor box will popup. Click on browse and select the **Fujitsu Downloads** folder, then click on **Extract**. The file will begin to unzip and when finished a message box will report the number of files unzipped. Click on OK and close WinZip.
11. In the **ASPI Twain Download** folder locate the **setup.exe** file and double click. Afterwards follow the prompts and reboot when finished

Fujitsu SCSI Scanner Installation Procedures

Windows 95\98\98SE\ME\2000\XP\Vista

Installing the ISIS driver.

1. Create a new folder and name it **Fujitsu Downloads**.
2. Next go to the following link and click on [Drivers and Downloads](#).
3. Fill in the pre-registration box when it pops up and continue to the drivers download page.
4. Afterwards click on **ISIS Software Drivers**.
5. Scroll down the list of scanner models in the left column and select the appropriate **ISIS driver** to the right of your scanner model.
6. Double click on the driver file name and the **File Download** box will popup.
7. Click on **Save** and then use the browse (or other folder navigation) button until you have the **ISIS Download** folder you created in the Save As box.
8. Click **Save**.
9. When completed close the **Download Complete** window and go to the **ISIS Download** folder.
10. Open the folder and you will see the saved ISIS driver file. Double click on the file to unzip it and the WinZip* self-extractor box will popup. Note and accept the default folder it is creating then click on **Extract**. The file will begin to unzip and when finished a message box will report the number of files unzipped. Click on OK and close WinZip.
11. In the new **ISIS** folder that you noted earlier locate the **setup.exe** file and double click. Afterwards follow the prompts and reboot when finished.

Step E: Unlocking the shipping lock.

If your model scanner does not have a flatbed then proceed to Step F.

The flatbed model scanners typically include a lock on the flatbed designed to protect the scanner during shipment. Before the scanner can be used the shipping lock must be unlocked. To unlock it do the following:

1. Located the shipping lock slider tab or knob either underneath or at the end of the scanner.
2. Slide or rotate the lock to the unlock position.

Step F: Connecting the Scanner.

Warning! Ensure that the power is off when connecting or disconnecting the SCSI cable to the scanner or workstation. Failure to follow the procedure above could result in damage to the SCSI card, scanner, and/or your system.

The default SCSI ID setting for the scanners is 5. However, selecting a different SCSI ID may be required when there are several devices on a SCSI chain. To change the SCSI ID rotate the yellow dial of the SCSI ID selector on the unit. Setting the SCSI ID to 0, 1, or 7 is NOT recommended as these settings are typically reserved for hard drives and the SCSI host adapter. Next if the scanner is the last device (only device) on the SCSI chain then it must be terminated. If the scanner is not the last device on the SCSI chain, then the terminator should be removed or turned off before connecting it to the next SCSI device. SCSI termination is handled automatically by these models.

Fujitsu SCSI Scanner Installation Procedures Windows 95\98\98SE\ME\2000\XP\Vista

Typically the SCSI ports are located on the back of the scanner (the exceptions being the Fi-5650C and Fi-6670A which are on the front). Depending on the model the SCSI port connector(s) may be one of the following:

- A. 50-pin High Density (HD-50) or
- B. 68-pin Wide SCSI.

Use the appropriate cable to connect the scanner to the SCSI controller in your PC and ensure that all connections are securely fastened.

Special note: The Fi-6670A and Fi-6770A are equipped with a 68-pin Wide SCSI port which is reserved for Hardware VRS usage only.

Finally connect the power cord to the scanner and a wall outlet then turn on the scanner. For those models without a power switch plug in the power supply to the back of the scanner. To establish communication between the Scanner and your PC system turn on the scanner prior to turning on your system. The scanner power and LED/LCD display will light up. Next after the scanner completes its startup initialization the LED/LCD will display either ready or the number one. This indicates that the scanner is ready.

The New Hardware wizard will now pop up. Select search for the driver automatically and follow the prompts. Since the driver is already installed on your system you do not need to select search the internet. When completed you will see the scanner installed under Imaging devices in Device Manager.

Step G: Scanning with ScandAll Pro.

To scan with Scandall Pro will require a little advance preparation because the Scan Menu has three different scanner control zones (four if you include the "cancel" function).

1. Launch ScandAll Pro by clicking on the shortcut link on your desktop or manually by clicking on **Start, Programs, Fujitsu ScandAll Pro, Fujitsu ScandAll Pro**.
2. After the **Untitled Screen** has open, click **Scan** on the Menu bar and go down to zone three, then click **Select Scanner**.
3. **Select the Fujitsu Twain source** for your scanner by **highlighting** it and **clicking OK**. You will only need to do this once unless you are scanning with multiple sources.
4. Once you are back at the Untitled Screen click on **Scan** on the Menu bar and in zone three click **Select Settings** to open the **Twain User Interface..**
5. **Select** the scanning parameters that you wish to use – **Color mode, resolution, paper size**, etc...
6. Next under **Scan Type** choose either **ADF** or **Flatbed** in the dropdown box then **click OK**.
7. Place your document in the ADF or on the Flatbed face down and click **Scan** on the Menu bar and then in zone one the **Scan Settings** button. This is where you decide what to do with the scanned image. E.G. Save to file, file type, file name, display image after scan. For this test uncheck the **Save to file** box and click **OK**.
8. Now click **Scan** on the Menu bar and then back in zone one the **Scan** button.
9. After the documents are scanned the images will appear on the Untitled Screen.

Fujitsu SCSI Scanner Installation Procedures Windows 95\98\98SE\ME\2000\XP\Vista

Congratulations! You have successfully completed and tested your scanner installation.

Step H: Installing third party software applications.

After you have successfully installed all the Fujitsu software and hardware, then it is time to install any additional third party scanning software that you wish to use. Please follow the software manufacturer's instructions for installation.

*If you do not have any unzipping software installed on your system, you can download a free evaluation copy at www.winzip.com.