

- Information applicable for PRIMEQUEST (PQ) and PRIMERGY (PY) Servers

Information on Operating Systems sold by Fujitsu can be found on the [Fujitsu Internet site](#).

1 of 6

- Information applicable for PRIMEQUEST (PQ) and PRIMERGY (PY) Servers

Information on Operating Systems sold by Fujitsu can be found on the [Fujitsu Internet site](#).

2 of 6

- Information applicable for PRIMEQUEST (PQ) and PRIMERGY (PY) Servers

Information on Operating Systems sold by Fujitsu can be found on the [Fujitsu Internet site](#).

3 of 6

- Information applicable for PRIMEQUEST (PQ) and PRIMERGY (PY) Servers

Information on Operating Systems sold by Fujitsu can be found on the [Fujitsu Internet site](#).

4 of 6

x86 Servers and Operating Systems
- Information applicable for PRIMEQUEST (PQ) and PRIMERGY (PY) Servers

Purchase of an Operating System:
Information on Operating Systems sold by Fujitsu can be found on the [Fujitsu Internet site](#).

<input checked="" type="checkbox"/>	Certified and Supported: The mentioned server system has met the OS Partner Certified/Logo program requirements. Fujitsu will provide technical support for the system-specific server drivers and ServerView management software that are compatible with the operating system.
<input type="checkbox"/>	Certified: The corresponding server system has met the OS Partner Certified/Logo program requirements. Fujitsu will not provide support for the operating system but support is available from the OS Partner.
✓	Supported: Fujitsu will provide technical support for the specific server drivers and ServerView management software that are compatible with the operating system.
T	Tested: The operating system could be installed on the server and basic functions of the system have been verified. Fujitsu will not provide support for the operating system.
+	Service Pack is a minimum requirement
++	Service Pack is recommended

Report created: Tuesday, February 03, 2015

		PQ 2400E	PQ 2800B	PQ 2800E	PY BX2560 M1	PY BX2580 M1	PY BX920 S4	PY BX924 S4	PY CX250 S2	PY CX2550 M1	PY CX2570 M1	PY CX270 S2	PY CX272 S1	PY RX1330 M1	PY RX200 S8	PY RX2520 M1	PY RX2530 M1	PY RX2540 M1	PY RX300 S8	PY RX350 S8	PY RX4770 M1	PY TX1310 M1	PY TX1320 M1	PY TX1330 M1	PY TX150 S8	PY TX2540 M1	PY TX300 S8
SUSE Linux Enterprise Server	SUSE Linux Enterprise Server 10 [XEN] (x86 & x86_64)																										
	SUSE Linux Enterprise Server 10 SP4 [XEN] (x86_64)																								<input checked="" type="checkbox"/>		
	SUSE Linux Enterprise Server 11 (x86)																										
	SUSE Linux Enterprise Server 11 SP2 (x86)														<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>					<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
	SUSE Linux Enterprise Server 11 SP3 (x86)													<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	SUSE Linux Enterprise Server 11 (x86_64)																										
	SUSE Linux Enterprise Server 11 SP2 (x86_64)						<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>					<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
	SUSE Linux Enterprise Server 11 SP3 (x86_64)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	SUSE Linux Enterprise Server 11 [XEN] (x86_64)																										
	SUSE Linux Enterprise Server 11 SP2 [XEN] (x86_64)						<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>					<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>
	SUSE Linux Enterprise Server 11 SP3 [XEN] (x86_64)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
	SUSE Linux Enterprise Server 12 (x86_64)																										
	SUSE Linux Enterprise Server 12 GA (x86_64)	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>					<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	✓	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	✓	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Univention Corporate Server	Univention Corporate Server 3.2						<input type="checkbox"/>								<input type="checkbox"/>				<input type="checkbox"/>						<input type="checkbox"/>	<input type="checkbox"/>	
	Univention Corporate Server 4														<input type="checkbox"/>			✓							<input type="checkbox"/>	<input type="checkbox"/>	
VMware	VMware ESX 4.1																										
	VMware ESX 4.1 Update 2																								<input checked="" type="checkbox"/>		
	VMware ESX 4.1 Update 3																								<input checked="" type="checkbox"/>		
	VMware ESXi 4.1 Embedded																										
	VMware ESXi 4.1 Embedded Update 2																								<input checked="" type="checkbox"/>		
	VMware ESXi 4.1 Embedded Update 3																								<input checked="" type="checkbox"/>		
	VMware ESXi 4.1 Installable																										
	VMware ESXi 4.1 Installable Update 2																								<input checked="" type="checkbox"/>		
	VMware ESXi 4.1 Installable Update 3																								<input checked="" type="checkbox"/>		
	VMware ESXi 5.0 Embedded																										
	VMware ESXi 5.0 Embedded Update 1																								<input checked="" type="checkbox"/>		
	VMware ESXi 5.0 Embedded Update 2														<input type="checkbox"/>				<input type="checkbox"/>	<input type="checkbox"/>					<input checked="" type="checkbox"/>		<input type="checkbox"/>
	VMware ESXi 5.0 Embedded Update 3																								<input checked="" type="checkbox"/>		
	VMware ESXi 5.0 Installable																										
	VMware ESXi 5.0 Installable Update 1																								<input checked="" type="checkbox"/>		
	VMware ESXi 5.0 Installable Update 2														<input type="checkbox"/>				<input type="checkbox"/>	<input type="checkbox"/>					<input checked="" type="checkbox"/>		<input type="checkbox"/>
	VMware ESXi 5.0 Installable Update 3																								<input checked="" type="checkbox"/>		

x86 Servers and Operating Systems

- Information applicable for PRIMEQUEST (PQ) and PRIMERGY (PY) Servers

Purchase of an Operating System:

Information on Operating Systems sold by Fujitsu can be found on the [Fujitsu Internet site](#).

<input checked="" type="checkbox"/>	Certified and Supported: The mentioned server system has met the OS Partner Certified/Logo program requirements. Fujitsu will provide technical support for the system-specific server drivers and ServerView management software that are compatible with the operating system.	2400E	2800B	2800E	BX2560 M1	BX2580 M1	BX920 S4	BX924 S4	CX250 S2	CX2550 M1	CX2570 M1	CX270 S2	CX272 S1	RX1330 M1	RX200 S8	RX2520 M1	RX2530 M1	RX2540 M1	RX300 S8	RX350 S8	RX4770 M1	TX1310 M1	TX1320 M1	TX1330 M1	TX150 S8	TX2540 M1	TX300 S8
<input type="checkbox"/>	Certified: The corresponding server system has met the OS Partner Certified/Logo program requirements. Fujitsu will not provide support for the operating system but support is available from the OS Partner.																										
✓	Supported: Fujitsu will provide technical support for the specific server drivers and ServerView management software that are compatible with the operating system.																										
T	Tested: The operating system could be installed on the server and basic functions of the system have been verified. Fujitsu will not provide support for the operating system.																										
+	Service Pack is a minimum requirement																										
++	Service Pack is recommended																										

Report created: Tuesday, February 03, 2015

[illegible]